

## REFERENCE & BUYER'S GUIDE

### AS-INTERFACE PRODUCTS

Edition 6.0



 **PEPPERL+FUCHS**  
SENSING YOUR NEEDS

# SPOTLIGHT on AS-Interface

## Safety Products

Fully approved low-cost networkable safety system

- Panel and enclosure mount e-stops
- Safety modules for gates, light curtains, and perimeter guarding
- Approved by NFPA, UL, and OSHA
- Safe to Cat 4/ SIL 3

See pages 125-162



## Advanced Gateways/Safety Controller

Gateways with advanced diagnostics for quick troubleshooting

- Duplicate address, noise, and ground fault detection built in
- RS232 port for diagnostic monitoring of network
- Advanced graphical display
- Ethernet/IP support allows direct integration with modern Allen-Bradley PLCs
- Removable memory card



See pages 27-54

## Tool-Free I/O Modules

No tools are required to install or remove this module from the network. The module snaps in and makes a secure connection every time.

- Stainless steel installation bar clicks in for secure worry free connection
- 1/2-turn SPEEDCON I/O connection for fast installation
- Gold plated machined pins for superior performance
- Quick change top for easy module swapping
- Outputs with RED overload indication right at each connector



See pages 78-81

## Magnetic and RFID Safety Interlock Switches

Noncontact safety devices are designed to be a low cost safety option for use in wet and dirty environments.

- IP69K watertight housing
- All AS-Interface powered
- Tamper-resistant coded magnet actuator
- RFID heads have no mechanical components for long lasting reliability
- Guard up to four doors on one controller



See pages 152-158

## New Safety Interlock Switches

AS-Interface mechanical safety interlock switches are used on doors and gates to restrict access.

- Direct connection to AS-Interface
- Power to lock/unlock options
- AS-Interface or auxiliary power options
- Manual override integrated
- Large selection of unique keys
- Rugged IP67 water-tight housing



See pages 146-151

## Enclosure Style Modules

Standard and low profile housings for J-boxes and enclosures

- Class I, Div. 2 approved for hazardous locations
- Color-coded, keyed, removable terminals included with modules
- Accessories to connect to any 120 VAC input
- Input power selectable, AS-Interface or auxiliary power




See pages 98-106

Visit us at [www.pepperl-fuchs.us](http://www.pepperl-fuchs.us) or call us at 330-486-0001

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - [sales@steveneng.com](mailto:sales@steveneng.com) - [www.stevenengineering.com](http://www.stevenengineering.com)





Pepperl+Fuchs has been providing the highest-quality industrial sensors for nearly 60 years. We are the world's largest sensor manufacturer, and we continue to set the standard by offering sensors that cover a vast range of applications, from the most basic to the most challenging. Pepperl+Fuchs' sensors are crafted using state-of-the-art components and the latest technologies to ensure precision, reliability, and functionality.

## **REFERENCE & BUYER'S GUIDE**

### **AS-INTERFACE PRODUCTS**

<b>Introduction .....</b>	<b>17</b>
<b>Gateways and Scanners .....</b>	<b>27</b>
<b>Power Supplies and Repeaters .....</b>	<b>55</b>
<b>I/O Modules.....</b>	<b>71</b>
<b>Safety Solutions .....</b>	<b>125</b>
<b>Intelligent Sensors.....</b>	<b>163</b>
<b>Cordsets .....</b>	<b>197</b>
<b>Accessories .....</b>	<b>211</b>
<b>Appendix .....</b>	<b>227</b>



## Automation using networks

The history of automation shows that innovative technologies often follow a similar path: before becoming accepted, they are greeted with skepticism. Before the PLC became widely accepted in the 1970s, automation depended heavily on relays to perform logic tasks. In hindsight, the logic tasks performed using relays were limited and made process changes difficult. Any changes to the logical operation required moving wires, adding additional relays, and possibly creating more panel space. All of that changed when Modicon introduced the Programmable Logic Controller (PLC) in the late 1960s.

Many control professionals were first skeptical of the PLC, questioning whether a single electrical component could replace electromechanical devices. They asked:

- Would the PLC be reliable enough to run a line?
- How difficult would it be to find errors and problems?
- Would the dedicated programming panels needed to set up the logic create another level of problems?
- Would the PLC present an affordable solution?
- Why would anybody want to change a logic system that worked?

While those were valid questions at the time, the PLC has since proven to be reliable and very capable of controlling complex automation systems. Advanced

diagnostics and PC-based programming with the ability to keep programmers from making many basic mistakes helped to establish the PLC. In addition, many electronic solutions, including PLCs and PCs, are extremely affordable today, offering fast setup time and reduced panel space over relays.

Perhaps the lesson to be learned with the introduction and eventual success of the PLC is this: many industry professionals must be convinced that innovations will improve their processes before making changes. Like the PLC, two other advancements in automation, I/O networks and more recently, the networking of safety devices such as light curtains, door interlock switches, and safety e-stops, were received with a similar level of skepticism and doubt.

## History repeats itself

The generation of control engineers who bucked tradition to bring us the PLC suddenly found themselves involved in another paradigm shift in 1987, when INTERBUS, the first I/O network for industrial applications was introduced, with many other such networks soon to follow. Some automation professionals embraced the concept while others adopted the mindset of their colleagues of the previous generation, repeating the concerns they once worked to dispel.



- Would networked I/O be reliable enough to run a line?
- How difficult would it be to find errors and problems?
- Would the additional electronics needed to set up the network just create another level of problems?
- Would it be an affordable solution?
- Why would anybody want to change an I/O system that worked?

Not only are these the same questions asked previously, but so are the answers. Of course, not every I/O network proposed at the time was able to address reliability concerns adequately, and some poorly designed solutions disappeared. Now, twenty years later, we know that well-designed I/O networks offer excellent reliability, and increased setup flexibility: the same features that aided the transition to PLCs. History had repeated itself.

## Networks in the New Millennium

Today, a few networks stand out in terms of features and flexibility: PROFIBUS, CC-Link, DeviceNet, Ethernet, and AS-Interface. Those familiar with networks know that this network quintet dominates the world market with a combined strength of close to 40 million installed nodes! However, it is less well-known that AS-Interface stands out in a very important way: AS-Interface was designed not to compete with the others, but rather to enhance them. To understand how AS-Interface can work to improve these higher-level networks, it helps to compare automation networks with another movement system we are familiar with: human transportation systems.

## Optimizing Flow

Moving data is comparable to moving people around the country using various transportation systems. Traveling cross country might include: driving to the airport, boarding a plane, flying to another airport, and finally using another car to reach the destination. While some people prefer driving the entire distance, nobody expects an airline to pick them up at home and drop them off at their final destination. Therefore, we have become accustomed to being "repackaged" in various vehicles, and with other travelers. In other words: the traveler starts out on a system that allows small units to be transported quickly to a consolidator. Here units, arriving from all different directions are repackaged into larger packets, moved at high speed to another consolidator, and again taken apart and sent on their final leg of the trip. Clearly, this structured approach optimizes flow, reduces the time it takes to reach a destination, and increases efficiency.

AS-Interface is the road system connecting highly distributed I/O to a data consolidator, handing it over to an upper-level network designed to handle

large amounts of data, which moves it to the PLC for processing and analysis. AS-Interface enhances networks such as DeviceNet because it collects I/O data to create large bundles, ensuring that it does not lose efficiency by transmitting a few data bits in its multibyte-size cargo space. PROFIBUS also works better because AS-Interface removes the stringent requirement of adhering to a single topology (daisy chain), allowing I/O to be placed anywhere needed. We call this topology-free networking.

In its 15 year history, AS-Interface has become the accepted universal feeder system for data. With over 13 million field nodes, AS-Interface is well past the initial acceptance phase, having proven its effectiveness in a wide variety of applications. This Reference & Buyer's Guide focuses on the many reasons for its success, including its flexibility and simplicity, exceptional noise immunity, availability of a full electromechanical installation system, and its low price point.

## Networking Safety

Today, another relatively new and revolutionary idea in automation concerns the way safety devices are connected. The concept of transmitting safety data over a network, while technologically a huge step, is ultimately just another example of technological innovation in automation. PLCs replaced relay logic, networks replaced hardwired I/O, and networking safety devices will most certainly make hardwired safety a relic of our times.

Again AS-Interface stands out, as the I/O network enhancing the functionality of upper level solutions. With AS-Interface Safety at Work—the base technology that allows AS-Interface to transmit safety data in applications up to Category 4 or Safety Integrity Level (SIL) 3—DeviceNet, PROFIBUS, CC-Link, and any industrial Ethernet can now benefit in more ways than ever from the flexibility and simplicity of AS-Interface.

## The Future

It is very difficult to predict what technological advances will shape the world of automation over the next decade. It is certainly not too early to recognize Ethernet as one of the technologies that will significantly influence the way control systems are designed and built. But irrespective of what the automation and networking future will hold, AS-Interface will surely be a part of it. As the only true, universal I/O level network, working flawlessly with all important upper-level solutions, addressing the most important demands of the automation market (broad support worldwide, excellent troubleshooting features, flexible installation, and low cost, to name just a few), it has all the great features needed to be the preferred partner for today's and tomorrow's automation networks.



# Gateways



Enhanced

Enhanced with  
Safety Controller

Basic  
with Display




Basic

See Pages	36, 40, 47, 52	41, 48	36, 40, 52	40
Highlights	<ul style="list-style-type: none"> <li>• Duplicate address detection and diagnostic port</li> <li>• One- and two-network versions available</li> </ul>	<ul style="list-style-type: none"> <li>• Duplicate address detection and diagnostic port</li> <li>• 16 independent release circuits</li> </ul>	<ul style="list-style-type: none"> <li>• RS-232 version comes with stand-alone control functionality</li> <li>• One- and two-network versions available</li> </ul>	<ul style="list-style-type: none"> <li>• Low-profile, slim housing with top-mount connector</li> <li>• LCD display with pushbuttons</li> </ul>
Specification and Profile	3.0 (M4)	3.0 (M4)	3.0 (M4)	3.0 (M4)
PLC Connectivity				
Ethernet/IP - Modbus/TCP	■	■		
PROFINET	■			
PROFIsafe (with PROFINET)		■		
PROFIBUS	■	■	■	■
DeviceNet	■		■	
Modbus ASCII/RTU	■			
RS232			■	
Diagnostics				
RS232 Port	■	■		
Ground Fault Detection	■	■	■	■
Noise Detection	■	■	■	■
Duplicate Addr. Detection	■	■		
Over Voltage Detection	■	■	■	■
Memory Card	■	■		
Approvals				
Safety				
Safe Outputs (onboard)		2 relay and 2 electronic		
Safe AS-i Output Channels		16 (PROFIsafe, 45)		
Safe Network Coupling		■		
Scan 2 Networks		■		
Graphical Display		■		
CAT 4/SIL 3 Approved		■		

## Scanner Cards



Allen-Bradley

See Page	30
Highlights	<ul style="list-style-type: none"> <li>• AS-i connected to backplane of PLC</li> <li>• Many scanner cards can be connected to one rack</li> </ul>
Specification and Profile	3.0 (M4)
PLC Connectivity	
SLC503/04/05	■
MicroLogix 1500	■
ControlLogix	■
CompactLogix	■
Diagnostics	
Diagnostic Port	■
Ground Fault Detection	
Noise Detection	
Duplicate Addr. Detection	
Over Voltage Detection	
Approvals	  

## Network Extension



Repeaters

See Page	65
Highlights	<ul style="list-style-type: none"> <li>• Field mount or enclosure mount housings</li> <li>• Built-in terminator extends the first segment up to 200 m, 300 m total</li> </ul>
Length of First Segment	100 m, up to 200 m
Length of Second Segment	100 m
Protection Rating	IP20, IP67
Communication Monitoring	■
AS-i Connection	Flat cable piercing or terminals



Terminator



Tuner

See Page	216	216
Highlights	<ul style="list-style-type: none"> <li>• Extends linear network up to 200 m without repeater</li> <li>• Low voltage diagnostic LEDs</li> <li>• Two impedance options</li> </ul>	<ul style="list-style-type: none"> <li>• Extends linear network up to 300 m without repeater</li> <li>• Network communication and diagnostic LEDs</li> </ul>
Length of Segment	200 m	300 m
Protection Rating	IP67, IP68*, IP69K*	IP65
Communication Monitoring		■
AS-i Connection	Flat cable	Flat cable piercing or micro

\*With VAZ-FK-S...flat cable

Want more information?

Simply go to: [www.pepperl-fuchs.us/as-interface](http://www.pepperl-fuchs.us/as-interface)

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com











Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

 **PEPPERL+FUCHS**  
SENSING YOUR NEEDS


















Courtesy of Steven Engineering, Inc. - (800) 258-9200 - [sales@steveneng.com](mailto:sales@steveneng.com) - [www.stevenengineering.com](http://www.stevenengineering.com)

# I/O Modules

					
	Flat (G2)	Flat (G12)	Round (G11)	Flat (G10)	Field (G4)
See Page	74	79	83	88	92
Highlights	<ul style="list-style-type: none"> <li>Low-profile flat housing</li> <li>Integrated addressing jack</li> </ul>	<ul style="list-style-type: none"> <li>Overload indication at each output</li> <li>No tools required for installation</li> <li>Metal M12 SPEEDCON connectors</li> </ul>	<ul style="list-style-type: none"> <li>IP69K for harsh environments</li> <li>Round clean design</li> <li>M12 or flat AS-i connection</li> </ul>	<ul style="list-style-type: none"> <li>Ultracompact enclosure</li> <li>Suited for decentralized installation</li> </ul>	<ul style="list-style-type: none"> <li>Input wires can be cut to exact length</li> <li>Antivibration spring terminals</li> </ul>
AS-Interface 3.0 (4 In/4 Out)	■	■	■		■
Address Range	1-31 A/B	1-31 A/B	1-31 A/B	1-31 A/B	1-31 A/B
I/O Mix	4 in, 4 in/2 out, 4 in/4 out, 4 in/3 out, 2 in/2 out, 8 in	4 in, 4 in/4 out, 2 in/2 out, 4 out, 8 in	4 in, 4 in/4 out	2 in, 2in/1 out	4 in, 4 in/4 out, 4 in/3 out, 2 in/2 out
Input Type	2-, 3-, 4-wire, dry contact	2-, 3-, 4-wire, dry contact	2-, 3-, 4-wire, dry contact	2-, 3-, 4-wire, dry contact	2-, 3-, 4-wire, dry contact
Input Power Supplied By	AS-Interface/aux.	AS-Interface/aux.	AS-Interface	AS-Interface	AS-Interface
Sensor Type	PNP	PNP	PNP	PNP	PNP
Output Power Supplied By	AS-Interface/aux.	Auxiliary	Auxiliary	Auxiliary	Auxiliary
Output Type	DC	DC	DC	DC	DC
Approvals					
Protection	IP67	IP67	IP68, IP69K	IP68, IP69K	IP65 or IP67
I/O Connection Method	Micro	Micro (SPEEDCON compatible)	Micro	Micro pigtail	Spring terminals





					
<b>Compact (G16)</b>	<b>Enclosure (KE)</b>	<b>Junction Box (KE1,CB1)</b>	<b>Analog (KE2, G11)</b>	<b>Pushbuttons and Stack Lights</b>	<b>Pneumatic</b>
96	99	103	107, 108	114, 115	120
<ul style="list-style-type: none"> <li>• Waterproof potted housing</li> <li>• Metal M8 connectors</li> </ul>	<ul style="list-style-type: none"> <li>• Thinnest housing offered</li> <li>• AS-Interface or external power, switchable</li> <li>• Approved for hazardous locations</li> </ul>	<ul style="list-style-type: none"> <li>• Lowest profile housing</li> <li>• Easy connection for pushbuttons &amp; pilot lights</li> <li>• Antivibration spring terminals option</li> </ul>	<ul style="list-style-type: none"> <li>• Scaled automatically 0-10,000 or 4,000-20,000</li> <li>• AS-Interface or auxiliary powered</li> </ul>	<ul style="list-style-type: none"> <li>• Different colored button covers available</li> <li>• Red, yellow, green, blue, clear stack light options</li> <li>• Audible alarm</li> </ul>	<ul style="list-style-type: none"> <li>• 4 inputs available on 2 connectors</li> <li>• Pneumatics powered from AS-Interface or auxiliary</li> </ul>
■	■	■			
1-31 A/B	1-31 A/B	1-31 A/B	1-31 A/B	1-31 A/B	1-31 A/B
4 in, 4 in/4 out	4 in, 4 in/4 out, 4 in/3 out	4 in, 4 in/2 out, 4 in/4 out	4 in, 2 in, 2 out	2 in/2 out, 4 out	4 in/2 out
2-, 3-wire, dry contact	2-, 3-, 4-wire, dry contact	2-, 3-wire, dry contact, 4-wire	2-, 3-, 4-wire	LEDs, pushbuttons	2-, 3-, 4-wire, dry contact
AS-Interface	AS-Interface/ext.	AS-Interface/aux.	AS-Interface/aux.	AS-Interface	AS-Interface
PNP	PNP	PNP	4-20 mA, 0-10 V or PT100	Pushbuttons	PNP
Auxiliary	AS-Interface/aux.	AS-Interface/aux.	AS-Interface/aux.	AS-Interface/aux.	AS-Interface/aux.
DC	DC, Relay	DC	4-20 mA or 0-10 V	LEDs/Horn	Pneumatic
 	  Class 1 Div 2, groups A,B,C,D	 	 	 	
IP68, IP69K Nano	IP20 Keyed, removable colored terminals	IP20 Keyed, removable colored terminals	IP20, IP67 Terminals	IP67	IP65 Micro, 8 mm air

## Accessories



### Flat Cable Splitters

Connects or splits two pieces of flat cable, 8 A capacity.



### Flat to M12 Adapters

Connects one or two flat cables to an M12 connector or pigtail. Many lengths and connector styles available.



### Handheld Programmer

A must for every network. Can set AS-i addresses, read inputs and set outputs of a single AS-Interface node.

## Want more information?

Simply go to: [www.pepperl-fuchs.us/as-interface](http://www.pepperl-fuchs.us/as-interface)

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

 **PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

## Safety Monitors



8-Channel Basic



16-Channel Enhanced

See Page	130	41, 48, 130
Highlights	<ul style="list-style-type: none"> <li>• Scans up to 31 safe input modules</li> <li>• 8 channels for safe AS-i outputs</li> <li>• 4 safe inputs or 8 I/O on board</li> </ul>	<ul style="list-style-type: none"> <li>• Scans up to 62 safe input modules on two networks</li> <li>• 16 channels for safe AS-i outputs</li> </ul>
Safe Outputs (onboard)	2 electronic	2 relay and 2 electronic or 2 relay
Safe AS-i Output Channels	8	16
Safe Network Coupling		■
Scan 2 Networks		■
Memory Card	■	■
Graphical Display		■
CAT 4/SIL 3 Approved	■	■

## Safety Modules



Safe Inputs



Safe Outputs



E-Stops

See Page	135	138	144
Highlights	<ul style="list-style-type: none"> <li>• Dry-contact inputs for connection of standard e-stops and gate switches</li> <li>• Electronic inputs for connection of light curtains or any device with electronic OSSDs</li> </ul>	<ul style="list-style-type: none"> <li>• One set of redundant relay outputs</li> <li>• EDM input</li> <li>• One address for safety output channel</li> <li>• One A/B diagnostic address</li> </ul>	<ul style="list-style-type: none"> <li>• AS-i safety e-stop connects directly to AS-i cable</li> <li>• Field-mount or panel-mount e-stop housings</li> <li>• Available with or without illumination</li> </ul>
Safe Inputs	1 or 2	-	1 E-Stop
Safe Relay Outputs	-	1	
Standard Inputs/Outputs	2-out	1-in/1-out	1-out
CAT 4/SIL 3 Approved	■	■	■

# Safety Interlock Switches



**Mechanical**



**Coded Magnetic**



**RFID**



**Enabling Switch**

See Page	147	153	156	160
<b>Highlights</b>	<ul style="list-style-type: none"> <li>• Steel actuator head</li> <li>• Key and coil monitoring</li> <li>• High-visibility LEDs</li> </ul>	<ul style="list-style-type: none"> <li>• Direct connection to AS-Interface</li> <li>• 1 m pigtail integrated</li> <li>• IP69K good for wash-down applications</li> <li>• Small mounting footprint</li> </ul>	<ul style="list-style-type: none"> <li>• High-end RFID solution replaces magnetic interlocks</li> <li>• Up to 4 doors monitored from one control unit</li> <li>• Long read range for worry-free alignment</li> <li>• High-visibility diagnostic LEDs</li> </ul>	<ul style="list-style-type: none"> <li>• Lightweight enabling switch</li> <li>• Rugged rubberized housing</li> <li>• Ergonomic design</li> </ul>
<b>Address Range</b>	1-31	1-31	1-31	1-31
<b>Input Type</b>	Safety, mechanical	Safety, magnetic	Safety, RFID	Safety, mechanical
<b>Input Activations</b>	1,000,000	100,000,000	Unlimited	100,000
<b>Input Powered By</b>	AS-Interface	AS-Interface	AS-Interface	AS-Interface
<b>Output Type</b>	Solenoid/LEDs	LED		
<b>Output Powered By</b>	AS-Interface/aux.	AS-Interface		
<b>CAT 4/SIL 3 Approved</b>	■	■	■	■

## Want more information?

Simply go to: [www.pepperl-fuchs.us/as-interface](http://www.pepperl-fuchs.us/as-interface)





# Power Supplies



AS-i



Power Conditioners



24 VDC

See Page	59	62	68
<b>Highlights</b>	<ul style="list-style-type: none"> <li>• Class 2 power option</li> <li>• Power/overload LEDs</li> <li>• High-output current in slim package</li> <li>• Low-current option for smaller networks</li> <li>• Ground fault detection built in</li> </ul>	<ul style="list-style-type: none"> <li>• Two networks or two segments can connect to one conditioner</li> <li>• Enclosure or field-mount options</li> <li>• LED low-voltage indication</li> <li>• 4 A field-mount version</li> </ul>	<ul style="list-style-type: none"> <li>• 115/230 VAC jumper selectable</li> <li>• Voltage adjustable from 24 V to 30 V</li> <li>• 3-phase power supply option</li> </ul>
<b>Output Current</b>	2.8 A, 4 A, 8 A	2.8 A, 4 A, 2 x 4 A	5 A, 10 A
<b>Input Voltage</b>	85-265 VAC	30 VDC	93-132 VAC, 187-265 VAC, or 3 x 340-500 VAC
<b>Output Voltage</b>	30 V AS-i	30 V AS-i	24-30 VDC
<b>Output Voltage Adjustable</b>			■
<b>IP Rating</b>	IP20	IP20 or IP67	IP20
<b>Mounting</b>	DIN rail	DIN rail or mounting holes	DIN rail
<b>Approvals</b>			



# Intelligent Sensors



**Cylindrical Inductive**



**Limit Switch Inductive**



**Rhino™ Inductive**



**Rectangular Inductive**

See Page	166	170	173	175
<b>Highlights</b>	<ul style="list-style-type: none"> <li>• 12, 18, and 30 mm diameter models</li> <li>• Weld field immunity</li> <li>• Normally open/normally closed programmable</li> <li>• Collision monitoring</li> </ul>	<ul style="list-style-type: none"> <li>• 20, 30, and 40 mm sensing ranges</li> <li>• Terminal compartment with conduit entrance</li> <li>• Oscillator monitoring</li> <li>• Collision monitoring</li> </ul>	<ul style="list-style-type: none"> <li>• 25-position rotating head</li> <li>• Multicorner LEDs for easy visibility</li> <li>• Quick connect lever</li> </ul>	<ul style="list-style-type: none"> <li>• Embeddable in metal with 6 mm range</li> <li>• 2 m pigtail</li> <li>• Normally open/normally closed programmable</li> <li>• Oscillator monitoring</li> </ul>



**Valve Positioning Inductive**







**Series 28 Photoelectric**












**Absolute Rotary Encoders**

See Page	177	180	188, 192
<b>Highlights</b>	<ul style="list-style-type: none"> <li>• Two inductive sensors for 1/4 turn valve positioning</li> <li>• 2.5 W solenoid driver</li> <li>• Normally open/normally closed programmable</li> </ul>	<ul style="list-style-type: none"> <li>• Background suppression, thru-beam, retroreflective, and foreground suppression modes available</li> <li>• Weak signal output</li> <li>• -40 °F rating</li> </ul>	<ul style="list-style-type: none"> <li>• 16-bit absolute rotary encoder, max 5 ms update time</li> <li>• Servo or clamping flange</li> <li>• 10 or 12 mm recessed hollow shaft</li> </ul>

# Accessories

				
	<b>Handheld Programmer</b>	<b>Software and Cables</b>	<b>Diagnostic Tools</b>	<b>Master Simulators</b>
See Page	212	213	214	215
Highlights	<ul style="list-style-type: none"><li>• Programs any AS-i module</li><li>• Rechargeable battery for cable-free operation</li></ul>	<ul style="list-style-type: none"><li>• AS-i safety programming software</li><li>• Diagnostic and configuration software</li></ul>	<ul style="list-style-type: none"><li>• AS-i network analyzer</li><li>• Statistical mode for easy health status of network</li></ul>	<ul style="list-style-type: none"><li>• Converters for PROFIBUS, DeviceNet, and RS485</li><li>• Easy RS232 or USB connections to the PC</li></ul>

				
	<b>Terminator and Tuner</b>	<b>Bases</b>	<b>AS-Interface Cable</b>	<b>Flat Cable Adapters/Splitters</b>
See Page	216	217	218	219, 220, 221
Highlights	<ul style="list-style-type: none"><li>• Extend network 200 m or 300 m without repeater</li><li>• Diagnostic LEDs for network health indication</li></ul>	<ul style="list-style-type: none"><li>• Bases for flat or round cable</li><li>• Standard or DIN rail mounting styles</li></ul>	<ul style="list-style-type: none"><li>• Yellow and black standard and oil-resistant flat cable</li><li>• Flat cable stripper available</li></ul>	<ul style="list-style-type: none"><li>• Flat cable splitters and M12 to flat cable adapters</li><li>• Water-tight housings IP69K rated</li></ul>


					
	<b>Bulkhead Connectors, Cordgrips, and Conduit Adapters</b>	<b>Covers and Mounting Accessories</b>	<b>AC Input Accessories</b>	<b>Passive and Protected Tees</b>	<b>PROFIBUS Accessories</b>
See Page	222	223	224	225	226
Highlights	<ul style="list-style-type: none"><li>• Attach flat cable to junction boxes and enclosures</li><li>• 0.606", 0.740", and 0.807" mounting hole clearances</li></ul>	<ul style="list-style-type: none"><li>• Flat cable mounting adapters</li><li>• M12 and M8 covers</li><li>• Flat cable rubber covers</li></ul>	<ul style="list-style-type: none"><li>• Convert any DC module into an AC input module</li><li>• LED diagnostic indicator</li><li>• Easy DIN rail mounting</li></ul>	<ul style="list-style-type: none"><li>• 1-, 2-, or 4-port protected and unprotected round cable splitters</li></ul>	<ul style="list-style-type: none"><li>• For one or two PROFIBUS cables and termination switch</li><li>• Up to 12 Mbps</li></ul>



# AS-Interface for the Material Handling Industry



Material handling applications demand fast and reliable networks. AS-Interface is a fast and dependable discrete I/O network designed to help you stay competitive and increase profitability in the new global economy. AS-Interface reduces the total cost of ownership for OEMs, as well as increasing productivity and safety for end users.




- Reduced cable cost and enclosure size
- Reduced installation and wiring time
- Communication through slip rings
- Faster machine commissioning/post commissioning
- Easy field system expansion
- Networking safety components and devices on one cable


# AS-Interface for the Automotive Industry



The automotive industry demands equipment that supports lean, flexible manufacturing. Pepperl+Fuchs' AS-Interface meets this challenge by providing speed, simplicity, and reliability in I/O networking.



- Reduced cost (smaller PLC rack, less wire, smaller panel, and fewer I/O cards)
- Fast I/O exchange on robots and end effectors
- Increased system availability and safety system uptime
- Reduced installation and maintenance time




# AS-Interface for the Packaging and Printing Industries



## Packaging

Changeover and uptime maximization are the name of the game in packaging. AS-Interface keeps networks simple, versatile, and ready to respond to changing demands. From flow wrappers to palletizers, AS-Interface connects all modular components together. In the dynamic world of packaging, AS-Interface just makes sense.

- **Simplified machine guarding (Safety at Work: SaW)**
- **Fast modular machine setup and changeover**
- **Superior diagnostics enable efficient and fast troubleshooting**
- **Fast I/O updates support high-speed packaging**
- **Rugged housings hold up to messy packaging materials**



## Printing

The printing/converting industries require heavy-duty, flexible equipment to get the job done right and on time. If your application requires high-speed operation, excellent diagnostic features, optimum cost-effectiveness, and safety device monitoring, you simply won't find a better solution than Pepperl+Fuchs' AS-Interface discrete I/O system.

- **Reduced wiring saves time and cabinet space**
- **Diagnostic monitoring decreases downtime**
- **Simplified safety device monitoring via Safety at Work (SaW)**









**We stand behind AS-Interface ... even if you bought it from the competition.**

The Pepperl+Fuchs AS-Interface Maintenance and Troubleshooting Guide is the true must have document for every maintenance person; even if you are currently not using Pepperl+Fuchs AS-Interface hardware. This is a handy document that can assist in setting up and troubleshooting a system and is available in print and electronically

Order your copy today and see why we are considered to be one of the premier AS-Interface suppliers ... worldwide.

The following topics are included in this guide:

- **AS-Interface Basics**
- **Handheld Programmer (Reading Inputs and Setting Outputs)**
- **Gateway Quick Start**
- **Gateway Advanced Features**
- **Exchanging SafetyNodes**
- **Exchanging SafetyMonitors**
- **LED Functionality (Modules)**
- **LED Functionality (SafetyMonitors)**
- **Repeaters**
- **Termination and Tuner**
- **Power Supplies**
- **Helpful Wiring Hints**
- **Common Problems and Solutions**
- **Analyzer**







## What is AS-Interface?

Actuator Sensor Interface (AS-Interface) is a simple-to-install two-wire network for discrete I/O, intelligent sensors, analog and safety data, encoders, light curtains, and e-stops. Specifically designed for simplicity, flexibility, and reliability, AS-Interface has extremely fast mounting, startup and update times, and replaces traditional wiring architectures. It has a totally open topology—there are no limitations on how to route or split network runs. A single unshielded cable with no termination and a very high degree of noise immunity carries both data and power. In addition, AS-Interface is truly an open system, supported by all major PLC manufacturers and compatible with any of the major industrial upper-level networks.

## The Development of AS-Interface



AS-Interface was developed by a group of companies that saw the need for a cost-effective, simple, and reliable sensor network designed for discrete sensors and simple output devices that could replace discrete wiring. The original objective was not a universal fieldbus for all

areas of automation, but rather a system for discrete I/O only. And so, a consortium of 11 sensor, actuator, and control-system companies—Balluff, Baumer, Elesta, Festo, ifm electronic, Leuze electronic, Pepperl+Fuchs, Sick, Siemens, Turck, and Visolux—started work on this innovative wiring system in 1990. The consortium completed its work in 1993, and ownership of the specification was transferred to AS-International.

AS-International is a nonprofit, member-funded organization of AS-Interface manufacturers. Numerous national organizations exist worldwide. There are over 300 members and to date, over 15 million AS-Interface chips are in use around the world.

## The AS-Interface Standard




AS-Interface was introduced into the market in 1994. Since that time, it has become the standard discrete I/O system used in automation industries throughout the world to connect devices such as sensors,

solenoids, limit switches, pushbuttons, valves, and relays to higher-level controllers such as PCs, PLCs, CNCs, and DCSs. Featuring a single, unshielded, two-wire cable design, AS-Interface transfers signals and power simultaneously, simplifying installation and significantly reducing commissioning costs. AS-Interface requires only a single cable to connect I/O modules from any manufacturer, offering users an elegant, simple-to-use I/O discrete communication system, requiring no knowledge of bus systems or communication protocols. And, unlike all other networks, AS-Interface doesn't use shielded cables and terminating resistors. Installing the network is fast and configuration takes less time than with other networks on the market. AS-Interface is standardized in EN50295 and IEC 62026-2.

With AS-Interface, compatibility between devices is not a matter of luck: compatibility is a guaranteed part of the system design. A module is only permitted to use the AS-Interface logo after it has successfully completed testing by an independent institute. The AS-Interface logo ensures quality and compatibility, guaranteeing that approved devices can be used in the system with no problems.

## How Does AS-Interface Operate?

The scanner/gateway automatically controls communication over the AS-Interface cable. Up to 62 modules can be connected to the network and each module can connect a number of I/O points. The scanner/gateway calls each module sequentially and awaits each response. If the module fails to respond, the scanner/gateway repeats the request. If there is still no response, the scanner/gateway will record the address of the module and inform the PLC. The scanner/gateway will continue to try to access the unresponsive address. In each cycle, 4 bits of information are transferred from the scanner/gateway unit to each module, and 4 bits are returned.



## Interoperability of Pepperl+Fuchs Products with Other AS-Interface Manufacturers

AS-Interface is truly an open, vendor-independent system. Interoperability of certified products is guaranteed by rigid conformance testing so that all AS-Interface products will work well on the same network.

## Device Profiles

Each module's I/O mix and device type are stored in its profile. The I/O code is used to define the inputs and outputs that are used by the module. The ID code defines other advanced features of the module. For example, the profile S-0.A means 4 inputs with extended addressing capability. In addition, many AS-Interface modules have an ID1 and ID2 subprofile that further breaks down the module's functionality. The ID1 can be programmed by the user, but caution must be taken to ensure that the device profile stored in the AS-Interface master matches that of the I/O module. If they are different, the AS-Interface scanner/gateway will need to be "retaught" to activate the node. While this transfer of information sounds complicated, the scanner/gateway knows what to do. It performs these actions seamlessly.

### Device Profiles

IO Code	Scanner profiles	ID code															
		0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
IO Code	0	I, I, I, I	I	0.0	0.1							0.A	0.B				0.F
	1	I, I, I, O	O	1.0	1.1							1.A					1.F
	2	I, I, I, B	B	2.0								R					2.F
	3	I, I, O, O	O	3.0	3.1							3.A					3.F
	4	I, I, B, B	B	4.0								4.A					4.F
	5	I, O, O, O	O	5.0								5.A					5.F
	6	I, B, B, B	B	6.0								6.A					6.F
	7	B, B, B, B	B	7.0	7.1	7.2	7.3	7.4	7.5			7.A	7.B		7.D	7.E	7.F
	8	O, O, O, O	O	8.0	8.1							8.A					8.F
	9	O, O, O, I	I	R								9.A					9.F
	A	O, O, O, B	B	A.0								R					A.F
	B	O, O, I, I	I	R	B.1							B.A					B.F
	C	O, O, B, B	B	C.0								C.A					C.F
	D	O, I, I, I	I	R	D.1							D.A					D.F
	E	O, B, B, B	B	E.0								E.A					E.F
	F	T, T, T, T															


I: input, O: output, B: bidirectional port, R: reserved, V: new status

### Extended Device Profiles with ID Code = A

Profile Description	IO Code	ID2 Code
Remote I/Os (X = 0, 1, 3-9, B-E)	X	0
Free profiles for slaves in extended address mode (X = 0 ... E)	X	E
Remote I/Os with dual signals (X = 0, 3, 7, 8, B)	X	2
Single sensor with extended control	3	1
Combination slave with support for serial profile	7	5
4I/4O in extended addressing mode	7	7
Slave profile for analog input (single channel)	7	8
Slave profile for analog input (dual channel)	7	9
8I/8O in extended addressing mode	7	A
Slave with support for serial profile	B	5

## AS-Interface Topology

The topology of the AS-Interface network is completely open, enabling the user to install the system in a layout that best fits each application. Because AS-Interface does not use termination, additions are possible without the time consuming task of locating the “end” of the existing network. The power supply and additional modules can also be placed anywhere in the segment. This truly unique approach not only reduces the total network length, but also simplifies installation, resulting in the shortest installation time possible.



## Network Length


AS-Interface segments can have a cumulative cable length of 100 meters (328 feet). This means that all network cable added together in a segment must equal less than 100 m. If larger networks are needed, a repeater can be used to extend the length by 100 meters. Because repeaters isolate the connected network segments, an AS-Interface power supply must be located in each. When designing networks with repeaters, it is important to note that no signal from a scanner/gateway to a node can travel through more than two repeaters. Consequently, the maximum length of a linear AS-Interface network is 500 m. Star-shaped networks can use even more repeaters allowing for even larger area networks.

**NOTE:** Regardless of cable length and number of repeaters, a maximum of 62 I/O modules can be placed on AS-Interface. Other than that, there are no complicated rules or limitations based on trunk and spur lengths to consider.

## Wiring


Installation and wiring of AS-Interface is as easy as it gets. First of all, the system is based on a two-conductor power and communication method. Secondly, when using the famous mechanically keyed “yellow flat cable” electrical connections are not only reliable and secure, but also extremely fast.

The distinctive yellow cable that typically identifies an AS-Interface system has several additional features that make it stand out. The cable has a special mechanical



profile that guarantees a correct connection every time by eliminating the danger of reversing polarity. It uses redundant piercing connection technology that allows the connectors to nestle tightly and securely among the fine copper strands in the core of each of the conductors. The reliability of the connections has been proven repeatedly and has been formally evaluated using the DIN EN-60068-2-64. The self-sealing property (insulation displacement) of the rubber insulation maintains a protection class of up to IP69K. To further enhance system reliability, Pepperl+Fuchs uses round, machined, and gold-plated piercing contacts in all models. In terms of long-term reliability, nothing beats gold!

Because the contacts penetrate the insulation to secure an electrical connection, some of the most time-consuming electrical tasks are eliminated. There is no need to cut, strip, apply terminals, or label the wire ends. AS-Interface does not use termination. Workers spend less time pulling long lengths of wire through hard-to-reach places. The reduction of wires not only decreases the size of the control panel, it increases modularity—machines are easier to disassemble, and easier to reassemble at another site.



## Update Time

AS-Interface is a deterministic network. Given the number and type of modules, one can determine the network update time. To calculate the total network update time, simply multiply the number of modules by 155 microseconds. The cycle time is the same for I/O modules with full or half addresses. Analog nodes, however, are exceptions as they split the data up over several scans. AS-Interface is typically as fast as the update time on a typical PLC (or faster) and in most cases, significantly faster than any upper-level network. In fact, because AS-Interface gateways act as data consolidators, they help to make those upper-level networks faster, while reducing overhead by as much as 90%.

## Data Integrity and Noise Immunity of AS-Interface

AS-Interface has been designed from the ground up to be used in tough industrial applications. As a result, AS-Interface is extremely noise immune—as applications involving linear sliding contacts and slip rings impressively prove every day. You can rely on AS-Interface to perform in environments where other systems fail. Nevertheless, an AS-Interface system does not negate the need for good wiring practices to make sure that AS-Interface's advanced noise management features are available when needed. Pepperl+Fuchs has over 10 years of application experience with AS-Interface. We can help you design an AS-Interface system that is most suitable for your application, assist you in choosing the correct components, and guide you through the installation in order to ensure that your system fulfils your manufacturing requirements

## Approvals

All Pepperl+Fuchs AS-Interface devices are constructed to adhere to national and international rules and regulations.



All Pepperl+Fuchs modules are CE approved and meet the highest level for electronic noise immunity possible for AS-Interface.



This symbol indicates products have been tested and listed to Underwriters Laboratory standards and are in compliance with both Canadian and U.S. requirements.




Safety modules with this approval can be used up to category 4 according to EN954 and up to SIL 3 according to IEC 61508.

## Round Cable and Flat Cable Connections of AS-Interface

Although a standard two-wire round cable can be used, the preferred way to install AS-Interface is via the famous yellow flat cable. It provides an efficient installation method and, due to the mechanical keying, guarantees correct polarity. Also, the yellow cable ensures that the network operates at peak electrical performance, regardless of the network length (up to 100 meters per segment) and network topology. On the practical side, AS-Interface cable is sold in 100-meter spools. This eliminates the possibility of inadvertently creating a network that is too long.



In addition to using the yellow AS-Interface network cable, a black, mechanically keyed flat cable supplies auxiliary power. The auxiliary power is used to power output devices, such as lights, valves, or actuators. Both cables are offered in standard and oil-resistant versions.



## Shielding or No Shielding

In general, AS-Interface uses unshielded cable. If shielded cable is used, it is important to connect the shielded wire to a solid machine ground wherever the data/power leads are exposed and at the power supply ground connection. Essentially, shielding is used for mechanical protection, not noise immunity. Because of the way AS-i is designed, the shield may reduce the performance of the network by as much as 20%.

**NOTE: Do not ground ANY of the AS-Interface leads under ANY circumstances.**

AS-Interface uses a floating signal and derives much of its noise immunity from it. Tying one lead to ground will interfere with AS-Interface communications. Data transmission of AS-Interface is at 167 kHz and requires no shielding, no termination, and no twisted pairs.

## Flat Cable Piercing Technology

In addition to being the fastest installation method, the AS-Interface flat cable offers other benefits resulting in long-term performance and reliability.

**Redundant piercing**—Redundant electrical connections are established when the AS-Interface flat cable is placed on a Pepperl+Fuchs I/O module. The reliability of those connections has been proven time and again and has been formally evaluated using the DIN EN-60068-2-64 standard.

## Applications

### Easy machine connection / breakdown / reassembly

AS-Interface is the ideal solution to wire modular systems. During the build phase, modules are placed on various sections of the machine, and sensors/actuators are connected. Quick-Blocks and molded cordsets are used between the individual conveyor/machine sections. Breaking down the machine is as easy as removing the

cordsets. No cutting. No splicing. No wire bundles hanging off the module during shipment.




### Slip Ring and Sliding Contact Wiring

AS-Interface is the wiring method of choice when I/O is required on a continuously rotating machine.

With AS-Interface, only two conductors are necessary to get hundreds of I/O back to a PLC. Therefore, it is no longer necessary to over size the slip rings. With its high noise immunity, AS-Interface will easily deal with the electrical noise generated by the sliding contacts.


AS-Interface has been successfully transferred to applications with linear sliders, such as on overhead cranes and assembly lines. Only the I/O modules are placed on the carrier system while the PLC remains separate, at a more convenient location. Since this system is controlled by a small number of PLCs, software modifications are quickly and easily accomplished. Additionally, adding I/O on the carriers is trouble-free, uncomplicated, and fast.



**Note:** To get the best possible long-term reliability, Pepperl+Fuchs suggests silver/carbon contacts. A silver/carbon combination has been proven to be superior to traditional copper contacts, which are less stable and have shorter service lives.

## Safety

It is also possible to route safety data (from door interlocks, e-stops, light curtains) over AS-Interface. AS-Interface Safety at Work allows networking of safety devices using a standard AS-Interface network. With the Safety at Work system, safety devices benefit from all of the advantages that AS-Interface offers. Safety input status is directly available to the PLC without the need for additional wiring to auxiliary contacts. The safe outputs on the SafetyMonitor (roughly equivalent to the safety relay in a hardwired system) can also be retrieved by the PLC without the need for additional wiring.




## Repositioning of Work Stations During System Startup

Frequently, workstations need to be redesigned, modified, or moved. While this is a common occurrence, only AS-Interface has the flexibility to address it fully and offer a simple, efficient, and cost-effective solution. If a module needs to be moved to a different location, it can simply be removed from the yellow cable and relocated where it will best fit the application. The piercings at the original location in the cable will self-heal. The same is true when larger groups of I/O modules, including safety devices, are moved.

## Quick Change Tools On Robotic Arms

Many robotic applications frequently require a change of end arms within the same work cell. AS-Interface is so versatile that a scanner is able to recognize the I/O components on the new end arm in a fraction of a second. With a fully loaded network of 62 nodes, the quick change time is only 35 ms. By the time the mechanical connections are complete, the I/O system is available.



## Valve Tops

Valves have been controlled by AS-Interface for many years and remain a prime example of network efficiency. Typically, a valve top has two sensors (indicating the open and closed position of the valve) and one or two outputs that drive the valve into position. AS-Interface uses a small I/O module that is integrated into the valve top. As a result, connecting a large number of valves to a PLC or DCS is reduced to running a single two-conductor cable between the DCS and the valves. It can't get any simpler.



## Enhancements and Compatibility: How to Expand to 62 Modules

In its original (2.0) specification, AS-Interface accommodates 31 I/O modules where each module uses one, complete address between 1 and 31. With later enhancements, AS-Interface 2.1 allows I/O modules to take up only one half of an address. Therefore, scanners/gateways that support this addressing scheme are able to communicate with up to 62 modules on a network. This is accomplished with full forward and backward compatibility where modules that use a full address offer up to 4 inputs and 4 outputs, and modules with one half of an address provide 4 inputs and 3 outputs. AS-Interface 2.0 supports up to 124 inputs and 124 outputs, AS-Interface 2.1 supports up to 248 inputs and 186 outputs, and AS-Interface 3.0 supports up to 248 inputs and 248 outputs.



Any scanner/gateway can communicate with any type of node. Whole-address modules and half-address modules may be used within the same AS-Interface network. However, the following rules must be observed:

- When an address number is assigned to a whole-address module (5, 6, 7...), that address number cannot be used for a half-address module (5A or 5B, 6A or 6B, 7A or 7B...). Another number must be selected. Likewise, an address number assigned to a half-address module (5A or 5B, 6A or 6B, 7A or 7B...) cannot be used for a whole-address module (5, 6, 7...).
- When an address number is assigned to a half-address module (9A), the other half of the address number (9B) can be used by another half-address module.
- When a half-address module is used on a scanner/gateway that does not support A/B addressing, that module must be set to an A address (3A). No additional modules can be used at that address (3B, for example, cannot be used). Also, the control/system must not turn on or use output D3 or parameter P3.

### NOTE:

- Analog modules with profile S-7.3 use a full address and profile S-7.A supports extended addressing.
- Safety at Work modules use a full address.

- The newest specification enhancements make AS-Interface even more powerful. With the release of Specification 3.0, it is possible to use I/O nodes that support half-addresses and still offer 4 inputs and 4 outputs. As long as a scanner/gateway is used that supports this newest specification, selecting an I/O module is easy: any configuration is possible, irrespective of how old the module is. How does that sound for design simplicity?

The AS-Interface gateways and scanners have a master specification. This specification defines the capabilities and features of the device. All gateways and scanners in this catalog support all features of the latest AS-Interface specification 3.0 and are M4 compliant.

### Master Specification

#### M4 (Version 3 extended master)

- Extended addressing 1-31A, 1-31B
- Support for analog profile S-7.1 and S-7.3
- Support for 4-in/4-out with extended addressing
- Support for analog with extended addressing
- Support for analog using consecutive addresses
- Support for bidirection serial data transfer

#### M3 (Full extended master)

- Extended addressing 1-31A, 1-31B, 4-in/3 out only
- Support for analog profile S-7.1 and S-7.3

#### M1 (Full standard master)


- Standard addressing 1-31, complete support

#### M2 (Reduced standard master)

- Standard addressing 1-31, some parameters used

#### M0 (minimum standard master)

- Standard addressing 1-31, I/O data only



## Standard AS-Interface Components

### Requirements

- **AS-Interface scanner or gateway:** This may be a Pepperl+Fuchs model or made directly by the PLC manufacturer.
- **AS-Interface power supply:** Every AS-Interface network must have a single power supply with AS-Interface decoupling circuitry. If a repeater is used, an additional power supply is required for each.
- **Cable:** This can be the patented flat cable with the piercing technology or any round cable that meets AS-Interface specifications.
- **I/O modules:** Any I/O module from any manufacturer will work, but the Pepperl+Fuchs modules are guaranteed AS-Interface compliant and will work for years to come.
- **24 V external power supply:** A power supply is required only if externally powered outputs are used. Any standard 24 V power supply is suitable. See page 67 for Pepperl+Fuchs standard 24-30 V power supplies.


## Safety at Work

AS-Interface Safety at Work (SaW) is a system that enables networking of safety devices (safety door switches, e-stops, safety light curtains, etc.) using a standard AS-Interface network. With SaW, users can quickly implement a safety system that satisfies the rules and regulations needed for Category 4, SIL 3, PLe safety. The simplicity of the successful AS-Interface is retained and is a major reason for users to implement SaW systems. The following features make SaW unique and powerful:



- Control I/O and safety information on the same network
- Usable up to Safety Category 4, SIL 3, PLe
- Does not require a Safety PLC
- Automatic single node replacement is supported
- SafetyMonitor allows implementation of both simple and powerful safety procedures
- Adding safety devices is simple and fast
- SafetyNodes can be added wherever needed, even during final phases of the project
- Each SafetyNode requires one whole address; 31 SafetyNodes per network






- SafetyMonitor can be placed anywhere on the AS-Interface network—it is not necessary to be close to the SafetyNodes
- The status of safety inputs and safety relays can be monitored directly on AS-Interface and sent to the PLC
- The SafetyMonitor does not require an address. Assign an address to read the states of OSSDs
- SaW devices are certified according EN 954 and IEC 61508 from TÜV Rheinland and are UL approved
- Configured using VAZ-SW-SIMON+ software
- Can scan up to two networks simultaneously
- Up to 16 channels on one safety monitor
- Gateways also available with integrated 16-channel enhanced safety monitors



### Notes





# Gateways and Scanners

<b>Allen-Bradley Scanners .....</b>	<b>29</b>
<b>DeviceNet .....</b>	<b>35</b>
<b>PROFIBUS .....</b>	<b>39</b>
<b>Ethernet.....</b>	<b>46</b>
<b>Serial.....</b>	<b>51</b>

## Gateways and Scanners

An AS-Interface system is based on just a few essential components. Scanner cards/gateways are at the heart of the AS-Interface system and “connect” the I/O to the control system. Scanner cards are directly mounted in the PLC rack and appear in the PLC configuration as large, standard I/O cards. Therefore, transitioning between discrete wiring with standard input and output card systems to the AS-Interface is seamless. The PLC programmer won’t even see a difference between the two systems. One AS-Interface card can replace 10, 20, or more I/O cards and save valuable panel space, as well as reduce the cost of the PLC.

### Gateways

Upper-level (i.e., word- and byte-based) networks such as PROFIBUS, DeviceNet, and Ethernet benefit from the strength of AS-Interface, and handle the AS-Interface gateway simply as a large collection of I/O. Users familiar with their upper-level network of choice will have no problem reading inputs and setting outputs on AS-Interface.

Pepperl+Fuchs’ large selection of scanner cards and gateways presents another advantage that is especially important for OEM users. Regardless of the upper-level network (or PLC model) used in a particular application,

the AS-Interface I/O modules remain unchanged. One can even use a PC with its graphical capabilities during the I/O system installation and setup. Once completed, the same two-conductor AS-Interface cable is connected to the scanner card or gateway. Assured that the I/O system is operational, and that sensor connections and output switches are connected correctly, programming the PLC logic will be fast and easy. AS-Interface drastically reduces the overall time necessary to complete an installation.

In addition to simplifying the installation, AS-Interface can also increase the performance speed of the upper-level bus. Because the AS-Interface gateway collects all I/O data for a single scan update on the upper-level network, overhead processing is significantly reduced, by up to 90%.

### Scanners

AS-Interface Scanners are available from virtually every PLC/DCS manufacturer, and are a great way to bring AS-Interface directly into your control system. A number of scanner card options are available to suit your networking needs. Some cards are available with two AS-Interface networks and with twice as many inputs and outputs available for simultaneous scanning (compared to single-network systems). Also, all scanners can communicate with A and B addressed AS-Interface modules. Up to 62 modules can be scanned by AS-Interface. Analog capabilities are often required for control systems. All scanners and gateways in the *Reference & Buyer’s Guide Edition 6.0* fully support analog modules.

## AS-Interface Scanners by Manufacturer

Manufacturer	PLC/PCS Platform	Extended Addressing	Number of AS-Interface Networks	Analog Capable	AS-i Specification
<b>Allen-Bradley</b> (sold by Pepperl+Fuchs, see page 29)	SLC 503/4/5	Yes	2	Yes	3.0 (M4)
	ControlLogix	Yes	2	Yes	3.0 (M4)
	MicroLogix 1500	Yes	1	Yes	3.0 (M4)
	CompactLogix	Yes	1	Yes	3.0 (M4)
<b>Emerson Process Management</b>	DeltaV	No	2	No	2.0 (M0)
<b>GE Fanuc</b>	VersaMax	No	1	No	2.0 (M1)
<b>Mitsubishi</b>	FX2N	No	1	No	2.0 (M1)
	AnS(H)/QnAS	No	2	No	2.0 (M1)
	Q	Yes	1	Yes	2.1 (M3)
<b>Schneider Electric (Modicon, Telemecanique)</b>	Quantum	No	1	No	2.0 (M1)
	Premium	No	1	No	2.0 (M1)
	Micro	No	1	No	2.0 (M1)
	Nano, Twido	Yes	1	Yes	2.1 (M3)
<b>Omron</b>	CQM1H	No	1	No	2.0 (M1)
<b>Siemens</b>	S7-300, ET-200M	Yes	1	Yes	3.0 (M4)
	S7-200	Yes	1	Yes	2.1 (M3)
<b>Wago</b>	Wago-I/O-System	Yes	1	Yes	3.0 (M4)

## Scanners and Gateways with Extended Addressing

Scanners/gateways that support version 2.1 or higher are able to communicate with up to 62 modules on one network. This is accomplished with full forward and backward compatibility; modules that use a full address offer up to 4 inputs and 4 outputs, and modules with one half of an address provide 4 inputs and 3 outputs. AS-Interface 2.1 supports up to 248 inputs and 186 outputs. A scanner/gateway that supports 2.1 can communicate with full-address modules, and can also communicate with half-address modules, set to both A and B addresses. With the release of AS-Interface specification 3.0, users also have the option of using modules that offer half-addressing mode and still have 4 inputs and 4 outputs.



## Diagnostics

How is the I/O data from the AS-Interface modules mapped into various PLCs?

Typically, PLCs are organized using 16/32-bit input and output words, and I/O cards are associated with those words, based on their location in the rack. The same is true when using an AS-Interface scanner card. The difference is that the AS-Interface scanner represents an I/O card with many more inputs and outputs. The following example for an Allen-Bradley PLC illustrates this difference:

The AS-Interface scanner has been mounted in rack slot 3 and the inputs are mapped in I:3. In contrast to a discrete input card at this rack location (where inputs are mapped between I:3.0/0 and I:3.0/15), the data from the AS-Interface scanner is mapped between I:3.0/0 to I:3.31/15. The input data from four AS-Interface modules is represented within each data table word.





## Allen-Bradley Scanners

- MicroLogix 1500, ControlLogix, SLC500, and CompactLogix supported
- Easy configuration port, PLC, or pushbutton programming
- Easy visual indication of network status
- Advanced diagnostics for easy troubleshooting

### A-B Scanner Overview

All scanner cards come with a configuration port that is great for online diagnostics and commissioning. The MicroLogix and ControlLogix cards can be monitored online while the PLC maintains control. During the start-up phase, the outputs can be set and the inputs can be read without going online with the PLC.

#### Display

Some cards have an integrated seven-segment display. This display is used in configuration mode to show all connected I/O modules. In Protected (Run) mode, the display is used to show missing nodes or recently added nodes that have not yet been added to the scan list.

**See pages 31-32 for Allen-Bradley gateway/scanner wiring.**




## Specifications

PLC PLATFORM OR NETWORK	SLC 5/03, SLC 5/04, SLC 5/05	ControlLogix	MicroLogix 1500, CompactLogix
<b>MODEL NUMBER(S)</b>	Single Network Dual Network		
	SST-ASI-SLC	VBM-CLX-DM	VBM-MLX/CPLX
<b>CAPABILITIES</b>			
SPECIFICATION		3.0	
MASTER PROFILE		M4	
EXTENDED ADDRESSING POSSIBLE (62)		Yes	
ANALOG CAPABILITY		Yes	
MAX DISCRETE I/O COUNT	496 in/496 out		248 in/248 out
<b>CONFIGURATION OPTIONS</b>			
PUSHBUTTONS	–		Yes
PLC		Yes	
DISPLAY	–		2, 7 segment + LEDs
SOFTWARE	Windows HyperTerminal		VAZ-SW-ACT32 (optional)
Cable	USB (included)		K-ADP2 RPI (purchased separately)
<b>STAND-ALONE CONTROL (Optional)</b>		No	
<b>ELECTRICAL SPECIFICATION</b>			
OPERATING CURRENT AS-INTERFACE (1/2)	50 mA	70 mA/70 mA	100 mA
OPERATING CURRENT BACKPLANE	500 mA @ 5 VDC	390 mA @ 5 VDC, 2 mA @ 24 VDC	450 mA @ 5 VDC
<b>ALLEN-BRADLEY</b>			
CONNECTION		Backplane	
I/O MAPPING		Input and output files	
DIAGNOSTICS MAPPING	M0 and M1 files		Input and output files using mailbox
CARDS PER PLC	Limited by rack space		Power supply rating of 4
<b>ADVANCED FUNCTIONALITY</b>			
GROUND FAULT DETECTION		No	
NOISE DETECTION		No	
DUPLICATE ADDRESS DETECTION		No	
OVER VOLTAGE DETECTION		No	
DIAGNOSTIC PORT	Yes (USB)		Yes (RS232)
<b>PROTECTION (IEC)</b>		IP20	
<b>TEMPERATURE RANGE</b>	Working	+32 °F to +122 °F (0 °C to +50 °C)	
	Storage	-13 °F to +158 °F (-25 °C to +70 °C)	
<b>WEIGHT</b>	620 g (22 oz)	375 g (13 oz)	258 g (9 oz)
<b>APPROVALS</b>	CE	CE UL US	45
<b>AS-INTERFACE CONNECTION</b>		Removable terminals	

## Wiring Diagrams

SST-ASI-SLC




LED Indicators

FAULT	COMM 1/COMM 2	Description
Off	Green	Normal operation
Red (flashing)		G-File error or slot disabled
Red (flashing)	Green (flashing)	2 or more AS-I nodes missing, configuration mismatch
Red (flashing)	Red (flashing)	In HyperTerminal configuration mode
	Red (flashing)	Power too low, off-line, in configuration mode
	Green (flashing)	1 AS-I node missing
Red	Red	Error

## Wiring Diagrams

VBM-CLX-DM



## LED Indicators

**SYS:** Green: PLC Connected

**AS-i:** Green (solid): Good  
 Green (flashing): In configuration mode  
 Red (flashing): Peripheral fault  
 Red (solid): Configuration error

**OK:** Red (solid/flashing): Error  
 Green (solid): PLC run mode  
 Green (flashing): PLC program mode

**PRJ Mode:** Yellow: AS-i master is in configuration mode

**AS-i act:** Green: AS-i network operating normally in either configuration or protected mode

**PRG Enable:** Green: Exactly one slave is missing in protected operating mode and automatic addressing is allowed

**PWR:** Green: Power on

## Pushbuttons


**Mode:** Switches between normal operating mode and configuration mode

**Set:** Changes slave addresses in configuration mode

## Display

**LED Display:** 4 digits

VBM-MLX/CPLX



## LED Indicators

**SYS: LED PWR:** Green: Power on

**U AS-i:** Green: AS-i network is sufficiently powered

**AS-i act:** Green: AS-i network operating normally in either configuration or protected mode

**Fault:** Red (solid): One slave missing or extra slave on the network  
 Red (flashing): Peripheral fault on network

**PRG Enable:** Green: Exactly one slave is missing in protected operating mode and automatic addressing is allowed

**PRJ Mode:** Yellow: AS-i master is in configuration mode

**OK:** Green: PLC in run mode

## Pushbuttons

**Mode:** Switches between normal operating mode and configuration mode

**Set:** Changes slave addresses in configuration mode

## Display

**7 Segment Display:** 2 digits and 2 dots




## DATA MAPPING – SLC500

Allen-Bradley scanners map directly into the input and output images of your PLC.

The SLC 500 scanner works with the SLC 5/03, SLS 5/04, and SLC 5/05.

An example of an RS Logix 500 screen capture for SLC 500 mapping (slot 3).



### Mapping Data


Address 1 outputs 1-4 O:3.0/4 - O:3.0/7  
 Address 2 outputs 1-4 O:3.0/8 - O:3.0/11  
 Address 3 outputs 1-4 O:3.0/12 - O:3.0/15  
 Address 4 outputs 1-4 O:3.1/0 - O:3.1/3

Address 5 outputs 1-4 O:3.1/4 - O:3.1/7  
 Address 6 outputs 1-4 O:3.1/8 - O:3.1/11  
 Address 7 outputs 1-4 O:3.0/12 - O:3.0/15  
 ...

## DATA MAPPING – ControlLogix

The ControlLogix scanner works with all models.

An example of an RS Logix 5000 screen capture for ControlLogix mapping (slot 1).




## DATA MAPPING – MicroLogix

Allen-Bradley scanners map directly into the input and output images of your PLC.

The Compact I/O scanner works with the MicroLogix 1500 or the CompactLogix.

An example of an RS Logix 500 screen capture for MicroLogix 1500 mapping third card.



### Mapping Data

Address 1/1A outputs 1-4 O:3.0/8 - O:3.0/11  
 Address 2/2A outputs 1-4 O:3.0/4 - O:3.0/7  
 Address 3/3A outputs 1-4 O:3.0/0 - I:3.0/3  
 Address 4/4A outputs 1-4 O:3.1/12 - O:3.1/15

Address 5/5A outputs 1-4 O:3.1/8 - O:3.1/11  
 Address 6/6A outputs 1-4 O:3.1/4 - O:3.1/7  
 Address 7/7A outputs 1-4 O:3.1/0 - O:3.1/3

## Accessories


### VAZ-SW-ACT32

AS-Interface Control Tools  
 configuration and diagnostic software for  
 ControlLogix and Compact I/O scanners



### K-ADP2 RPI

Communication cable for ControlLogix and  
 Compact I/O scanners (RS232)



See pages 211-226 for complete AS-Interface accessory listing.



## DeviceNet Gateways

- Advanced graphical display
- Polled, cyclic, change of state, and explicit messaging
- Powered via AS-Interface
- Duplicate address, noise, and ground fault detection

### DeviceNet Gateway Overview

The VBG-DN-K20-D single network gateway and the VBG-DN-K20-DMD... double network gateway support the AS-Interface Specification 3.0.



The advanced graphical display is great for configuring the AS-Interface network as well as diagnosing problems at every stage of installation. Complete lists of all configured nodes, failed nodes, and detected nodes are all stored in the unit. Diagnostic counters keep track of all communication errors in the unlikely event of EMC or noise problems on the network. The easy-to-use pushbuttons can also be used to configure the entire network. DeviceNet gateways also offer features such as duplicate address detection, over voltage detection, and integrated noise monitoring—features no other manufacturer can match.

**DEVICENET**  
 QUICK SETUP  
 SLAVE ADR TOOL  
 SLAVE TEST TOOL  
 SETUP  
 IO + PARAM. TEST  
 DIAGNOSIS  
 ADV. DIAGNOSIS  
 AS-I SAFETY  
 LANGUAGE  
 DISP CONTRAST

To expedite troubleshooting, all outputs can be set directly from the display and every input can be easily read.

In addition to discrete inputs and outputs, analog points are easy to troubleshoot as well. Analog outputs can be written and analog inputs can be read as if you were standing in front of an HMI.

#### BINARY INPUTS

D3 ... D0

1A - 0 1 0 1

2A - 0 1 0 1 ↓

#### BINARY OUTPUTS






D3 ... D0

1A - 0 1 0 1

2A - 0 1 0 1 ↓


**See pages 37-38 for DeviceNet gateway wiring and dimensions.**



Specifications	Enhanced	Basic with Display
<b>NETWORK</b>	<b>DeviceNet</b>	
<b>MODEL</b>	Single Network	VBG-DN-K20-D
<b>NUMBER(S)</b>	Dual Network	VBG-DN-K20-DMD
<b>CAPABILITIES</b>		
SPECIFICATION	3.0	
MASTER PROFILE	M4	
EXTENDED ADDRESSING POSSIBLE (62)	Yes	
ANALOG CAPABILITY	Yes	
MAX DISCRETE I/O COUNT	248 inputs/248 outputs per network	
<b>CONFIGURATION OPTIONS</b>		
PUSHBUTTONS	Yes	
PLC / DEVICENET	Yes	
DISPLAY	Graphical	
SOFTWARE	VAZ-SW-ACT32 (optional)	
Converter required	No	Yes
<b>STAND-ALONE CONTROL (Optional)</b>	Disabled by default, purchase VAZ-CTR to unlock	
<b>ELECTRICAL SPECIFICATION</b>		
OPERATING CURRENT (1/2)	200 mA/70 mA	
OPERATING CURRENT DEVICENET	35 mA	
<b>DEVICENET</b>		
CONNECTION	Dual row 5-pin removable terminals	
COMMUNICATION	Polling, change of state, cyclic	
BAUD RATES (Set via DeviceNet or graphical display)	125, 250, 500 kbps	
MAC ID (Set via DeviceNet or graphical display)	0-63	
<b>ADVANCED FUNCTIONALITY</b>		
GROUND FAULT DETECTION	Yes	
NOISE DETECTION	Yes	
DUPLICATE ADDRESS DETECTION	Yes	No
OVER VOLTAGE DETECTION	Yes	
RS232 DIAGNOSTIC PORT	Yes	No
<b>PROTECTION (IEC)</b>	IP20	
<b>TEMPERATURE</b>	+32 °F to +131 °F (0 °C to +55 °C)	
<b>RANGE</b>	-13 °F to +185 °F (-25 °C to +85 °C)	
<b>HOUSING MATERIAL</b>	Stainless steel	
<b>WEIGHT</b>	590 g (21 oz)	
<b>APPROVALS</b>	  	
<b>AS-INTERFACE CONNECTION</b>	 Yellow removable spring terminals	
<b>AS-INTERFACE POWER SUPPLY CONNECTION</b>	 Black removable spring terminals for 30 V AS-i power supply	



## Wiring Diagrams



## LED Indicators

**Power:** Green: Power on

**MNS:** DeviceNet Status: Green (solid): Online connected  
Green (brinking): Online not connected  
Red: Bus off  
Off: Offline no connection

**Config Error:** Red (solid): One slave missing or extra slave on the network  
Red (flashing): Peripheral fault on network

**U AS-i:** Green: AS-i network is sufficiently powered

**AS-i Active:** Green: AS-i network operating normally in either configuration or protected mode

**PRG Enable:** Green: Automatic addressing of missing slave enabled

**PRJ Mode:** Yellow: AS-i master is in configuration mode

## Pushbuttons

**↑ Mode:** Switches between normal operating mode and configuration mode and moving up through display

**↓ Set:** Changes slave addresses in configuration mode and moves down through display

**OK:** Moves forward through graphical display and to accept changes


**ESC:** Moves backward through display

## Display

**Graphical Display:** 4-line black and white display

## Dimensions (mm)

VBG-DN-K20-D  
VBG-DN-K20-DMD  
VBG-DN-K20-DMD-BV



## Accessories

### VAZ-DN-SIM-USB

DeviceNet master simulator connects DeviceNet gateway directly to USB port on PC.



### VAZ-SW-ACT32

AS-Interface Control Tools configuration and diagnostic software. BV version also requires simulator.



### VAZ-CTR

Unlock codes for stand-alone control functionality of gateway. Must have VAZ-SW-ACT32 to program and unlock stand-alone control functionality. BV version also requires simulator.

Serial Number: 1234567  
Unlock codes: \_\_\_\_, \_\_\_\_, \_\_\_\_

**See pages 211-226 for complete AS-Interface accessory listing.**



## PROFIBUS Gateways

- RS232 port for diagnostic monitoring of network
- Low-cost housing option available without advanced diagnostics
- Built-in duplicate address, noise, and ground fault detection

### PROFIBUS Gateway Overview

Pepperl+Fuchs offers single and double PROFIBUS gateways that fulfill AS-Interface Specification 3.0. These units are also modular PROFIBUS slaves, which means that they can be configured using the GSD file to specify which data, and the amount of data that will be transferred.

These gateways also support acyclical communication of the PROFIBUS DPV1. The acyclical services are used to access all the data made available by the AS-Interface/PROFIBUS gateway. Communication is available up to 12 Mbps.

Pushbuttons or the graphical display are used to assign addresses, accept the target configuration, and adjust the PROFIBUS address and baud rate. Some models use seven LEDs on the front panel to show the current status of the AS-Interface network. Our top-of-the line PROFIBUS gateways use a graphical display to provide status indication in full text.

AS-Interface gateways with graphical displays allow the AS-Interface circuit to be placed in service and the test of

the connected I/O can be kept entirely separate from the commissioning of PROFIBUS and the programming.

The K20 housing series provides new functions with an improved display. The PROFIBUS connection is recessed on the side. When connected, the device and the connector fit snugly together (only 83 mm high). These gateways are ideal for installation in low-profile junction boxes.

#### BINARY INPUTS

D3 ... D0

1A - 0 1 0 1

2A - 0 1 0 1 ↓

#### BINARY OUTPUTS

D3 ... D0

1A - 0 1 0 1

2A - 0 1 0 1 ↓

All of the information presented on the large, graphic display is clearly readable thanks to the backlit illumination. Extensive diagnostic functions make fault location a simple task.

Dual addresses are detected via the gateway. The gateway also monitors AS-Interface for ground faults. The integrated ground connection and the color-coded removable terminals make it easy to replace a defective unit or to disassemble a machine for maintenance.

**See pages 42-44 for PROFIBUS gateway wiring and dimensions.**

#### PROFIBUS

QUICK SETUP

AS-I SAFETY

DIAGNOSIS

SLAVE ADR TOOL



TEST

SETUP

DISP CONTRAST






Specifications		Enhanced	Basic with Display	Basic
NETWORK		PROFIBUS		
MODEL	Single Network	VBG-PB-K20-D		VBG-PB-K25
NUMBER(S)	Dual Network	VBG-PB-K20-DMD	VBG-PB-K20-DMD-BV	
CAPABILITIES				
SPECIFICATION		3.0		
MASTER PROFILE		M4		
EXTENDED ADDRESSING POSSIBLE (62)		Yes		
ANALOG CAPABILITY		Yes		
MAX DISCRETE I/O COUNT		248 inputs/248 outputs per network		
CONFIGURATION OPTIONS				
PUSHBUTTONS		Yes		
PLC / PROFIBUS		Yes		
DISPLAY		Graphical	3, 7 segment + LEDs	
SOFTWARE		VAZ-SW-ACT32 (optional)		
Converter Required		No	Yes	
STAND-ALONE CONTROL (Optional)		Disabled by default, purchase VAZ-CTR to unlock		
ELECTRICAL SPECIFICATION				
OPERATING CURRENT (1/2)		200 mA/70 mA	200 mA	
PROFIBUS				
CONNECTION		DB9		
COMMUNICATION		PROFIBUS, DPV0, AND DPV1		
BAUD RATES		Up to 12 Mbps		
ADDRESSES		0-127		
ADVANCED FUNCTIONALITY				
GROUND FAULT DETECTION		Yes		
NOISE DETECTION		Yes		
DUPLICATE ADDRESS DETECTION		Yes	No	
OVER VOLTAGE DETECTION		Yes		
RS232 DIAGNOSTIC PORT		Yes	No	
PROTECTION (IEC)		IP20		
TEMPERATURE WORKING		+32 °F to +131 °F (0 °C to +55 °C)		
RANGE STORAGE		+5 °F to +167 °F (-15 °C to +75 °C)	-13 °F to +185 °F (-25 °C to +85 °C)	
HOUSING MATERIAL		Stainless steel		
WEIGHT		590 g (21 oz)	460 g (16 oz)	
APPROVALS		CEULUS		
AS-INTERFACE CONNECTION		 Yellow removable spring terminals		
POWER SUPPLY CONNECTION		 Black removable spring terminals for 30 V AS-i power supply		





Specifications	Enhanced with Safety Controller
<b>NETWORK</b>	<b>PROFIBUS</b>
<b>MODEL</b> Single Network	<b>VBG-PB-K30-D-S16</b>
<b>NUMBER(S)</b> Dual Network	<b>VBG-PB-K30-DMD-S16</b>
<b>CAPABILITIES</b>	
SPECIFICATION	3.0
MASTER PROFILE	M4
EXTENDED ADDRESSING POSSIBLE (62)	Yes
ANALOG CAPABILITY	Yes
MAX DISCRETE I/O COUNT	248 inputs/248 outputs per network
<b>CONFIGURATION OPTIONS</b>	
PUSHBUTTONS	Yes
PLC / PROFIBUS	Yes
DISPLAY	Graphical
SOFTWARE	VAZ-SW-ACT32 (optional) and VAZ-SW-SIMON+ (required)*
Converter Required	No
<b>STAND-ALONE CONTROL (Optional)</b>	No
<b>ELECTRICAL SPECIFICATION</b>	
OPERATING CURRENT (1/2)	300 mA/70 mA
<b>PROFIBUS</b>	
CONNECTION	DB9
COMMUNICATION	PROFIBUS, DPV0, AND DPV1
BAUD RATES	Up to 12 Mbps
ADDRESSES	0-127
<b>ADVANCED FUNCTIONALITY</b>	
GROUND FAULT DETECTION	Yes
NOISE DETECTION	Yes
DUPLICATE ADDRESS DETECTION	Yes
OVER VOLTAGE DETECTION	Yes
RS-232 DIAGNOSTIC PORT	Yes
REMOVABLE MEMORY CARD	Yes
<b>PROTECTION (IEC)</b>	IP20
<b>TEMPERATURE</b> WORKING	+32 °F to +131 °F (0 °C to +55 °C)
<b>RANGE</b> STORAGE	-13 °F to +185 °F (-25 °C to +85 °C)
<b>HOUSING MATERIAL</b>	Stainless steel
<b>WEIGHT</b>	800 g (28 oz)
<b>APPROVALS</b>	CE cULus 45
<b>AS-INTERFACE CONNECTION</b>	 Yellow removable spring terminals
<b>POWER SUPPLY CONNECTION</b>	 Black removable spring terminals for 30 V AS-i power supply
<b>SAFETY INFORMATION</b>	
START/EDM INPUTS	4, 10 mA @ 24 VDC
SAFETY OUTPUT CHANNELS	16
SAFETY OUTPUTS (OSSDs)	4 channels (2 relay, 2 PNP)
SAFE OUTPUTS ON AS-i	Yes (up to 16 channels)
SAFE COUPLING	Yes (up to 16 channels)
NETWORK CONNECTIONS	2
MAX NUMBER SAFETY DEVICES	(31 x 2 networks) = 62
MAX NUMBER PROG. BLOCKS	256

\*Cable VAZ-SIMON+-R2-1,8M-PS/2 required

Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work


Sensors

Cordsets

Accessories


## Wiring Diagrams

VBG-PB-K20-D



AS-i Network  
AS-i Network  
AS-i Power Supply

VBG-PB-K20-DMD  
VBG-PB-K20-DMD-BV (no RS232 port)



AS-i Network 1  
AS-i Network 1  
AS-i Network 2  
AS-i Network 2  
AS-i Power Supply

## LED Indicators

**Power:** Green: Power on

**PROFIBUS:** Green (solid): Allocated to a PROFIBUS master

**Config Error:** Red (solid): One slave missing or extra slave on the network  
Red (flashing): Peripheral fault on network

**U AS-i:** Green: AS-i network is sufficiently powered

**AS-i Active:** Green: AS-i network operating normally in either configuration or protected mode

**PRG Enable:** Green: Automatic addressing of missing slave enabled

**PRJ Mode:** Yellow: AS-i master is in configuration mode

## Pushbuttons

**↑ Mode:** Switches between normal operating mode and configuration mode and moves up through display

**↓ Set:** Changes slave addresses in configuration mode and moves down through display


**OK:** Moves forward through graphical display and to accept changes

**ESC:** Moves backward through display

## Display

**Graphical Display:** 4-line black and white display

VBG-PB-K25



AS-i Network  
AS-i Network  
AS-i Power Supply

## LED Indicators

**Power:** Green: Power on

**PROFIBUS:** Green (solid): Allocated to a PROFIBUS master

**Config Error:** Red (solid): One slave missing or extra slave on the network  
Red (flashing): Peripheral fault on network

**U AS-i:** Green: AS-i network is sufficiently powered

**AS-i Active:** Green: AS-i network operating normally in either configuration or protected mode

**PRG Enable:** Green: Automatic addressing of missing slave enabled

**PRJ Mode:** Yellow: AS-i master is in configuration mode

## Pushbuttons

**Mode:** Switches between normal operating mode and configuration mode


**Set:** Changes slave addresses in configuration mode

## Display

**7 Segment Display:** 3 digits, 2 dots

## Wiring Diagrams

VBG-PB-K30-D-S16



## LED Indicators

**Power:** Green: Power on

**PROFIBUS:** Green (solid): Allocated to a PROFIBUS master

**Config Error:** Red (solid): One slave missing or extra slave on the network  
Red (flashing): Peripheral fault on network

**U AS-i:** Green: AS-i network is sufficiently powered

**AS-i Active:** Green: AS-i network operating normally in either configuration or protected mode

**PRG Enable:** Green: Automatic addressing of missing slave enabled

**PRJ Mode:** Yellow: AS-i master is in configuration mode

**Aux:** Green: Power on

**1.Yx, 2.Yx:** Yellow: Input on

**Kx:** Yellow: OSSD on

## Pushbuttons

**1 Mode:** Switches between normal operating mode and configuration mode and moves up through display

**↓ Set:** Changes slave addresses in configuration mode and moves down through display


**OK:** Moves forward through graphical display and to accept changes

**ESC:** Moves backward through display


## Display

**Graphical Display:** 4-line black and white display

VBG-PB-K30-DMD-S16




## Wiring Diagrams




## Dimensions (mm)


**VBG-PB-K20-D**  
**VBG-PB-K20-DMD**  
**VBG-PB-K20-DMD-BV**



**VBG-PB-K25**



**VBG-PB-K30-D-S16**  
**VBG-PB-K30-DMD-S16**





## Accessories

**VAZ-PB-SIM**  
PROFIBUS master simulator



**VAZ-SW-ACT32**  
AS-Interface Control Tools  
configuration and diagnostic software



**VAZ-PB-DB9-W**  
PROFIBUS 9-pin, right-angle D-sub  
connector for 2 PROFIBUS cables  
with terminator switch



**VAZ-SW-SIMON+**  
AS-Interface safety monitor configuration  
software. RS232 configuration cable included.



**VAZ-SIMON+-R2-1,8M-PS/2**  
AS-Interface safety monitor programming cable



**VAZ-CTR**  
Unlock codes for stand-alone control functionality of  
gateway. Must have VAZ-SW-ACT32 to program and  
unlock stand-alone control functionality. BV and K25  
also require simulator to communicate with gateway.

Serial Number: 1234567  
Unlock codes: \_\_\_\_, \_\_\_\_, \_\_\_\_

See pages 211-226 for complete AS-Interface accessory listing.

# Ethernet Gateways

- RS232 port for diagnostic monitoring of network
- Advanced graphical display
- Duplicate address, noise, and ground fault detection built in
- 10/100 Mbps Ethernet connection, IP address set using display or DHCP
- Removable memory card
- Ethernet/IP support allows direct integration with modern Allen-Bradley PLCs
- Integrated PROFINET and Modbus/TCP protocols
- Safe data transfer to PROFI-safe



## Overview

Pepperl+Fuchs offers gateways that function as complete AS-Interface networks and also as servers to the upper-level Ethernet networks. In configuration mode, all AS-Interface modules detected are displayed on the LCD. There are seven LEDs on the front panel available for diagnostics. Pushbuttons are used to program the addresses of the AS-Interface modules and to store the network configuration.

Each Ethernet gateway is supplied with a unique MAC-ID. An IP address can be assigned to the gateway using the graphical display or DHCP. All the information presented on the large, graphical display is clearly readable thanks to the backlit illumination. Extensive diagnostic functions make fault location a simple task.

Duplicate addresses are detected via the gateway. The gateway also monitors AS-Interface for ground faults. The integrated ground connection and the color-coded removable

terminals make it easy to replace a defective unit or disassemble a machine.

With direct Ethernet/IP, support integration of our Ethernet gateways into an Allen-Bradley ControlLogix or Compact I/O environment is easy and convenient. Once the gateway is inserted into the configuration, all I/O data is directly mapped and immediately available for use. The native implementations guarantee fast data updates. PROFINET is another Ethernet-based protocol predominately supported by many, including Siemens PLCs.

If Ethernet is used, Modbus/TCP is uniquely qualified to allow multiple users to log on simultaneously. This function enables one control program to be used alongside data acquisition, diagnostic, and monitoring software.

**See pages 49-50 for Ethernet gateway wiring and dimensions.**

### BINARY INPUTS

D3 ... D0

1A - 0 1 0 1

2A - 0 1 0 1 ↓






### BINARY OUTPUTS

D3 ... D0






1A - 0 1 0 1

2A - 0 1 0 1 ↓



Specifications	Enhanced	
NETWORK	Ethernet/IP, Modbus/TCP	PROFINET
<b>MODEL</b>	<b>VBG-ENX-K20-D</b>	<b>VBG-PN-K20-D</b>
<b>NUMBER(S)</b>	<b>VBG-ENX-K20-DMD</b>	<b>VBG-PN-K20-DMD</b>
<b>CAPABILITIES</b>		
SPECIFICATION	3.0	
MASTER PROFILE	M4	
EXTENDED ADDRESSING POSSIBLE (62)	Yes	
ANALOG CAPABILITY	Yes	
MAX DISCRETE I/O COUNT	248 inputs/248 outputs per network	
<b>CONFIGURATION OPTIONS</b>		
PUSHBUTTONS	Yes	
PLC / ETHERNET	Yes	
DISPLAY	Graphical	
SOFTWARE	VAZ-SW-ACT32 (optional)	
Converter required	No	
<b>STAND-ALONE CONTROL (Optional)</b>	No	
<b>ELECTRICAL SPECIFICATION</b>		
OPERATING CURRENT (1/2)	≤300 mA	
<b>ETHERNET</b>		
CONNECTION	RJ45 (2)	
COMMUNICATION	Ethernet/IP and Modbus/TCP	PROFINET I/O
BAUD RATES	Autonegotiate 10/100 Mbps full/half duplex	
ADDRESSES	IP address static, DHCP	IP address static, DHCP, and PROFINET Name
<b>ADVANCED FUNCTIONALITY</b>		
GROUND FAULT DETECTION	Yes	
NOISE DETECTION	Yes	
DUPLICATE ADDRESS DETECTION	Yes	
OVER VOLTAGE DETECTION	Yes	
RS232 DIAGNOSTIC PORT	Yes	
REMOVABLE MEMORY CARD	Yes	
<b>AVAILABLE DRIVERS</b>	ActiveX-Control, 32 bit DLL, OPC SERVER, .NET, LINUX	–
<b>PROTECTION (IEC)</b>	IP20	
<b>TEMPERATURE</b>		
WORKING RANGE	+32 °F to +131 °F (0 °C to +55 °C)	
STORAGE	-13 °F to +185 °F (-25 °C to +85 °C)	
<b>HOUSING MATERIAL</b>	Stainless steel	
<b>WEIGHT</b>	500 g (18 oz)	
<b>APPROVALS</b>	  	
<b>AS-INTERFACE CONNECTION</b>	 Yellow removable spring terminals	
<b>AS-INTERFACE POWER SUPPLY CONNECTION</b>	 Black removable spring terminals for 30 V AS-i power supply	



Specifications		Enhanced with Safety Controller	
NETWORK		Ethernet/IP, Modbus/TCP	PROFIsafe
MODEL NUMBER(S)	Single Network		
	Dual Network	VBG-ENX-K30-DMD-S16	VBG-PNS-K30-DMD
CAPABILITIES			
SPECIFICATION		3.0	
MASTER PROFILE		M4	
EXTENDED ADDRESSING POSSIBLE (62)		Yes	
ANALOG CAPABILITY		Yes	
MAX DISCRETE I/O COUNT		248 inputs/248 outputs per network	
CONFIGURATION OPTIONS			
PUSHBUTTONS		Yes	
PLC / ETHERNET		Yes	
DISPLAY		Graphical	
SOFTWARE		VAZ-SW-SIMON+ (required), VAZ-SW-ACT32 (optional)*	
Converter required		No	
STAND-ALONE CONTROL (Optional)		No	
ELECTRICAL SPECIFICATION			
OPERATING CURRENT (1/2)		≤300 mA	≤370 mA
ETHERNET			
CONNECTION		RJ45 (2)	
COMMUNICATION		Ethernet/IP and Modbus/TCP	PROFINET/PROFIsafe
BAUD RATES		Autonegotiate 10/100 Mbps full/half duplex	
ADDRESSES		IP address static, DHCP	IP address static, DHCP, and PROFINET Name
ADVANCED FUNCTIONALITY			
GROUND FAULT DETECTION		Yes	
NOISE DETECTION		Yes	
DUPLICATE ADDRESS DETECTION		Yes	
OVER VOLTAGE DETECTION		Yes	
RS232 DIAGNOSTIC PORT		Yes	
REMOVABLE MEMORY CARD		Yes	
AVAILABLE DRIVERS		ActiveX-Control, 32 bit DLL, OPC SERVER, .NET, LINUX	—
PROTECTION (IEC)		IP20	
TEMPERATURE RANGE	WORKING	+32 °F to +131 °F (0 °C to +55 °C)	
	STORAGE	-13 °F to +185 °F (-25 °C to +85 °C)	
HOUSING MATERIAL		Stainless steel	
WEIGHT		800 g (28 oz)	
APPROVALS		  	
AS-INTERFACE CONNECTION		 Yellow removable spring terminals	
AS-INTERFACE POWER SUPPLY CONNECTION		 Black removable spring terminals for 30 V AS-i power supply	
SAFETY INFORMATION			
START/EDM INPUTS		4, 10 mA @ 24 VDC	
SAFETY OUTPUT CHANNELS		16	45
SAFETY OUTPUTS (OSSDs)		4 channels (2 relay, 2 PNP)	
SAFE OUTPUTS ON AS-i		Yes (up to 16)	Yes (up to 45)
SAFE COUPLING		Yes (up to 16)	Yes (up to 62)
NETWORK CONNECTIONS		2	
MAX NUMBER SAFETY DEVICES		(31 x 2 networks) = 62	
MAX NUMBER PROG BLOCKS		256	

\*Use of VAZ-SIMON+-R2-1,8M-PS/2 optional

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com




Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

 **PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com



## Wiring Diagrams

VBG-ENX-K20-D  
VBG-PN-K20-DVBG-PNS-K30-DMD  
VBG-ENX-K30-DMD-S16VBG-ENX-K20-DMD  
VBG-PN-K20-DMD

## LED Indicators

**Power:** Green: Power on**Ethernet:** Green (solid): IP address assigned

Green (3 flashes): No Ethernet cable connected

Green (4 flashes): No MAC address assigned, defective

Green (5 flashes): Waiting for DHCP

**Config Error:** Red (solid): One slave missing or extra slave on the network

Red (flashing): Peripheral fault on network

**U AS-i:** Green: AS-i network is sufficiently powered**AS-i Active:** Green: AS-i network operating normally in either configuration or protected mode**PRG Enable:** Green: Automatic addressing of missing slave enabled**PRJ Mode:** Yellow: AS-i master is in configuration mode

## Pushbuttons


**↑ Mode:** Switches between normal operating mode and configuration mode and moves up through display**↓ Set:** Changes slave addresses in configuration mode and moves down through display**OK:** Moves forward through graphical display and to accept changes**ESC:** Moves backward through display

## Display


**Graphical Display:** 4-line black and white display

## Dimensions (mm)

VBG-ENX-K20-D  
 VBG-PN-K20-D  
 VBG-ENX-K20-DMD  
 VBG-PN-K20-DMD



VBG-PNS-K30-DMD  
 VBG-ENX-K30-DMD-S16



## Accessories

**VAZ-SW-ACT32**

AS-Interface Control Tools  
 configuration and diagnostic software

**VAZ-SW-SIMON+**

AS-Interface safety monitor configuration  
 software. RS232 configuration cable included.



See pages 211-226 for complete AS-Interface accessory listing.

## Serial Gateways

- Pepperl+Fuchs or Modbus protocol support
- Stand-alone control
- Removable terminals
- ActiveX, DLLs, OPC, .NET drivers
- Up to 115.2 kbps



### Serial Gateway Overview

The RS232 gateway is used for PC or stand-alone control applications. The serial port can communicate up to 57.6 kbps. Up to 62 discrete I/O or 31 analog modules can be placed on one network. The keyed removable terminals add flexibility when connecting AS-Interface or RS232.

Our Modbus gateways are designed to support the open Modbus protocol. Since many PC-based control platforms and SCADA packages support the Modbus protocol, our serial gateway is the ideal solution for adding hundreds of I/O points. Modbus driver communication can also be used with custom PC-based applications written in Visual Basic or other higher-level languages.

Our gateways using the Pepperl+Fuchs protocol, such as VBM-CTR..., also have built-in and enabled stand-alone control offering PLC functionality. This control platform allows users to write powerful programs to control their process without using a PLC or PC. In addition, these gateways are perfect for distributed control systems where some outputs are controlled by the gateways, while others are controlled by the PLC. Stand-alone control programs have the following capabilities:

#### Stand-Alone Control Capabilities

<b>Program memory</b>	16 kB
<b>Data memory ex. counters, timers</b>	8 kB
<b>Cycle time</b>	2 ms /1000 instructions
<b>Timers</b>	1024, 10ms resolution
<b>Counters</b>	1024
<b>Programming language</b>	AWL (structured text), or Assembly

This simple programming language allows for easy reading of inputs, setting of outputs, and manipulation of analog data. Binary operations such as AND, AND NOT, OR, OR NOT, =, NOT, SET, and RESET are available. Word-based operations include Load Timer, Load Counter, Load Parameter, Load Byte,

Load Word, Copy Byte, Copy Word, Addition, and Subtraction. In addition, logical operators such as LESS THAN, LESS THAN OR EQUAL, GREATER THAN, GREATER THAN OR EQUAL, EQUAL, and NOT EQUAL can be used.

Program control is done with segment end, block end, and jump type instructions. These gateways also have built-in function blocks to retrieve and send data up to the AS-Interface master. These blocks include read/write parameters, reading slave lists, reading safety data, and accessing the mailbox. Over 15 built-in function blocks are available to the user.


**See page 53 for Serial gateway wiring and dimensions.**



Specifications	Enhanced	Basic with display
<b>NETWORK</b>	<b>Modbus Serial RS485</b>	<b>P+F Serial RS232</b>
<b>MODEL</b>	<b>VBG-MOD-K20-D</b>	<b>VBM-CTR-K20-R2</b>
<b>NUMBER(S)</b>		
Single Network		
Dual Network		
<b>CAPABILITIES</b>		
SPECIFICATION	3.0	
MASTER PROFILE	M4	
NUMBER OF NETWORKS	1	
EXTENDED ADDRESSING POSSIBLE (62)	Yes	
ANALOG CAPABILITY	Yes	
MAX DISCRETE I/O COUNT	248 inputs/248 outputs per network	
<b>CONFIGURATION OPTIONS</b>		
PUSHBUTTONS	Yes	
PC	Yes	
DISPLAY	Graphical	
SOFTWARE	VAZ-SW-ACT32 (optional)	
Converter required	No	
<b>STAND-ALONE CONTROL (Optional)</b>	Disabled by default, purchase VAZ-CTR to unlock	Enabled by default
<b>ELECTRICAL SPECIFICATION</b>		
OPERATING CURRENT AS-INTERFACE	200 mA	
<b>SERIAL-SPECIFIC INFORMATION</b>		
CONNECTION	DB9	
SERIAL INTERFACE	RS485	RS232
COMMUNICATION	Modbus ASCII/RTU	Standard Pepperl+Fuchs protocol
BAUD RATES	1200 to 115200 bps	1200 to 115200 bps, autobaud
PARITY	Odd, even, or none	None
ADDRESSES	1-31	None
<b>ADVANCED FUNCTIONALITY</b>		
GROUND FAULT DETECTION	Yes	
NOISE DETECTION	Yes	
DUPLICATE ADDRESS DETECTION	Yes	No
OVER VOLTAGE DETECTION	Yes	
RS232 DIAGNOSTIC PORT	Yes	No
<b>AVAILABLE DRIVERS</b>	ActiveX-Control, 32 bit DLL, OPC SERVER, .NET, LINUX	
<b>PROTECTION (IEC)</b>	IP20	
<b>TEMPERATURE</b>	+32 °F to +131 °F (0 °C to +55 °C)	
<b>RANGE</b>		
WORKING		
STORAGE	+5 °F to +167 °F (-15 °C to +75 °C)	-13 °F to +185 °F (-25 °C to +85 °C)
<b>HOUSING MATERIAL</b>	Stainless steel	
<b>WEIGHT</b>	590 g (21 oz)	
<b>APPROVALS</b>	CE, UL, AS	
<b>AS-INTERFACE CONNECTION</b>	Yellow removable spring terminals	
<b>AS-INTERFACE POWER SUPPLY CONNECTION</b>	Black removable spring terminals for 30 V AS-i power supply	

## Wiring Diagrams

VBG-MOD-K20-D  
VBM-CTR-K20-R2



### LED Indicators

**Power:** Green: Power on

**Ser. Active:** Green (flash): On successful send/receive of serial data

**Config Error:** Red (solid): One slave missing or extra slave on the network  
Red (flashing): Peripheral fault on network

**U AS-i:** Green: AS-i network is sufficiently powered

**AS-i Active:** Green: AS-i network operating normally in either configuration or protected mode

**PRG Enable:** Green: Automatic addressing of missing slave enabled

**PRJ Mode:** Yellow: AS-i master is in configuration mode

### Pushbuttons

**↑ Mode:** Switches between normal operating mode and configuration mode and moves up through display

**↓ Set:** Changes slave addresses in configuration mode and moves down through display

**OK:** Moves forward through graphical display and to accept changes


**ESC:** Moves backward through display

### Display

**Graphical Display:** 4-line black and white display

## Dimensions (mm)

VBG-MOD-K20-D  
VBM-CTR-K20-R2



## Accessories

### VAZ-SW-ACT32

AS-Interface Control Tools  
configuration and diagnostic software



### VAZ-R4-R2

RS232 to RS485 converter



### VAZ-CTR

Unlock codes for stand-alone control  
functionality of gateway. Must have  
VAZ-SW-ACT32 to program and unlock  
stand-alone control functionality.

Serial Number: 1234567

Unlock codes: \_\_\_\_, \_\_\_\_, \_\_\_\_


See pages 211-226 for complete AS-Interface accessory listing.





Notes

Gateways and Scanners
Power Supplies and Repeaters
I/O Modules
Safety at Work
Sensors
Cordsets
Accessories




# Power Supplies and Repeaters

<b>AS-Interface Power Supplies .....</b>	<b>58</b>
<b>Power Conditioners .....</b>	<b>61</b>
<b>Repeaters .....</b>	<b>64</b>
<b>Standard 24-30 VDC Power Supplies.....</b>	<b>67</b>

## Power Supplies and Repeaters

AS-Interface power supplies are an integral part of the AS-Interface network. On AS-Interface, data and power are transmitted on the same cable. The data signal is transferred using amplitude pulse modulation and rides on top of 30 VDC that powers the modules. Because both DC and high-frequency communication components are present on AS-Interface, power conditioning circuitry is required.



## Features of AS-Interface Power Supplies

### Startup and overload protection

An overload can last for an indefinite amount of time without damaging the power supply. Removing the overload will allow the power supply to come back automatically to the the full-rated current.

### Power specifications

The output voltage of the power supply is between 29.5 VDC and 31.6 VDC over the entire load range.

### Power interruptions

Power interruption of 10 ms or less on the primary side will not affect AS-Interface.

### Power-on delay

The power-on delay is less than 2 s.

## Rated Operating Current

The rated operating current can be exceeded by a maximum of 0.4 A to meet the expectations of the modules requiring extra current during power up.

### AC input and AS-Interface output connections

Primary	<b>L</b>	Single phase
	<b>N</b>	Neutral
	<b>PE</b>	Protected earth ground
	<b>AS-i+</b>	AS-Interface Power +
	<b>AS-i-</b>	AS-Interface Power -
	<b>GND</b>	Machine ground and shield connection

## Ground Fault Detection

AS-Interface (+) and AS-Interface (-) must never be grounded. In addition, they can never be connected to any load other than the appropriate terminals on AS-Interface I/O modules, AS-Interface intelligent sensors, or other loads. Standard PNP sensors are connected to AS-Interface through I/O modules. Grounding will reduce the noise immunity of the network. For this reason, ground fault detection supplies have been developed and will ensure that the AS-Interface network runs properly. This feature is also built into a number of AS-Interface gateways. Pepperl+Fuchs recommends using a power supply with ground fault detection when the scanner or gateway does not have integrated ground fault detection. We also recommend using these supplies in network segments after a repeater.

## Choosing the Correct Power Supply

AS-Interface power supplies feature short-circuit and overload protection. In addition to providing power to the AS-Interface scanner/gateway, the AS-Interface power supply provides power to the electronics of the I/O modules and most inputs on the network. Modules

can consume between 15 and 250 mA and a typical AS-Interface scanner/gateway uses 200 mA. A power supply must be chosen that has a current rating that is equal to or greater than the total current required by the network. Power supply units are certified by the AS-Interface Association and are available with current ratings from 2.8 A to 8 A.

#### Sizing the AS-Interface power supply:

$$\begin{array}{l} \text{Current AS-Interface Scanner/Gateway} \\ + \text{ Max current of I/O modules} \\ \hline = \text{Total Current} \end{array}$$

#### Example:

1	AS-Interface scanner	VBM-MLX/CPLX	100 mA
10	Flat 4 input modules	VBA-4E-G2-ZA	240 mA
10	Flat 4 output modules	VAA-4A-G12-EA2	40 mA

$$\begin{array}{r} 100 \text{ mA} \\ + 10 (240 \text{ mA}) \\ + 10 (40 \text{ mA}) \\ \hline = 2.9 \text{ A} \end{array}$$

With a total of 2.9 A, a number of power supplies or power conditioners can be used:

VAN-115/230AC-K27	4 A
VAN-115/230AC-K16	8 A
VAN-G4-PE-4A	4 A
VAN-KE2-2PE	2 x 4 A


The calculations are very conservative because not all of the modules will be used to the maximum current consumption listed. See the AS-Interface power supply calculator and network checking utility on our website for a more accurate calculation. The software is called "AS-Interface Power Calculator."

With AS-Interface, one single cable transmits both power and data. Pepperl+Fuchs' power supplies contain internal data decoupling coils so that the capacitive filtering of the supply does not interfere with the data stream. One of the strongest features of AS-Interface is its level of noise immunity without a shielded cable. The communication signal is symmetrically transmitted on AS-Interface (+) and AS-Interface (-) so that noise transmitted and radiated that affects (+) and (-) will be filtered out.


### Network Length and Repeaters

AS-Interface segments can have a cumulative cable length of 100 meters (328 feet). If larger networks are needed, the use of a repeater allows extension by another 100 meters. Because repeaters isolate the connected network segments, an additional AS-Interface power supply must be located in each additional 100-meter segment. I/O modules can be placed anywhere within the segments. Repeaters occupy no AS-Interface address (they are passive on the AS-Interface network).


**NOTE:** Regardless of cable length and number of repeaters, a maximum of 62 I/O modules can be placed on one AS-Interface network.



300 m network with three segments and two repeaters



800 m network in a star topology; eight segments



500 m network with gateway/scanner in the middle; five segments

## AS-Interface Power Supplies

- LED power/overload indicators
- Automatic overload recovery
- Narrow 49 mm housing
- NEC Class 2 power supply
- Ground fault detection



### AS-Interface Power Supply Overview

Pepperl+Fuchs' power supplies have power factor correction and high-efficiency ratings. The wide input voltage range allows the power supplies to be used in Europe, the United States, and all over the world. All are overload protected and require no external fusing for proper operation. Fault recovery is automatic when the short circuit is removed. All AS-Interface power supplies have an inductive output. When used in non-AS-Interface applications, connect a 470  $\mu$ F capacitor between the AS-Interface + and AS-Interface – terminals.

The K19, a narrow power supply, fits in almost any application. At 2.8 A, it will supply almost any application with enough current. It is an NEC Class 2-rated power supply. These supplies are often used when devices connected to them require a Class 2 power source. This supply should be used whenever open wiring must have a maximum of 100 VA of power.

The 4 A power supply, VAN-115/230AC-K27, includes ground-fault protection. If the AS-Interface wires ever touch ground, the noise immunity will be severely reduced, but the network can still run. The error will be displayed on the power supply and a normally closed relay will open up, signaling the fault.








The VAN-115/230AC-K16 power supply can provide the highest-rated current possible to the AS-Interface network: 8A. And it has a low-profile housing.

**See pages 59-60 for standard AS-Interface power supply wiring and dimensions.**






## Specifications


TYPE	8 A	4 A	2.8 A
MODEL NUMBER(S)	VAN-115/230AC-K16	VAN-115/230AC-K27	VAN-115/230AC-K19
OUTPUT SUPPLY			
CURRENT NOMINAL	8 A	4 A	2.8 A
CURRENT LIMIT	> 8.4 A	> 4.2 A	> 3.2 A
VOLTAGE	30.55 VDC ± 3% fixed		
SHORT CIRCUIT/ OVERLOAD PROTECTED	Yes		
INPUT SUPPLY			
RATED OPERATING CUR- RENT @ 115 VAC	6 A	2.2 A	2 A
FREQUENCY	47-63 Hz, DC also possible		
OPERATING VOLTAGE	85-132 VAC, 184-264 VAC, 230-375 VDC		
EFFICIENCY	92% (230 VAC, 8 A)	90% (230 VAC, 4 A)	90.5% (230 VAC, 2.8 A)
POWER FACTOR CORRECTION	Yes		
INPUT VOLTAGE SELECTION	115/230 AC selector switch		
FUSE INTERNAL	T8A / 250 V	T3A / 250 V	T2.5 / 250 V
POWER SUPPLY OVERLOAD RESET	No (push button)	Automatic	
GROUND FAULT DETECTION	No	Yes	No
PROTECTION (IEC)	IP20		
TEMPERATURE WORKING	+14 °F to +158 °F (-10 °C to +70 °C)		
RANGE STORAGE	-13 °F to +185 °F (-25 °C to +85 °C)		
HOUSING MATERIAL	Steel, aluminum		
WEIGHT	890 g (31 oz)	650 g (23 oz)	500 g (18 oz)
APPROVALS	  		   NEC Class 2 supply
MOUNTING	DIN rail (Allow 25 mm top/bottom clearance and 15 mm side clearance)		
AS-INTERFACE CONNECTION	 Nonremovable terminals		

## Wiring Diagrams


VAN-115/230AC-K16



VAN-115/230AC-K27




VAN-115/230AC-K19




## Dimensions (mm)


VAN-115/230AC-K19



VAN-115/230AC-K27



VAN-115/230AC-K16



See pages 211-226 for complete AS-Interface accessory listing.

## Power Conditioners

- Output current up to 4 A per segment
- DC input voltage
- Diagnostic LED indication
- Protection degree IP20 or IP67



Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories

### DC Input Overview

The AS-Interface power supply unit VAN-24DC-K28 can supply 31.5 V at 4 A to a fully loaded AS-Interface system. The input voltage from 18-32 VDC is stepped up to power AS-Interface. This model is perfect for mobile equipment or other applications where no AC power is present.

The VAN-G4-PE-4A is a power conditioner for either flat or round cable. Often, multiple power extenders are used with a single 30 VDC power supply. Also available is an enclosure mount power extender, VAN-KE2-2PE, for two AS-Interface segments. This is often used on a dual network gateway or before and after a repeater.

Because any 30 VDC supply can be used with the power conditioner, it is possible to use redundant power supplies. Often, redundant power supplies are required for process applications. The power conditioner, however, can never be redundant. A maximum of one power conditioner can be used in each AS-Interface segment.

Since power conditioners are field-mountable IP67 devices, it is now possible to feed an AS-Interface segment from a standard 30 VDC power supply located in an enclosure far away from the AS-Interface network without taking up segment length. The length of cable that feeds the power conditioner does not count towards the 100 m AS-Interface segment limit.


Regardless of the cable length and the use of repeaters, a maximum of 62 modules per gateway can be placed on an AS-Interface network.

Power conditioner input voltage requirements depend on network length. The following typical limits should be observed:

INPUT VOLTAGE	MAXIMUM POSSIBLE CABLE LENGTH
≈ 30 V	100 m AS-Interface cable
≈ 28 V	80 m AS-Interface cable

See pages 62-63 for DC input power supply wiring and dimensions.

### 30 V Standard or Redundant Power Supplies



Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com




## Specifications

TYPE	4 A Power Supply	4 A Power Conditioner	Dual 4 A Power Conditioner
MODEL NUMBER(S)	VAN-24DC-K28	VAN-G4-PE-4A	VAN-KE2-2PE
<b>OUTPUT SUPPLY</b>			
CURRENT NOMINAL	4 A*	4 A	4 A x 2 networks
CURRENT LIMIT	> 4.4 A	≈ 6 A	≈ 6 A x 2 networks
VOLTAGE	30.55 VDC ± 3 % fixed	Input supply -0.05 V	
SHORT CIRCUIT/ OVERLOAD PROTECTED	Yes	—	—
<b>INPUT SUPPLY</b>			
RATED OPERATING CURRENT	5.6 A @ 24 VDC	4 A @ 30 VDC	8 A @ 30 VDC
FREQUENCY	—	—	—
OPERATING VOLTAGE	24 V	30 VDC	
VOLTAGE RANGE	18-32 VDC	—	—
EFFICIENCY	90.5 % (24 VDC/4 A)	99.83 % (30 VDC/4 A)	
POWER SUPPLY OVERLOAD RESET	Automatic	—	—
GROUND FAULT DETECTION	—	No	—
PROTECTION (IEC)	IP20	IP67	IP20
TEMPERATURE WORKING RANGE	-13 °F to +158 °F (-25 °C to +70 °C)	+32 °F to +158 °F (0 °C to +70 °C)	+32 °F to +131 °F (0 °C to +55 °C)
STORAGE RANGE	-40 °F to +185 °F (-40 °C to +85 °C)	-13 °F to +185 °F (-25 °C to +85 °C)	-13 °F to +185 °F (-25 °C to +85 °C)
HOUSING MATERIAL	Steel, aluminum	PA6-GF30	PA 66-FR
WEIGHT	500 g (18 oz)	120 g (6 oz)	120 g (6 oz)
APPROVALS			
MOUNTING	DIN rail	DIN rail, mounting holes	DIN rail
AS-INTERFACE CONNECTION	Terminals	Flat or round cable	Removable terminals


\*Greater than 60 °C the power supply is derated to 3 A max output current.

## Wiring Diagrams




## Dimensions (mm)


**VAN-24DC-K28**



**VAN-G4-PE-4A**



**VAN-KE2-2PE**



## Accessories


**U-G1PP**

Round cable base with external power terminals



**U-G1FF**

Flat cable mounting base for black and yellow cables



**PG11-1/2NPT**

PG11 male to 1/2" NPT female conduit adapter



See pages 211-226 for complete AS-Interface accessory listing.





## Repeaters

- Lengthens line by 100 m (max 2 repeaters in series)
- Galvanic isolation
- IP67 or IP20 housings
- No address required


### Repeaters Overview

AS-Interface cable length can be increased an additional 100 meters with the use of a repeater. Since repeaters isolate the connected network segments, an AS-Interface power supply must be located in both segments. A maximum of two repeaters can be used back to back in a single cable run resulting in an overall length of 300 meters. As long as a signal traveling from the scanner/gateway to a module does not cross more than two repeaters, longer networks can be built. A linear network of 500 m is easily possible by placing the scanner/gateway in the middle section. When using repeaters, I/O modules can be placed in any cable segment. Regardless of the cable length and number of repeaters, a maximum of 62 modules per gateway can be placed on an AS-Interface network.

The enclosure mount repeater VAR-KE3-TERM, only 22.5 mm in width, takes up little space in the control cabinet. The new KE3 Series modules feature color-coded terminals to help simplify the installation. This method of mounting permits easy removal during initial operation or servicing.

The VAR-KE3-TERM also includes a termination switch. Once enabled, this termination can extend the first segment to 200 m. In this case, the incoming segment is 200 m long and the outgoing segment is 100 m, for a total length of 300 m. If termination is used, the power supply must be located as far from the termination as possible at the other end of the network.

**See pages 65-66 for repeater wiring and dimensions.**






## Specifications

TYPE	Advanced Repeaters	
MODEL NUMBER(S)	VAR-KE3-TERM	VAR-G4F
BASE	–	Flat cable base included, U-G1PP base optional
MAX SEGMENT LENGTH (1/2)	100 m (200 m with activated termination)/100 m	100 m/100 m
OPERATING CURRENT		
NETWORK 1	60 mA	
NETWORK 2	60 mA	
DELAY TIME	9 µs	
TERMINATION SWITCH	Yes	No
PROTECTION (IEC)	IP20	IP67
TEMPERATURE WORKING RANGE	+32 °F to +131 °F (0 °C to +55 °C)	+14 °F to +131 °F (-10 °C to +55 °C)
STORAGE	-13 °F to +167 °F (-25 °C to +75 °C)	-13 °F to +167 °F (-25 °C to +75 °C)
HOUSING MATERIAL	PA66-FR	PA6-GF
WEIGHT	120 g (6 oz)	
APPROVALS		
MOUNTING	DIN rail	DIN rail, mounting holes
AS-INTERFACE CONNECTION	Removable terminals	Flat yellow or round cable

## Wiring Diagrams

### TERMINALS

VAR-KE3-TERM



### LED Indicators

**PWRx:** Green: Power on  
Off: No power


**FAULT:** Off: No errors  
Red: Communication errors

**TERM:** On: Termination connected  
Off: No termination

**26V:** On: Voltage above 26 V  
Off: Voltage below 26 V

**18.5V:** On: Voltage above 18.5 V  
Off: Voltage below 18.5 V

VAR-G4F




### LED Indicators

**PWRx:** Green: Power on  
Off: No power


**FLT:** Off: No errors  
Red: Communication errors

## Dimensions (mm)

VAR-KE3-TERM



VAR-G4F



## Accessories

**U-G1PP**

Round cable base with  
external power terminals

**PG11-1/2NPT**

PG11 male to 1/2" NPT female  
conduit adapter



See pages 211-226 for complete AS-Interface accessory listing.

## Standard 24-30 VDC Power Supplies

- Slim 70 mm housing
- Cover to protect AC terminals
- Voltage adjustment potentiometer



### Standard 24-30 VDC Power Supply Overview

These power supplies are designed to be used with the AS-Interface black cable or with the power conditioner only. They can never be used on the AS-Interface yellow cable or with an AS-Interface gateway without a built-in conditioner. These power supplies do not have the required decoupling coils in them to allow error-free AS-Interface communication.

Three versions are available with 5 A or 10 A capacities. Plastic covers protect the power supplies against accidental shorting of AC input lines as well as the voltage adjustment terminals. The voltage adjustment screw is often used to bump the power supply up to the 30 V required by AS-Interface if you are using the power conditioner. If the voltage is increased, then the total current output will be reduced to a maximum of 4 A and 8 A, respectively.

**See pages 68-69 for standard 24-30 VDC power supply wiring and dimensions.**

Gateways and Scanners

Power Supplies and  
Repeaters

I/O Modules

Safety at Work




Sensors

Cordsets

Accessories




## Specifications

TYPE	5 A	10 A	10 A (3-phase)
MODEL NUMBER(S)	K17-STR-24..30VDC-5A	K24-STR-24..30VDC-10A	K34-STR-24..30V-3X500VAC-10A
OUTPUT SUPPLY			
CURRENT NOMINAL	5 A @ 24 VDC	10 A @ 24 VDC	
CURRENT LIMIT	≈ 6 A	≈ 12 A	≈ 12.5 A
VOLTAGE	24 V ± 1 %		24 V ± 1 %
ADJUSTMENT RANGE	22 - 30 VDC, default 30 VDC		23 - 30 VDC, default 30 VDC
SHORT CIRCUIT/ OVERLOAD PROTECTED	Yes		Yes
MAX OUTPUT POWER	220 W, 30 V @ 4 A	240 W, 30 V @ 8 A	
PARALLEL/REDUNDANT WIRING POSSIBLE	Yes		
INPUT SUPPLY			
RATED OPERATING CURRENT	2.2 A @ 115 VAC	4.2 A @ 115 VAC	3 x 0.7 A @ 400 VAC
FREQUENCY	47-63 Hz		
OPERATING VOLTAGE	93-132 VAC, 187-265 VAC		3 x 380-500 VAC, 3-phase
EFFICIENCY	≈ 89%		
POWER FACTOR CORRECTION	Yes		
INPUT VOLTAGE SELECTION	115/230 VAC, selectable using jumper		–
FUSE INTERNAL	T3.15 / 250 V	T6.3 / 250 V	None (protect with 690 V 1A fuse on each line)
POWER SUPPLY OVERLOAD RESET	Automatic		
PROTECTION (IEC)	IP20		
TEMPERATURE WORKING	+14 °F to +140 °F (-10 °C to +60 °C)		
RANGE STORAGE	-13 °F to +185 °F (-25 °C to +85 °C)		
HOUSING MATERIAL	Steel, aluminum		
WEIGHT	890 g (31 oz)		1400 g (49 oz)
APPROVALS	 		
MOUNTING*	DIN rail		
AS-INTERFACE CONNECTION	 Spring terminals		


\* Important: Power supplies must be mounted with ventilation holes located at top.  
Allow 100 mm top/bottom clearance and 30 mm side clearance.

## Wiring Diagrams


K17-STR-24..30VDC-5A



K24-STR-24..30VDC-10A



K34-STR-24..30V-3X500VAC-10A









### Dimensions (mm)


**K17-STR-24..30VDC-5A**



**K24-STR-24..30VDC-10A**



**K34-STR-24..30V-3X500VAC-10A**





Notes

Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories

# I/O Modules

<b>Low-Profile Flat .....</b>	<b>73</b>
<b>Low-Profile Flat with SPEEDCON.....</b>	<b>78</b>
<b>Round with High IP Rating.....</b>	<b>82</b>
<b>Ultracompact .....</b>	<b>87</b>
<b>Field Mountable .....</b>	<b>91</b>
<b>Compact .....</b>	<b>95</b>
<b>Enclosure.....</b>	<b>98</b>
<b>Junction Box .....</b>	<b>102</b>
<b>Analog.....</b>	<b>106</b>
<b>Pushbuttons and Stack Lights .....</b>	<b>113</b>
<b>Pneumatic .....</b>	<b>119</b>
<b>Drive Control.....</b>	<b>123</b>

## I/O modules

I/O modules are the essence of the AS-Interface system. All inputs and outputs communicate with the scanner/gateway through the modules. They drive the solenoids and relays, initiate the valves, and enable the pushbuttons. For enclosures and junction boxes, Pepperl+Fuchs offers a broad selection of modules to connect AS-Interface to DIN rail, as well as junction box modules sure to meet the specific needs of each application. Pepperl+Fuchs offers a wide variety of rugged and robust field-mountable modules for any application, including flat modules for limited space applications, compact modules with a variety of mounting options, field modules that use cord grips instead of quick disconnects, and modules that use both the AS-Interface flat cable or standard 16 AWG round cable.

Our top-of-the-line family of field-mounted modules, the G12 Series, reduces installation time and enhances diagnostics even further. It is now possible to install AS-Interface I/O modules without any tools! The G12 line is an important addition to our products and is Pepperl+Fuchs' long-term answer to our customers demands concerning high-end, feature-rich products. It is yet another reason why Pepperl+Fuchs' AS-Interface system stands out from the competition.

## Within an Enclosure

Enclosure modules feature a narrow profile that uses a minimal amount of space. All enclosure modules have diagnostic LEDs, feature removable terminals that support wire sizes up to 14 AWG for connection of the I/O, and have a protection rating of IP20.

**KE Series Modules** feature color-coded terminals to help simplify installation. Both standard and extended addressing versions are available.



**KE1 Series Modules** are especially designed to be installed in junction boxes. The height of the KE1 is only 50 mm. These modules are available with 4 inputs, 4 inputs and 2 outputs, or 4 inputs and 4 outputs. The addressing can be accomplished via an addressing jack.

## In the Field

Pepperl+Fuchs offers modules with rugged housings and high IP ratings for various types of field applications where cost savings, installation time, and module size are crucial.


**G4 Modules** are designed for quick installation. Sensors and actuators are connected to the G4 module via cable glands and cage tension spring terminals, making it ideal for applications where heavy vibrations may be encountered. These connections also enable the use of standard cabled sensors and eliminate the need for coiled up, molded cables. Additionally, G4 modules can be used with flat or round AS-Interface cable.



**G2 Flat Modules** have a classic design consisting of two parts, a top piece that has M12 quick disconnects and a bottom mounting base that connects to the machine and receives flat cable. This low-profile housing sits only 30 mm high and offers a short 4 I/O and a long 8 I/O version to fit most applications.



**G12 Series Modules** incorporate what we have learned over the last 15 years and offer an AS-Interface solution that reduces installation time to an absolute minimum. No tools are required; no screws need to be turned. Additionally, we added diagnostic features like true output overload/short-circuit indication on a per-output basis. With clear, uncomplicated fault indication, maintenance personnel can act faster, getting lines up and running again in the shortest time imaginable. The universal SPEEDCON M12 makes sensor connections faster than ever before; a 1/2 turn on the connector is all it takes to install the modules. Naturally, these top-of-the-line modules satisfy IP67, making them applicable for most field-mounted applications.




**G11 Field Modules** offer an innovative sealing concept in a robust, compact design and are particularly suitable for material handling and washdown applications. Cleaning processes involving steam cleaners and high mechanical stresses do not affect the performance of G11 modules. You can connect sensors and actuators to AS-Interface quickly and easily, even under these harsh ambient conditions.



**G10 Ultracompact Modules** are the smallest, full-featured AS-Interface modules on the market. Developed for low-density I/O requirements, they are smaller than a matchbook, less than one inch thick, and fit into the smallest spaces, including cable trays. The AS-Interface cable simply clips to the module and the housing is securely closed with just a single screw. It has a superior IP rating and comes with one-meter-long pigtails so that additional cordsets are eliminated.



**G16 Compact Modules** are ideal for limited space applications. G16 modules are commonly used for material handling equipment and robotics. The AS-Interface and external power connections are made using a single M12x1 quick disconnect. The sensors/actuators are attached via nano (M8x1) quick disconnects. The IP69K-rated compact module is simple to mount.



**Analog Modules** use standard AS-Interface analog profiles, which put these modules into operation in the same way as digital modules and starts the data exchange automatically.




**Illuminated Pushbutton Modules** are offered in two styles and attach to the network to provide a link between maintenance personnel and AS-Interface.



**AS-Interface Stack Lights** are flexible devices that allow multiple configurations by simply combining individual light and audible alarm modules. The 4-output base can power up to four modules in any combination.



Additionally, Pepperl+Fuchs offers **pneumatic modules**.




8-port Module

4-port Module

## Flat Module Overview

With the G2 line of AS-Interface, Pepperl+Fuchs offers a wide variety of I/O modules suitable when the advanced features offered by the high-end G12 line are not desired. With a height of only 30 mm, the G2 line is ideal for limited space applications. This IP67 housing can be mounted directly in the field and accepts sourcing I/O from a variety of different devices. The following diagrams show some of the features of this product:



The flat module mounting bases (U-G2FF and U-G3FF) are mechanically coded for reverse polarity protection. To prevent the possibility of connection errors, each AS-Interface module has I/O and ID codes that allow

## Low-Profile Flat I/O Modules

- Low-profile flat housing—30 mm high
- Built-in addressing jack
- M12 quick disconnect for all I/O
- Flat cable AS-Interface connections

the scanner/gateway to electronically identify the I/O configuration and version of the device.

To simplify addressing of the flat modules, an addressing jack is integrated into the housing for easy connection of a handheld addressing device (e.g., VBP-HH1-...). The addressing jack enables the user to address the module before or after connection to AS-Interface.

**See pages 75-76 for Flat Module wiring and dimensions.**

## Common Specifications

OPERATING VOLTAGE AS-i		26.5-31.6 V
OPERATING VOLTAGE, V <sub>AUX</sub>		20-30 VDC
INPUT SWITCHING FREQUENCY		≤ 250 Hz
INPUT DELAY		≤ 2 ms from input to AS-i
PROTECTION		IP67
HOUSING MATERIAL		PBT-FR
TEMPERATURE RANGE	Working	-13 °F to +140 °F (-25 °C to +60 °C)
	Storage	-13 °F to +185 °F (-25 °C to +85 °C)
APPROVALS		



Specifications		4-in	8-in	2-in/2-out	4-in/4-out
INPUTS/OUTPUTS		4-in	8-in	2-in/2-out	4-in/4-out
MODEL NUMBER(S)*		VBA-4E-G2-ZA	VBA-8E-G2-ZA	VBA-2E2A-G2-ZA/EA2	VBA-4E4A-G2-ZA/EA2
BASE		U-G3FF	U-G2FF	U-G3FF	U-G2FF
EXTENDED ADDRESSING (62 NODES)		Yes	Yes (2 addresses)	Yes	Yes
REQUIRED MASTER SPEC.		–	–	M3, M4	M4
AS-i OPERATING CURRENT		40-240 mA	80-280 mA	40-140 mA	40-220 mA
AUXILIARY CURRENT LIMIT		–	–	2 A	2 A
INPUTS		PNP, AS-i powered	PNP, AS-i powered	PNP, AS-i powered	PNP, AS-i powered
TYPE		2-, 3-, or 4-wire	2-, 3-, or 4-wire	2-, 3-, or 4-wire	2-, 3-, or 4-wire
SUPPLY VOLTAGE		21-31 V from AS-Interface	21-31 V from AS-Interface	21-31 V from AS-Interface	21-31 V from AS-Interface
MAXIMUM CURRENT		150 mA, 200 mA (T ≤ 104 °F)	200 mA	75 mA, 100 mA (T ≤ 104 °F)	140 mA, 180 mA (T ≤ 104 °F)
SWITCH POINT		OFF ≤ 2 mA, ON ≥ 4 mA	OFF ≤ 2 mA, ON ≥ 4 mA	OFF ≤ 2 mA, ON ≥ 4 mA	OFF ≤ 3 mA, ON ≥ 5 mA
LOAD CURRENT		≤ 8 mA	≤ 8 mA	≤ 8 mA	≤ 9 mA
OUTPUTS		–	–	PNP, auxiliary powered	PNP, auxiliary powered
SUPPLY VOLTAGE		–	–	≥ (V <sub>AUX</sub> -0.5 V)	≥ (V <sub>AUX</sub> -0.5 V)
CURRENT PER OUTPUT		–	–	≤ 1 A	≤ 0.5 A
DATA BITS	D0	IN1	IN1.1, IN2.1	OUT1	IN1/OUT1
	D1	IN2	IN1.2, IN2.2	OUT2	IN2/OUT2
	D2	IN3	IN1.3, IN2.3	IN3	IN3/OUT3
	D3	IN4	IN1.4, IN2.4	IN4	IN4/OUT4
PARAMETER BITS	P0	–	–	–	Watchdog on†/off
	P1	–	–	–	–
	P2	–	–	–	–
PERIPHERAL FAULT BIT		Input overload	Input overload	Input/output overload	Input/output overload
PROFILE		S-0.A.7.2	S-0.A.7.2, S-0.A.7.2	S-B.A.7.2	S-7.A.7.7
WEIGHT		100 g (3.5 oz)	150 g (5.3 oz)	100 g (3.5 oz)	150 g (5.3 oz)
AS-INTERFACE CONNECTION		Flat yellow cable	Flat yellow cable	Flat yellow cable	Flat yellow cable
AUXILIARY POWER CONNECTION		–	–	Flat black cable	Flat black cable
I/O CONNECTION		M12 quick disconnect	M12 quick disconnect	M12 quick disconnect	M12 quick disconnect

† Default setting

## \*Also Available

INPUTS/OUTPUTS	Model Number	Base	Required Master Spec.	Profile S-IO.ID1.ID2	Extended Addressing	Special Features
2-in/2-out	VBA-2E2A-G2-ZEJ/XE2J	U-G3FF	M3, M4	S-B.A.7.E	Yes	AS-i powered inputs and outputs
	VAA-2EA-G2-ZA/EA2	U-G3FF	–	S-3.F.F.F	No	
4-in/2-out	VBA-4E2A-G2-XE/E2	U-G3FF	M3, M4	S-7.A.7.E	Yes	Auxiliary powered inputs and outputs
4-in/3-out	VBA-4E3A-G2-ZA/EA2	U-G2FF	M3, M4	S-7.A.7.2	Yes	
4-in/4-out	VAA-4E4A-G2-ZA/EA2	U-G2FF	–	S-7.F.F.E	No	

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.comUSA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.comGermany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.comCopyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com


**PEPPERL+FUCHS**  
 SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com



## Wiring Diagrams

**Note:** Wiring Diagrams show quick disconnect pin numbers.




### LED Indicators

**IN:** Yellow: Input on


**PWR:** Green: AS-Interface powered

**FAULT:** Red (solid): Address 0 or no communication  
Red (flashing): Overload of input power

VBA-4E-G2-ZA




VBA-8E-G2-ZA




### LED Indicators

**IN:** Yellow: Input on

**PWR/FAULT:** Green: Powered  
Red (solid): Address 0 or no communication  
Green/Red (flashing): Overload of input power



VBA-2E2A-G2-ZA/EA2



### LED Indicators


**IN:** Yellow: Input on

**OUT:** Yellow: Output on

**PWR:** Green: AS-Interface powered


**FAULT:** Red (solid): Address 0 or no communication  
Red (flashing): Overload of input power or outputs

**AUX:** Green: Auxiliary powered



## Wiring Diagrams

**Note:** Wiring Diagrams show quick disconnect pin numbers.



## LED Indicators


**IN:** Yellow: Input on

**OUT:** Yellow: Output on

**PWR:** Green: AS-Interface powered


**FAULT:** Red (solid): Address 0 or no communication  
Red (flashing): Overload of input power or outputs

## VBA-4E4A-G2-ZA/EA2




## Dimensions (mm)

VBA-4E-G2-ZA  
VBA-2E2A-G2-ZA/EA2



VBA-8E-G2-ZA  
VBA-4E4A-G2-ZA/EA2



Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs

Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

## Accessories

**U-G3FF**

Mounting base for 4-port flat modules

**U-G2FF**

Mounting base for 8-port flat modules

**VAZ-V1-B3**

M12x1 protective cap



See pages 211-226 for complete AS-Interface accessory listing.

Gateways and Scanners

Power Supplies and  
Repeaters

I/O Modules

Safety at Work


Sensors

Cordsets

Accessories

## Low-Profile Flat with SPEEDCON I/O Modules

- Low-profile flat housing—30 mm high
- Standard and DIN rail mount integrated in base
- Built-in addressing jack
- SPEEDCON M12 quick disconnect for all I/O
- Flat cable AS-Interface connections




### Flat Module with SPEEDCON Overview

High-end G12 modules are ideal for applications requiring fast and flexible installation, easy access to diagnostic feedback, and long service lives. The G12 features a stainless steel installation bar that pulls the module safely onto the stainless steel base. Once the installation bar has been closed, a “click” tells the user that the module has been installed properly and securely. I/O connections are achieved with a single ½ turn using our SPEEDCON M12 solution. These M12 I/O connectors can be used with both standard cables as well as SPEEDCON versions.

G12 comes in a number of I/O mixes and two distinct housing sizes. Both housing sizes use the same rugged stainless steel mounting base. With the stainless steel mounting base, changing the I/O count is as simple as replacing one module top with another, without having to remount the base and AS-Interface cable.

Diagnostic feedback is provided with an output-specific overload indication right on the module. Under normal operating conditions, the multicolor LEDs display the state of the output. Short-circuited and overloaded outputs are provided at the PLC via the peripheral fault bit. This allows maintenance personnel to quickly determine which module has a problem. The overloaded output is directly indicated via a red LED. Faster problem resolution results in higher machine uptime.

Gold-plated piercing contacts ensure long-term AS-Interface performance. Our machined, gold-plated contacts offer corrosion resistance that is superior to stamped (flat) contacts plated with nonprecious metals.




The G12 also features an integrated DIN clip for DIN rail mounting. With the integrated DIN clip, stainless steel mounting base customers do not have to choose ahead of time how G12 is mounted. Less to consider means faster planning, ordering, and installation.

**See pages 80-81 for Flat Module with SPEEDCON wiring and dimensions.**

### Common Specifications

OPERATING VOLTAGE AS-i	26.5-31.6 V
OPERATING VOLTAGE, V <sub>AUX</sub>	20.4-27.6 VDC
INPUT SWITCHING FREQUENCY	≤ 1 kHz
INPUT DELAY	≤ 1 ms from input to AS-i
PROTECTION	IP67
HOUSING MATERIAL	PBT
TEMPERATURE RANGE	Working -13 °F to +158 °F (-25 °C to +70 °C) Storage -13 °F to +185 °F (-25 °C to +85 °C)
APPROVALS	CE cUL US



## Specifications

INPUTS/OUTPUTS	4-in	8-in	2-in/2-out	4-in/4-out
MODEL NUMBER(S)*	VBA-4E-G12-ZAJ	VBA-4E4E-G12-ZAJ	VBA-2E2A-G12-ZAJ/EA2L	VBA-4E4A-G12-ZAJ/EA2L
BASE	Included	Included	Included	Included
EXTENDED ADDRESSING (62 NODES)	Yes	Yes (2 addresses)	Yes	Yes
REQUIRED MASTER SPEC.	–	–	M3, M4	M4
AS-i OPERATING CURRENT	40-240 mA	80-280 mA	40-240 mA	40-240 mA
AUXILIARY CURRENT LIMIT	–	–	3 A, 4 A (T ≤ 104 °F)	4 A, 6 A (T ≤ 104 °F)
INPUTS -ZAJ	PNP, AS-i powered	PNP, AS-i powered	PNP, AS-i powered	PNP, AS-i powered
TYPE	2-, 3-, or 4-wire	2-, 3-, or 4-wire	2-, 3-, or 4-wire	2-, 3-, or 4-wire
SUPPLY VOLTAGE	21-31 V from AS-Interface	21-31 V from AS-Interface	21-31 V from AS-Interface	21-31 V from AS-Interface
MAXIMUM CURRENT	200 mA	200 mA	200 mA	200 mA
SWITCH POINT	OFF ≤ 2 mA, ON ≥ 6 mA	OFF ≤ 2 mA, ON ≥ 6 mA	OFF ≤ 2 mA, ON ≥ 6 mA	OFF ≤ 2 mA, ON ≥ 6 mA
LOAD CURRENT	≤ 8 mA	≤ 8 mA	≤ 8 mA	≤ 8 mA
OUTPUTS EA2L	–	–	PNP, auxiliary powered	PNP, auxiliary powered
SUPPLY VOLTAGE	–	–	≥ (V <sub>AUX</sub> -0.5 V)	≥ (V <sub>AUX</sub> -0.5 V)
CURRENT PER OUTPUT	–	–	≤ 2 A	≤ 2 A
DATA BITS D0	IN1	IN1.1, IN2.1	OUT1	IN1/OUT1
D1	IN2	IN1.2, IN2.2	OUT2	IN2/OUT2
D2	IN3	IN1.3, IN2.3	IN3	IN3/OUT3
D3	IN4	IN1.4, IN2.4	IN4	IN4/OUT4
PARAMETER BITS P0	–	–	Watchdog on <sup>†</sup> /off	Watchdog on <sup>†</sup> /off
P1	2 ms input filtering on/off <sup>†</sup>	2 ms input filtering on/off <sup>†</sup>	2 ms input filtering on/off <sup>†</sup>	2 ms input filtering on/off <sup>†</sup>
P2	Synchronization on/off <sup>†</sup>	Synchronization on/off <sup>†</sup>	Synchronization on/off <sup>†</sup>	Synchronization on/off <sup>†</sup>
PERIPHERAL FAULT BIT	Input overload	Input overload	Input/output overload	Input/output overload
PROFILE S-IO.ID.ID1.ID2	S-0.A.7.2	S-0.A.1.2, S-0.A.2.2	S-B.A.7.2	S-7.A.7.7
WEIGHT	200 g (7.1 oz)	230 g (8.1 oz)	200 g (7.1 oz)	230 g (8.1 oz)
AS-INTERFACE CONNECTION	Flat yellow cable	Flat yellow cable	Flat yellow cable	Flat yellow cable
AUXILIARY POWER CONNECTION	–	–	Flat black cable	Flat black cable
I/O CONNECTION	M12 SPEEDCON	M12 SPEEDCON	M12 SPEEDCON	M12 SPEEDCON

† Default setting

## \*Also Available

INPUTS/OUTPUTS	Model Number	Base	Required Master Spec.	Profile S-IO.ID.ID1.ID2	Extended Addressing	Special Features
4-in	VBA-4E-G12-ZAL	Included	–	S-0.A.7.2	Yes	Auxiliary powered inputs
4-in/3-out	VBA-4E3A-G12-ZAJ/EA2L	Included	M3, M4	S-7.A.7.2	Yes	
4-in/4-out	VAA-4E4A-G12-ZAJ/EA2L	Included	–	S-7.F.F.E	No	
	VAA-4E4A-G12-ZAL/EA2L	Included	–	S-7.F.F.E	No	Auxiliary powered inputs and outputs
	VBA-4E4A-G12-XEL	Included	M3, M4	S-7.A.7.7	Yes	Auxiliary powered inputs and outputs, inputs/outputs on one M12 port
	VBA-4E4A-G12-ZAL/EA2L	Included	M3,M4	S-7.A.7.7	Yes	Auxiliary powered inputs and outputs
4-out	VAA-4A-G12-EA2L	Included	–	S-8.1.F.E	No	

Subject to modifications without notice


Pepperl+Fuchs Group  
www.pepperl-fuchs.comUSA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.comGermany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.comCopyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
 SENSING YOUR NEEDS


Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

## Wiring Diagrams

**Note:** Wiring Diagrams show quick disconnect pin numbers.



VBA-4E-G12-ZAJ





## LED Indicators

**I:** Yellow: Input on

**PWR:** Green (solid): AS-Interface powered  
Green (flashing): Address 0

**FAULT:** Red (solid): Address 0 or no communication  
Red (flashing): Overload of input power

VBA-4E4E-G12-ZAJ





## LED Indicators

**I:** Yellow: Input on

**PWR/FAULT:** Green (solid): AS-Interface powered  
Red (solid): No communication  
Red/Yellow (alternating): Address 0  
Red/Green (alternating): Overload of input power

VBA-2E2A-G12-ZAJ/EA2L



## LED Indicators

**I:** Yellow: Input on

**O:** Yellow: Output on  
Red: Output overload

**PWR:** Green (solid): AS-Interface powered  
Green (flashing): Address 0

**FAULT:** Red (solid): Address 0 or no communication  
Red (flashing): Overload of input power or outputs

**AUX:** Green: Auxiliary powered  
Red: Reverse polarity

See pages 211-226 for complete AS-Interface accessory listing.



## Wiring Diagrams

**Note:** Wiring Diagrams show quick disconnect pin numbers.

VBA-4E4A-G12-ZAJ/EA2L

### LED Indicators



**I:** Yellow: Input on

**O:** Yellow: Output on  
Red: Output overload

**PWR:** Green (solid): AS-Interface powered  
Green (flashing): Address 0


**FAULT:** Red (solid): Address 0 or no communication  
Red (flashing): Overload of input power or outputs

**AUX:** Green: Auxiliary powered  
Red: Reverse polarity




## Dimensions (mm)

VBA-4E-G12-ZAJ  
VBA-2E2A-G12-ZAJ/EA2L



VBA-4E4E-G12-ZAJ  
VBA-4E4A-G12-ZAJ/EA2L



## Accessories

### VAZ-CLIP-G12

Clip to keep bar down in high-vibration applications



### VAZ-V1-B3

M12x1 protective cap



Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

## Round with High IP Rating I/O Modules


- Supply of sensors for AS-Interface
- Inputs for 2-, 3-, and 4-wire sensors
- AS-Interface POWER24
- Protection degree IP68/IP69K
- Communication monitoring
- M12 or flat cable versions
- Clean design, Ecolab certified

### Round with High IP Rating Overview

The AS-Interface G11 field modules offer an innovative clean housing concept in a robust, compact, round design, and are particularly suitable for assembly machines and process automation applications.

Due to the unique O-ring seal technology, even cleaning processes involving pressure washers and mechanical stress do not affect the performance of the G11 modules. The smooth surfaces prevent dirt from accumulating. Aging and thermal loading are not a concern.

The housing is only 85 mm in diameter and can be mounted with the flat cable aligned in any direction.



The outputs offer up to 2 A per M12 port, are short-circuit protected, and indicate an overload condition directly at the relevant M12 port. As a result,



troubleshooting time at the installation location is minimized.

Four versions are available with different types of connection to the AS-Interface network, and input/output configurations.

**See pages 84-86 for Field Module wiring and dimensions.**

### Common Specifications

<b>OPERATING VOLTAGE AS-i</b>		18-31.6 V
<b>OPERATING VOLTAGE, V<sub>AUX</sub></b>		20-30 VDC
<b>INPUT SWITCHING FREQUENCY</b>		≤ 1 kHz
<b>INPUT DELAY</b>		≤ 1 ms from input to AS-i
<b>PROTECTION</b>		IP67/IP68/IP69K
<b>HOUSING MATERIAL</b>		PBT, PC
<b>TEMPERATURE RANGE</b>	Working	-13 °F to +158 °F (-25 °C to +70 °C)
	Storage	-13 °F to +185 °F (-25 °C to +85 °C)
<b>APPROVALS</b>		CE cULus



## Specifications

INPUTS/OUTPUTS		4-in	4-in	4-in/4-out	4-in/4-out
MODEL NUMBER(S)*		VBA-4E-G11-ZAJ-F	VBA-4E-G11-ZAJ-V1	VBA-4E4A-G11-ZAJ/EA2L-F	VBA-4E4A-G11-ZAJ/EA2L-V1
BASE		Included	Included	Included	Included
EXTENDED ADDRESSING (62 NODES)		Yes	Yes	Yes	Yes
REQUIRED MASTER SPEC.		–	–	M4	M4
AS-i OPERATING CURRENT		40-240 mA	40-240 mA	40-240 mA	40-240 mA
AUXILIARY CURRENT LIMIT				4 A, 6 A (T ≤ 104 °F)	4 A, 6 A (T ≤ 104 °F)
INPUTS		–ZAJ	PNP, AS-i powered	PNP, AS-i powered	PNP, AS-i powered
TYPE			2-, 3-, or 4-wire	2-, 3-, or 4-wire	2-, 3-, or 4-wire
SUPPLY VOLTAGE			12-31 V from AS-Interface	12-31 V from AS-Interface	12-31 V from AS-Interface
MAXIMUM CURRENT			200 mA	200 mA	200 mA
SWITCH POINT			OFF ≤ 3 mA, ON ≥ 5 mA	OFF ≤ 3 mA, ON ≥ 5 mA	OFF ≤ 3 mA, ON ≥ 5 mA
LOAD CURRENT			≤ 9 mA	≤ 9 mA	≤ 9 mA
OUTPUTS		EA2L	–	PNP, auxiliary powered	PNP, auxiliary powered
SUPPLY VOLTAGE			–	≥ (V <sub>AUX</sub> –0.5 V)	≥ (V <sub>AUX</sub> –0.5 V)
CURRENT PER OUTPUT			–	≤ 2 A	≤ 2 A
DATA BITS	D0	IN1	IN1	IN1/OUT1	IN1/OUT1
	D1	IN2	IN2	IN2/OUT2	IN2/OUT2
	D2	IN3	IN3	IN3/OUT3	IN3/OUT3
	D3	IN4	IN4	IN4/OUT4	IN4/OUT4
PARAMETER BITS	P0	–	–	Watchdog on <sup>†</sup> /off	Watchdog on <sup>†</sup> /off
	P1	2 ms input filtering on/off <sup>†</sup>	2 ms input filtering on/off <sup>†</sup>	2 ms input filtering on/off <sup>†</sup>	2 ms input filtering on/off <sup>†</sup>
	P2	–	–	Lead breakage detection on/off <sup>†</sup>	–
	P3	–	–	–	–
PERIPHERAL FAULT BIT		Input overload	Input overload	Input/output overload	Input/output overload
PROFILE		S-IO.ID1.ID2	S-0.A.7.2	S-7.A.7.7	S-7.A.7.7
WEIGHT		200 g (7.1 oz)	200 g (7.1 oz)	200 g (7.1 oz)	200 g (7.1 oz)
AS-INTERFACE CONNECTION		Flat yellow cable	M12 quick disconnect	Flat yellow cable	M12 quick disconnect
AUXILIARY POWER CONNECTION		–	–	Flat black cable	–
I/O CONNECTION		M12 quick disconnect	M12 quick disconnect	M12 quick disconnect	M12 quick disconnect

<sup>†</sup> Default setting





## \*Also Available

INPUTS/OUTPUTS	Model Number	Base	Required Master Spec.	Profile S-IO.ID1.ID2	Extended Addressing	Special Features
4-in/4-out	VAA-4E4A-G11-ZAJ/EA2L-F	Included	–	S-7.F.F.E	No	–
	VAA-4E4A-G11-ZAJ/EA2L-V1	Included	–	S-7.F.F.E	No	AS-Interface M12 quick disconnect

## Wiring Diagrams

**Note:** Wiring Diagrams show quick disconnect pin numbers.

### VBA-4E-G11-ZAJ-F








#### LED Indicators

**IN:** Yellow: Input on

**AS-I/FAULT:** Green (solid): AS-Interface powered  
 Red (solid): Communication error  
 Yellow/Red (flashing): Address 0  
 Green/Red (flashing): Overload of input power

### VBA-4E4A-G11-ZAJ/EA2L-F



#### LED Indicators

**IN:** Yellow: Input on

**OUT:** Yellow: Output on, Red: Output overload or lead breakage

**AS-I/FAULT:** Green (solid): AS-Interface powered  
 Red (solid): Communication error  
 Yellow/Red (flashing): Address 0  
 Green/Red (flashing): Overload of input power or outputs, or lead breakage


**AUX:** Green: Auxiliary powered  
 Red: Reverse polarity

See pages 211-226 for complete AS-Interface accessory listing.

## Wiring Diagrams

**Note:** Wiring Diagrams show quick disconnect pin numbers.



### VBA-4E-G11-ZAJ-V1




#### LED Indicators

**IN:** Yellow: Input on

**AS-i/FAULT:** Green (solid): AS-Interface powered  
 Red (solid): Communication error  
 Yellow/Red (flashing): Address 0  
 Green/Red (flashing): Overload of input power



### VBA-4E4A-G11-ZAJ/EA2L-V1





#### LED Indicators

**IN:** Yellow: Input on

**OUT:** Yellow: Output on, Red: Output overload or lead breakage


**AS-i/FAULT:** Green (solid): AS-Interface powered  
 Red (solid): Communication error  
 Yellow/Red (flashing): Address 0  
 Green/Red (flashing): Overload of input power or outputs, or lead breakage

**AUX:** Green: Auxiliary powered  
 Red: Reverse polarity



See pages 211-226 for complete AS-Interface accessory listing.

## Dimensions (mm)



## Accessories

**VAZ-V1-B3**  
M12x1 protective cap




See pages 211-226 for complete  
AS-Interface accessory listing.



## Ultracompact I/O Modules

- Small footprint
- Cable piercing method with gold-plated contact pins
- Suited for decentralized installation
- Protection degree IP68/IP69K
- Connect & Done technology
- Available with one or two cables




### Ultracompact Overview

The AS-Interface G10 field module was developed for low-density I/O requirements. Less than one inch thick, it is the smallest, full-featured AS-Interface module on the market.

The one-piece housing mounts in seconds and is made from PBT to provide a long service life. The AS-Interface cable clips to the module and the housing is securely closed with just a single screw.

The unique seal contours around the gold-plated contact pins help to ensure IP68/69K protection. The center screw tightly seals the housing shut, guaranteeing high and uniform contact pressure against the flat cable.




With decentralized installation, the modules can be placed exactly where you need them, anywhere along the cable tray. The integrated pigtails eliminate the need for additional cordsets and reduce the number of M12 connections.

**See pages 88-90 for Field Module wiring and dimensions.**

### Common Specifications

OPERATING VOLTAGE AS-i		18.5-31.6 V
OPERATING VOLTAGE, $V_{AUX}$		20-30 VDC
INPUT SWITCHING FREQUENCY		≤ 1 kHz
INPUT DELAY		≤ 1 ms from input to AS-i
PROTECTION		IP67, IP68/IP69K when using VAZ-FK-S...flat cable
HOUSING MATERIAL		PBT, PC
TEMPERATURE RANGE	Working	-13 °F to +158 °F (-25 °C to +70 °C)
	Storage	-13 °F to +185 °F (-25 °C to +85 °C)
APPROVALS		CE




## Specifications

INPUTS/OUTPUTS		2-in	2-in	2-in/1-out
MODEL NUMBER(S)		VBA-2E-G10-ZAJ-1M-V1-W	VBA-2E-G10-ZEJ-1M-2V1-W	VBA-2E1A-G10-ZAL/E2L-1M-2V1-W
BASE		Included	Included	Included
EXTENDED ADDRESSING (62 NODES)		Yes	Yes	Yes
REQUIRED MASTER SPEC.		–	–	M3, M4
AS-i OPERATING CURRENT		40-120 mA	40-120 mA	40-60 mA
AUXILIARY CURRENT LIMIT		–	–	1 A
INPUTS -ZAJ, -ZEJ, -ZAL		PNP, AS-i powered	PNP, AS-i powered	PNP, auxiliary powered
TYPE		2-, 3-, or 4-wire	2- or 3-wire	2-, 3-, or 4-wire
SUPPLY VOLTAGE		21-31 V from AS-Interface	21-31 V from AS-Interface	20-30 V from auxiliary
MAXIMUM CURRENT		60 mA, 75 mA (T ≤ 104 °F)	60 mA, 75 mA (T ≤ 104 °F)	(Inputs + outputs) < 1 A
SWITCH POINT		OFF ≤ 3 mA, ON ≥ 5 mA	OFF ≤ 3 mA, ON ≥ 5 mA	OFF ≤ 3 mA, ON ≥ 5 mA
LOAD CURRENT		≤ 9 mA	≤ 9 mA	≤ 9 mA
OUTPUTS E2L		–	–	PNP, auxiliary powered
SUPPLY VOLTAGE		–	–	≥ (V <sub>AUX</sub> -0.5 V)
CURRENT PER OUTPUT		–	–	(Inputs + outputs) < 1 A
DATA BITS	D0	IN1	IN1	IN1, OUT1
	D1	IN2	IN2	IN2
	D2	–	–	–
	D3	–	–	–
PARAMETER BITS	P0	–	–	Watchdog on/off
	P1	2 ms input filtering on/off†	2 ms input filtering on/off†	2 ms input filtering on/off†
	P2	Synchronization on/off†	Synchronization on/off†	Synchronization on/off†
PERIPHERAL FAULT BIT		Input overload	Input overload	Aux. overload or no aux. power
PROFILE S-IO.ID1.ID2		S-0.A.7.2	S-0.A.7.2	S-7.A.7.E
WEIGHT		100 g (3.5 oz)	100 g (3.5 oz)	100 g (3.5 oz)
AS-INTERFACE CONNECTION		Flat yellow cable	Flat yellow cable	Flat yellow cable
AUXILIARY POWER CONNECTION		–	–	Flat black cable
I/O CONNECTION		1 m right-angle pigtail, M12 quick disconnect	1 m right-angle pigtail x 2, M12 quick disconnect	1 m right-angle pigtail x 2, M12 quick disconnect


† Default setting

## Wiring Diagrams

VBA-2E-G10-ZAJ-1M-V1-W




Input



### LED Indicators




I: Yellow: Input on

AS-i: Green (solid): AS-Interface powered  
Green (flashing): Address 0FLT: Red (solid): Address 0 or no communication  
Red (flashing): Overload of inputs

## Wiring Diagrams

**Note:** Wiring Diagrams show quick disconnect pin numbers.

### VBA-2E-G10-ZEJ-1M-2V1-W






#### LED Indicators

**I:** Yellow: Input on

**AS-I:** Green (solid): AS-Interface powered  
Green (flashing): Address 0

**FLT:** Red (solid): Address 0 or no communication  
Red (flashing): Overload of inputs

### VBA-2E1A-G10-ZAL/E2L-1M-2V1-W



#### LED Indicators

**I:** Yellow: Input on

**O:** Yellow: Output on


**AS-I:** Green (solid): AS-Interface powered  
Green (flashing): Address 0

**FLT:** Red (solid): Address 0 or no communication  
Red (flashing): No auxiliary power or overload of inputs or outputs



See pages 211-226 for complete AS-Interface accessory listing.

## Dimensions (mm)

VBA-2E-G10-ZAJ-1M-V1-W



Mounting Configuration

VBA-2E-G10-ZEJ-1M-2V1-W  
VBA-2E1A-G10-ZAL/E2L-1M-2V1-W

## Accessories

VAZ-PK-FK-0,2M-V1-W

Addressing cable for all G10 style modules that attach only to the flat cable




See pages 211-226 for complete AS-Interface accessory listing.

## Field-Mountable I/O Modules



- Cord grips allow input cable to be cut to length
- Module fits directly on top of programmer without cable
- Flat or round cable AS-Interface connection through base
- Mounting through holes or DIN rail
- Field-mount housing

### Field Module Overview


These watertight modules were developed in response to customer requests for a rugged, watertight housing. They can withstand high-vibration applications such as valve positioning and actuation. The following is an overview of the G4 module key features:



Sensors and actuators are connected to the field module using the included cord grips for the cable connection and cage tension spring terminals for the electrical connection. By eliminating the quick disconnect, I/O connections are inexpensive and offer a watertight, more compact installation. Custom-molded cables of differing lengths are no longer required because these field modules accept cable that can be cut to any length, eliminating waste and coiled leads. Below are the two AS-Interface cable options.



The field modules are connected to the AS-Interface cable using standard bases. These bases allow connection of AS-Interface flat or round cable. Also, the U-G1FFA base has an integrated addressing jack that eliminates the need to unscrew the cover or use a master for addressing.



See pages 93-94 for Field Module wiring and dimensions.

### Common Specifications

OPERATING VOLTAGE AS-i		26.5-31.6 V
OPERATING VOLTAGE, $V_{AUX}$		21.4-27.6 VDC
INPUT SWITCHING FREQUENCY		≤ 250 Hz
INPUT DELAY		≤ 2 ms from input to AS-i
HOUSING MATERIAL		PA 6 GF30
TEMPERATURE RANGE	Working	-13 °F to +140 °F (-25 °C to +60 °C)
	Storage	-13 °F to +185 °F (-25 °C to +85 °C)
APPROVALS		CE cUL US AS



## Specifications

INPUTS/OUTPUTS		4-in	2-in/2-out	4-in/4-out
MODEL NUMBER(S)*		VBA-4E-G4-ZE	VBA-2E2A-G4-ZE/E2	VBA-4E4A-G4-ZE/E2
BASES		U-G1FFA, U-G1PP	U-G1FFA, U-G1PP	U-G1FFA, U-G1PP
EXTENDED ADDRESSING (62 NODES)		Yes	Yes	Yes
REQUIRED MASTER SPEC.		–	M3, M4	M4
AS-i OPERATING CURRENT		40-190 mA	30-140 mA	30-230 mA
AUXILIARY CURRENT LIMIT		–	2 A	4 A
INPUTS		PNP, AS-i powered	PNP, AS-i powered	PNP, AS-i powered
		–	–	–
TYPE		2-, 3-wire	2-, 3-wire	2-, 3-wire
SUPPLY VOLTAGE		21-31 V from AS-Interface	21-31 V from AS-Interface	21-31 V from AS-Interface
MAXIMUM CURRENT		120 mA, 150 mA (T ≤ 104 °F)	75 mA, 100 mA (T ≤ 104 °F)	160 mA, 200 mA (T ≤ 104 °F)
SWITCH POINT		OFF ≤ 2 mA, ON ≥ 4 mA	OFF ≤ 2 mA, ON ≥ 4 mA	OFF ≤ 3 mA, ON ≥ 5 mA
LOAD CURRENT		≤ 8 mA	≤ 8 mA	≤ 9 mA
OUTPUTS		–	PNP, auxiliary powered	PNP, auxiliary powered
SUPPLY VOLTAGE		–	≥ (V <sub>AUX</sub> -0.5 V)	≥ (V <sub>AUX</sub> -0.5 V)
CURRENT PER OUTPUT		–	≤ 1 A	≤ 1 A
DATA BITS	D0	IN1	OUT1	IN1/OUT1
	D1	IN2	OUT2	IN2/OUT2
	D2	IN3	IN3	IN3/OUT3
	D3	IN4	IN4	IN4/OUT4
PARAMETER BITS	P0	–	–	Watchdog on/off
	P1	–	–	–
	P2	–	–	–
PERIPHERAL FAULT BIT		Input overload	Input/output overload	Input/output overload
PROFILE S-IO.ID.ID1.ID2		S-0.A.7.0	S-B-A.7.0	S-7.A.7.7
PROTECTION		IP67	IP67	IP65
WEIGHT		180 g (6.3 oz)	180 g (6.3 oz)	312 g (11 oz)
AS-INTERFACE CONNECTION		Flat yellow or round cable	Flat yellow or round cable	Flat yellow or round cable
AUXILIARY POWER CONNECTION		–	Flat black or round cable	Flat black or round cable
I/O CONNECTION		Cage tension spring terminals	Cage tension spring terminals	Cage tension spring terminals

† Default setting


## \*Also Available

INPUTS/OUTPUTS	Model Number	Bases	Required Master Spec.	Profile S-IO.ID.ID1.ID2	Extended Addressing	Special Features
4-in	VAA-4E-G4-ZE	U-G1FFA, U-G1PP	–	S-0.0.FE	No	
4-in/3-out	VBA-4E3A-G4-ZE/E2	U-G1FFA, U-G1PP	M3, M4	S-7.A.7.0	Yes	
4-in/4-out	VAA-4E4A-G4-ZE/E2	U-G1FFA, U-G1PP	–	S-7.0.FE	No	



## Wiring Diagrams

VBA-4E-G4-ZE



## LED Indicators


**INPUTS:** Yellow: Input on

**PWR/FAULT:** Green: AS-Interface powered

Red (solid): Address 0 or no communication

Green/Red (flashing): Overload of input power

VBA-2E2A-G4-ZE/E2



## LED Indicators

**I:** Yellow: Input on


**O:** Yellow: Output on

**PWR/FAULT:** Green: AS-Interface powered

Red (solid): Address 0 or no communication

Green/Red (flashing): Overload of input power or outputs

VBA-4E4A-G4-ZE/E2



## LED Indicators

**I:** Yellow: Input on



**O:** Yellow: Output on

**PWR/FAULT:** Green: AS-Interface powered


Red (solid): Address 0 or no communication

Green/Red (flashing): Overload of input power or outputs

**AUX:** Green: Auxiliary powered




INPUTS




OUTPUTS

## Dimensions (mm)

VBA-4E-G4-ZE  
VBA-2E2A-G4-ZE/E2



VBA-4E4A-G4-ZE/E2



## Accessories

**U-G1FFA**

Flat cable mounting base for black and yellow cables with addressing jack

**U-G1PP**

Round cable base with external power terminals

**PG11 CORD GRIP**

PG11 cord grip, includes nut and round cable grommet

**PG11-1/2NPT**


PG11 male to 1/2" NPT female conduit adapter



See pages 211-226 for complete AS-Interface accessory listing.

## Compact I/O Modules

- Potted watertight housing, IP69K
- AS-Interface and I/O quick disconnect
- Smallest field-mountable housing available
- Short-circuit indication output



4-port Module

8-port Module

### Compact Module Overview


AS-Interface offers advantages for many areas of automation. Many of the modules commonly available on the market are too large for robotics and material handling applications. Circuit boards are an alternative but are expensive to protect from rigorous industrial environmental conditions. Pepperl+Fuchs offers these compact modules as a cost-effective solution.

Our compact modules connect to field devices through the use of Nano (M8x1) quick disconnects. These small modules are rated IP69K and are ideal for rugged industrial environments. The unique mounting hole arrangement enables the module to be mounted in almost any location.

Compact modules use V1 M12x1 quick disconnects to attach AS-Interface and external power. The VAZ-2T1-FK... adapter connects both the yellow (AS-Interface) and black (external 24 VDC) flat cables.



The same adapter can also be used for the 4-input modules, but because no external power is required for input-only modules, the VAZ-T1-FK... is the preferred option. The VAZ-2T8-G11 adapter allows connection of up to eight compact modules using standard V1 (M12x1) extension cables.


The VBP-HH1-... handheld addressing device uses a V1 (M12x1) quick disconnect and a V1-G-2M-PVC-V1-G cable to connect to the compact module. The VBP-HH1-... enables the user to address the compact module before or during installation.







See page 97 for Compact Module wiring and dimensions.

### Common Specifications

OPERATING VOLTAGE AS-i		26.5-31.6 V
OPERATING VOLTAGE, V <sub>AUX</sub>		20-30 VDC
INPUT SWITCHING FREQUENCY		≤ 1 kHz
INPUT DELAY		≤ 1 ms from Input to AS-i
PROTECTION		IP67, IP68, IP69K
HOUSING MATERIAL		PBT
TEMPERATURE RANGE	Working	-13 °F to +158 °F (-25 °C to +70 °C)
	Storage	-13 °F to +185 °F (-25 °C to +85 °C)
APPROVALS		CE  



## Specifications

INPUTS/OUTPUTS		4-in	4-in/4-out
MODEL NUMBER(S)*		VBA-4E-G16-ZEJ	VBA-4E4A-G16-ZEJ/E2L
EXTENDED ADDRESSING (62 NODES)		Yes	Yes
REQUIRED MASTER SPEC.		–	M4
AS-i OPERATING CURRENT		40-240 mA	40-240 mA
AUXILIARY CURRENT LIMIT		–	4 A
INPUTS	–ZEJ	PNP, AS-i powered	PNP, AS-i powered
		–	–
	TYPE	2- or 3-wire	2- or 3-wire
	SUPPLY VOLTAGE	21-31 V from AS-Interface	21-31 V from AS-Interface
	MAXIMUM CURRENT	150 mA, 200 mA (T ≤ 104 °F)	150 mA, 200 mA (T ≤ 104 °F)
	SWITCH POINT	OFF ≤ 3 mA, ON ≥ 5 mA	OFF ≤ 3 mA, ON ≥ 5 mA
	LOAD CURRENT	≤ 9 mA	≤ 9 mA
OUTPUTS	E2L	–	PNP, auxiliary powered
	SUPPLY VOLTAGE	–	≥ (V <sub>AUX</sub> -0.5 V)
	CURRENT PER OUTPUT	–	≤ 1 A
DATA BITS	D0	IN1	IN1/OUT1
	D1	IN2	IN2/OUT2
	D2	IN3	IN3/OUT3
	D3	IN4	IN4/OUT4
PARAMETER BITS	P0	–	Watchdog on <sup>†</sup> /off
	P1	2 ms input filtering on/off <sup>†</sup>	2 ms input filtering on/off <sup>†</sup>
	P2	Synchronization on/off <sup>†</sup>	Synchronization on/off <sup>†</sup>
PERIPHERAL FAULT BIT		Input overload	Input/output overload
PROFILE S-IO.ID.ID1.ID2		S-0.A.7.0	S-7.A.7.7
WEIGHT		100 g (3.5 oz)	150 g (5.3 oz)
AS-INTERFACE CONNECTION		 M12 quick disconnect	 M12 quick disconnect
AUXILIARY POWER CONNECTION		–	
I/O CONNECTION		 M8 quick disconnect	 M8 quick disconnect


<sup>†</sup> Default setting

## \*Also Available


INPUTS/OUTPUTS	Model Number	Bases	Required Master Spec.	Profile S-IO.ID.ID1.ID2	Extended Addressing	Special Features
4-in/4-out	VAA-4E4A-G16-ZEJ/E2L	–	–	S-7.0.FE	No	

## Wiring Diagrams

**Note:** Wiring Diagrams show quick disconnect pin numbers.



VBA-4E-G16-ZEJ



## LED Indicators


I: Yellow: Input on

PWR/FLT: Green (solid): AS-Interface powered


Red (solid): Communication error

Yellow/Red (flashing): Address 0

Green/Red (flashing): Overload of input power



VBA-4E4A-G16-ZEJ/E2L



## LED Indicators

I: Yellow: Input on

O: Yellow: Output on, Red: Output overload

PWR/FLT: Green (solid): AS-Interface powered

Red (solid): Communication error

Yellow/Red (flashing): Address 0


Green/Red (flashing): Overload of input power or outputs

AUX: Green: Auxiliary powered


Red: Reverse polarity

## Dimensions (mm)

VBA-4E-G16-ZEJ



VBA-4E4A-G16-ZEJ/E2L




## Accessories

## VAZ-V3-B

V3 (M8 x 1) protective cover  
(Bag of 10)



See pages 211-226 for complete  
AS-Interface accessory listing.




## Enclosure I/O Modules

- Color-coded removable terminals
- Choose between AS-Interface or externally powered inputs
- Class I, Division 2 approvals for electronic and relay outputs
- Input filtering
- Lead breakage detection for outputs
- Advanced diagnostic LEDs





### Enclosure Module Overview

The KE modules have the following features: narrow housing, internal/external input power switch, color-coded removable terminals, and advanced diagnostic capabilities. Special relays are used so that the modules can carry the Class I, Division 2 hazardous location approval. The AS-Interface network is signaled when a short occurs on the inputs or outputs. If the outputs are shorted, the inputs will still function, and the reverse is also true. The module will automatically recover once the overload/short circuit is removed. Both standard versions and extended addressing versions are available for any application.



See pages 100-101 for Enclosure wiring and dimensions.

### Common Specifications

OPERATING VOLTAGE AS-i		26.5-31.6 V
OPERATING VOLTAGE, $V_{EXT}$		12-30 VDC (inputs using EXT mode)
OPERATING VOLTAGE, $V_{AUX}$		20-30 VDC (electronic outputs)
INPUT SWITCHING FREQUENCY		$\leq 1$ kHz
INPUT DELAY		$\leq 1$ ms from input to AS-i
PROTECTION		IP20
HOUSING MATERIAL		PA 66-FR
RELATIVE HUMIDITY		90%, non-condensing
TEMPERATURE RANGE	Working	-13 °F to +140 °F (-25 °C to +60 °C)
	Storage	-13 °F to +185 °F (-25 °C to +85 °C)
APPROVALS	Hazardous location*	 Class I, Div. 2, Groups A, B, C, D
	General purpose	  

\*Modules with outputs only





## Specifications

INPUTS/OUTPUTS	4-in	4-in/4-out	4-in/4-out (relay)
MODEL NUMBER(S)*	VBA-4E-KE-ZEJQ	VBA-4E4A-KE-ZEJQ/E2L	VBA-4E4A-KE-ZE/R
EXTENDED ADDRESSING (62 NODES)	Yes	Yes	Yes
REQUIRED MASTER SPEC.	–	M4	M4
AS-i OPERATING CURRENT	30-180 mA	35-190 mA	35-210 mA
AUXILIARY CURRENT LIMIT	–	2 A, 4 A*	–
INPUTS -ZE, -ZEJQ	PNP, AS-i or V <sub>EXT</sub> powered	PNP, AS-i or V <sub>EXT</sub> powered	PNP, AS-i or V <sub>EXT</sub> powered
TYPE	2-, 3-wire	2-, 3-wire	2-, 3-wire
SUPPLY VOLTAGE	21-31 V from AS-i, or V <sub>EXT</sub>	21-31 V from AS-i, or V <sub>EXT</sub>	21-31 V from AS-i, or V <sub>EXT</sub>
MAXIMUM CURRENT	150 mA (when using AS-i power)	150 mA (when using AS-i power)	150 mA (when using AS-i power)
SWITCH POINT	OFF ≤ 3 mA, ON ≥ 5 mA	OFF ≤ 3 mA, ON ≥ 5 mA	OFF ≤ 2 mA, ON ≥ 4 mA
LOAD CURRENT	≤ 9 mA	≤ 9 mA	≤ 8 mA
ELECTRONIC OUTPUTS -E2L	–	PNP, auxiliary powered	–
SUPPLY VOLTAGE	–	≥ (V <sub>AUX</sub> -0.5 V)	–
CURRENT PER OUTPUT	–	≤ 0.5 A, 2 A*	–
RELAY OUTPUTS -R	–	–	Relay, SPST
NOMINAL LOAD PER CONTACT	–	–	2 A @ 30 VDC, 2 A @ 253 VAC
NOMINAL LOAD PER MODULE	–	–	8 A
SWITCH DELAY	–	–	< 10 ms
MAXIMUM SWITCHING OPERATIONS	–	–	5,000,000 (no load) 200,000 (250 VAC, 2 A, cos φ = 0.4)
CONTROL CIRCUIT	–	–	8 mA from AS-i per relay
DATA BITS			
D0	IN1	IN1/OUT1	IN1/OUT1
D1	IN2	IN2/OUT2	IN2/OUT2
D2	IN3	IN3/OUT3	IN3/OUT3
D3	IN4	IN4/OUT4	IN4/OUT4
PARAMETER BITS			
P0	–	Watchdog on <sup>†</sup> /off	Watchdog on <sup>†</sup> /off
P1	2 ms input filtering on/off <sup>†</sup>	2 ms input filtering on/off <sup>†</sup>	2 ms input filtering on/off <sup>†</sup>
P2	Synchronization on/off <sup>†</sup>	Lead breakage detection on/off <sup>†</sup>	Synchronization on/off <sup>†</sup>
PERIPHERAL FAULT BIT	Input overload	Input/output overload	Input overload
PROFILE S-IO.ID1.ID2	S-0.A.7.0	S-7.A.7.7	S-7.A.7.7
WEIGHT	150 g (5.3 oz)	150 g (5.3 oz)	170 g (6.0 oz)
AS-INTERFACE CONNECTION	Yellow removable terminals	Yellow removable terminals	Yellow removable terminals
AUXILIARY POWER CONNECTION	–	Gray removable terminals	–
I/O CONNECTION	Black removable terminals	Black removable terminals	Black removable terminals (input), red removable terminals (output)

<sup>†</sup> Default setting

\* 5 mm gap between modules required if temperature is above 40 °C

## \*Also Available

INPUTS/OUTPUTS	Model Number	Base	Required Master Spec.	Profile S-IO.ID1.ID2	Extended Addressing	Special Features
4-in/3-out	VBA-4E3A-KE-ZEJQ/E2L	–	M3, M4	S-7.A.7.0	Yes	Outputs 3 A or 1.5 A, 6 A total
4-in/3-out (relay)	VBA-4E3A-KE-ZE/R	–	M3, M4	S-7.A.7.0	Yes	Relay outputs
4-in/4-out	VAA-4E4A-KE-ZEJQ/E2L	–	–	S-7.0.F.E	No	
4-in/4-out (relay)	VAA-4E4A-KE-ZE/R	–	–	S-7.0.F.E	No	Relay outputs

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets


Accessories

## Wiring Diagrams


## Switching Between AS-i and External Input Power

VBA-4E-KE-ZEJQ  
VBA-4E4A-KE-ZEJQ/E2L

**ATTENTION**  
Do not connect the terminals I+, IN, and I- with any external potential when switch set to "INT"



VBA-4E-KE-ZEJQ



## LED Indicators


**IN:** Yellow: Input on

**PWR:** Green: AS-Interface powered  
Green (flashing): Address 0

**FAULT:** Red (solid): Address 0 or no communication  
Red (flashing): Overload of input power

**INT:** Yellow: Inputs powered by AS-Interface  
Off: Inputs powered externally

VBA-4E4A-KE-ZEJQ/E2L



## LED Indicators

**IN:** Yellow: Input on

**OUT:** Yellow: Output on  
Red: Overload or lead breakage

**PWR:** Green: AS-Interface powered  
Green (flashing): Address 0

**FAULT:** Red (solid): Address 0 or no communication  
Red (flashing): Overload of input power or outputs, lead breakage

**INT:** Yellow: Inputs powered by AS-Interface  
Off: Inputs powered externally

**AUX:** Green: Auxiliary powered  
Red: Reverse polarity

## Wiring Diagrams

VBA-4E4A-KE-ZE/R






The plug connectors with dangerous contact voltage must not be connected or disconnected under power

**ATTENTION**

Do not connect the terminals I+, IN, and I- with any external potential when switch set to "INT"

Sensor supply:  
INT = internal sensor supply (from AS-i)  
EXT = external sensor supply

**LED Indicators**

**IN:** Yellow: Input on

**OUT:** Yellow: Output on


**PWR:** Green: AS-Interface powered

**FAULT:** Red (solid): Address 0 or no communication  
Red (flashing): Overload of input power


**INT:** Yellow: Inputs powered by AS-Interface  
Off: Inputs powered externally

## Dimensions (mm)


VBA-4E-KE-ZEJQ  
VBA-4E4A-KE-ZEJQ/E2L



VBA-4E4A-KE-ZE/R



See pages 211-226 for complete AS-Interface accessory listing.



## Junction Box I/O Modules

- 2- and 3-wire models
- AS-Interface and auxiliary-powered options
- Lowest profile housing, 1" high including removable terminals

### Junction Box Module Overview



To ensure the correct fit for your applications, Pepperl+Fuchs offers the compact KE1 series modules.

The KE1 series modules come in several input/output configurations. The housing, only 22.5 mm in width and 48.5 mm in height, takes up very little space in the junction box. The module is mounted by snapping onto the 35 mm DIN rail. Plug-in terminals are used for connection. LEDs on the front control plate are used to display the current switching state for each input.

The VBA-4E-KE1-Z connects to AS-Interface using a yellow removable terminal. Inputs are for 2-wire and dry-contact type inputs only. The load current is limited internally to 8 mA.




The VBA-4E2A-KE1-Z/E2 connects to AS-Interface and external power using gray and yellow removable terminals. This makes it possible to separate power to individual modules or to disconnect power during commissioning or servicing. Inputs are for two-wire and dry-contact type inputs only. The load current is limited internally to 8 mA.

The CB1 junction box module offers the lowest profile housing. Including the removable terminals, the module only sits 25 mm high. It is uniquely mounted with dual-lock mounting strips, eliminating the requirement for the extra space required for a DIN rail. This 3.0 spec housing allows up to 62 nodes to be put on one network all having 4-in and 4-out. The completely encapsulated housing protects it from accidental damage.



See pages 104-105 for Junction Box Module wiring and dimensions.

### Common Specifications

OPERATING VOLTAGE AS-i	26.5-31.6 V
OPERATING VOLTAGE, V <sub>AUX</sub>	20-30 VDC
INPUT SWITCHING FREQUENCY	≤ 250 Hz
INPUT DELAY	≤ 2 ms from input to AS-i
PROTECTION	IP20
HOUSING MATERIAL	PA 66-FR
APPROVALS	  



## Specifications



INPUTS/OUTPUTS	4-in (2-wire)	4-in/2-out (2-wire)	4-in/4-out (AUX powered)	4-in/4-out (AS-i powered)
MODEL NUMBER(S)*	VBA-4E-KE1-Z	VBA-4E2A-KE1-Z/E2	VAA-4E4A-KE1-Z/E2	VBA-4E4A-CB1-ZEJ/E2J
EXTENDED ADDRESSING (62 NODES)	Yes	Yes	No	Yes
REQUIRED MASTER SPEC.	–	M3, M4	–	M4
AS-i OPERATING CURRENT	25-60 mA	25-60 mA	≤ 40 mA	30-180 mA
AUXILIARY CURRENT LIMIT	–	2 A, 3 A (T ≤ 104 °F)	2 A	–
INPUTS –Z, -ZEJ	PNP, AS-i powered	PNP, AS-i powered	PNP, auxiliary powered	PNP, AS-i powered
TYPE	2-wire	2-wire	2-, 3-wire	2-, 3-wire
SUPPLY VOLTAGE	21-31 V from AS-Interface	21-31 V from AS-Interface	V <sub>AUX</sub>	21-31 V from AS-Interface
MAXIMUM CURRENT	–	–	–	Limited by operating current
SWITCH POINT	OFF ≤ 2 mA, ON ≥ 4 mA	OFF ≤ 2 mA, ON ≥ 4 mA	OFF ≤ 2 mA, ON ≥ 4 mA	OFF ≤ 0.5 mA, ON ≥ 2 mA
LOAD CURRENT	≤ 8 mA	≤ 8 mA	≤ 8 mA	≤ 5 mA
OUTPUTS –E2, E2J	–	PNP, auxiliary powered	PNP, auxiliary powered	PNP, AS-i powered
SUPPLY VOLTAGE	–	≥ (V <sub>AUX</sub> -0.5 V)	≥ (V <sub>AUX</sub> -0.5 V)	21-31 V from AS-Interface
CURRENT PER OUTPUT	–	≤ 1 A, ≤ 1.5 A (T ≤ 104 °F)	≤ 0.5 A	≤ 100 mA (≤ 140 mA total)
DATA BITS D0	IN1	IN1/OUT1	IN1/OUT1	IN1/OUT1
D1	IN2	IN2/OUT2	IN2/OUT2	IN2/OUT2
D2	IN3	IN3	IN3/OUT3	IN3/OUT3
D3	IN4	IN4	IN4/OUT4	IN4/OUT4
PARAMETER BITS P0	–	–	–	Watchdog on <sup>†</sup> /off
P1	–	–	–	2 ms input filtering on/off <sup>†</sup>
P2	–	–	–	Synchronization on/off <sup>†</sup>
PERIPHERAL FAULT BIT	Input overload	Input/output overload	Output overload	Output overload
PROFILE S-IO.ID.ID1.ID2	S-0.A.7.0	S-7.A.7.0	S-7.0.FE	S-7.A.7.7
TEMPERATURE WORKING RANGE	-13 °F to +185 °F (-25 °C to +85 °C)	-13 °F to +158 °F (-25 °C to +70 °C)	-13 °F to +140 °F (-25 °C to +60 °C)	-13 °F to +140 °F (-25 °C to +60 °C)
STORAGE	-13 °F to +185 °F (-25 °C to +85 °C)	-13 °F to +185 °F (-25 °C to +85 °C)	-40 °F to +185 °F (-40 °C to +85 °C)	-40 °F to +185 °F (-40 °C to +85 °C)
WEIGHT	80 g (2.8 oz)	80 g (2.8 oz)	80 g (2.8 oz)	90 g (3.2 oz)
AS-INTERFACE CONNECTION	Yellow removable terminals	Yellow removable terminals	Removable cage tension spring terminals	Green removable terminals
AUXILIARY POWER CONNECTION	–	Gray removable terminals	Removable cage tension spring terminals	–
I/O CONNECTION	Black removable terminals	Black removable terminals	Removable cage tension spring terminals	Green removable terminals

<sup>†</sup> Default setting

## \*Also Available

INPUTS/OUTPUTS	Model Number	Base	Required Master Spec.	Profile S-IO.ID.ID1.ID2	Extended Addressing	Special Features
4-in/4-out	VAA-4E4A-CB1-Z/E2	–	–	S-7.0.FE	No	AS-i powered inputs and outputs
4-in/4-out	VAA-4E4A-CB2-Z/E2	–	–	S-7.0.FE	No	Auxiliary powered inputs and outputs
4-in/4-out	VBA-4E4A-CB1-ZEJ/E2J-FL	–	M4	S-7.A.7.7	Yes	AS-i powered inputs and outputs, flying leads

## Wiring Diagrams





## LED Indicators

**IN:** Yellow: Input on

**PWR:** Green: AS-Interface powered

**FAULT:** Red (solid): Address 0 or no communication



## LED Indicators



**IN:** Yellow: Input on

**OUT:** Yellow: Output on

**PWR:** Green: AS-Interface powered

**FAULT:** Red (solid): Address 0 or no communication  
Red (flashing): Overload of outputs

**AUX:** Green: Auxiliary powered



## LED Indicators


**IN:** Yellow: Input on

**OUT:** Yellow: Output on


**PWR:** Green: AS-Interface powered

**FAULT:** Red (solid): Address 0 or no communication  
Red (flashing): Overload of outputs

**AUX:** Green: Auxiliary powered  
Red: Reverse polarity



## VBA-4E4A-CB1-ZEJ/E2J



## LED Indicators

**PWR:** Green: AS-Interface powered

**FAULT:** Red (solid): Address 0 or no communication  
Red (flashing): Overload of outputs


**IN:** Yellow: Input on

**OUT:** Yellow: Output on




## Dimensions (mm)


VBA-4E-KE1-Z  
VBA-4E2A-KE1-Z/E2



VAA-4E4A-KE1-Z/E2



VBA-4E4A-CB1-ZEJ/E2J



See pages 211-226 for complete AS-Interface accessory listing.

Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories



## Analog I/O Modules

- Monitor 4-20 mA, 0-10 V analog signals via AS-Interface
- Transmit analog values as simply as binary signals
- Automatic scaling 4000-20000 or 0-10000
- Modules with extended addressing now available
- 12- and 14-bit resolution possible for fast response times

### Analog Module Overview


Analog modules have been around for more than 10 years with the AS-Interface specification 2.1. The latest AS-Interface specification 3.0 adds new analog profiles to make the transmission of analog data even faster. The transmission of analog data is completely transparent and as easy to use as digital data in your application.

The new G11 analog modules are state of the art in analog development. The G11 analog modules have a very rugged “clean” design that has an IP69K protection rating. These modules use a true external analog-to-digital converter to speed up the conversion rate from 20-30 ms, down to 8 ms. Modules are now available for 2 inputs and 2/4 analog outputs. These modules are completely universal. That means you can now buy one analog input module for 4-20 mA, 0-10 V, and PT100 inputs. Also, one analog output module can be purchased for both 0-20 mA and 0-10 V outputs.



The KE2 modules are designed for enclosure mounting and also offer both analog current and voltage in one housing. The 3.0 specification version of the analog

input KE module must be used with the latest M4 AS-Interface master. Normally, an AS-Interface analog module takes 7 scans per analog point but these modules take only 3 or 4 scans, depending on the configuration. This doubles the analog input transmission rate, allowing faster process control.














See pages 109-112 for Analog Module wiring and dimensions.

### Common Specifications

OPERATING VOLTAGE AS-i	26.5-31.6 V
OPERATING VOLTAGE, V <sub>AUX</sub>	21.4-27.6 VDC
HOUSING MATERIAL	PA 6 GF30, PA66-FR for KE2 module
PROTECTION	G11 IP67, IP68, IP69K
KE2	IP20
APPROVALS	



## Specifications

INPUTS/OUTPUTS		2-in (analog I, V, or PT100)	2-out (analog I)	4-out (analog I or V)
MODEL	Flat	VBA-2E-G11-I/U/PT100-F	VBA-2A-G11-I-F	VBA-4A-G11-I/U-F
NUMBER(S)	M12	VBA-2E-G11-I/U/PT100-V1	VBA-2A-G11-I-V1	
EXTENDED ADDRESSING (62 NODES)		No	No	No
REQUIRED MASTER SPEC.		M3, M4	M3, M4	M3, M4
AS-i CYCLES PER ANALOG CHANNEL		7	7	7
AS-i OPERATING CURRENT		60-200 mA	≤ 110 mA	75-200 mA
AUXILIARY CURRENT LIMIT		600 mA	–	700 mA
INPUTS	-I/U/PT100,	4-20 mA, 0-10 V, RTD -200 °C to 850 °C	–	–
TYPE		2-, 3-, 4-wire	–	–
SUPPLY VOLTAGE		26.5-31.6 V from AS-i or Aux	–	–
MAXIMUM CURRENT		140 mA AS-i or 600 mA Aux	–	–
INPUT RESISTANCE		Current ≤ 70 Ω, voltage 100 kΩ	–	–
RESOLUTION		1 µA/1 mV/0.1 °C	–	–
OUTPUTS	-I/U, -I,	–	0-20 mA	0-20 mA, 0-10 V
TYPE		–	2-wire	2-, 3-, 4-wire
SUPPLY VOLTAGE		–	–	26.5-31.6 V from AS-i or V <sub>AUX</sub>
MAXIMUM CURRENT		–	–	120 mA AS-i or 700 mA Aux
LOAD RESISTANCE		–	≤ 600 Ω	Current ≤ 600 Ω, voltage ≥ 1 kΩ
RESOLUTION		–	6 µA	3 mV/6 µA
ANALOG DATA	W1	Analog input 1	Analog output 1	Analog output 1
	W2	Analog input 2	Analog output 2	Analog output 2
	W3	–	–	Analog output 3
	W4	–	–	Analog output 4
SCALING		4-20 mA (4000 to 20000), 0-10 V (0 to 10000), -200 °C to 850 °C (-2000 to 8500)	0-20 mA (0 to 20000)	0-20 mA (0 to 20000), 0-10 V (0 to 10000)
PARAMETER BITS	P0	50-60 Hz filter on*/off	Watchdog on*/off	Watchdog on*/off†
	P1	2nd channel connected yes*/no	–	Current*/voltage mode setting†
	P2	Peripheral fault bit yes*/no	Peripheral fault bit yes*/no	Peripheral fault bit yes*/no†
	P3	Both channels current mode yes*/no	–	Automatic/manual* mode setting†
PERIPHERAL FAULT BIT		< 1 mA, > 23 mA, > 11.5 V	> 23 mA	> 23 mA, > 1.5 V
PROFILE	S-IO.ID.ID1.ID2	S-7.3.F.D	S-7.3.F.5	S.7.3.F.6
TEMPERATURE RANGE	WORKING	-13 °F to +158 °F (-25 °C to +70 °C)		
	STORAGE	-13 °F to +185 °F (-25 °C to +85 °C)		
WEIGHT		200 g (7.1 oz)	200 g (7.1 oz)	200 g (7.1 oz)
AS-INTERFACE CONNECTION		 -F: Flat yellow	 -F: Flat yellow	 Flat yellow
		 -V1: M12 quick disconnect	 -V1: M12 quick disconnect	
AUXILIARY POWER CONNECTION		 -F: Flat black	–	 Flat black
		 -V1: M12 quick disconnect		
I/O CONNECTION		 M12 quick disconnect	 M12 quick disconnect	 M12 quick disconnect

\* Default setting

† Parameter bits used only when DIP switches are in current mode

## \*Also Available

INPUTS/OUTPUTS	Model Number	Base	Required Master Spec.	Profile S-IO.ID.ID1.ID2	Extended Addressing
2-in (analog I or V)	VBA-2E-G4-I VBA-2E-G4-U	U-G1FFA, U-G1PP	M3, M4	S-7.3.F.D	No
2-out(analog I or V)	VBA-2A-G4-I VBA-2A-G4-U	U-G1FFA, U-G1PP	M3, M4	S-7.3.F.5	No
4-in (analog RTD)	VBA-4E-G4-PT100	U-G1FFA, U-G1PP	M3, M4	S-7.3.F.E	No

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.comUSA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.comGermany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.comCopyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com
 **PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com



## Specifications

INPUTS/OUTPUTS		2-in (analog I or V)	2-in (analog I or V)	2-out (analog I or V)
MODEL NUMBER(S)		VBA-2E-KE2-I/U	VBA-2E-KE2-I/U-V3.0	VBA-2A-KE2-I/U
EXTENDED ADDRESSING (62 NODES)		No	Yes	No
REQUIRED MASTER SPEC.		M3, M4	M4	M3, M4
AS-i CYCLES PER ANALOG CHANNEL		7	3 (12-bit) or 4 (14-bit)*	7
AS-i OPERATING CURRENT		80-170 mA	80-170 mA	80-170 mA
AUXILIARY CURRENT LIMIT		500 mA	500 mA	500 mA
INPUTS		-I/U, 2 analog in 4-20 mA or 0-10 V	2 analog in 4-20 mA or 0-10 V	-
TYPE		2-, 3-, 4-wire	2-, 3-, 4-wire	-
SUPPLY VOLTAGE		21-31 V from AS-i or from V <sub>AUX</sub>	21-31 V from AS-i or from V <sub>AUX</sub>	-
MAXIMUM CURRENT		90 mA from AS-i or use V <sub>AUX</sub>	90 mA from AS-i or use V <sub>AUX</sub>	-
INPUT RESISTANCE		4-20 mA is 50 Ω, 0-10 V is 100 kΩ	4-20 mA is 50 Ω, 0-10 V is 100 kΩ	-
MAXIMUM INPUT LOAD		40 mA, 50 V	40 mA, 50 V	-
RESOLUTION		16 bit / 1 mV / 1 μA	12 bit or 14 bit / 1 mV / 1 μA	-
SCALING		4-20 mA (4000 to 20000), 0-10 V (0 to 10000)	4-20 mA (4000 to 20000), 0-10 V (0 to 10000)	-
OUTPUTS		-I/U, -	-	2 analog out 0-20 mA or 0-10 V
TYPE		-	-	2-, 3-, 4-wire
SUPPLY VOLTAGE		-	-	21-31 V from AS-i or from V <sub>AUX</sub>
MAXIMUM CURRENT		-	-	90 mA from AS-i or use V <sub>AUX</sub>
LOAD RESISTANCE		-	-	max 600 Ω (0-20 mA), min 3.3 kΩ (0-10V)
RESOLUTION		-	-	16 bit / 1 mV / 1 μA
SCALING		-	-	0-20 mA (0 to 20000), 0-10 V (0 to 10000)
ANALOG DATA	W1	Analog Input 1	Analog Input 1 (address A)	Analog Output 1
	W2	Analog Input 2	Analog Input 2 (address A)	Analog Output 2
	W3	-	Analog Input 1 (address B)	-
	W4	-	Analog Input 2 (address B)	-
PARAMETER BITS	P0	Main power filter 50 Hz*, 60 Hz	Main power filter 50 Hz*, 60 Hz	Automatic output recognition* or set by parameter
	P1	2nd channel connected yes*/no	Both channels 4-20 mA or automatic input recognition*	Channel 1 current* or voltage
	P2	Peripheral fault bit reported yes*/no	Peripheral fault bit reported yes*/no	Peripheral fault bit reported yes*/no
	P3	Both channels 4-20 mA or automatic input recognition*	-	Channel 2 current* or voltage
PERIPHERAL FAULT BIT		< 1 mA (only in automatic mode), > 23 mA, > 11.5 V	< 1 mA (only in automatic mode), > 23 mA, > 11.5 V	> 23 mA, > 11.5 V
PROFILE		S-7.3.FD	S-7.A.7.9†	S-7.3.F5
TEMPERATURE RANGE	WORKING	+32 °F to +158 °F (0 °C to +70 °C)		+32 °F to +131 °F (0 °C to +55 °C)
	STORAGE	-13 °F to +185 °F (-25 °C to +85 °C)		-13 °F to +185 °F (-25 °C to +85 °C)
WEIGHT		150 g (5.3 oz)	150 g (5.3 oz)	150 g (5.3 oz)
AS-INTERFACE CONNECTION		Yellow removable terminals	Yellow removable terminals	Yellow removable terminals
AUXILIARY POWER CONNECTION		Gray removable terminals	Gray removable terminals	Gray removable terminals
I/O CONNECTION		Black removable terminals	Black removable terminals	Black removable terminals

\* Default setting

† See ID1 configuration table on page 110

16 bits, 14 bits, or 12 bits of analog data are sent to or from the I/O modules. When only 14 bits or 12 bits of analog data are used, the least significant 2 bits or 4 bits are set to 0 respectively.

Analog data bits sent based on the resolution of the module																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
16-bit (profile 7.3.x.x)	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
14-bit (profile 7.A.x.x)	x	x	x	x	x	x	x	x	x	x	x	x	x	x	0	0
12-bit (profile 7.A.x.x)	x	x	x	x	x	x	x	x	x	x	x	x	0	0	0	0

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs

Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com




**PEPPERL+FUCHS**  
SENSING YOUR NEEDS



Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

## Wiring Diagrams

VBA-2E-G11-I/U/PT100-F




VBA-2E-G11-I/U/PT100-V1

VBA-2E-G11-I/U/PT100-F  
VBA-2E-G11-I/U/PT100-V1



## LED Indicators

- U:** Yellow: Activated,  $V \leq 11.5 V$   
Yellow (flashing): Voltage out of range
- I:** Yellow: Activated,  $1 \text{ mA} \leq I \leq 23 \text{ mA}$   
Yellow (flashing): Lead breakage or current out of range
- PT:** Yellow: Activated,  $-219^\circ\text{C} \leq \text{PT100} \leq 884^\circ\text{C}$   
Yellow (flashing): Temperature out of range
- AS-I/FAULT:** Green: AS-interface powered  
Red: Communication fault  
Yellow/Red (flashing): Address 0  
Green/Red (flashing): Peripheral fault
- AUX:** Green: Auxiliary powered  
Red: Reverse Polarity
- INT/EXT:** Green: Input supply from AS-interface  
Off: Input supply from Auxiliary

VBA-2A-G11-I-F



VBA-2A-G11-I-V1


VBA-2A-G11-I-F  
VBA-2A-G11-I-V1

## LED Indicators

- OUT:** Yellow: Activated  $0 \text{ mA} \leq I \leq 23 \text{ mA}$   
Yellow (flashing): Lead breakage or current out of range
- AS-I/FAULT:** Green: AS-interface powered  
Red: Communication fault  
Yellow/Red (flashing): Address 0  
Green/Red (flashing): Peripheral fault


## Wiring Diagrams

**VBA-4A-G11-I/U-F**



**NOTE:**  
Automatic detection of load type only happens initially or on DIP switch change.

VBA-2E-KE2-I/U  
VBA-2E-KE2-I/U-V3.0



## LED Indicators

**Analog OK:** Green:  $0\text{ V} \leq V \leq 11.5\text{ V}$  or  $1\text{ mA} \leq I \leq 23\text{ mA}$   
 Green (flashing): Out of range  
 Off: Not connected

**Analog UI:** Green: Analog current mode  
Off: Analog voltage mode

**PWR:** Green: AS-Interface powered

**FAULT:** Red (solid): Address 0 or no communication  
Red (flashing): Analog current out of range

**AUX:** Green: Power available to analog devices

**INT:** Yellow: Inputs powered by AS-Interface  
Off: Inputs powered by auxiliary




## Special ID1 Settings for VBA-2E-KE2-I/U-V3.0

	14-bit	12-bit
Input 1 only	ID1 = (0,2,3)	ID1 = (1)
Input 1 and 2	ID1 = (4,5,7)	ID1 = (6)



## Wiring Diagrams

VBA-2A-KE2-I/U



## LED Indicators

**Analog OK:** Green:  $0\text{ V} \leq V \leq 11.5\text{ V}$  or  $1\text{ mA} \leq I \leq 23\text{ mA}$   
 Green (flashing): Out of range  
 Off: Not connected

**Analog UI:** Green: Analog current mode  
 Off: Analog voltage mode

**PWR:** Green: AS-Interface powered


**FAULT:** Red (solid): Address 0 or no communication  
 Red (flashing): Analog current out of range

**AUX:** Green: Power available to analog devices

**INT:** Yellow: Inputs powered by AS-Interface  
 Off: Inputs powered by auxiliary


## Dimensions (mm)

VBA-2E-KE2-I/U  
 VBA-2E-KE2-I/U-V3.0  
 VBA-2A-KE2-I/U




## Dimensions (mm)



VBA-2A-G11-I-F




VBA-4A-G11-I/U-F





VBA-2E-G11-I/U/PT100-F




VBA-2E-G11-I/U/PT100-V1



VBA-2A-G11-I-V1



## Mounting Configuration



## Accessories

## VAZ-FK-S-BK-SEAL

For sealing unused flat cable openings



## V1-G-0,3M-PUR-ABG-V1-W-Y

## V1-G-42-0,3M-PUR-ABG-V1-W-Y

Adapter cables for analog modules that shield properly and jumper pins 3 and 4\*



See pages 211-226 for complete  
AS-Interface accessory listing.

\*See page 201 for adapter cable specifications



## Pushbuttons and Stack Lights I/O Modules

- User configurable housing for pushbuttons, selector switches, and LEDs
- Up to 62 LT2 pushbutton stations on one network
- Red, yellow, blue, green, and clear stack light options
- 85 and 105 dBA audible alarms

Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets


Accessories

### Pushbutton and Stack Lights Overview

Illuminated pushbutton modules attach easily to AS-Interface without diminishing the simplicity of the system, providing a link between the maintenance personnel and AS-Interface. Pepperl+Fuchs offers I/O pushbutton modules for AS-Interface in two styles:

The VBA-LT2-G1 module features two LEDs that are integrated in the buttons. The LEDs are white with green and red lens covers.

The module has an IP67 protection class and is especially suitable for use in the field. Use the U-G1FFA base to connect to the AS-Interface flat cable, or use the U-G1PP base to connect to the round cable. The VBA-LT2-G1 is fully powered from AS-Interface. The AS-Interface standardized base U-G1FFA includes an integrated addressing jack that allows easy connection to the handheld addressing device.



The VAA-LT3-F86-V1 module is a user-configurable pushbutton station for AS-Interface. The internal AS-Interface I/O module is ideally suited for integrating customer-specific electronics. Six 22.5 mm diameter holes can be used for any combination of pushbuttons, rotary selectors, key switches, and LED clusters that are typically used at operator call stations.

The inputs and outputs are protected against short circuits and overload. The connection to the AS-Interface is implemented by means of a micro (M12 x 1) quick disconnect.

Output overloads are relayed to the AS-Interface gateway/scanner via the “peripheral fault” function. Communication via the AS-Interface remains intact. The pushbutton module can be expanded to a total of 8 inputs/8 outputs by means of an additional printed circuit board module VAA-4E4A-CB1-Z/E2.










The stack light is a fully configurable system utilizing a 4-output AS-Interface node and up to four light/audible alarm modules. Lights can be used in any combination (including the same color multiple times) while each stack light can have only one audible alarm, which must be the last module. Power to the lights/alarm is switch selectable (internal from AS-Interface or external from AUX power). Status LEDs on the base output node provide detailed diagnostics information. The node is addressed using a standard addressing jack cable.






## Specifications

INPUTS/OUTPUTS		2-in (pushbuttons)/2-out (LEDs)	6 knockouts for 4-in/4-out
MODEL NUMBER(S)		VBA-LT2-G1	VAA-LT3-F86-V1
BASES		U-G1FFA, U-G1PP	—
EXTENDED ADDRESSING (62 NODES)		Yes	No
REQUIRED MASTER SPEC.		M3, M4	—
OPERATING VOLTAGE AS-i		26.5-31.6 V	26.5-31.6 V
OPERATING VOLTAGE V <sub>AUX</sub>		—	—
AS-i OPERATING CURRENT		≤ 50 mA	30-180 mA
INPUTS		PNP, AS-i powered	PNP, AS-i powered
TYPE		Pushbuttons	2-, 3-wire
SUPPLY VOLTAGE		21-31 V from AS-i	21-31 V from AS-i
MAXIMUM CURRENT		—	Limited by operating current of module
SWITCH POINT		—	OFF ≤ 1.5 mA, ON ≥ 4 mA
LOAD CURRENT		—	≤ 8 mA
OUTPUTS		PNP, AS-i powered	PNP, AS-i powered
SUPPLY VOLTAGE		21-31 V from AS-i	21-31 V from AS-i
CURRENT PER OUTPUT		—	100 mA
CURRENT PER MODULE		—	140 mA
DATA BITS	D0	LED 2 red	IN1/OUT1
	D1	LED 1 green	IN2/OUT2
	D2	Button 2 red	IN3/OUT3
	D3	Button 1 green	IN4/OUT4
PARAMETER BITS	P0	—	—
	P1	—	—
	P2	—	—
PERIPHERAL FAULT BIT		—	—
PROFILE S-IO.ID.ID1.ID2		S-B.A.FE	S-7.0.FE
PROTECTION (IEC)		IP67	IP65 (when knockouts are covered)
TEMPERATURE RANGE	Working	32 °F to +158 °F (-25 °C to +60 °C)	32 °F to +104 °F (-25 °C to +40 °C)
	Storage	-40 °F to +185 °F (-40 °C to +85 °C)	-40 °F to +185 °F (-40 °C to +85 °C)
HOUSING MATERIAL		—	Polycarbonate
WEIGHT		110 g (3.9 oz)	80 g (5.3 oz)
APPROVALS		 	 
AS-INTERFACE CONNECTION		 Flat yellow or round cable	 M12 quick disconnect
AUXILIARY POWER CONNECTION		—	—
I/O CONNECTION		—	 Terminals

## Specifications

INPUTS/OUTPUTS		4-out
<b>MODEL NUMBER(S)</b>		
<b>AS-i Module (optional)</b>		VAA-4A-70MM
<b>LEDs, lights, and Audible Alarms (choose up to 4 with AS-i, 5 without AS-i)</b>	Red LED	VAZ-LED-70MM-RD
	Red	VAZ-LAMP-70MM-RD
	Red (flashing) LED	VAZ-FLASH-70MM-RD
	Yellow LED	VAZ-LED-70MM-YE
	Yellow	VAZ-LAMP-70MM-YE
	Yellow (flashing) LED	VAZ-FLASH-70MM-YE
	Green LED	VAZ-LED-70MM-GN
	Green	VAZ-LAMP-70MM-GN
	Blue LED	VAZ-LED-70MM-BU
	Blue	VAZ-LAMP-70MM-BU
	Clear LED	VAZ-LED-70MM-CL
	Clear	VAZ-LAMP-70MM-CL
	Alarm (85 dBA)	VAZ-HORN-70MM-85DBA
	Alarm (105 dBA)	VAZ-HORN-70MM-105DBA
	8 toneAlarm (0 to 100 dBA)	VAZ-HORN-70MM-0..100DBA-8TONE
<b>Terminal base, mount and cover (choose 1 set)</b>	Tube mount (order both)	VAZ-CLAMP-70MM VAZ-MH 100-70MM
	90° mount (order both)	VAZ-CLAMP-70MM-90° VAZ-MH 90°-70MM
<b>EXTENDED ADDRESSING (62 NODES)</b>		No
<b>REQUIRED MASTER SPEC.</b>		-
<b>OPERATING VOLTAGE AS-i</b>		26.5-31.6 V
<b>OPERATING VOLTAGE V<sub>AUX</sub></b>		21.4-27.6 VDC
<b>AS-i OPERATING CURRENT</b>		21-200 mA
<b>AUXILIARY CURRENT LIMIT</b>		≤ 300 mA per light element
<b>OUTPUTS</b>		
<b>SUPPLY VOLTAGE</b>		From AS-i or AUX switchable
<b>CURRENT PER OUTPUT</b>		25 mA - green, blue, clear, 85 dBA alarm 30 mA - red, yellow 35 mA - red, yellow (flashing) 210 mA from AUX, all lamps 150 mA - 105 dBA alarm ≤ 80 mA - 0 to 100 dBA alarm
<b>DATA BITS</b>	D0	OUT1
	D1	OUT2
	D2	OUT3
	D3	OUT4
<b>PARAMETER BITS</b>	P0	Watchdog on*/off
	P1	-
	P2	-
<b>PERIPHERAL FAULT BIT</b>		-
<b>PROFILE</b> S-IO.ID1.ID2		S-8.F.F.F
<b>PROTECTION (IEC)</b>		IP65, IP40 (using 105 dBA alarm)
<b>TEMPERATURE RANGE</b>	Working	-4 °F to +122 °F (-20 °C to +50 °C)
	Storage	-4 °F to +122 °F (-20 °C to +50 °C)
<b>HOUSING MATERIAL</b>		Polycarbonate
<b>APPROVALS</b>		CE cUL US
<b>AS-INTERFACE CONNECTION</b>		Terminals
<b>AUXILIARY POWER CONNECTION</b>		Terminals (optional)

\* Default setting



**Bulb for use with all VAZ-LAMP... incandescent lights**



VAZ-LAMP-70MM-BULB-5W/24V

NOTE: VAZ-LAMP... modules do not come with bulb. Order separately.

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com


Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

## Wiring Diagrams



VBA-LT2-G1




## LED Indicators

**PWR/FAULT:** Green: AS-Interface powered  
Red (solid): Address 0 or no communication



VAA-LT3-F86-V1



Stack lights



Without AS-Interface Module




With AS-Interface Module

- 0 - AS-Interface
- 1 + AS-Interface

optional supply from  $V_{AUX}$

- 3 -  $V_{AUX}$
- 4 +  $V_{AUX}$




## LED Indicators


**AS-i:** Green: AS-Interface powered  
**FAULT:** Red (solid): Address 0 or no communication  
**AUX:** Green: Auxiliary powered




## Dimensions (mm)




## Stack lights



## VAZ-MH 100-70MM



## VAZ-MH 90°-70MM



## Accessories

### Pushbutton Module Accessories

#### U-G1FFA

Flat cable mounting base for black and yellow cables with addressing jack



#### U-G1PP

Round cable base with external power terminals



#### PG11 CORD GRIP

PG11 cord grip, includes nut and round cable grommet



#### PG11-1/2NPT


PG11 male to 1/2" NPT female conduit adapter



### Stack Light Accessories


#### VAZ-MH-1/2"Conduit-70MM

Connects tube mount base VAZ-CLAMP-70MM to 1/2" NPT conduit.




#### VAZ-TUBE400-70MM

A 400 mm long tube. Connects to tube mount base VAZ-CLAMP-70MM.



#### VAZ-TUBE-BASE-70MM

Mounting base for VAZ-TUBE400-70MM



#### VAZ-LAMP-70MM-BULB-5W/24V

Replacement bulbs for VAZ-LAMP... modules.



See pages 211-226 for complete AS-Interface accessory listing.



## Pneumatic I/O Modules


- 4 standard inputs and 2 pneumatic outputs
- Connects directly to pneumatic cylinders
- AS-Interface or externally powered outputs
- Flat or round cable AS-Interface connection
- Filter allows easy, direct exhaust to open air

### Pneumatic Module Overview

Pepperl+Fuchs offers pneumatic modules that broaden the concept of integrated system components. Two single cylinders or one double-acting cylinder, for example, can be connected to a module of this series. You can wire up the input sockets directly with sensors (PNP, via M12 plugs) in 2- or 3-wire connection. The outputs (two 3/2-way valves) and the compressed air supply are connected to the module via an 8 mm plug-in tube connector.

Filtered (5 µm), oiled or unoled compressed air (2 to 8 bar) must be used for correct operation.

**See page 121 for Pneumatic Module wiring and dimensions.**






### Common Specifications

OPERATING VOLTAGE AS-i		26.5-31.6 V
OPERATING VOLTAGE, V <sub>AUX</sub>		21.4-27.6 VDC
PROTECTION		IP65
HOUSING MATERIAL		PBT
TEMPERATURE RANGE	Working	32 °F to +131 °F (0 °C to +55 °C)
	Storage	-4 °F to +185 °F (-20 °C to +85 °C)
APPROVALS		CE



## Specifications

INPUTS/OUTPUTS		4-in/ 2-out (pneumatic AS-i powered)	4-in/2-out (pneumatic AUX powered)
MODEL NUMBER(S)*		VBA-4E2A-G1-ZE/P-S	VBA-4E2A-G1-ZE/PEXT-S
BASES		U-G1FFA, U-G1PP	
EXTENDED ADDRESSING (62 NODES)		Yes	
REQUIRED MASTER SPEC.		M3, M4	
AS-i OPERATING CURRENT		45-195 mA	45-145 mA
AUXILIARY CURRENT LIMIT		–	≤ 50 mA
INPUTS –ZE		PNP, AS-i powered	
TYPE		–	
SUPPLY VOLTAGE		2-, 3-, 4-wire	
MAXIMUM CURRENT		21-31 V from AS-Interface	
SWITCH POINT		100 mA	
LOAD CURRENT		OFF ≤ 1.5 mA, ON ≥ 5 mA	
OUTPUTS P-S, PEXT-S		≤ 8 mA	
SUPPLY VOLTAGE		Pneumatic, AS-i powered	Pneumatic, AUX powered
AIR VENTING		From AS-Interface	From auxiliary
COMPRESSED AIR		Sinter filter	
AIR THROUGHPUT		2-8 bar, filtered (5 µm), oiled or unoled	
CONNECTION		550 l/min at 6/0 bar, 350 l/min at 6/5 bar	
DATA BITS D0		8 mm	
D1		IN1/OUT1	
D2		IN2/OUT2	
D3		IN3	
D4		IN4	
PARAMETER BITS P0		–	
P1		–	
P2		–	
PERIPHERAL FAULT BIT		Input overload	
PROFILE S-IO.ID1.ID2		S-7.A.7.E	
WEIGHT		230 g (8 oz)	
AS-INTERFACE CONNECTION		 Flat yellow or round cable	
AUXILIARY POWER CONNECTION		–	 Flat black or round cable
I/O CONNECTION		 M12 quick disconnect and 8 mm pneumatic	


## \*Also Available

INPUTS/OUTPUTS	Model Number	Base	Required Master Spec.	Profile S-IO.ID1.ID2	Extended Addressing	Special Features
4-in/2-out	VAA-4E2A-G1-ZE/P-S	U-G1FFA, U-G1PP	–	S-7.F.F.F	No	
4-in/2-out	VAA-4E2A-G1-ZE/PEXT-S	U-G1FFA, U-G1PP	–	S-7.F.F.F	No	Auxiliary-powered outputs
2-in/2-out	VAA-2EA-G1-ZE/P-S	U-G1FFA, U-G1PP	–	S-3.F.F.F	No	
2-in/2-out	VAA-2EA-G1-ZE/P-V2A	U-G1FFA, U-G1PP	–	S-3.F.F.F	No	8 mm exhaust port, stainless steel



## Wiring Diagrams

Note: Wiring Diagrams show terminal numbers.

## VBA-4E2A-G1-ZE/P-S



## VBA-4E2A-G1-ZE/PEXT-S



## LED Indicators


IN: Yellow: Input on

OUT: Yellow: Output on

Power: Green: AS-Interface powered


AUX: Green: Auxiliary powered  
(VBA-4E2A-G1-ZE/PEXT-S only)

## Dimensions (mm)


VBA-4E2A-G1-ZE/P-S  
VBA-4E2A-G1-ZE/PEXT-S

## Example for AS-Interface Airbox Functions


## 3/2-way valve




## 4/2-way valve



## 5/2-way valve



## 5/2-way valve



## Accessories

**U-G1FFA**

Flat cable mounting base for black and yellow cables with addressing jack

**U-G1PP**

Round cable base with external power terminals

**PG11 CORD GRIP**

PG11 cord grip, includes nut and round cable grommet

**PG11-1/2NPT**

PG11 male to 1/2" NPT female conduit adapter



See pages 211-226 for complete AS-Interface accessory listing.





## Drive Control I/O Module

- 1-in/3-out in small cylindrical housing
- Included adapter to fit MOVIMOT® by SEW Eurodrive
- I/O Auxiliary powered

Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories

### Drive Control Overview

Networks like AS-Interface are often used in decentralized control systems where a single AS-Interface module controls the functionality of a motor on a conveyor section.

Our AS-Interface module was specifically designed to control MOVIMOT® by SEW Eurodrive. MOVIMOT is a motor with a built-in digital frequency inverter. Because the drive is built into the motor, the AS-Interface module needs only to control the variable operation of the drive, including direction and speed. Our AS-Interface module for drive control can also be used for any application requiring 1 input and 3 outputs.


The 3 outputs on the module are often used to control motor Start/Stop, Forward/Reverse, and Fast/Slow. The input can be used to detect pallet presence on a power and free conveyor system, or any other common PNP/dry contact input.

### Other options

Pepperl+Fuchs also offers other I/O modules particularly useful for drives. The flat module, VBA-2E2A-G2-ZEJ/XE2J (see page 76), is very useful for controlling two MOVISWITCH® drive inverters by SEW Eurodrive. The MOVISWITCH does not require any special motor starter, and the VBA-2E2A-G2-ZEJ/XE2J from Pepperl+Fuchs controls its on/off functionality directly from the field. What makes our VBA-2E2A-G2-ZEJ/XE2J so special is that it allows both inputs and outputs to be powered using AS-Interface, and each connector has an input and output both for easy wiring and control.

**See page 124 for Drive Control wiring and dimensions.**

### Common Specifications



OPERATING VOLTAGE AS-i		26.5-31.6 V
OPERATING VOLTAGE, V <sub>AUX</sub>		21.6 - 26.4 VDC
PROTECTION		IP67
HOUSING MATERIAL		Stainless Steel
TEMPERATURE RANGE	Working	32 °F to +158 °F (0 °C to +70 °C)
	Storage	-13 °F to +158 °F (-25 °C to +70 °C)
APPROVALS		CE 



## Specifications

INPUTS/OUTPUTS		1-in/3-out (AUX powered)
MODEL NUMBER(S)		VBA-1E3A-M18-ZE/E2-V1
EXTENDED ADDRESSING (62 NODES)		Yes
REQUIRED MASTER SPEC.		M3, M4
AS-i OPERATING CURRENT		≤ 30 mA
AUXILIARY CURRENT LIMIT		≤ 68 mA
INPUTS		PNP, AS-i powered
TYPE		2-, 3-wire
SUPPLY VOLTAGE		from AUX
MAXIMUM CURRENT		–
SWITCH POINT		OFF ≤ 0.8 mA, ON ≥ 5 mA
LOAD CURRENT		≤ 8 mA
OUTPUTS		PNP, auxiliary powered
SUPPLY VOLTAGE		≥ (V <sub>AUX</sub> - 0.5 V)
CURRENT PER OUTPUT		≤ 20 mA
DATA BITS	D0	OUT1
	D1	OUT2
	D2	OUT3
	D3	IN1
PARAMETER BITS	P0	–
	P1	–
	P2	–
PERIPHERAL FAULT BIT		Input overload
PROFILE	S-IO.ID.ID1.ID2	S-9.A.7.E
	ID1	7
WEIGHT		110 g (3.9 oz)
AS-INTERFACE CONNECTION		M12 quick disconnect
AUXILIARY POWER CONNECTION		0.2 m pigtail with flying leads
I/O CONNECTION		0.2 m pigtail with flying leads

## Wiring Diagrams




### LED Indicators

**FAULT:** Red (solid): Address 0 or no communication  
**PWR:** Green: AS-Interface powered

## Dimensions (mm)

VBA-1E3A-M18-ZE/E2-V1



See pages 211-226 for complete AS-Interface accessory listing.



# Safety at Work

<b>Safety Monitors .....</b>	<b>129</b>
<b>Safe Input/Output Modules .....</b>	<b>134</b>
<b>Emergency Stops .....</b>	<b>143</b>
<b>Mechanical Safety Interlock Switches.....</b>	<b>146</b>
<b>Coded Magnetic Safety Interlock Switches.....</b>	<b>152</b>
<b>RFID Safety Interlock Switches .....</b>	<b>155</b>
<b>Enabling Switch .....</b>	<b>159</b>

## Overview

AS-Interface Safety at Work (SaW) is a system that enables networking of safety devices (safety door switches, emergency stop pushbuttons, safety light arrays, etc.) using standard AS-Interface networks. With SaW, users can quickly implement a safety system that satisfies the rules and regulations needed for Category 4/SIL 3, PLe Safety. The simplicity of AS-Interface is retained and is a major reason for users to implement SaW systems.

The following features make SaW unique and powerful:

- Control I/O and safety information on the same network
- Usable up to Safety Category 4, SIL 3, PLe
- Does not require a Safety PLC
- Automatic single SafetyNode replacement is supported
- SafetyMonitor allows implementation of powerful safety procedures
- Safe inputs and outputs both supported
- Scan one or two networks simultaneously
- Up to 16 safe, independent output/coupling channels on a single network
- Adding safety devices is fast and easy

## What is needed?

SaW utilizes AS-Interface's proven wiring design to transmit safety information (position of an e-stop, state of a blade switch, position of a key switch, etc.) from a SafetyNode to a SafetyMonitor. SafetyNode and SafetyMonitor are the only new hardware items needed to implement SaW. The AS-Interface gateway/scanner and the AS-Interface power supply remain the same. The power supply and gateway/scanner chosen enable communication over the network and reflect the parameters of the job (e.g, the upper-level network used, speed of application, etc.), but do not affect the safety level.

## Safe input modules

SafetyNodes are I/O modules that have been designed and constructed to satisfy the rules and regulations necessary to obtain desired safety ratings. This construction includes redundancy at the inputs and internal components. A SafetyNode transmits 4 bits of data like any other I/O module, but with the SafetyNode, the 4 bits transmitted from the module to the AS-Interface gateway/scanner follow special rules that allow the SafetyMonitor to determine whether an e-stop has been activated. The gateway/scanner evaluates this data in the same manner as the data from a "nonsafe" I/O module. The SafetyMonitor takes the place of a safety relay in conventional hardwire systems.

## Safe output modules

Safety output modules work opposite to the way that safe input modules do. The SafetyMonitor generates an address called the safe output channel. This safe output channel and a standard A/B address are programmed into the safety output module. The safety sequence is transmitted over the safe output channel only when the SafetyMonitor determines that its configuration is safe. This information from the SafetyMonitor is then evaluated by the safe output module and the safe contacts are closed. If the SafetyMonitor determines that the machine must stop, all data bits transmitted via the safe output channel are set to 0. Diagnostics and

EDM inputs are all sent/connected through the inputs on the safety output module that can be monitored by the SafetyMonitor and PLC. Several safe output modules can be configured for the same safe output channel and, in that case, their safe contacts will all switch at the same time. An A/B standard address must, however, be unique for each safety output module used.

## Safe coupling


Safe coupling is a term used to define a method of transmitting the state of one SafetyMonitor to another. A SafetyMonitor that needs to send the state of a channel generates a safety address. It sends the safety sequence while running and sends 0000 when released. This safety address can be entered into the configuration of other SafetyMonitors, allowing one SafetyMonitor to control another.

## SafetyMonitors

Constructed to meet safety requirements, the SafetyMonitor connects to the AS-Interface network like any other module, monitoring the data sent by AS-Interface modules on the network.

## SafetyMonitor configuration

SaW can be added to an existing AS-Interface system as long as the basic AS-Interface network rules are satisfied (see pages 21-25). In most cases, SaW is used alongside standard I/O modules. All components are wired according to AS-Interface installation rules, and the data from the SafetyNodes are evaluated in the same manner as any other I/O module on the network. The SafetyMonitor is added to the network as if it were a module. The SafetyMonitor is configured with the software package VAZ-SW-SIMON+. This MS Windows package offers a simple, user-friendly interface and supports drag and drop functionality. This software allows users to quickly configure a new SafetyMonitor, or retrieve an existing configuration from one, and make modifications to a configuration if the safety system has been changed. In addition, the software has powerful diagnostics tool. After configuration and startup, the SafetyMonitor continuously monitors the data going over the AS-Interface network. If the monitor detects a discrepancy, it shuts down. The maximum time for the SafetyMonitor to open an OSSD (including the time it take for the relays to physically open) is 40 ms.



Two safe, remote output modules share the safe address 8, thus switching simultaneously when the SafetyMonitor signals an on/off state. The two safe output modules also have a unique, standard A/B address to transmit standard inputs, EDM, and diagnostics data.

Figure 1

## SIMON+, the graphical drag and drop user interface

Setting up an AS-Interface safety system is as easy as 1, 2, 3 thanks to the superior AS-Interface connectivity and the simplicity of SIMON+.

### Step 1 – Getting the network to talk (Figure 1, pg 126)

Before dealing with the safety setup the network needs to run. Since all AS-Interface devices, safe or conventional, connect to the network the same way, setting up the network does not change at all when safety components are used. All it takes is to:

- Address the devices – safe devices and non-safe devices are addressed in an identical fashion
- Connect them to the network – again safe and non-safe hardware is connected identically
- Activate the gateway

### Step 2 – Defining the safe logic

When working with conventional hardwired safety, the safe logic is created by appropriate wire connections. In order to logically AND two safe inputs, their contacts are connected in series. Similarly, to logically OR those safe inputs, their contacts are connected in parallel. Configuring an AS-Interface safety system using SIMON+ is not all that different. The big difference is that the logic is not wired but drawn in SIMON+.

The SIMON+ Device library (Figure 2) contains graphics function blocks that are then connected to specify the desired operation. SIMON+ nicely groups the function blocks by operation and thus allows the user to quickly find the necessary operation.

Once a function block has been dropped onto the configuration screen, the details screen (Figure 3) opens.




Figure 2





Figure 3

### Step 3 – Running the safe logic

After the desired safe logic has been configured, it is downloaded into the safety controller where it can be activated. The SIMON+ user interface also acts as an easy-to-understand monitoring and debugging tool. Colors are used to indicate the states of the function blocks. This not only helps the safety engineer in debugging safe logic, but also simplifies maintenance and troubleshooting.

SIMON+ uses an intuitive graphical interface that utilizes colors to identify the states of the inputs and outputs.

In this example, both magnetic switches are closed and released (green). The safe output is deactivated (red) because the e-stop has not yet been released (yellow).







## Safety Monitors Safety Solutions

- Connects to standard AS-Interface network
- Monitors status of safety inputs and sets safe outputs
- Safety requirements in accordance with category 4 to EN 954-1
- Comes with one or two redundant relay outputs, electronic outputs, and up to 16 safe output channels
- Safe coupling allows communication between safety monitors

Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories

### Monitors Overview

The safety monitor is an integral part of an AS-Interface Safety at Work system. A safety monitor can be a stand-alone device, as seen in this section, or can be combined in a safety monitor/gateway combination. This combination has the advantage of being less expensive for a two-network system and has very fast diagnostics. See pages 41 and 48 if this is the best option for your application. Stand-alone safety monitors are a great way to achieve a low-cost, safe output on AS-Interface, because AS-Interface safety can be added to any network regardless of age or master type.

Common safety monitor terms include:

#### Safe outputs

These are the onboard OSSDs (Output Signal Switching Devices) on the safety monitor and can be electronic or relay. These outputs are always redundant and used to switch a contactor, safe relay, or cut auxiliary power.

#### Safe output channels

A safety monitor has safe outputs; some can be on board and others can be remotely activated. This unique combination of both onboard and remote outputs provides the total number of available safe output channels. Remote safe outputs require the use of a safe output module as well.

#### Safe coupling channels

If multiple safety monitors are on one network, safety data can be exchanged between each monitor using the safe coupling channel. A safe coupling channel is simply a safety slave set up by one safety monitor and

received by another. Some of the safety monitors have multiple AS-Interface connections, allowing them to couple from one network to another.

### Monitor Options

#### 16-channel safety monitor

This is the most powerful safety monitor. It offers connectivity to two AS-Interface networks with up to 31 safety modules on each network. Up to 16 safety output channels are available with two safe electronic and two safe relay channels on board. Extra diagnostics are also available, including ground fault detection and duplicate address detection.

#### 8-channel safety monitor

The 8-channel is a lower cost, yet full-featured safety monitor. It can scan safety devices on only one network, but has two safe electronic OSSDs on board and up to six unique remote safe output channels. Eight inputs are available and can be configured for connection of standard inputs, safe dry contact inputs, or safe electronic inputs.







#### 2-channel safety monitor

This is one of the original safety monitors. It has one AS-Interface connection for safe inputs and one for the safe output or coupling channel. This allows complete flexibility to use one network only or couple to a second network. The safe relays are available to switch 120 VAC if required.

**See pages 131-132 for SafetyMonitor wiring and dimensions.**



## Specifications

NUMBER OF CHANNELS	16	8	2
MODEL NUMBER(S)	VAS-4A16L-K31	VAS-2A8L-KE4-8SE	VAS-2A1L-K12
RESPONSE DELAY	40 ms	40 ms	40 ms
STARTUP DELAY	< 10 s	< 10 s	< 10 s
EXTENDED ADDRESSING (62 NODES)	No	No	No
NETWORK CONNECTIONS	2	1	1/1 for safe output/coupling
REQUIRED MASTER SPEC	M4	M3, M4	M3, M4
OPERATING VOLTAGE AS-i	26.5-31.6 V	18-31.6 V	26.5-31.6 V
OPERATING VOLTAGE V <sub>AUX</sub>	21.4-27.6 VDC	20-30 VDC	21.4-27.6 VDC
AS-i OPERATING CURRENT	45 mA	≤ 200 mA	45 mA
AUXILIARY CURRENT LIMIT	< 200 mA	≤ 4A	< 200 mA
INPUTS: Standard and safe	4 standard	8 standard or 4 safe	4 standard
SUPPLY VOLTAGE	From AS-Interface	24 VDC	24 VDC
LOAD CURRENT	≈ 4 mA	≈ 4 mA	≈ 10 mA
SAFE COUPLING CHANNELS	16	8	1
SAFE OUTPUT CHANNELS	16	8	2
OUTPUTS: Safe Relays	2	–	–
DRY CONTACT LOAD (RELAY)	DC-13, 1 A @ 30 VDC AC-15, 3 A @ 30 VAC	–	DC-13, 1 A @ 24 VDC AC-15, 3 A @ 230 VAC
OUTPUTS: Safe Electronic	2	2	–
LOAD CURRENT	DC-13, 0.5 A @ 30 VDC	DC-13, 0.7 A @ 24 V	–
OUTPUTS: Non safe	–	8 (If inputs are used as standard)	2
LOAD CURRENT	–	10 mA at 24 VDC	< 200 mA at 24 VDC
PROGRAMMING INTERFACE	RS232: 19200, 8, n, 1	Micro USB	RS232: 9600, 8, n, 1
PROFILE	Base addr.(S-7.5.F.5), Simulated addr.(S-7.F.F.F), Safe coupling addr.(S-7.B.F.E), Safe output addr. (S-6.B.F.D)	Base addr.(S-7.5.F.5 or S-7.F.F.F), Simulated addr.(S-7.F.F.F), Safe coupling addr.(S-7.B.F.E), Safe output addr. (S-6.B.F.D)	Base addr.(S-7.F.F.F), Simulated addr.(S-7.F.F.F), Safe coupling addr.(S-7.B.1.F), Safe output addr. (S-6.B.0.D)
PROTECTION (IEC)	IP20	IP20	IP20
TEMPERATURE WORKING RANGE	+32 °F to +131 °F (0 °C to +55 °C)	+32 °F to +131 °F (0 °C to +55 °C)	-4 °F to +140 °F (-20 °C to +60 °C)
TEMPERATURE STORAGE RANGE	-13 °F to +185 °F (-25 °C to +85 °C)	-13 °F to +185 °F (-25 °C to +85 °C)	-22 °F to +158 °F (-30 °C to +70 °C)
HOUSING MATERIAL	Stainless steel	PA 66-FR	PA 66
WEIGHT	800 g (27 oz)	185 g (6.5 oz)	405 g (14 oz)
APPROVALS	  TÜV approved up to cat.4 / SIL3 NFPA 79	  TÜV approved up to cat.4 / SIL3 NFPA 79	  TÜV approved up to cat.4 / SIL3 NFPA 79
AS-INTERFACE CONNECTION	Removable terminals	Removable terminals	Removable terminals

## \*Also Available

Number of Channels	Model Number	Onboard Channels	Onboard Channel Type	Remote Safe Outputs	Network Connections
2	VAS-1A1L-K12	1	Relay, 230 VAC, 24 VDC	1	1/1 for safe output/coupling
1	VAS-1A-K12	1	Relay, 230 VAC, 24 VDC	–	1
2	VAS-2A-K12	2	Relay, 230 VAC, 24 VDC	–	1
16	VAS-2A1L-K31	2	Relay, 30 VAC, 30 VDC	16	2




See pages 41 and 48 for PROFIBUS, Ethernet/IP, or Modbus/TCP gateways with integrated 16-channel safety monitors: same functionality and diagnostics and no base address required.

## Wiring Diagrams

**Note:** Wiring diagrams show terminal numbers.

VAS-4A16L-K31



### LED Indicators

**Power:** Green: powered

**Fault:** Red (solid): Communication error on AS-Interface  
Red (flashing): At least one OSSD released

**Ready:** Yellow (solid): Waiting for start condition  
Yellow (flashing): Safety module test or local acknowledge required

**UASI1:** Green: AS-Interface power okay

**UASI2:** Green: AS-Interface power okay

**Aux:** Green: Power on

**1.Yx, 2.Yx:** Yellow: Input on

**Kx:** Yellow: OSSD on

### Pushbuttons

**↑ Mode:** Switches between normal operating mode and configuration mode and moves up through display

**↓ Set:** Changes slave addresses in configuration mode and moves down through display


**OK:** Moves forward through graphical display and accepts changes

**ESC:** Moves backward through display

### Display

**Graphical Display:** 4-line black and white display

VAS-2A1L-K12



### Service Button

Press to clear faults, teach safety sequences of safety modules, swap safety monitors.  
See manual for complete details.


### LED Indicators

LED	Indication	Meaning
AS-i 1	Off	No 30 V AS-i connection to AS-i+ and AS-i- terminals
	On (Green)	Normal
AS-i 2	Off	Normal operation
	On (Red)	No AS-i communication or monitor address not stored in gateway/scanner
1 READY	On (Yellow)	Waiting for start condition or door unlock condition
	Flashing (Yellow)	Safety module test, local acknowledge required, or diagnostic stop enabled
2 ON	On (Green)	Contacts of the output switching elements closed
	Flashing (Green)	Delay time runs in event of Stop Category 1
3 OFF/FAULT	On (Red)	Contacts of the output switching elements open
	Flashing (Red)	Error on level of the monitored AS-i components
1 READY 2 ON 3 OFF/FAULT	Simultaneously flashing rapidly	Internal device error; power cycle is required
1 READY 2 ON 3 OFF/FAULT	Cycling slowly	Learning safety code sequences
1 READY 2 ON 3 OFF/FAULT	Off	No 24 V supply connected to L+ and M terminals

## Wiring Diagrams

**Note:** Wiring diagrams show terminal numbers.

**VAS-2A8L-KE4-8SE**



## LED Indicators


**Sx:** Yellow (solid): Standard/safe input connected  
Yellow (flashing): Cross circuit wiring of inputs  
Off: Input off/open

**SM:** Yellow (solid): Service button ready  
Yellow (flashing): Service button teach error  
Yellow/Red (flashing): At least one device in flashing yellow or red state  
Red (solid): Configuration mode active  
Red (flashing): Configuration mode and ASIMON active  
Green (solid): Protected mode active  
Green (blinking): Protected mode and ASIMON active  
Off: Power supply off


**O1, O2:** Red (solid): No auxiliary voltage  
Yellow (solid): OSSD On  
Yellow (flashing 1 Hz): Restart inhibited  
Yellow (flashing 8 Hz): Correctable error condition  
Off: OSSD off

### Dimensions (mm)


**VAS-4A16L-K31**



**VAS-2A8L-KE4-8SE**



**VAS-2A1L-K12**



## Accessories

### VAZ-SIMON-R2

AS-Interface cable for programming  
(only used with VAS-2A1L-K12 models).



### VAZ-SIMON-RJ45

AS-Interface cable for downloading  
configuration from one monitor to another  
(only used with VAS-2A1L-K12 models).



### VAZ-SIMON+-R2-1,8M-PS/2

AS-Interface cable for programming (only  
used with VAS-4A16L-K31 models).



### VAZ-SIMON-USB

AS-Interface cable for programming (only  
used with VAS-2A8L-KE4-8SE models).



### VAZ-SW-SIMON+

Configuration software for all  
SafetyMonitors. Cables not included.



**See pages 211-226 for complete AS-Interface accessory listing.**

Gateways and Scanners

Power Supplies and  
Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories



## Safe Input/Output Modules Safety Solutions

- Available in field and enclosure mount versions
- Easily connect existing safe components to modules
- Standard outputs can be controlled by PLC or directly by module
- Connect two safe inputs for Category 2 safety
- Connect one safe input for Category 3/4 safety

### Safe Input/Output Modules Overview

SafetyNodes are I/O modules that have been designed and constructed to satisfy the rules and regulations necessary to obtain desired safety ratings. This construction includes redundancy at the inputs and internal components.

#### Safe input modules

Typically, safe input modules are used to connect existing safety devices or muting sensors. Modules are available in a number of housing designs to accept dry contacts from an emergency stop or electronic outputs from a light curtain or muting sensor. Also safety input modules have the advantage of accepting two Category 2 inputs when a higher level of safety isn't necessary. The advantage is that two Category 2 e-stops, for example, would take up one AS-Interface address where two integrated AS-Interface e-stops would require two addresses.

#### Safe output modules

The safety output module has the same safety output rating as a SafetyMonitor, but without programming. All of the programming and logic still resides on the SafetyMonitor itself. The safe output module should be viewed as a remote set of safe contacts controlled

by the SafetyMonitor. These are often used to control motors locally and safely. Two addresses are programmed into the safety output module. The first is the safe data channel that controls the safe operation of the module, and the second is an A/B address that is used for EDM inputs and diagnostics. Multiple modules can have the same safe data channel if required.

Safe output nodes can also be configured so that their safe relay output is controlled by the PLC. If there is a problem, the SafetyMonitor will act as an override and release the relay.


**See pages 139-140 for Safety Solutions Safe Input/Output Modules wiring and dimensions.**









Specifications		Safe Input (Dry Contact)	
INPUTS/OUTPUTS		2-in (safe)	2-in (safe)/2-out
MODEL NUMBER(S)		VAA-2E-KE1-S	VAA-2E2A-KE1-S/E2
EXTENDED ADDRESSING (62 NODES)		No	No
REQUIRED MASTER SPEC		–	–
OPERATING VOLTAGE AS-i		26.5-31.6 V	26.5-31.6 V
OPERATING VOLTAGE V <sub>AUX</sub>		–	20-30 VDC
AS-i OPERATING CURRENT		≤ 70 mA	≤ 70 mA
AUXILIARY CURRENT LIMIT		–	1 A
INPUTS -S		Safety, dry contacts	Safety, dry contacts
TYPE		2-wire	2-wire
SUPPLY VOLTAGE		20-30 V from AS-Interface, pulsed	20-30 V from AS-Interface, pulsed
LOAD CURRENT		≤ 15 mA	≤ 15 mA
MAX INPUT CABLE LENGTH		30 m each	30 m each
OUTPUTS E2		–	PNP, auxiliary powered
SUPPLY VOLTAGE		–	≥ (V <sub>AUX</sub> -0.5 V)
CURRENT PER OUTPUT		–	≤ 0.5 A
DATA BITS D0		Input 1	Input 1/OUT1
D1		Input 1	Input 1/OUT2
D2		Input 2	Input 2
D3		Input 2	Input 2
PARAMETER BITS P0		–	Outputs controlled via AS-Interface* or inputs
P1		–	–
P2		–	–
PERIPHERAL FAULT BIT		–	Output overload
PROFILE S-IO.ID1.ID2		S-0.B.F.0	S-7.B.F.0
PROTECTION (IEC)		IP20	IP20
TEMPERATURE WORKING RANGE		-13 °F to +122 °F (-25 °C to +50 °C)	-13 °F to +122 °F (-25 °C to +50 °C)
STORAGE		-13 °F to +185 °F (-25 °C to +85 °C)	-13 °F to +185 °F (-25 °C to +85 °C)
HOUSING MATERIAL		PA 66-FR	PA 66-FR
WEIGHT		80 g (2.8 oz)	80 g (2.8 oz)
APPROVALS		NFPA 79	NFPA 79
AS-INTERFACE CONNECTION		Yellow removable terminals	Yellow removable terminals
AUXILIARY POWER CONNECTION		–	Gray removable terminals
I/O CONNECTION		Black removable terminals	Black removable terminals

\* Default setting



Specifications		Safe Input (Dry Contact)		
INPUTS/OUTPUTS		2-in (safe)/1-out		2-in (safe)/2-out
MODEL NUMBER(S)		VAA-2E1A-G10-SAJ/EA2L-1M	VAA-2E1A-G10-SAJ/EA2L-2X1M	VAA-2E2A-G12-SAJ/EA2L
BASES		Included	Included	Included
EXTENDED ADDRESSING (62 NODES)		No		No
REQUIRED MASTER SPEC		-		-
OPERATING VOLTAGE AS-i		26.5-31.6 V		26.5-31.6 V
OPERATING VOLTAGE V <sub>AUX</sub>		-		20-30 VDC
AS-i OPERATING CURRENT		≤ 90 mA		≤ 70 mA
AUXILIARY CURRENT LIMIT		-		4 A
INPUTS -SAJ		Safety, dry contacts		Safety, dry contacts
TYPE		2-wire		2-wire
SUPPLY VOLTAGE		20-30 V from AS-Interface, pulsed		20-30 V from AS-Interface, pulsed
LOAD CURRENT		≤ 15 mA		≤ 15 mA
MAX INPUT CABLE LENGTH		30 m each		30 m each
OUTPUTS -EA2L		PNP, AS-i powered		PNP, auxiliary powered
SUPPLY VOLTAGE		V <sub>AS-i</sub> -4 V		≥ (V <sub>AUX</sub> -0.5 V)
CURRENT PER OUTPUT		50 mA		≤ 1.5 A
DATA BITS		Input 1/OUT1		Input 1/OUT1
		Input 1		Input 1/OUT2
		Input 2		Input 2
		Input 2		Input 2
PARAMETER BITS		Watchdog on*/off		Watchdog on*/off
		-		Outputs controlled via AS-Interface* or inputs
		-		-
PERIPHERAL FAULT BIT		Output overload		Output overload
PROFILE S-IO.ID.ID1.ID2		S-7.B.F.0		S-7.B.F.0
PROTECTION (IEC)		IP67		IP67
TEMPERATURE WORKING		-13 °F to +140 °F (-25 °C to +60 °C)		-13 °F to +131 °F (-25 °C to +55 °C)
RANGE STORAGE		-13 °F to +185 °F (-25 °C to +85 °C)		-13 °F to +185 °F (-25 °C to +85 °C)
HOUSING MATERIAL		PBT PC		PBT
WEIGHT		100 g (3.5 oz)		100 g (3.5 oz)
APPROVALS		   NFPA 79		   NFPA 79
AS-INTERFACE CONNECTION		 Flat yellow cable		 Flat yellow cable
AUXILIARY POWER CONNECTION		-		 Flat black cable
I/O CONNECTION		 1 m pigtail, safe input and output	 1 m pigtail, safe input 1 m pigtail, output	 M12 SPEEDCON

\* Default setting



Specifications		Safe Input (Electronic)
INPUTS/OUTPUTS		2-in (safe)
MODEL NUMBER(S)		VAA-2E-G4-SE
BASES		U-G1FFA, U-G1PP
EXTENDED ADDRESSING (62 NODES)		No
REQUIRED MASTER SPEC.		–
OPERATING VOLTAGE AS-i		26.5-31.6 V
OPERATING VOLTAGE $V_{AUX}$		21.4-27.6 VDC
AS-i OPERATING CURRENT		≤ 30 mA
AUXILIARY CURRENT LIMIT		2 A
INPUTS -SE		Safety, electronic auxiliary powered
TYPE		3-wire, PNP
SUPPLY VOLTAGE		$V_{AUX}$
LOAD CURRENT		≤ 45 mA
MAX INPUT CABLE LENGTH		30 m each
SWITCH POINT		OFF ≤ 5V/2 mA, ON ≥ 11 V/6 mA
TEST PULSE REQUIREMENTS		1% duty cycle, pulse duration max. 1 ms, 16 V min.
CAPACITANCE		≤ 10 nF
DATA BITS	D0	Input 1
	D1	Input 1
	D2	Input 2
	D3	Input 2
PARAMETER BITS	P0	–
	P1	–
	P2	–
PERIPHERAL FAULT BIT		–
PROFILE S-IO.ID1.ID2		S-0.B.FE
PROTECTION (IEC)		IP67
TEMPERATURE WORKING RANGE		-13 °F to +131 °F (-25 °C to +55 °C)
STORAGE		-13 °F to +185 °F (-25 °C to +85 °C)
HOUSING MATERIAL		PA 6 GF30
WEIGHT		180 g (6.3 oz)
APPROVALS		TÜV approved up to cat.4 / SIL3           NFPA 79
AS-INTERFACE CONNECTION		Flat yellow or round cable
AUXILIARY POWER CONNECTION		Flat black or round cable
I/O CONNECTION		Cage tension spring terminals








## Pepperl+Fuchs Safety Light Curtains

- Versions available for finger, hand, and perimeter access detection
- Control-reliable and self-monitoring (conform to Type 4 according to IEC61496)
- Approvals: CUL, TÜV
- CE marked
- Integral diagnostics
- Weak signal indication
- Enclosure rating: IP67
- Available with ATEX Approval for Ex Zone 2 and 22

(Refer to the Pepperl+Fuchs Machine Safety Products Selection Guide for further details.)




Specifications		Safe Output (Relay)
INPUTS/OUTPUTS		1-in*/1-out (safe)
MODEL NUMBER(S)		VBA-4E1A-KE3-ZEJ/SR
RESPONSE DELAY		50 ms
EXTENDED ADDRESSING (62 NODES)		Yes
REQUIRED MASTER SPEC		M3, M4
OPERATING VOLTAGE AS-i		26.5-31.6 V
OPERATING VOLTAGE V <sub>AUX</sub>		–
AS-i OPERATING CURRENT		30-200 mA
AUXILIARY CURRENT LIMIT		–
INPUTS	-ZEJ	4 PNP, AS-Interface powered
TYPE		2-, 3-wire
SUPPLY VOLTAGE		26.5-31.6 V from AS-Interface
MAXIMUM CURRENT		90 mA
SWITCH POINT		OFF ≤ 2 mA, ON ≥ 4 mA
LOAD CURRENT		8 mA
OUTPUTS	SR	1 safe relay
DRY CONTACT LOAD (Relay)		DC-13, 3 A @ 24 VDC AC-15, 3 A @ 230 VAC
DATA BITS*	D0	Diagnostics Bit 1/LED alarm
	D1	Diagnostics Bit 2
	D2	Diagnostics Bit 3
	D3	1.Y1
PARAMETER BITS	P0	–
	P1	See user manual
	P2	See user manual
PERIPHERAL FAULT BIT		Input overload
PROFILE	S-IO.ID.ID1.ID2	S.7.A.5.F
PROTECTION (IEC)		IP20
TEMPERATURE WORKING RANGE		+32 °F to +131 °F (0 °C to +55 °C)
STORAGE		-13 °F to +185 °F (-25 °C to +85 °C)
HOUSING MATERIAL		PA 66-FR
WEIGHT		170 g (6.0 oz)
APPROVALS		   NFPA 79
AS-INTERFACE CONNECTION		 Yellow removable terminals
AUXILIARY POWER CONNECTION		–
I/O CONNECTION		 Black removable terminals

\* See user manual for other input configurations

## Wiring Diagrams

**Note:** Wiring diagrams show terminal numbers.


VAA-2E-KE1-S



### LED Indicators

**IN:** Yellow (solid or flashing very fast): Input on  
**PWR:** Green: AS-Interface powered  
**FAULT:** Red (solid): Address 0 or no communication


VAA-2E2A-KE1-S/E2



### LED Indicators

**IN:** Yellow (solid or flashing very fast): Input on  
**OUT:** Yellow: Output on  
**PWR:** Green: AS-Interface powered  
**FAULT:** Red (solid): Address 0 or no communication  
 Red (flashing): Overload of outputs  
**AUX:** Green: Auxiliary powered


VAA-2E1A-G10-SAJ/EA2L-1M



### LED Indicators

**I:** Yellow (solid or flashing very fast): Input on  
**O:** Yellow: Output on  
**PWR:** Green: AS-Interface powered  
**FAULT:** Red (solid): Address 0 or no communication  
 Red (flashing): Overload of outputs

VAA-2E1A-G10-SAJ/EA2L-2X1M




### LED Indicators

**I:** Yellow (solid or flashing very fast): Input on  
**O:** Yellow: Output on  
**PWR:** Green: AS-Interface powered  
**FAULT:** Red (solid): Address 0 or no communication  
 Red (flashing): Overload of outputs


## Wiring Diagrams

**Note:** Wiring diagrams show terminal numbers.



### LED Indicators


**IN:** Yellow (solid or flashing very fast): Input on  
**OUT:** Yellow: Output on  
 Red: Output overload  
**PWR:** Green (solid): AS-Interface powered  
 Green (flashing): Address 0  
**FAULT:** Red (solid): Address 0 or no communication  
 Red (flashing): Overload of outputs  
**AUX:** Green: Auxiliary powered



### LED Indicators


**SE:** Yellow: Input on  
**AUX:** Green: Auxiliary powered  
**FAULT:** Red (solid): Address 0 or no communication  
**PWR:** Green: AS-Interface powered

## VBA-4E1A-KE3-ZEJ/SR



### LED Indicators


**PWR:** Off: No power  
 Green (solid): Power on  
 Green (flashing): Power on and address 0  
**FAULT:** Red: No communication  
**OUT:** Yellow (solid): Relay contact closed  
 Yellow (flashing, 1 Hz): restart inhibited, waiting for start signal  
 Yellow (flashing, 8 Hz): device locked in error, Waiting for "reset" error condition" signal  
**ALARM:** Red (solid): Output D0 has been turned on  
 1.Y1: Yellow: Input on






## Dimensions (mm)



VAA-2E-KE1-S  
VAA-2E2A-KE1-S/E2





VAA-2E-G4-SE




VAA-2E1A-G10-SAJ/EA2L-1M




VAA-2E1A-G10-SAJ/EA2L-2X1M



VAA-2E2A-G12-SAJ/EA2L



VBA-4E1A-KE3-ZEJ/SR



Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories

## Accessories

### Accessories for VAA-2E2A-G12-SAJ/EA2L

#### V1-CLIP

Prevents quick disconnects from being disconnected easily



### Accessories for VAA-2E-G4-SE

#### U-G1FFA

Flat cable mounting base for black and yellow cables with addressing jack



#### U-G1PP


Round cable base with external power terminals



### Accessories for VAA-2E1A-G10-SAJ/EA2L-1M and VAA-2E1A-G10-SAJ/EA2L-2X1M

#### VAZ-PK-FK-0,2M-V1-W

Addressing cable for all G10 style modules that attach only to the flat cable



See pages 211-226 for complete AS-Interface accessory listing.

## Emergency Stops Safety Solutions

- Connects directly to AS-Interface cable
- Illuminated and nonilluminated versions
- Field mount and panel mount housings available
- Field mount e-stops with M12 quick disconnect
- Twist or pull to release
- Completely powered off AS-Interface




### Emergency Stop Overview





These emergency stops connect directly to the AS-Interface cable for easy mounting. Because the AS-Interface safety module is integrated into the e-stop itself, the wiring between the two is eliminated. This reduces the overall wiring/complexity of your machine.

The four versions available are illuminated panel mount, nonilluminated panel mount, illuminated field mount, and nonilluminated field mount.

**See page 145 for Emergency Stop wiring and dimensions.**







Specifications		Panel Mount	Field Mount
<b>INPUTS/OUTPUTS</b>		<b>1 e-stop/1 LED (optional)</b>	
<b>MODEL</b>	Non-illuminated	<b>VAA-2E-PM-S</b>	<b>VAA-2E-F85A-S-V1</b>
<b>NUMBER(S)</b>	Illuminated	<b>VAA-2E1A-PM-S</b>	<b>VAA-2E1A-F85A-S-V1</b>
<b>EXTENDED ADDRESSING (62 NODES)</b>		No	
<b>REQUIRED MASTER SPEC</b>		-	
<b>OPERATING VOLTAGE AS-i</b>		26.5-31.6 V	
<b>OPERATING VOLTAGE <math>V_{AUX}</math></b>		-	
<b>AS-i OPERATING CURRENT</b>		≤ 25 mA (non-illuminated models) ≤ 40 mA (illuminated models)	
<b>AUXILIARY CURRENT LIMIT</b>		-	
<b>INPUTS</b>	-S	Safety	
<b>TYPE</b>		E-stop	
<b>SUPPLY VOLTAGE</b>		From AS-Interface	
<b>MECHANICAL ACTIVATIONS</b>		> 250,000	
<b>OUTPUTS (Illuminated models)</b>		LED, red	
<b>SUPPLY VOLTAGE</b>		From AS-Interface	
<b>CURRENT PER OUTPUT</b>		≤ 15 mA	
<b>DATA BITS</b>	D0	Contact 1/out 1 (only for illuminated models)	
	D1	Contact 1	
	D2	Contact 2	
	D3	Contact 2	
<b>PARAMETER BITS</b>	P0	-	
	P1	-	
	P2	-	
<b>PERIPHERAL FAULT BIT</b>		-	
<b>PROFILE</b>	S-IO.ID1.ID2	S-0.B.F.E (non-illuminated models) S-7.B.F.E (illuminated models)	
<b>PROTECTION (IEC)</b>		IP65 (when mounted)	IP65
<b>TEMPERATURE WORKING RANGE</b>		-13 °F to +131 °F (-25 °C to +55 °C)	
<b>STORAGE</b>		-40 °F to +158 °F (-40 °C to +70 °C)	
<b>HOUSING MATERIAL</b>		PA 6 GF30	
<b>WEIGHT</b>		60 g (2 oz)	195 g (7 oz)
<b>APPROVALS</b>		  NFPA 79	
<b>AS-INTERFACE CONNECTION</b>		 Quick connect with pigtail 1.5 m long	 M12 quick disconnect

## Wiring Diagrams


VAA-2E-PM-S  
VAA-2E1A-PM-S



VAA-2E-F85A-S-V1  
VAA-2E1A-F85A-S-V1




LED Indicator on VAA-2E1A-PM-S and  
VAA-2E1A-F85A-S-V1




### Dimensions (mm)

VAA-2E-PM-S  
VAA-2E1A-PM-S



VAA-2E-F85A-S-V1  
VAA-2E1A-F85A-S-V1





## Mechanical Safety Interlock Switches Safety Solutions

- Connect directly to AS-Interface cable using M12 quick connect
- All AS-Interface powered versions available
- Tamper-resistant, unique key is difficult to defeat
- Power to lock and power to unlock options
- Metal head for robust and long-lasting design

### Mechanical Safety Interlock Switches

#### Safety contacts

Safety switches are tasked with preventing machine operation in the event of a potential hazard. Every safety switch has two internal contacts that are safely opened when the key is removed. The safety data will immediately go to 0 when the gate is opened. This will cause the safety monitor to go into shut down and bring the machine to a safe state. Standard designs come with or without LEDs, and power to unlock or power to lock options are available.

#### Tamper-resistant actuating key

Tamper-resistant, removable keys cannot be simply defeated with screwdrivers, wire, or other mechanical components. Multiple key entry points are allowed from top or side. The head can be moved to allow a total of five different entry positions for maximum flexibility.

#### Power to lock/unlock

Four models are available with the power to lock/unlock feature. A data bit on AS-Interface must be turned on in order to close the door, power to lock, or open the door, power to unlock. The power-to-lock feature prevents unintentional closing by requiring the PLC to turn the output bit on first. The power-to-unlock version works by preventing the key from being removed until the output is actuated.


All switches include a mechanical override that can be used in the event of a power outage. The override acts the same as sending the output bit on AS-Interface

and will not run again until the override is put back into the locked position. Additionally, if the output that allows the unit to be locked or unlocked is left on, the switch will not be considered safe and the machine will not run.

All power to lock/unlock switches also come with two user-controlled LEDs, red and green. These are often used to show if the device is locked or unlocked, giving the user permission to enter the area.

#### Power options

Two power options are available: AS-Interface powered and auxiliary-powered. The separation of power on the auxiliary-powered versions allows the safety interlock switch to remain on AS-Interface but disable the power to lock/unlock feature. Use auxiliary-powered version when coils are controlled by safe outputs.







**See pages 149-150 for Mechanical Safety Interlock Switches wiring and dimensions**





## Specifications

<b>Specifications</b>		
<b>MODEL</b>	No LEDs	<b>VAA-2E-IM1-J-S-V1</b>
<b>NUMBER(S)</b>	With LEDs	<b>VAA-2E2A-IM1-J-S-V1</b>
<b>EXTENDED ADDRESSING (62 NODES)</b>		No
<b>REQUIRED MASTER SPEC.</b>		–
<b>OPERATING VOLTAGE AS-i</b>		26.5-31.6 V
<b>OPERATING VOLTAGE <math>V_{AUX}</math></b>		–
<b>AS-i OPERATING CURRENT</b>		45 mA
<b>AUXILIARY CURRENT LIMIT</b>		–
<b>INPUTS</b>	-S	Safety
<b>TYPE</b>		Mechanical Interlock
<b>SUPPLY VOLTAGE</b>		From AS-Interface
<b>MECHANICAL ACTIVATIONS</b>		2 x 10 <sup>6</sup>
<b>OUTPUTS</b>		–
<b>SUPPLY VOLTAGE</b>		–
<b>DATA BITS</b>	D0	Contact 1
	D1	Contact 1
	D2	Contact 2
	D3	Contact 2
<b>PERIPHERAL FAULT BIT</b>		–
<b>PROFILE</b>	S-IO.ID.ID1.ID2	S-7.B.F.E
<b>INSERTION SPEED</b>		20 m/min
<b>MIN/MAX TRAVEL</b>		24.5 mm / 29.5 mm
<b>INSERTION FORCE</b>		25 N
<b>EXTRACTION FORCE</b>		25 N
<b>RETENTION FORCE</b>		10 N
<b>PROTECTION (IEC)</b>		IP67
<b>TEMPERATURE WORKING RANGE</b>		-4 °F to +131 °F (-20 °C to +55 °C)
<b>STORAGE</b>		-4 °F to +131 °F (-20 °C to +55 °C)
<b>HOUSING MATERIAL</b>		PA6-GF30, metal head
<b>WEIGHT</b>		198 g (7 oz)
<b>APPROVALS</b>		   NFPA 79
<b>AS-INTERFACE CONNECTION</b>		 M12 quick disconnect

Gateways and Scanners

Power Supplies and Repeaters


I/O Modules

Safety at Work









Sensors

Cordsets


Accessories



## Specifications

		AS-i powered	AUX powered
MODEL	Power to lock	VAA-2E3A-LIM1-PL-J-S-V1	VAA-2E3A-LIM1-PL-L-S-V1
NUMBER(S)	Power to unlock	VAA-2E3A-LIM1-PU-J-S-V1	VAA-2E3A-LIM1-PU-L-S-V1
EXTENDED ADDRESSING (62 NODES)		No	No
REQUIRED MASTER SPEC.		–	–
OPERATING VOLTAGE AS-i		26.5-31.6 V	26.5-31.6 V
OPERATING VOLTAGE V <sub>AUX</sub>		–	21.6-27.6 VDC
AS-i OPERATING CURRENT		45-300mA	45 mA
AUXILIARY CURRENT LIMIT		–	300 mA
INPUTS	-S	Safety	Safety
TYPE		Mechanical Interlock	Mechanical Interlock
SUPPLY VOLTAGE		From AS-Interface	From AS-Interface
MECHANICAL ACTIVATIONS		1 x 10 <sup>6</sup>	1 x 10 <sup>6</sup>
OUTPUTS		Power to lock (-PL) Power to unlock (-PU)	Power to lock (-PL) Power to unlock (-PU)
SUPPLY VOLTAGE		From AS-Interface	From Auxiliary
DATA BITS	D0	Contact 1+solenoid monitor/solenoid	Contact 1+solenoid monitor/solenoid
	D1	Contact 1+solenoid monitor/LED Red	Contact 1+solenoid monitor/LED Red
	D2	Contact 2/LED Green	Contact 2/LED Green
	D3	Contact 2	Contact 2
PERIPHERAL FAULT BIT		–	–
PROFILE	S-IO.ID.ID1.ID2	S-7.B.F.E	S-7.B.F.E
INSERTION SPEED		20 m/min	20 m/min
MIN/MAX TRAVEL		24.5 mm / 29.5 mm	24.5 mm / 29.5 mm
INSERTION FORCE (Not locked)		30 N	30 N
EXTRACTION FORCE (Not locked)		20 N	20 N
LOCKING FORCE		2000 N (2500 N max.)	2000 N (2500 N max.)
PROTECTION (IEC)		IP67	IP67
TEMPERATURE WORKING RANGE		-4 °F to +131 °F (-20 °C to +55 °C)	-4 °F to +131 °F (-20 °C to +55 °C)
STORAGE		-4 °F to +131 °F (-20 °C to +55 °C)	-4 °F to +131 °F (-20 °C to +55 °C)
HOUSING MATERIAL		PA6-GF30, metal head	PA6-GF30, metal head
WEIGHT		482 g (17 oz)	482 g (17 oz)
APPROVALS		   NFPA 79	   NFPA 79
AS-INTERFACE CONNECTION		 M12 quick disconnect	 M12 quick disconnect


## Wiring Diagrams



### LED Indicators

**PWR:** Green: AS-Interface powered

**FAULT:** Red: Address 0 or no communication



### LED Indicators

**Power:** Green: AS-Interface powered


**Fault:** Red: Address 0 or no communication

**RD:** Red: User definable


**GN:** Green: User definable

# Dimensions (mm)

VAA-2E-IM1-J-S-V1  
VAA-2E2A-IM1-J-S-V1




VAA-2E3A-LIM1-PL-J-S-V1  
VAA-2E3A-LIM1-PU-J-S-V1  
VAA-2E3A-LIM1-PL-L-S-V1  
VAA-2E3A-LIM1-PU-L-S-V1




## Accessories


**VAZ-IM1-90°-BOLT-S**  
Right-angled key



**VAZ-IM1-BOLT-S**  
Straight key




**VAZ-IM1-LR-RADIUS-BOLT-S**  
Right-angled key, adjustable





**VAZ-IM1-BASE-BOLT-S**  
**VAZ-IM1-BASE-S**

Door handle and base for safe door locking. Key included. Design allows for lockout installation.



**VAZ-IM1-TD-RADIUS-BOLT-S**  
Key with adjustable start position, highly tolerant to close angle.



See pages 211-226 for complete  
AS-Interface accessory listing.

Gateways and Scanners

Power Supplies and  
Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories



## Coded Magnetic Safety Interlock Switches

### Safety Solutions

- Tamper-resistant coded magnet actuator
- Sealed housing, good for washdown or dirty environments
- M12 quick disconnect for easy AS-Interface connection


### Coded Magnetic Safety Interlock Switches Overview

Noncontact magnetic switches are designed for use on moveable machine guarding components. Their small size makes them perfect for space-limited mounting applications. Two housing designs are available depending on the space available and sensing range requirements.

Typical applications include food processing, chemical processing, packaging equipment, and robotics.

These magnetic switches are coded, meaning that a simple magnet cannot be used to bypass the safety switch. A special magnetic-coded actuator is required with this product. Because they are noncontact, they are rugged and withstand mechanical abuse and vibration. See sensing distances and mounting tolerances to find out if they are right for your application.

**See page 154 for Coded Magnetic Safety Interlock Switches wiring and dimensions.**








## Specifications


OFF DISTANCE/ON DISTANCE	70 mm/9 mm	40 mm/7 mm	40 mm/7 mm
MODEL Interlock Switch NUMBER(S) Actuator	VAA-2E1A-IER1-S-1M-V1 VAZ-IER1-ACTUATOR1-S	VAA-2E-IER2-S-1M-V1 VAZ-IER2-ACTUATOR2-S	VAA-2E-IER2-S-0,15M-V1 VAZ-IER2-ACTUATOR2-S
EXTENDED ADDRESSING (62 NODES)	No	No	No
REQUIRED MASTER SPEC	-	-	-
OPERATING VOLTAGE AS-i	26.5-31.6 V	26.5-31.6 V	26.5-31.6 V
OPERATING VOLTAGE V <sub>AUX</sub>	-	-	-
AS-i OPERATING CURRENT	< 30 mA	< 30 mA	< 30 mA
AUXILIARY CURRENT LIMIT	-	-	-
INPUTS	Safety	Safety	Safety
TYPE	Coded magnetic	Coded magnetic	Coded magnetic
SUPPLY VOLTAGE	From AS-Interface	From AS-Interface	From AS-Interface
MECHANICAL ACTIVATIONS	100 x 10 <sup>6</sup>	100 x 10 <sup>6</sup>	100 x 10 <sup>6</sup>
OUTPUTS	-	-	-
SUPPLY VOLTAGE	-	-	-
CURRENT PER OUTPUT	-	-	-
DATA BITS			
D0	Contact 1	Contact 1	Contact 1
D1	Contact 1/LED	Contact 1	Contact 1
D2	Contact 2	Contact 2	Contact 2
D3	Contact 2	Contact 2	Contact 2
PERIPHERAL FAULT BIT	-	-	-
PROFILE S-IO.ID.ID1.ID2	S-7.B.F.E	S-0.B.F.E	S-0.B.F.E
ALLOWABLE LATERAL OFFSET	± 2.5 mm at 3 mm separation	± 2.5 mm at 3 mm separation	± 2.5 mm at 3 mm separation
PROTECTION (IEC)	IP67	IP67	IP67
TEMPERATURE WORKING RANGE	-4 °F to +140 °F (-20 °C to +60 °C)	-4 °F to +140 °F (-20 °C to +60 °C)	-4 °F to +140 °F (-20 °C to +60 °C)
STORAGE	-4 °F to +140 °F (-20 °C to +60 °C)	-4 °F to +140 °F (-20 °C to +60 °C)	-4 °F to +140 °F (-20 °C to +60 °C)
HOUSING MATERIAL	PPS	PPS	PPS
WEIGHT	800 g (27 oz)	405 g (14 oz)	405 g (14 oz)
APPROVALS	CE, UL, TÜV approved up to cat.4 / SIL3, NFPA 79	CE, UL, TÜV approved up to cat.4 / SIL3, NFPA 79	CE, UL, TÜV approved up to cat.4 / SIL3, NFPA 79
AS-INTERFACE CONNECTION	1 m pigtail with M12 quick disconnect	1 m pigtail with M12 quick disconnect	.15 m pigtail with M12 quick disconnect

## Activation Diagrams

VAA-2E1A-IER1-S-1M-V1



VAA-2E-IER2-S-1M-V1  
VAA-2E-IER2-S-,15M-V1



## 154

# RFID Safety Interlock Switches

## Safety Solutions

- Up to 4 safe read heads on one safety module
- No mechanical components to wear out
- Worry-free installation with no alignment issues
- Read heads and tags good for washdown or dirty environments
- Noncontact heads and tags great for high-vibration environments



### RFID Safety Interlock Switches Overview

RFID safety modules are unique because you can choose to connect as few as one read head, or as many as four read heads to one control module. A factory-programmed read-only code is embedded in every RFID tag. During the teach phase of the installation, the tag code is read and associated with a specific read head channel. If any one of the heads does not see the corresponding tag, the module will safely switch to the off state and inform the SafetyMonitors on the network.

RFID read heads and tags are typically used in harsh and dirty environments where other mechanical safety switches would not hold up. Because RFID technology is used, alignment issues are a thing of the

past and the RFID-based solution offers significant improvements in high-vibration environments. Other safety switches can get into states where one of its contacts are closed but the other is not. RFID readers can be off or on and no other intermediate or undetermined conditions are possible.

RFID readers cannot be bypassed or overridden by other noncontact guard switching technologies, making them the safest technology in the industry.

**See pages 157-158 for RFID Safety Interlock Switches wiring and dimensions.**

Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets


Accessories



## Specifications


OFF DISTANCE/ON DISTANCE		32 mm/15 mm
MODEL NUMBER(S)	Controller	VAA-4E-IEI1-CONTROL-J-S
	Read Head	VAZ-IEI1-READER1-S-V3
	Tag	VAZ-IEI1-TAG1-S
EXTENDED ADDRESSING (62 NODES)		No
REQUIRED MASTER SPEC		-
OPERATING VOLTAGE AS-i		22.5-31.6 V
OPERATING VOLTAGE V <sub>AUX</sub>		-
AS-i OPERATING CURRENT		< 130 mA
AUXILIARY CURRENT LIMIT		-
INPUTS		-S Safety
TYPE		RFID, noncontact
SUPPLY VOLTAGE		From AS-Interface
OUTPUTS		-
SUPPLY VOLTAGE		-
DATA BITS	D0	Safe code sequence
	D1	Safe code sequence
	D2	Safe code sequence
	D3	Safe code sequence
	D4	Safe code sequence
PARAMETER BITS (read)	P0	Head 1 tag present/absent
	P1	Head 2 tag present/absent
	P2	Head 3 tag present/absent
	P3	Head 4 tag present/absent
PERIPHERAL FAULT BIT		Read head power overload
PROFILE	S-IO.ID.ID1.ID2	S-0.B.F.E
READ RANGE (see diagram)	On	15 mm (6 mm embedded)
	Off	32 mm (23 mm embedded)
MINIMUM READ DISTANCE		3 mm
PROTECTION (IEC)		IP67 (Read head/tag IP69K)
TEMPERATURE RANGE	WORKING	Controller: +32 °F to +122 °F (0 °C to +50 °C) Read head/tag: -13 °F to +122 °F (-25 °C to +70 °C)
	STORAGE	Controller: +32 °F to +122 °F (0 °C to +50 °C) Read head/tag: -13 °F to +158 °F (-25 °C to +77 °C)
HOUSING MATERIAL		PBT, PPS
WEIGHT		150 g (5.3 oz)
APPROVALS		CE UL TÜV approved up to cat.4 / SIL3 NFPA 79
AS-INTERFACE CONNECTION		Flat yellow cable
I/O CONNECTION		Controller: M12 quick disconnect, Read head: M8 quick disconnect (max. read head to module distance is 25 m)

## Typical operating distance




For a side approach direction for the actuator and read head, a minimum distance of  $s = 3$  mm must be maintained so that the operating distance of the side lobes is not entered.

## Wiring Diagrams



VAA-4E-IEI1-CONTROL-J-S



## LED Indicators

**FAULT:** Red (solid): Communication error or address 0  
Red (flashing): Overload of read head power

**PWR:** Green (solid): AS-Interface powered  
Green (flashing): Address 0


**IN:** Yellow: Tag in front of read head

**OUT/ERROR:** Yellow (solid): Tag in front of all read heads  
Red (solid): Device internal error, less than 0.5 s in detection zone  
Red (solid) with state blinking: Configuration error

**STATE:** Green (solid) with OUT/ERROR Red: tag not in front of all read heads  
Green (solid) with OUT/ERROR Yellow: tag in front of all read heads  
Green (flashing 15 Hz): Self test  
Green (flashing 4 Hz): Ready to teach tag  
Green (flashing 1 Hz): Teaching tag  
Green (flashing 3 times): Configuration error

VAZ-IEI1-READER1-S-V3

Male Receptacle End View




## Read head/Tag teach procedure


1. Disconnect node from AS-Interface, Remove right blank cover and turn DIP switch 1 on.
2. Remove left blank cover and set DIP switches to enable read heads to be used
  - Switch 1 ON = Read head 1 connected
  - Switch 2 ON = Read head 2 connected
  - Switch 3 ON = Read head 3 connected
  - Switch 4 ON = Read head 4 connected
3. Place tags over read heads
4. Connect node to AS-Interface, Wait for 10s self test, and teach to complete.
  - Teach successful: STATE LED blinks 3 times then switches off
  - Teach failed (no tag): Error LED is red, STATE LED is flashing continuously and FAULT/ASI PWR LED's are toggling
5. Disconnect node from AS-Interface and wait 10s. Turn DIP switches off under right blank cover.
6. Connect node to AS-Interface.

## Dimensions (mm)


### VAA-4E-IEI1-CONTROL-J-S



### VAZ-IEI1-READER1-S-V3



### VAZ-IEI1-TAG1-S



## Accessories

### V3-GM-2M-PUR-ABG43-V1-G

2-meter shielded cable for connection of read head to controller.

### V3-GM-5M-PUR-ABG43-V1-G

5-meter shielded cable for connection of read head to controller.



See pages 211-226 for complete AS-Interface accessory listing.



## Enabling Switch Safety Solutions

- Ergonomic, lightweight design
- Connects directly to AS-Interface
- Three switch positions for maximum safety



### Enabling Switch Overview

Enabling switches are unique devices that allow a user to enter a potentially harmful area to do required maintenance without shutting the machine down. The three-position device (OFF-ON-OFF) must be continuously held in the center position to enable machine power. If the user senses an unsafe condition exists they can fully push or release the enabling switch to go to shut down.

Because the enabling switch has its own AS-Interface address, it can be linked to any and all safety zones on the network. When the enabling switch is used with AS-Interface, the speed of the machine is reduced when a user enters the potentially harmful area, further reducing the risk of injury.

This device is particularly useful in robotics applications in conjunction with our 16-channel SafetyMonitor and the safe output modules. The safe output module can be used to locally interface with safe input on the robot, instructing the robot controller to operate at reduced speed.

**See pages 160-161 for Enabling Switch wiring and dimensions.**

Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories




## Specifications

Specifications	
MODEL NUMBER(S)	VAA-3E-HH30-J-S-V1
EXTENDED ADDRESSING (62 NODES)	No
REQUIRED MASTER SPEC	-
OPERATING VOLTAGE AS-i	26.5-31.6 V
OPERATING VOLTAGE V <sub>AUX</sub>	-
AS-i OPERATING CURRENT	< 45 mA
AUXILIARY CURRENT LIMIT	-
INPUTS	-S Safety
TYPE	Enabling switch
SUPPLY VOLTAGE	From AS-Interface
MECHANICAL ACTIVATIONS	1 x 10 <sup>5</sup>
DATA BITS	D0 Contact 1
	D1 Contact 1
	D2 Contact 2
	D3 Contact 2
PERIPHERAL FAULT BIT	-
PROFILE	S-IO.ID1.ID2 S-7.B.F.E
PROTECTION (IEC)	IP67
TEMPERATURE WORKING RANGE	+23 °F to +122 °F (-5 °C to +50 °C)
STORAGE	+23 °F to +122 °F (-5 °C to +50 °C)
HOUSING MATERIAL	PA, Neoprene
WEIGHT	150 g (5.3 oz)
APPROVALS	CE cUL us TÜV approved up to cat.4 / SIL3 NFPA 79
AS-INTERFACE CONNECTION	M12 quick disconnect


## Wiring Diagrams

VAA-3E-HH30-J-S-V1


Male Receptacle End View



## Function of the switching element



Travel diagram




Contacts open  
Contacts closed

E = Switching element  
Φ = Action point




## Dimensions (mm)

VAA-3E-HH30-J-S-V1



## Accessories

VAZ-HH30-BRACKET




See pages 211-226 for complete AS-Interface accessory listing.



Notes

Gateways and Scanners
Power Supplies and Repeaters
I/O Modules
 Safety at Work
Sensors
Cordsets
Accessories



# Intelligent Sensors

<b>Cylindrical Inductive.....</b>	<b>165</b>
<b>Limit Switch Inductive .....</b>	<b>169</b>
<b>Rhino™ Inductive .....</b>	<b>172</b>
<b>Rectangular Inductive .....</b>	<b>174</b>
<b>Valve Positioning Inductive .....</b>	<b>176</b>
<b>Series 28 Photoelectric .....</b>	<b>179</b>
<b>BVS58/BVM58 Series Solid-Shaft Absolute Rotary Encoders.....</b>	<b>188</b>
<b>BSS58/BSM58 Series Hollow-Shaft Absolute Rotary Encoders.....</b>	<b>192</b>

## Intelligent Inductive Sensors

Sensors can be equipped with the AS-Interface chip. Every sensor can be a module on AS-Interface and up to 62 smart sensors can be on the network at one time. Each sensor provides valuable diagnostic information. “Intelligent” sensors are self-monitoring, programmable, and transmit data over the network to a controller. An AS-Interface sensor offers many features that are not available with a standard sensor, such as coil monitoring, precollision, and out of range detection; and all are NO/NC programmable. Additional diagnostic capabilities available with intelligent inductive sensors include the following:

### Normally Open/Normally Closed Programmable

Stocking two sensors is no longer required. With AS-Interface intelligent sensors, OEMs have the opportunity to reduce the number of sensors on a system. Instead of stocking inductive sensors with normally open and normally closed outputs, one intelligent sensor can be used and configured to be normally open or normally closed. Each time the sensor is plugged in, it is automatically configured to the correct setting.

### Prefailure Indication

Prefailure indication is another advanced function offered in some of the Pepperl+Fuchs AS-Interface intelligent inductive sensors. If the target is between 100% and 120% of the sensor’s nominal sensing range, the prefailure bit is reported. When this situation is indicated, users can correct the mounting and/or the misalignment before the target is out of range.

### Precollision Indication

When a target gets too close to an inductive sensor face, a precollision condition is indicated. Users can reposition the sensor so that the target does not hit the sensor. This type of indication can reduce the cost of replacing a standard sensor that was damaged because of misalignment.

### Oscillator Monitoring

Repeated direct contact between sensors and their targets can cause coils and oscillators to stop running. If a sensor without oscillator monitoring stops operating, the PLC receives a failure code only after the target is missed. Using AS-Interface and intelligent sensors, a failure notice is immediately sent to the scanner/gateway in a data bit. The PLC is then notified, and the damaged sensor can be replaced quickly and easily, improving quality and reducing downtime.

### Activation Delay Filter

With activation filtering, all targets present for less than 15 ms will not be transferred to AS-Interface. This eliminates false triggering due to noise, weld fields, and other unforeseen disruptions. When the sensor is programmed for normally open, there is a 15 ms ON delay. When the sensor is programmed for normally closed, there is a 15 ms OFF delay.

There are many housing styles available. All are directly connected to the AS-Interface line, and power and communications run over the same two wires. Pepperl+Fuchs has 12 mm, 18 mm, and 30 mm

cylindrical, limit switch style, rectangular, Rhino, and flat packs for your AS-Interface network.

Intelligent Photoelectric Sensors

In most applications, I/O modules bring sensor inputs back to the AS-Interface scanner/gateway and to the PLC. Modules can have up to 4 inputs (plus additional outputs), and each module takes up a full or a half address. Like modules, intelligent photoelectric sensors also take up a half address. Up to 4 input bits are available to provide valuable diagnostic information.

Additional Diagnostic Capabilities Available With Intelligent Photoelectric Sensors

- Weak signal indication: When photoelectric sensors are used, it is possible to detect a weak signal before the sensor stops working. Maintenance can be performed on an as-needed basis.
- Configurable light ON/dark ON: One intelligent sensor can be used and configured for the light ON/dark ON behavior. Separate sensors are not necessary.

Absolute Rotary Encoders

In automation applications, rotary encoders are used as sensors for angle, position, speed, and acceleration. By using spindles, gear racks, measuring wheels, or cable pulls, linear movements can also be monitored by a rotary encoder. Rotary encoders convert a mechanical rotation value into an electrical signal that can be processed by counters, tachometers, logic controllers, and industrial PCs. Rotary encoders are among the most useful and versatile pieces of equipment available to the automation industry.

Pepperl+Fuchs is proud to offer the industry’s only AS-Interface absolute rotary encoders. Absolute encoders provide a uniquely coded numerical value for each shaft position. They eliminate the need for expensive input components in a positioning

application because they have built-in reference data.

Pepperl+Fuchs AS-Interface rotary encoders use state-of-the-art components and the latest technologies to ensure reliability and a long service life. Additionally, Pepperl+Fuchs encoders feature precision bearings for a long life and low maintenance, with wire connections that are sealed up to IP65. Durable aluminum housings and solid-state circuitry make Pepperl+Fuchs encoders suitable for rugged environments.

Our absolute rotary encoders allow an easy 2-wire connection to AS-Interface and are available in both single- and multi-turn versions. Single-turn absolute encoders divide the shaft into a defined number of steps. The maximum resolution is 13 bits, which means that up to 8192 positions can be defined. By using a multi-step gear, multi-turn absolute encoders not only provide the angular position within a revolution, but also the number of revolutions. Multi-turn encoders have a 16-bit resolution or 65,536 total measuring steps.

Four nodes are used to transmit the 16 bits of data back to the AS-Interface network, and there is an AS-Interface network gateway/scanner available for almost any system. The standard 58 mm housings are available in solid-shaft (BV series) or recessed hollow-shaft (BS series) versions and in a variety of mounting configurations.





## Cylindrical Inductive Proximity Sensors

- Oscillator monitoring
- Programmable normally open/normally closed
- Programmable activation delay filter
- Warning outputs for target too close and too far
- M12 quick disconnect AS-Interface connection

### Cylindrical Sensors Overview

Inductive proximity sensors are inexpensive, durable, resistant to industrial contaminants, and have precise triggering characteristics. They use a high-frequency electromagnetic field to detect metal objects. Their combination of durability, high accuracy, and quick response time makes them an invaluable tool in a wide variety of industries.

Cylindrical sensors are available that allow up to 62 intelligent sensors to be put on one AS-Interface network (2.1 compatible) and then be brought back to a controller. Pepperl+Fuchs offers these sensors in shielded (flush-mounted) or unshielded (nonflush-mounted) versions with sensing ranges from 4 mm to 15 mm in threaded stainless steel housings. All have micro (M12x1) connectors with multiple LEDs, IP67

rating, and all are programmable (normally open/normally closed). Sensor diameters range from 12 mm to 30 mm.

Many of the cylindrical AS-Interface intelligent sensors offer oscillator monitoring, input filtering, and target too close/target too far away outputs.

A specially coated, weld-immune version is available that is specifically designed to prevent weld slag accumulations and operate reliably in harsh welding conditions. The sensor coil system and control circuitry provide excellent protection from the effects of AC electromagnetic fields.

**See pages 166-167 for Cylindrical Sensors wiring and dimensions.**




## Specifications

SENSING RANGE		4 mm	4 mm	5 mm
SHIELDED		Yes	No	Yes
MODEL NUMBER(S)		NCB4-12GM60-B3B-V1	NCN4-12GM60-B3B-C2-V1	NCB5-18GM60-B3B-V1
EXTENDED ADDRESSING (62 NODES)		Yes	Yes	Yes
OPERATING CURRENT		30 mA	30 mA	30 mA
REPEATABILITY		≤ 0.01 mm	≤ 0.01 mm	≤ 0.01 mm
HYSTERESIS		1-15% (5% typical)	1-15% (5% typical)	1-15% (5% typical)
SWITCHING FREQUENCY		500 Hz	500 Hz	100 Hz
WELD FIELD IMMUNE		No	Yes, AC field 100 mT	No
DATA BITS	D0	Sensor output	Sensor output	Sensor output
	D1	Not used	Not used	Target too far away output
	D2	Not used	Not used	Oscillator monitor
	D3	Not used	Not used	Target too close output
PARAMETER BIT	P0	15 ms activation delay on*/off	15 ms activation delay on*/off	15 ms activation delay on*/off
	P1	N.O.*N.C. programming	N.O.*N.C. programming	N.O.*N.C. programming
PROFILE	S-IO.ID.ID1. ID2	S-0.A.7.E	S-0.A.7.E	S-0.A.7.E
PROTECTION (IEC)		IP67	IP67	IP67
TEMPERATURE RANGE	WORKING	-13 °F to +158 °F (-25 °C to +70 °F)	-13 °F to +158 °F (-25 °C to +70 °F)	-13 °F to +158 °F (-25 °C to +70 °F)
	STORAGE	-40 °F to +185 °F (-40 °C to +85 °F)	-40 °F to +185 °F (-40 °C to +85 °F)	-40 °F to +185 °F (-40 °C to +85 °F)
HOUSING MATERIAL		PBT/stainless steel	PBT/stainless steel	PBT/stainless steel
WEIGHT		43 g (1.5 oz)	43 g (1.5 oz)	57 g (2 oz)
APPROVALS		CE 	CE 	CE 
ELECTRICAL CONNECTION		 M12 quick disconnect	 M12 quick disconnect	 M12 quick disconnect


\* Default setting

## Dimensions (mm)


NCB4-12GM60-B3B-V1



NCN4-12GM60-B3B-C2-V1



NCB5-18GM60-B3B-V1



Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com



**PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com




## Specifications

SENSING RANGE		8 mm	15 mm
SHIELDED		No	Yes
MODEL NUMBER(S)		NCN8-18GM60-B3B-V1	NBB15-30GM60-B3B-V1
EXTENDED ADDRESSING (62 NODES)		Yes	Yes
OPERATING CURRENT		30 mA	30 mA
REPEATABILITY		≤ 0.01 mm	≤ 0.01 mm
HYSTERESIS		1-15% (5% typical)	1-15% (5% typical)
SWITCHING FREQUENCY		100 Hz	200 Hz
WELD FIELD IMMUNE		No	No
DATA BITS	D0	Sensor output	Sensor output
	D1	Target too far away output	Not used
	D2	Oscillator monitor	Not used
	D3	Target too close output	Not used
PARAMETER BIT	P0	15 ms activation delay on*/off	15 ms activation delay on*/off
	P1	N.O.*/N.C. programming	N.O.*/N.C. programming
PROFILE	S-I0.ID1.ID2	S-0.A.7.E	S-0.A.7.E
PROTECTION (IEC)		IP67	IP67
TEMPERATURE RANGE	WORKING	-13 °F to +158 °F (-25 °C to +70 °F)	-13 °F to +158 °F (-25 °C to +70 °F)
	STORAGE	-40 °F to +185 °F (-40 °C to +85 °F)	-40 °F to +185 °F (-40 °C to +85 °F)
HOUSING MATERIAL		PBT/stainless steel	Nickel-plated brass
WEIGHT		57 g (2 oz)	142 g (5 oz)
APPROVALS		CE	CE
ELECTRICAL CONNECTION		M12 quick disconnect	M12 quick disconnect


\* Default setting

## Dimensions (mm)

NCN8-18GM60-B3B-V1



NBB15-30GM60-B3B-V1




## Wiring Diagrams



### Quick Disconnect

**Note:** Wiring diagrams show quick disconnect pin numbers

Male Receptacle End View



## Accessories

(Dimensions in mm)

### Universal Bracket Model No. BF 5-30

- Holds inductive, photoelectric, and ultrasonic sensors of all diameters
- Easy installation
- Simple adjustment
- Secure fastening
- Flexible
- Durable




The BF 5-30 handles standard sensor sizes from 5 mm to 30 mm in diameter and provides 360° rotation on 2 axes.


**Model Number**  
BF5-30

### Adjustable Bracket

Brackets are available for cylindrical sensors of all diameters. Made of tough Crastin, the mounting bracket simplifies mounting and sensor adjustment. Order bracket by model number shown.




Model No.	Sensor Diameter	A	B	C	D	E	F	Slot Width	Mounting Screws
BF12	12 mm	24	36	19	12	30	16	4.5 mm	#8-32
BF18	18 mm	30	44	24	18	40	26	5.5 mm	#10-24
BF30	30 mm	40	56	36	30	40	24	5.5 mm	#10-24



### Right Angle Bracket

Angle brackets are available in three diameter sizes and made of stainless steel. Sensors can be adjusted by using lock nuts supplied with sensor. Order by model number shown.



See pages 211-226 for complete AS-Interface accessory listing.

Model No. and Sensor Dia	Sensor Hole Dia	A	B	C	D	E	F	G	Mounting Dia 2 Places	H	I	J	K
AB12 12 mm	(1/2")	12.70 (1-1/4")	31.75 (1-1/4")	15.87 (5/8")	17.46 (11/16")	31.75 (1-1/4")	19.05 (3/4")	6.35 (1/4")	4.76 (3/16")	25.40 (1")	5.56 (7/32")	3.17 (1/8")	
AB18 18 mm	(3/4")	19.05 (3/4")	34.92 (1-3/8")	17.46 (11/16")	19.84 (25/32")	38.10 (1-1/2")	22.22 (7/8")	6.35 (1/4")	4.76 (3/16")	25.40 (1")	5.56 (7/32")	3.17 (1/8")	
AB30 30 mm	(1-7/32")	30.96 (2")	50.80 (2")	25.40 (1")	36.91 (1-29/64")	63.50 (2-1/2")	31.75 (1-1/4")	9.52 (3/8")	6.35 (1/4")	38.10 (1-1/2")	9.52 (3/8")	3.17 (1/8")	

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com



**PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com



## Limit Switch Inductive Proximity Sensors

- 5-way rotatable head
- Easy AS-Interface connection with terminal compartment
- Oscillator monitoring
- Normally open/normally closed programmable
- Programmable activation delay filter


### Limit Switch Sensors Overview

AS-Interface limit switch inductive sensors mount in the same footprint as traditional mechanical limit switches. Their sensing ranges extend from 20 mm to 40 mm. External power connections are made through a terminal compartment, and all are normally open/normally closed programmable.





All intelligent limit switch sensors are 2.1 compatible, and offer oscillator monitoring and input filtering. The 20 mm limit switch (NBB20+U1+B3B) is available in a shielded version and may be flush mounted. The NBN30+U1+B3B and the NBN40+U1+B3B are unshielded versions and cannot be flush mounted.

The housing of the sensor is made of PBT, which is resistant to abrasion and has excellent mechanical properties. Additionally, these limit switch sensors have a sensing face that is rotatable to any one of five positions, from front to top, to both sides, and to bottom.

**See page 170 for Limit Switch Sensors wiring and dimensions.**



## Specifications

SENSING RANGE		20 mm	40 mm
SHIELDED		Yes	No
MODEL NUMBER(S)		NBB20-U1-B3B	NBN40-U1-B3B
EXTENDED ADDRESSING (62 NODES)		Yes	Yes
OPERATING CURRENT		30 mA	30 mA
REPEATABILITY		≤ 0.01 mm	≤ 0.01 mm
HYSTERESIS		1-15% (5% typical)	1-15% (5% typical)
SWITCHING FREQUENCY		150 Hz	150 Hz
WELD FIELD IMMUNE		No	No
DATA BITS	D0	Sensor output	Sensor output
	D1	Not used	Not used
	D2	Oscillator monitor	Oscillator monitor
	D3	Not used	Not used
PARAMETER BIT	P0	15 ms activation delay on*/off	15 ms activation delay on*/off
	P1	N.O.*/N.C. programming	N.O.*/N.C. programming
PROFILE	S-IO.ID1.ID2	S-0.A.7.E	S-0.A.7.E
PROTECTION (IEC)		IP68	IP68
TEMPERATURE RANGE	WORKING	-13 °F to +158 °F (-25 °C to +70 °F)	-13 °F to +158 °F (-25 °C to +70 °F)
	STORAGE	-40 °F to +185 °F (-40 °C to +85 °F)	-40 °F to +185 °F (-40 °C to +85 °F)
HOUSING MATERIAL		PBT	PBT
WEIGHT		200 g (7 oz)	200 g (7 oz)
APPROVALS		CE 	CE 
ELECTRICAL CONNECTION		 Terminal housing	 Terminal housing

\* Default setting

## Dimensions (mm)

### Wiring Diagrams





#### Terminal Connection

Normally Open or  
Normally Closed



NBB20-U1-B3B  
NBN40-U1-B3B






## Accessories

(Dimensions in mm)

### Adjustable Unistrut® Bracket

The adjustable Unistrut type mounting bracket is especially designed for the limit switch style sensors and can be adjusted up to 20 mm along the Y axis. It can be rotated 360° in increments of 1.87° and fits into the Unistrut. The bracket can be moved along the X axis to the full length of the Unistrut. The bracket is furnished with four M5x20 mm screws and two headless screws. The Unistrut mounting track can be ordered in lengths of 2 feet.


To order, specify model number **MH4-2681 UNI**.



### Adjustable Slide Bracket

With this bracket, the completely mounted and wired sensor can be moved up to 30 mm. When the M5-16 mm sensor mounting screws are loosened, the sensor can be moved back and forth easily. This allows precise adjustment of the sensing point. The sensor can be secured in the proper position by tightening the mounting screws. The bracket is made of aluminum to resist corrosion.

To order, specify model number **MH4-2057**.



**VAZ-T1-FK-M20**  
Flat cable to M20x1.5 adapter



See pages 211-226 for complete AS-Interface accessory listing.

# Rhino™

## Inductive Proximity Sensors

- 25-position rotating head
- Oscillator monitoring
- Normally open/normally closed programmable
- Programmable activation delay filter
- M12 quick disconnect AS-Interface connection



### Rhino Sensors Overview

The popular Rhino series uses a durable, die-cast metal mounting bracket. Rhinos feature a “Quick-Pivot” sensing head, allowing tool-free configuration of the sensing face to any position. Rhino models offer sensing ranges and mounting footprints identical to inductive limit switches, but require only 1/3 the mounting space.

All of our intelligent Rhino sensors are 2.1 compatible, and offer oscillator monitoring, input filtering, and are normally open/normally closed programmable. The Rhino has a sensing range up to 30 mm. The 20 mm Rhino (NBB20-L2-B3B-V1) is available in a shielded version and may be flush mounted. The NBN30-L2-B3B-V1 and the NBN40-L2-B3B-V1 are unshielded versions and cannot be flush mounted.

**See page 173 for Rhino Sensors wiring and dimensions.**




## Specifications

SENSING RANGE		20 mm	30 mm	40 mm
SHIELDED		Yes	No	No
MODEL NUMBER(S)		NBB20-L2-B3B-V1	NBN30-L2-B3B-V1	NBN40-L2-B3B-V1
EXTENDED ADDRESSING (62 NODES)		Yes	Yes	Yes
OPERATING CURRENT		30 mA	30 mA	30 mA
REPEATABILITY		≤ 0.01 mm	≤ 0.01 mm	≤ 0.01 mm
HYSTERESIS		1-15% (5% typical)	1-15% (5% typical)	1-15% (5% typical)
SWITCHING FREQUENCY		100 Hz	100 Hz	100 Hz
WELD FIELD IMMUNE		No	No	No
DATA BITS	D0	Sensor output	Sensor output	Sensor output
	D1	Not used	Not used	Not used
	D2	Oscillator monitor	Oscillator monitor	Oscillator monitor
	D3	Not used	Not used	Not used
PARAMETER BIT	P0	15 ms activation delay on*/off	15 ms activation delay on*/off	15 ms activation delay on*/off
	P1	N.O.*/N.C. programming	N.O.*/N.C. programming	N.O.*/N.C. programming
PROFILE S-IO.ID1.ID2		S-O.A.7.E	S-O.A.7.E	S-O.A.7.E
PROTECTION (IEC)		IP67	IP67	IP67
TEMPERATURE RANGE	WORKING	-13 °F to +158 °F (-25 °C to +70 °F)	-13 °F to +158 °F (-25 °C to +70 °F)	-13 °F to +158 °F (-25 °C to +70 °F)
	STORAGE	-40 °F to +185 °F (-40 °C to +85 °F)	-40 °F to +185 °F (-40 °C to +85 °F)	-40 °F to +185 °F (-40 °C to +85 °F)
HOUSING MATERIAL		PBT	PBT	PBT
WEIGHT		150 g (5 oz)	150 g (5 oz)	150 g (5 oz)
APPROVALS		CE	CE	CE
ELECTRICAL CONNECTION		M12 quick disconnect	M12 quick disconnect	M12 quick disconnect

\* Default setting

## Dimensions (mm)

NBB20-L2-B3B-V1  
NBN30-L2-B3B-V1  
NBN40-L2-B3B-V1




## Wiring Diagrams



### Quick Disconnect

**Note:** Wiring diagrams show quick disconnect pin numbers



See pages 211-226 for complete AS-Interface accessory listing.

Subject to modifications without notice

Pepperl+Fuchs Group USA: +1 330 486 0001  
www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

## Rectangular Inductive Proximity Sensors

- Mounting holes in small flat housing
- Oscillator monitoring
- Normally open/normally closed programmable
- 2 m PVC cable for AS-Interface connection



### Rectangular Sensors Overview




Pepperl+Fuchs offers a compact surface-mount AS-Interface intelligent sensor that is only 12 mm thick, yet offers all of the features available in sensors twice the size. The NBB6-F-B3B offers oscillator monitoring, input filtering, and all are programmable (normally open/normally closed). This sensor is a shielded version and may be flush mounted. It has a protection rating of IP67.

The sensor's housing is made of PBT, which retains its dimensional stability. This rugged material is resistant to abrasion, has excellent mechanical properties, and exceptional resistance to chemicals, oils, fats, and most aqueous media.

**See page 175 for Rectangular Sensors wiring and dimensions.**




## Specifications

SENSING RANGE		6 mm
SHIELDED		Yes
MODEL NUMBER(S)		NBB6-F-B3B
EXTENDED ADDRESSING (62 NODES)		Yes
OPERATING CURRENT		20 mA
REPEATABILITY		≤ 0.01 mm
HYSTERESIS		1-15% (5% typical)
SWITCHING FREQUENCY		≥ 500 (P3=0), ≥ 100 (P3=1)
WELD FIELD IMMUNE		No
DATA BITS	D0	Sensor output
	D1	Not used
	D2	Oscillating monitor
	D3	Not used
PARAMETER	P0	10 ms activation delay on*/off
BIT	P1	NO*/NC programming
PROFILE	S-IO.ID1.ID2	S-0.A.7.E
PROTECTION (IEC)		IP67
TEMPERATURE WORKING RANGE		-13 °F to +158 °F (-25 °C to +70 °F)
STORAGE		-40 °F to +185 °F (-40 °C to +85 °F)
HOUSING MATERIAL		PBT
WEIGHT		90 g (3 oz)
APPROVALS		 
ELECTRICAL CONNECTION		 2-meter cable, PVC covered, 2-conductor, #24AWG

\* Default setting

## Dimensions (mm)

NBB6-F-B3B




## Wiring Diagrams



### Cable Connection

Normally Open or  
Normally Closed



See pages 211-226 for complete  
AS-Interface accessory listing.

## Valve Positioning Inductive Proximity Sensors

- 2 integrated sensors and AS-Interface powered solenoid driver
- Lead breakage and short-circuit monitoring of the solenoid
- LED indication for inputs and output




### Valve Positioning Overview

Discrete position sensors offer valve position and AS-Interface all in a single housing. Units are available that allow up to 62 intelligent valve position indicators can be put on one AS-Interface network (2.1 compatible) and then be brought back to a controller.

This is a dual inductive sensor and solenoid driver used to indicate and control valve position. This dual sensor uses two screws to mount directly on the quarter-turn valve and requires no additional adjustment. It connects to the AS-Interface with a micro (M12x1) quick disconnect. The D1 data bit monitors the solenoid for lead breakage and short circuit. Yellow LEDs display the current switch conditions. A dual LED displays the current solenoid status and error indication.

**See page 177 for Valve Positioning wiring and dimensions.**





## Specifications

NUMBER OF INPUTS		3 mm	3 mm
SHIELDED		Yes	Yes
MODEL NUMBER(S)		NCN3-F31-B3B-V1-K	NCN3-F31-B3B-V1-V1
EXTENDED ADDRESSING (62 NODES)		Yes	Yes
OPERATING CURRENT		50-150 mA	50-150 mA
REPEATABILITY		≤ 0.01 mm	≤ 0.01 mm
HYSTERESIS		1-15% (5% typical)	1-15% (5% typical)
SWITCHING FREQUENCY		100 Hz	100 Hz
WELD FIELD IMMUNE		No	No
OUTPUTS (SOLENOID DRIVER)			
SUPPLY VOLTAGE		from AS-Interface	from AS-Interface
POWER		2.5 W	2.5 W
DATA BITS	D0	Solenoid driver output	Solenoid driver output
	D1	Leak breakage/ short-circuit solenoid driver	Leak breakage/ short-circuit solenoid driver
	D2	Sensor 1	Sensor 1
	D3	Sensor 2	Sensor 2
PARAMETER BIT	P0	Watchdog on*/off	Watchdog on*/off
	P1	N.O./N.C.* programming sensor 1	N.O./N.C.* programming sensor 1
	P2	N.O./N.C.* programming sensor 2	N.O./N.C.* programming sensor 2
PROFILE S-I.O.ID.ID1.ID2		S-D.A.7.E	S-D.A.7.E
PROTECTION (IEC)		IP67	IP67
TEMPERATURE RANGE	WORKING	-13 °F to +158 °F (-25 °C to +70 °F)	-13 °F to +158 °F (-25 °C to +70 °F)
	STORAGE	-40 °F to +185 °F (-40 °C to +85 °F)	-40 °F to +185 °F (-40 °C to +85 °F)
HOUSING MATERIAL		PBT	PBT
WEIGHT		150 g (5 oz)	150 g (5 oz)
APPROVALS		CE 45	CE 45
ELECTRICAL CONNECTION		M12 quick disconnect and 500 mm cable for solenoid driver	M12 quick disconnect

\* Default setting

## Wiring Diagrams




### Quick Disconnect


Note: Wiring diagrams show quick disconnect pin numbers

#### NCN3-F31-B3B-V1-K

##### Male Receptacle End View




##### Solenoid Driver Output:




#### NCN3-F31-B3B-V1-V1

##### Male Receptacle End View




##### Female Receptacle End View

##### Solenoid Driver Output:




## Dimensions (mm)

#### NCN3-F31-B3B-V1-K



#### NCN3-F31-B3B-V1-V1



Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

178



## Series 28 Photoelectric Sensors

- Extreme low temperature operation (-40 °C/F) available
- Status LEDs visible from 15 m (50')
- Extended addressing with up to 62 addresses




### Diffuse Mode with Background Suppression

See page 180

**Features:**

- Sharp sensing range cut-off
- Thru-hole or dovetail mounting

**Sensing Ranges:** 700 mm



### Retroreflective Mode

See page 181

**Features:**

- Reliable detection of even the shiniest material
- Weak signal output available

**Sensing Ranges:** 17 m, 30 m




### Retroreflective Mode with Foreground Suppression

See page 182

**Features:**

- Glossy targets not erroneously identified as the reflector up to 200 mm away
- Reliable detection of shrink-wrapped pallets

**Sensing Range:** 13 m



### Thru-beam Mode





See page 183

**Features:**



- Alignment LED visible through lens for faster setup
- Laser light source for long-range sensing


**Sensing Range:** 300 m

## Diffuse Mode with Background Suppression

Specifications	
<b>SENSING RANGE</b>	20-700 mm
<b>SENSITIVITY ADJUSTMENT</b>	Yes
<b>MODEL NUMBER(S)</b>	RL28-8-H-700-RT-B3B/73c
<b>OUTPUT</b> -B3B	AS-Interface
<b>SUPPLY VOLTAGE</b>	from AS-Interface
<b>LED(s)</b>	Yes (3)
<b>OPERATING MODE</b>	Light ON/dark ON
<b>RESPONSE TIME</b>	≤ 2 ms
<b>TIMER FUNCTION</b>	One-shot (50 ms) through AS-Interface
<b>SWITCHING FREQUENCY</b>	250 Hz
<b>STANDARDS</b>	EN 60947-5-2
<b>PROTECTION (IEC)</b>	IP67
<b>LIGHT SPOT DIAMETER</b>	≈ 15 mm at a range of 700 m
<b>LIGHT BEAM ANGLE</b>	< 1.2° emitter/< 2° receiver
<b>LIGHT SOURCE</b>	Visible red LED 660 nm
<b>AMBIENT LIGHT RESISTANCE</b>	≤ 50,000 lux
<b>TEMPERATURE WORKING RANGE</b>	-40 °F to +140 °F (-40 °C to +60 °C)
<b>STORAGE</b>	-40 °F to +167 °F (-40 °C to +75 °C)
<b>HOUSING MATERIAL</b>	ABS
<b>LENS</b>	Plastic
<b>WEIGHT</b>	2.5 oz
<b>APPROVALS</b>	  
<b>ELECTRICAL CONNECTION</b>	 M12 quick disconnect

## Sensing Characteristics









## Retroreflective Mode

Specifications	Laser*	
<b>SENSING RANGE</b>	0-17 m	0-30 m
<b>SENSITIVITY ADJUSTMENT</b>	Yes	Yes
<b>REFLECTOR DISTANCE</b>	50 mm-17 m	300 mm-30 m
<b>POLARIZED FILTER</b>	Yes	Yes
<b>MODEL NUMBER(S)</b>	RL28-55-B3B/73c	RL28-55-LAS-B3B/73c
<b>OUTPUT</b> -B3B	AS-Interface	AS-Interface
<b>SUPPLY VOLTAGE</b>	from AS-Interface	from AS-Interface
<b>VOLTAGE RIPPLE</b>	—	≤ 10%
<b>LED(s)</b>	Yes (3)	Yes (3)
<b>OPERATING MODE</b>	Light ON/dark ON	Light ON/dark ON
<b>RESPONSE TIME</b>	≤ 0.5 ms	≤ 0.5 ms
<b>TIMER FUNCTION</b>	One-shot (50 ms) through AS-Interface	One-shot (50 ms) through AS-Interface
<b>SWITCHING FREQUENCY</b>	1 kHz	1 kHz
<b>EMITTER FREQUENCY</b>	≈ 6-20 kHz	≈ 6-20 kHz
<b>STANDARDS</b>	EN 60947-5-2	EN 60947-5-2
<b>PROTECTION (IEC)</b>	IP67	IP67
<b>LIGHT SPOT DIAMETER</b>	≈ 290 mm at a range of 17 m	≈ 45 mm at a range of 30 m
<b>LIGHT BEAM ANGLE</b>	< 1.2° emitter < 2° receiver	< 0.1° emitter < 2° receiver
<b>LIGHT SOURCE</b>	Visible red LED 660 nm	Visible red laser 650 nm Class 1
<b>AMBIENT LIGHT RESISTANCE</b>	≤ 80,000 lux	≤ 50,000 lux
<b>TEMPERATURE WORKING RANGE</b>	-40 °F to +140 °F (-40 °C to +60 °C)	+14 °F to +122 °F (-10 °C to +50 °C)
<b>STORAGE</b>	-40 °F to +167 °F (-40 °C to +75 °C)	-4 °F to +167 °F (-20 °C to +75 °C)
<b>HOUSING MATERIAL</b>	ABS	ABS
<b>LENS</b>	Plastic	Plastic
<b>WEIGHT</b>	2.5 oz	2.8 oz
<b>APPROVALS</b>	CE, UL, ATEX	CE, UL, ATEX
<b>ELECTRICAL CONNECTION</b>	M12 quick disconnect	M12 quick disconnect





\*Microstructure corner-cube reflectors are recommended with laser retroreflective mode sensors.

## Sensing Characteristics



## Retroreflective Mode with Foreground Suppression


### Specifications

<b>SENSING RANGE</b>	<b>200 mm-13 m</b>	
<b>SENSITIVITY ADJUSTMENT</b>	Yes	
<b>FOREGROUND SUPPRESSION RANGE</b>	0-200 mm	
<b>REFLECTOR DISTANCE</b>	500 mm-13 m	
<b>POLARIZED FILTER</b>	Yes	
<b>MODEL NUMBER(S)</b>	<b>RL28-55-V-B3B/73c</b>	
<b>OUTPUT</b>	<b>-B3B</b>	AS-Interface
<b>SUPPLY VOLTAGE</b>	from AS-Interface	
<b>VOLTAGE RIPPLE</b>	10%	
<b>LED(s)</b>	Yes (3)	
<b>OPERATING MODE</b>	Light ON/dark ON	
<b>RESPONSE TIME</b>	≤ 0.5 ms	
<b>TIMER FUNCTION</b>	One-shot (50 ms) through AS-Interface	
<b>SWITCHING FREQUENCY</b>	1 kHz	
<b>STANDARDS</b>	EN 60947-5-2	
<b>PROTECTION (IEC)</b>	IP67	
<b>LIGHT SPOT DIAMETER</b>	≈ 220 mm at a range of 13 m	
<b>LIGHT BEAM ANGLE</b>	1.2° emitter/2° receiver	
<b>LIGHT SOURCE</b>	Visible red LED	
<b>AMBIENT LIGHT RESISTANCE</b>	≤ 80,000 lux	
<b>TEMPERATURE WORKING RANGE</b>	-40 °F to +140 °F (-40 °C to +60 °C)	
<b>STORAGE</b>	-40 °F to +167 °F (-40 °C to +75 °C)	
<b>HOUSING MATERIAL</b>	ABS	
<b>LENS</b>	Plastic	
<b>WEIGHT</b>	2.5 oz	
<b>APPROVALS</b>	  	
<b>ELECTRICAL CONNECTION</b>	 M12 quick disconnect	

### Sensing Characteristics


Excess Gain vs. Sensing Range

RL28-55-V



Movement Characteristics

RL28-55-V










## Thru-beam Mode

Specifications		Laser*
<b>SENSING RANGE</b>		0-300 m
<b>SENSITIVITY ADJUSTMENT</b>		Yes
<b>MODEL NUMBER(S)</b>	<b>Emitter</b>	LD28-LAS-F1-B3B/73c
	<b>Receiver</b>	LV28-LAS-F1-B3B/73c
<b>OUTPUT</b>		-B3B AS-Interface
<b>SUPPLY VOLTAGE</b>		from AS-Interface
<b>LED(s)</b>		Yes (3) plus alignment LED
<b>OPERATING MODE</b>		Light on/dark on
<b>RESPONSE TIME</b>		≤ 0.5 ms
<b>TIMER FUNCTION</b>		One-shot (50 ms) through AS-Interface
<b>SWITCHING FREQUENCY</b>		1 kHz
<b>EMITTER FREQUENCY</b>		F1=25 kHz
<b>STANDARDS</b>		NEMA ICS5-2000
<b>PROTECTION (IEC)</b>		IP67
<b>LIGHT SPOT SIZE</b>		≈ 1 x 4.5 mm at a range of 0.1 m, ≈ 6 mm at a range of 5 m, ≈ 75 x 300 mm at a range of 300 m (parallel to housing)
<b>LIGHT BEAM ANGLE</b>		0.06° emitter/5° receiver
<b>LIGHT SOURCE</b>		Visible red laser 650 nm Class 2
<b>AMBIENT LIGHT RESISTANCE</b>		≤ 50,000 lux
<b>TEMPERATURE RANGE</b>	<b>WORKING</b>	+14 °F to +122 °F (-10 °C to +50 °C)
	<b>STORAGE</b>	-4 °F to +167 °F (-20 °C to +75 °C)
<b>HOUSING MATERIAL</b>		ABS
<b>LENS</b>		Plastic
<b>WEIGHT</b>		2.8 oz per housing
<b>APPROVALS</b>		CE, UL, and other safety symbols
<b>ELECTRICAL CONNECTION</b>		M12 quick disconnect

\*Microstructure corner-cube reflectors are recommended with laser retroreflective mode sensors.

## Sensing Characteristics



# CAUTION



LASER RADIATION—  
DO NOT STARE INTO BEAM

650 nm LASER LIGHT  
1 mW PEAK POWER

PRODUCT CONFORMS TO 21CFR1040  
CLASS II LASER PRODUCT


AVOID EXPOSURE – Laser radiation  
is emitted from this aperture

## Wiring Diagrams



### Quick Disconnect

**Note:** Wiring diagrams show  
quick disconnect pin numbers



## AS-Interface Programming

Address preset to 00; can be changed via the master or with a handheld addressing device.

Addresses 1A-31A and 1B-31B are available.

IO-Code 3

ID-Code A

ID2 1

### Data bits

Bit	Function	Description
D0	switch output	0 = no light received (with P1=1), 0=light received (with P1=0) 1 = no light received (with P1=0), 1=light received (with P1=1)
D1*	weak signal output	0 = alarm 1 = no alarm
D2	test input	0 = emitter active 1 = emitter deactivated
D3	not used	

### Parameter bits

Bit	Function (1/0)	
P0	not used	
P1	light ON/dark ON mode	(0=dark ON, 1=light ON)
P2	50 ms one shot timer	(0=timer on, 1=timer off)
P3	not used	

\* not used for RL28-8-H models

## Dimensions (mm)

RL28-8-H-700-RT-B3B/73c


RL28-55-B3B/73c

RL28-55-LAS-B3B/73c

RL28-55-V-B3B/73c

LD28-LAS-F1-B3B/73c

LV28-LAS-F1-B3B/73c



Emitter models have LED Green: Power only

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs

Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com



**PEPPERL+FUCHS**  
SENSING YOUR NEEDS


Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

## Accessories

(Dimensions in mm)


## Mounting Bracket Model OMH-RL25

## Right angle mounting bracket




### Mounting Bracket Model OMH-21-T

High-profile right angle mounting bracket




### Dovetail Mounting Clamp Model OMH-MLV11-K




## Mounting Bracket Model OMH-21

Right angle mounting bracket



### Mounting Bracket Model OMH-RL2-H

Hinged right angle mounting bracket




**See pages 211-226 for complete AS-Interface accessory listing.**

## Accessories (cont.)

(Dimensions in mm)

### Mounting Bracket Model OMH-RL2-S


Protective shroud bracket with 360° rotatability half clamp



Material: Stainless steel shroud, nickel-plated zinc half clamp, zinc-plated steel screws and nuts.


## Reflectors

### Thru-hole




#### FE-RR1

Round, corner-cube reflector  
Temperature range -4 °F to +150 °F




#### REF-H32

Rectangular, corner-cube reflector  
Temperature range -4 °F to +185 °F



#### REF-H51x72

Rectangular, corner-cube reflector  
Temperature range -4 °F to +140 °F



#### REF-H100


Square, corner-cube reflector  
Temperature range -4 °F to +158 °F

Reflectors continued on next page...

## Accessories (cont.)


(Dimensions in mm)

### Self Adhesive




#### REF-A35

Round, corner-cube reflector  
Temperature range -4 °F to +150 °F



#### REF-A25


Round, corner-cube reflector  
Temperature range -4 °F to +150 °F



Precut, corner-cube reflective tape.  
Reflective tapes can be cut. 150' rolls are available. Contact Pepperl+Fuchs.  
Temperature range -40 °F to 180 °F


MODEL	H	L
RT1 X 100	1.0"	100"
RT1 X 2	1.0"	2.0"
RT2 X 100	2.0"	100"
RT3 X 100	3.0"	100"

### Microstructure




#### REF-MA21

Round, microstructure, corner-cube reflector. Self-adhesive mounting.  
Temperature range -4 °F to +185 °F




#### REF-MH23

Rectangular, microstructure corner-cube reflector. Through-hole mounting.  
Temperature range -4 °F to +185 °F




#### REF-MH20

Square, microstructure corner-cube reflector. Through-hole mounting.  
Temperature range -4 °F to +185 °F



#### REF-MH50

Square, microstructure corner-cube reflector. Through-hole mounting.  
Temperature range -4 °F to +185 °F



#### REF-MH78

Rectangular, microstructure, corner-cube reflector. Through-hole mounting.  
Temperature range -4 °F to +185 °F

See pages 211-226 for complete AS-Interface accessory listing.

# BVS58/BVM58 Series Absolute Rotary Encoders

- Industrial standard 58 mm diameter housing
- Single or multiturn
- Uses 4 AS-Interface slaves
- IP65
- Servo flange and 6 mm shaft or clamping flange and 10 mm shaft



Pepperl+Fuchs' BVS58 and BVM58 series absolute encoders communicate via AS-Interface. They are available in either single turn with 13-bit resolution, or multi turn with 16-bit resolution versions. The position value is output to the master within a single cycle via the 4 integrated AS-Interface chips. Each slave address can be individually set. These encoders are rated IP65 and feature a rugged aluminum housing.

## Order Code

**BV 58N- AVR0NN-**

Type  
S Single-turn  
M Multi-turn

### Shaft option/flange style

011 Ø 10 mm x 20 mm with clamping flange  
032 Ø 6 mm x 10 mm with servo flange

Resolution	Single-turn		Multi-turn	
	Number of Revolutions	Steps per Revolutions	Number of Revolutions	Steps per Revolutions
0013	1	8192	0313	8
			0412	16
			0511	32
			0610	64
			0709	128
			0808	256
			0907	512
			1006	1024
			1105	2048
			1204	4096

Example: BVS58N-032AVR0NN-0013

## Technical Specifications

### Electrical

SUPPLY VOLTAGE	29.5-31.6 VDC
CURRENT CONSUMPTION	Starting ≤ 155 mA
	Operational ≤ 65 mA
OUTPUT CODE	Programmable gray or binary
LINEARITY	±1 LSB
COUNTING DIRECTION (Shaft End View)	Programmable
INTERFACE	Type AS-Interface
	Transfer rate ≤ 0.167 MBaud
RESOLUTION	Bits/steps per turn 13-bit / ≤ 8192
	Bits/number of turns 12-bit / ≤ 4096
OVERALL RESOLUTION	Single turn 13-bit
	Multi turn 16-bit
STANDARD CONFORMITY	AS-Interface
CERTIFICATES	CE

### Mechanical

MATERIAL	Housing	Powder-coated aluminum
	Flange	Aluminum
	Shaft	Stainless steel
	Code disc	Glass
WEIGHT	BVS58	≈ 12 oz
	BVM58	≈ 13 oz
ROTATIONAL SPEED	BVS58	≤ 12,000 rpm
	BVM58	≤ 6,000 rpm
MOMENT OF INERTIA		≤ 4.3 x 10 <sup>-4</sup> oz-in-sec <sup>2</sup>
STARTING TORQUE AT 20 °C		≤ 2.1 in-oz
SHAFT LOADING	Axial - BVS	9.8 lbs at 12,000 rpm
		BVM 40 lbs at 6,000 rpm
	Radial - BVS	13.3 lbs at 12,000 rpm
		BVM 40 lbs at 6,000 rpm
BEARING WORKING LIFE		> 4 x 10 <sup>6</sup> revolutions

### Environmental

STORAGE TEMPERATURE	-25 °C to +85 °C (-13 °F to +185 °F)
OPERATING TEMPERATURE	-20 °C to +70 °C (-4 °F to +158 °F)
HUMIDITY	98% RH non-condensing
SHOCK RESISTANCE	100 g for 3 ms
VIBRATION RESISTANCE	10 g, 10-2,000 Hz
ENCLOSURE RATING	IP65

### Connection Types


CONNECTOR	Type V1, M12, 4-Pin
-----------	---------------------





## Dimensions

mm (in.)



## Electrical Connection

Signal	Type V1, 4-pin quick disconnect	Description
AS-i +	1	
Reserved*	2	Not wired
AS-i -	3	
Reserved*	4	Not wired

\*Pins 2 and 4 **MUST** not be wired to the auxiliary power. Encoder will be damaged.

## Programming

### Addresses

	Slave A	Slave B	Slave C	Slave D
Preset address	1	2	3	4
IO code	7	0	0	0
ID code	F	F	F	F



When using an AS-Interface master or handheld programmer to change the slave addresses, it is absolutely essential to assign a different address to each of the four slaves.

### Parameter Bits

The four parameter bits of slave A are used to set the parameters of the encoder. The parameter bits of slave B, C, and D are not used.

Status of parameter bit	Slave A			
	P0	P1	P2	P3
0	Gray code	Transfer with flag bits	Count down with clockwise rotation	Not used
1	Binary code	Transfer without flag bits	Count up with clockwise rotation	Not used

### Data Bits

#### From the AS-Interface master to the encoder

Data from the AS-Interface master is transferred to the encoder via slave A, which works bidirectionally. Slaves B, C, and D operate unidirectionally and can only send data.

When data bits D2 and D3 are changed from 01 to 10 or vice versa, the position data is saved in the encoder.

Status of D0/D1 or D2/D3	Slave A	
	D0/D1	D2/D3
00	Normal mode	Position data is not saved
01	Rotary encoder is set to 1/4 of the single-turn resolution	Position data is saved
10	Rotary encoder is set to 0	Position data is saved
11	Normal mode	Position data is not saved

#### From the encoder to the AS-Interface master

Parameter bit P1 of slave A is used to determine if the encoder transfers data to the AS-Interface master with or without flag bits.

P1 = 1: Transfer without flag bits

Slave A				Slave B				Slave C				Slave D			
D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3
Bit 0	Bit 1	Bit 2	Bit 3	Bit 4	Bit 5	Bit 6	Bit 7	Bit 8	Bit 9	Bit 10	Bit 11	Bit 12	Not used!		

P1 = 0: Transfer with flag bits MA, MB, MC, MD

Slave A				Slave B				Slave C				Slave D			
D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3
Bit 0	Bit 1	Bit 2	MA	Bit 0	Bit 1	Bit 2	MB	Bit 0	Bit 1	Bit 2	MC	Bit 0	Bit 1	Bit 2	MD

## Programming (continued)

### Operating Modes

#### Address assignments for the four slaves

The AS-Interface master accesses all slaves sequentially within an AS-Interface cycle to transfer output data to slave A or to read input data from the slaves. The single-turn absolute encoder uses four AS-Interface chips to transfer a position of 13 bits using 4 slave addresses.

These four slaves are queried sequentially and data can originate from any one of four different sampling times. To minimize this effect, sequential addresses (n, n+1, n+2, and n+3) should be assigned to slaves A, B, C, and D.

In addition, slave A is responsible for controlling the encoder's functions. If the order of slaves is changed (D=n, C=n+1, B=n+2, A=n+3), the output word, which is supposed to be transmitted by the function control module of the absolute encoder, will not be transmitted until slaves D, C, and B have been read in. A memory command would then take effect only for slave A. The command would not affect the slaves that had already been read until the next read cycle. This change of slave order will result in data inconsistency.

#### Temporary storage and transfer with flag bits

If any data from the rotary encoder is interrupted during transmission, it is possible that some of the data transferred to the controller originates from a different position in the data word. The controller can check the data integrity for a single data word by comparing the four flag bits. Each slave can transfer one flag bit, making it possible for the control module to check which position data set an individual data set belongs to by comparing the 4 bits. Data bit D2 is used for this purpose. Using the flag bits reduces the size of the usable data from 16 bits to 12 bits.

Cycle	Slave A Data bit D2	Position data			
		Slave A	Slave B	Slave C	Slave D
1	0	XXX0	XXX0	XXX0	XXX0
2	1	XXX1	XXX1	XXX1	XXX1
3	0	XXX0	XXX0	XXX0	XXX0
4	1	XXX1	XXX1	XXX1	XXX1
etc.					

See pages 211-226 for complete AS-Interface accessory listing.

# BSS58/BSM58 Series Absolute Rotary Encoders

- Industrial standard 58 mm diameter housing
- Single or multiturn
- Uses 4 AS-Interface slaves
- IP65
- 10 mm or 12 mm recessed hollow shaft



Pepperl+Fuchs' BSS58 and BSM58 series absolute encoders feature recessed hollow shafts and communicate via AS-Interface. Available in either single turn with 13-bit resolution, or multiturn with 16-bit resolution versions. The position value is output to the master within a single cycle via the 4 integrated AS-Interface chips. Each slave address can be individually set. These encoders are rated IP65 and feature a rugged aluminum housing.

## Order Code

**BS 58N- AVR0NN-**

Type  
S Single-turn  
M Multi-turn

### Shaft option

01A Ø 10 mm x 21 mm recessed hollow shaft  
02A Ø 12 mm x 21 mm recessed hollow shaft

Resolution	Number of Revolutions	Steps per Revolutions
Single-turn		
0013	1	8192
Multi-turn		
0313	8	8192
0412	16	4096
0511	32	2048
0610	64	1024
0709	128	512
0808	256	256
0907	512	128
1006	1024	64
1105	2048	32
1204	4096	16

Example: BVS58N-032AVR0NN-0013

## Technical Specifications

### Electrical

SUPPLY VOLTAGE	29.5-31.6 VDC
CURRENT CONSUMPTION	Starting ≤ 155 mA Operational ≤ 65 mA
OUTPUT CODE	Programmable gray or binary
LINEARITY	±1 LSB
COUNTING DIRECTION (Shaft End View)	Programmable
INTERFACE	Type AS-Interface Transfer rate ≤ 0.167 MBaud
RESOLUTION	Bits/steps per turn 13-bit / ≤ 8192 Bits/number of turns 12-bit / ≤ 4096
OVERALL RESOLUTION	Single turn 13-bit Multi turn 16-bit
STANDARD CONFORMITY	AS-Interface
CERTIFICATES	CE

### Mechanical

MATERIAL	Housing Powder-coated aluminum Flange Aluminum Shaft Stainless steel Code disc Glass
WEIGHT	≈ 12 oz
ROTATIONAL SPEED	BSS58 ≤ 10,000 rpm BSM58 ≤ 6,000 rpm
MOMENT OF INERTIA	≤ 4.3 x 10 <sup>-4</sup> oz-in-sec <sup>2</sup>
STARTING TORQUE AT 20 °C	≤ 2.1 in-oz
SHAFT LOADING	Angle offset 1° Axial offset ≤ 1 mm
BEARING WORKING LIFE	> 4 x 10 <sup>10</sup> revolutions

### Environmental

STORAGE TEMPERATURE	-25 °C to +85 °C (-13 °F to +185 °F)
OPERATING TEMPERATURE	-20 °C to +70 °C (-4 °F to +158 °F)
HUMIDITY	98% RH non-condensing
SHOCK RESISTANCE	100 g for 3 ms
VIBRATION RESISTANCE	10 g, 10-2,000 Hz
ENCLOSURE RATING	IP65


### Connection Types

CONNECTOR	Type V1, M12, 4-Pin
-----------	---------------------




## Dimensions

mm (in.)



	Dimension X	Dimension Y
Single-turn	67 (2.64)	41 (1.61)
Multi-turn	94 (3.70)	68 (2.68)

## Electrical Connection


Signal	Type V1, 4-pin quick disconnect	Description
AS-i +	1	
Reserved*	2	Not wired
AS-i -	3	
Reserved*	4	Not wired
		

\*Pins 2 and 4 MUST not be wired to the auxiliary

## Programming

### Addresses

	Slave A	Slave B	Slave C	Slave D
Preset address	1	2	3	4
IO code	7	0	0	0
ID code	F	F	F	F

 When using an AS-Interface master or handheld programmer to change the slave addresses, it is absolutely essential to assign a different address to each of the four slaves.

### Parameter Bits

The four parameter bits of slave A are used to set the parameters of the encoder. The parameter bits of slave B, C, and D are not used.

Status of parameter bit	Slave A			
	P0	P1	P2	P3
0	Gray code	Transfer with flag bits	Count down with clockwise rotation	Not used
1	Binary code	Transfer without flag bits	Count up with clockwise rotation	Not used

### Data Bits

#### From the AS-Interface master to the encoder

Data from the AS-Interface master is transferred to the encoder via slave A, which works bidirectionally. Slaves B, C, and D operate unidirectionally and can only send data.

When data bits D2 and D3 are changed from 01 to 10 or vice versa, the position data is saved in the encoder.

Status of D0/D1 or D2/D3	Slave A	
	D0/D1	D2/D3
00	Normal mode	Position data is not saved
01	Rotary encoder is set to 1/4 of the single-turn resolution	Position data is saved
10	Rotary encoder is set to 0	Position data is saved
11	Normal mode	Position data is not saved

#### From the encoder to the AS-Interface master

Parameter bit P1 of slave A is used to determine if the encoder transfers data to the AS-Interface master with or without flag bits.

P1 = 1: Transfer without flag bits

Slave A				Slave B				Slave C				Slave D			
D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3
Bit 0	Bit 1	Bit 2	Bit 3	Bit 4	Bit 5	Bit 6	Bit 7	Bit 8	Bit 9	Bit 10	Bit 11	Bit 12	Not used!		

P1 = 0: Transfer with flag bits MA, MB, MC, MD

Slave A				Slave B				Slave C				Slave D			
D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3
Bit 0	Bit 1	Bit 2	MA	Bit 0	Bit 1	Bit 2	MB	Bit 0	Bit 1	Bit 2	MC	Bit 0	Bit 1	Bit 2	MD



## Programming (continued)

### Operating Modes

#### Address assignments for the four slaves

The AS-Interface master accesses all slaves sequentially within an AS-Interface cycle to transfer output data to slave A or to read input data from the slaves. The single-turn absolute encoder uses four AS-Interface chips to transfer a position of 13 bits using 4 slave addresses.

These four slaves are queried sequentially and data can originate from any one of four different sampling times. To minimize this effect, sequential addresses (n, n+1, n+2, and n+3) should be assigned to slaves A, B, C, and D.

In addition, slave A is responsible for controlling the encoder's functions. If the order of slaves is changed (D=n, C=n+1, B=n+2, A=n+3), the output word, which is supposed to be transmitted by the function control module of the absolute encoder, will not be transmitted until slaves D, C, and B have been read in. A memory command would then take effect only for slave A. The command would not affect the slaves that had already been read until the next read cycle. This change of slave order will result in data inconsistency.

#### Temporary storage and transfer with flag bits

If any data from the rotary encoder is interrupted during transmission, it is possible that some of the data transferred to the controller originates from a different position in the data word. The controller can check the data integrity for a single data word by comparing the four flag bits. Each slave can transfer one flag bit, making it possible for the control module to check which position data set an individual data set belongs to by comparing the 4 bits. Data bit D2 is used for this purpose. Using the flag bits reduces the size of the usable data from 16 bits to 12 bits.

Cycle	Slave A Data bit D2	Position data			
		Slave A	Slave B	Slave C	Slave D
1	0	XXX0	XXX0	XXX0	XXX0
2	1	XXX1	XXX1	XXX1	XXX1
3	0	XXX0	XXX0	XXX0	XXX0
4	1	XXX1	XXX1	XXX1	XXX1
etc.					

See pages 211-226 for complete AS-Interface accessory listing.



Notes

Gateways and Scanners

Power Supplies and  
Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories



# Cordsets

<b>Micro Cordsets .....</b>	<b>198</b>
<b>Micro Extension Cables .....</b>	<b>197</b>
<b>3-Pin Micro Extension Cables .....</b>	<b>200</b>
<b>3-Pin Crossed Micro Extension Cables .....</b>	<b>201</b>
<b>Crossed Micro Adapter .....</b>	<b>202</b>
<b>Adapter Cables for Analog Modules .....</b>	<b>203</b>
<b>4-Pin Nano-to-Micro Adapter Cables .....</b>	<b>204</b>
<b>Nano Extension Cables .....</b>	<b>205</b>
<b>Micro Dual-Port Junction Blocks .....</b>	<b>206</b>
<b>Micro Network Splitters.....</b>	<b>209</b>

## Cordsets

To simplify your installation, Pepperl+Fuchs offers a complete line of Nano and Micro cordsets along with extension cables in a wide variety of protective jacket options to ensure reliable operation in mechanically and chemically abusive environments.

Tough, heavy-duty, oil- and weather-resistant PVC and PUR cable jackets provide superior protection and ensure a safe connection. Oil, water, metal shavings, grime, and other common contaminants cannot penetrate the molded, one-piece connector head and cable. Integrated cable stress relief allows cables to withstand heavy flexing and physical abuse without decreasing cable life.


# Micro Cordsets

12 mm receptacle  
DC sensor compatibility

- Single key
- Gray PVC cable jacket
- #22 AWG
- Female or male connection
- 4- and 5-pin




Male



## Dimensions (mm)

Female



## Specifications

Specifications	
<b>MATERIAL DATA</b>	
MOLDED HEAD	Green TPU
INSERT	PUR
CABLE TYPE	Gray, flexible PVC jacket
CONTACTS	Machined copper and tin over gold
CONTACT PLATING	Copper and tin over nickel
SHELL	N/A
WIRE GAUGE	#22 AWG
COUPLING NUT	Copper and tin over nickel
CABLE OUTER DIAMETER	4.5 mm
<b>ELECTRICAL DATA</b>	
CONTACT RESISTANCE	≤ 5 mΩ
ELECTRICAL ISOLATION	1500 VAC
CURRENT RATING	4 A
VOLTAGE RATING (4/5 pole)	300 VDC/60 VDC
<b>ENVIRONMENT DATA</b>	
PROTECTION CLASSES	IP68/69K
TEMPERATURE RANGE	-13 °F to +212 °F

## Model Number Selection

Face View (female)	Color Code	Length (m)	Female Straight	Female Right Angle	Male Straight	Male Right Angle
	1. Brown 2. White 3. Blue 4. Black 5. Not used	2 5 10 15 20	V1-G-2M-PVC V1-G-5M-PVC V1-G-10M-PVC V1-G-15M-PVC V1-G-20M-PVC	V1-W-2M-PVC V1-W-5M-PVC V1-W-10M-PVC V1-W-15M-PVC V1-W-20M-PVC	V1S-G-2M-PVC V1S-G-5M-PVC V1S-G-10M-PVC	V1S-W-2M-PVC V1S-W-5M-PVC V1S-W-10M-PVC
	1. Brown 2. White 3. Blue 4. Black 5. Gray	2 5 10	V15-G-2M-PVC V15-G-5M-PVC V15-G-10M-PVC	V15-W-2M-PVC V15-W-5M-PVC V15-W-10M-PVC	V15S-G-2M-PVC V15S-G-5M-PVC V15S-G-10M-PVC	

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs

Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com



**PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

## Specifications



Specifications	
<b>MATERIAL DATA</b>	
BODY	Green TPU
INSERT	PUR
CABLE TYPE	Gray, flexible PVC or PUR jacket
CONTACTS	Machined copper and tin over gold
CONTACT PLATING	Copper and tin over nickel
SHELL	N/A
WIRE GAUGE	#22 AWG
COUPLING NUT	Copper and tin over nickel
CABLE OUTER DIAMETER	4.5 mm
<b>ELECTRICAL DATA</b>	
CONTACT RESISTANCE	≤ 5 mΩ
ELECTRICAL ISOLATION	1500 VAC
CURRENT RATING	4 A
VOLTAGE RATING	250 VDC
<b>ENVIRONMENT DATA</b>	
PROTECTION CLASSES	IP68
TEMPERATURE RANGE	-40 °F to +176 °F

## Micro Extension Cables

- Single key
- Gray PVC or PUR (halogen-free) cable jacket
- #22 AWG
- Male to female
- Straight or right angle heads
- 4-pin



## Dimensions (mm)



## Model Number Selection

Face View (female)	Color Code	Length (m)	Female Straight to Male Straight	Female Straight to Male Right Angle	Female Right Angle to Male Straight
	1. Brown 2. White 3. Blue 4. Black 5. Not used	2 5 10	V1-G-2M-PVC-V1-G V1-G-5M-PVC-V1-G V1-G-10M-PVC-V1-G	V1-G-2M-PVC-V1-W V1-G-5M-PVC-V1-W V1-G-10M-PVC-V1-W	V1-W-2M-PVC-V1-G V1-W-5M-PVC-V1-G V1-W-10M-PVC-V1-G
		2 5 10 0.5 to 2.5 (coiled)	V1-G-2M-PUR-V1-G V1-G-5M-PUR-V1-G V1-G-10M-PUR-V1-G V1-G-0.5/2.5M-PUR-V1-G	V1-G-2M-PUR-V1-W V1-G-5M-PUR-V1-W V1-G-10M-PUR-V1-W	V1-W-2M-PUR-V1-G V1-W-5M-PUR-V1-G V1-W-10M-PUR-V1-G V1-W-0.5/2.5M-PUR-V1-G

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.comUSA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.comGermany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.comCopyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
 SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

# 3-Pin Micro Extension Cables


- Single key
- Gray PVC (halogen-free) cable jacket
- #22 AWG
- Male to female
- Straight heads
- 3-pin




## Specifications

Specifications	
<b>MATERIAL DATA</b>	
BODY	Green TPU
INSERT	PUR
CABLE TYPE	Gray, flexible PVC jacket
CONTACTS	Machined copper and tin over gold
CONTACT PLATING	Copper and tin over nickel
SHELL	N/A
WIRE GAUGE	#22 AWG
COUPLING NUT	Copper and tin over nickel
CABLE OUTER DIAMETER	4.5 mm
<b>ELECTRICAL DATA</b>	
CONTACT RESISTANCE	≤ 5 mΩ
ELECTRICAL ISOLATION	1500 VAC
CURRENT RATING	4 A
VOLTAGE RATING	250 VDC
<b>ENVIRONMENT DATA</b>	
PROTECTION CLASSES	IP68
TEMPERATURE RANGE	-40 °F to +176 °F

## Dimensions (mm)



Male



Female



## Model Number Selection

Face View (female)	Color Code	Length (m)	Female Straight to Male Straight
	1. Brown 2. Not used 3. Blue 4. Black 5. Not used	1	V11-G-1M-PVC-V11-G
		2	V11-G-2M-PVC-V11-G
		3	V11-G-3M-PVC-V11-G
		4	V11-G-4M-PVC-V11-G
		5	V11-G-5M-PVC-V11-G
		6	V11-G-6M-PVC-V11-G
		7	V11-G-7M-PVC-V11-G
		8	V11-G-8M-PVC-V11-G
		10	V11-G-10M-PVC-V11-G



## Specifications


Specifications	
<b>MATERIAL DATA</b>	
BODY	Green TPU
INSERT	PUR
CABLE TYPE	Gray, flexible PVC jacket
CONTACTS	Machined copper and tin over gold
CONTACT PLATING	Copper and tin over nickel
SHELL	N/A
WIRE GAUGE	#22 AWG
COUPLING NUT	Copper and tin over nickel
CABLE OUTER DIAMETER	4.5 mm
<b>ELECTRICAL DATA</b>	
CONTACT RESISTANCE	≤ 5 mΩ
ELECTRICAL ISOLATION	1500 VAC
CURRENT RATING	4 A
VOLTAGE RATING	250 VDC
<b>ENVIRONMENT DATA</b>	
PROTECTION CLASSES	IP68
TEMPERATURE RANGE	-40 °F to +176 °F

## 3-Pin Crossed Micro Extension Cables


- Single key
- Gray PVC (halogen-free) cable jacket
- #22 AWG
- Male to female
- Right angle heads
- 3-pin



## Dimensions (mm)




Male



Female



## Wiring Diagram



## Model Number Selection

Face View (female)	Color Code	Length (m)	Female Right Angle to Male Right Angle	Face View (male)	Color Code
	1. Brown 2. Black 3. Blue 4. Not used 5. Not used	2 5	V1-W-42-2M-PVC-V11-W V1-W-42-5M-PVC-V11-W		1. Brown 2. Not used 3. Blue 4. Black 5. Not used

## Specifications


MATERIAL DATA	
BODY	Clear PA
INSERT	
CONTACTS	Machined copper and tin over gold
CONTACT PLATING	Copper and tin over nickel
WIRE GAUGE	#22 AWG
COUPLING NUT	Aluminum
ELECTRICAL DATA	
CONTACT RESISTANCE	≤ 5 mΩ
ELECTRICAL ISOLATION	1500 VAC
CURRENT RATING	4 A
VOLTAGE RATING	250 VDC
ENVIRONMENT DATA	
PROTECTION CLASSES	IP67
TEMPERATURE RANGE	-13 °F to +176 °F

## Crossed Micro Adapter


- Single key
- Pins 2 and 4 crossed
- Attaches directly to any sensor and crosses the output pins



## Dimensions (mm)



## Wiring Diagram



## Model Number Selection

Face View (female)	Color Code	Length (m)	Female Straight to Straight	Face View (male)	Color Code
	1. Brown 2. Black 3. Blue 4. White		<b>V1-G-V1-Y904948</b>		1. Brown 2. White 3. Blue 4. Black

# Adapter Cables for Analog Modules


- Single key
- Shielded
- Ground jumpered automatically
- Straight and crossover versions available



## Specifications


Specifications	
<b>MATERIAL DATA</b>	
BODY	Green TPU
INSERT	PUR
CABLE TYPE	Gray, flexible PUR jacket (shielded 90% coverage)
CONTACTS	Machined copper and tin over gold
CONTACT PLATING	Copper and tin over nickel
SHELL	N/A
WIRE GAUGE	#22 AWG
COUPLING NUT	Copper and tin over nickel
CABLE OUTER DIAMETER	4.5 mm
<b>ELECTRICAL DATA</b>	
CONTACT RESISTANCE	≤ 5 mΩ
ELECTRICAL ISOLATION	1500 VAC
CURRENT RATING	4 A
VOLTAGE RATING	250 VDC
<b>ENVIRONMENT DATA</b>	
PROTECTION CLASSES	IP68
TEMPERATURE RANGE	-40 °F to +176 °F

## Dimensions (mm)




## Wiring Diagram

V1-G-0,3...



V1-G-42-0,3...



## Model Number Selection

Face View (female)	Color Code	Length (m)	Female Straight to Male Right Angle	Face View (male)	Color Code
	1. Brown 2. White 3. Blue 4. Black 5. Not used		V1-G-0,3M-PUR-ABG-V1-W-Y V1-G-42-0,3M-PUR-ABG-V1-W-Y		1. Brown 2. White/Black 3. Blue 4. Black 5. Shield

# 4-Pin Nano-to-Micro Adapter Cables


- Single key
- Gray PVC or PUR (halogen-free) cable jacket
- #22 AWG
- Male to female
- Straight or right angle heads




## Specifications

Specifications	
<b>MATERIAL DATA</b>	
<b>BODY</b>	Green TPU
<b>INSERT</b>	PUR
<b>CABLE TYPE</b>	Gray, flexible PVC or PUR jacket
<b>CONTACTS</b>	Machined copper and tin over gold
<b>CONTACT PLATING</b>	Copper and tin over nickel
<b>SHELL</b>	N/A
<b>WIRE GAUGE</b>	#22 AWG
<b>COUPLING NUT</b>	Copper and tin over nickel
<b>CABLE OUTER DIAMETER</b>	4.5 mm
<b>ELECTRICAL DATA</b>	
<b>CONTACT RESISTANCE</b>	≤ 5 mΩ
<b>ELECTRICAL ISOLATION</b>	1500 VAC
<b>CURRENT RATING</b>	4 A
<b>VOLTAGE RATING</b>	250 VDC
<b>ENVIRONMENT DATA</b>	
<b>PROTECTION CLASSES</b>	IP68
<b>TEMPERATURE RANGE</b>	-40 °F to +176 °F


## Dimensions (mm)




Male



Female



## Wiring Diagram (...-42... models)



## Model Number Selection

Face View (female)	Color Code	Length (m)	Female Straight to Male Straight	Face View (male)	Color Code
	1. Brown 2. White 3. Blue 4. Black	0.1	<b>V31-GM-0.1M-PUR-V1-G</b>		1. Brown 2. White 3. Blue 4. Black 5. Not used
Face View (female)	Color Code	Length (m)	Female Straight to Male Right Angle	Face View (male)	Color Code
	1. Brown 2. White 3. Blue 4. Not used	2	<b>V31-GM-42-2M-PVC-V11-W</b>		1. Brown 2. Not used 3. Blue 4. Black 5. Not used

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.comUSA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.comGermany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.comCopyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
 SENSING YOUR NEEDS


Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

## Specifications


MATERIAL DATA	
BODY	Green TPU
INSERT	PUR
CABLE TYPE	Gray, flexible PUR jacket
CONTACTS	Machined copper and tin
CONTACT PLATING	Gold
SHELL	N/A
WIRE GAUGE	#22 AWG
COUPLING NUT	Die-cast zinc
CABLE OUTER DIAMETER	4.8 mm
ELECTRICAL DATA	
CONTACT RESISTANCE	≤ 5 mΩ
ELECTRICAL ISOLATION	1500 VAC
CURRENT RATING	4 A
VOLTAGE RATING	60 VDC
ENVIRONMENT DATA	
PROTECTION CLASSES	IP68
TEMPERATURE RANGE	-22 °F to +212 °F

## Nano Extension Cables

- Single key
- Gray PUR cable jacket
- #24 AWG
- Male to female
- 3-pin
- Straight connection



## Model Number Selection

Face View (female)	Color Code	Length (m)	Female Straight to Male Straight
	1. Brown 3. Blue 4. Black	1 2 5 10	V3-GM-1M-PUR-V3-GM V3-GM-2M-PUR-V3-GM V3-GM-5M-PUR-V3-GM V3-GM-10M-PUR-V3-GM

# Micro Dual-Port Junction Blocks

## 12 mm receptacle


- Single key
- PVC cable jacket
- #18 AWG
- 4-pin




### Specifications

Specifications	
<b>MATERIAL DATA</b>	
MOLDED HEAD	Yellow TPU
CABLE OUTER JACKET	Irradiated PUR
CONTACTS	Brass (nickel & gold plated)
CONTACT CARRIER	TPU with 20% glass fiber
COUPLING NUT	Nickel-plated die-cast zinc
WIRE GAUGE	22 AWG
CABLE OUTER DIAMETER	5.2 mm
<b>ELECTRICAL DATA</b>	
NOMINAL CURRENT	3 A
RATED VOLTAGE	300 V
CONTACT RESISTANCE	≤ 5 mΩ
<b>ENVIRONMENT DATA</b>	
PROTECTION CLASSES	IP68/IP69K
TEMPERATURE RANGE	-40 °F to +176 °F

### Dimensions (mm)



### Wiring Diagram



### Model Number Selection

Face View (female)	Color Code	Length (m)	Model Number
	1. Brown 2. White 3. Blue 4. Black 5. Not Used	.3	V1-G-.3M-T-0M-V1-G

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.comUSA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.comGermany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.comCopyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
 SENSING YOUR NEEDS


Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com




## Specifications

Specifications	
<b>MATERIAL DATA</b>	
CONNECTOR	TPU
CONTACTS	Brass (nickel & gold plated)
CONTACT CARRIER	TPU with 20% glass fiber
COUPLING NUT	Nickel-plated die-cast zinc
<b>ELECTRICAL DATA</b>	
NOMINAL CURRENT	3 A
RATED VOLTAGE	24 V
CONTACT RESISTANCE	≤ 5 mΩ
<b>ENVIRONMENT DATA</b>	
PROTECTION CLASSES	IP67
TEMPERATURE RANGE	-13 °F to +194 °F


## Dimensions (mm)



## Wiring Diagram



## Model Number Selection

Face View (female)	Color Code	Model Number
	1. Brown 2. White 3. Blue 4. Black 5. Gray	V15S-TV15

# Micro Dual-Port Junction Blocks

## 12 mm receptacle

- Single key
- For dual-input multiport junction blocks
- 5-pin
- Pins 2 and 4 bridged

## Specifications


MATERIAL DATA	
CONNECTOR	TPU
CONTACTS	Brass (nickel & gold plated)
CONTACT CARRIER	TPU with 20% glass fiber
COUPLING NUT	Nickel-plated die-cast zinc
ELECTRICAL DATA	
NOMINAL CURRENT	3 A
RATED VOLTAGE	24 V
CONTACT RESISTANCE	≤ 5 mΩ
ENVIRONMENT DATA	
PROTECTION CLASSES	IP67
TEMPERATURE RANGE	-13 °F to +194 °F

## Micro Dual-Port Junction Blocks


### 12 mm receptacle

- Single key
- For dual-input multiport junction blocks


## Dimensions (mm)



## Wiring Diagram



## Model Number Selection

Face View (female)	Color Code	Model Number
	1. Brown 2. White 3. Blue 4. Black	V11S-T-V11

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.comUSA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.comGermany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.comCopyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
 SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

# Micro Network Splitters

## 12 mm receptacle

- Single key
- One male input and two female outputs
- 5-pin




### Specifications


Specifications	
<b>MATERIAL DATA</b>	
CONNECTOR	TPU
CONTACTS	Brass (nickel & gold plated)
CONTACT CARRIER	TPU with 20% glass fiber
COUPLING NUT	Nickel-plated die-cast zinc
<b>ELECTRICAL DATA</b>	
NOMINAL CURRENT	3 A
RATED VOLTAGE	24 V
CONTACT RESISTANCE	≤ 5 mΩ
<b>ENVIRONMENT DATA</b>	
PROTECTION CLASSES	IP67
TEMPERATURE RANGE	-13 °F to +194 °F

### Dimensions (mm)


V15S-TEE-V15




V15S-YEE-V15



### Wiring Diagram



### Model Number Selection

Face View (female)	Color Code	Model Number
	1. Brown 2. White 3. Blue 4. Black 5. Gray	V15S-TEE-V15 V15S-YEE-V15

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.comUSA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.comGermany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.comCopyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

## Notes

Gateways and Scanners

Power Supplies and  
Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories



# Accessories

## Accessories

Pepperl+Fuchs offers a complete line of accessories for your AS-Interface network—everything from cordsets and connectors to AS-Interface flat cable and module bases. As a guarantee of our quality, our products are produced according to the ISO 9001 International Standard and carry all of the national and international certifications and registrations. That means that every Pepperl+Fuchs product, from a part as simple as a wiring tee to a handheld AS-Interface addressing device, will meet the demands of your most challenging applications, no matter where you are.

Whether it is for a replacement component or a complete AS-Interface system, Pepperl+Fuchs has the right part and the right solution. Get the parts you need at Pepperl+Fuchs.

<b>Handheld Programmer .....</b>	<b>210</b>
<b>Software and Cables .....</b>	<b>211</b>
<b>Diagnostic Tools .....</b>	<b>212</b>
<b>Master Simulators.....</b>	<b>213</b>
<b>AS-Interface Terminator and Tuner.....</b>	<b>214</b>
<b>Bases .....</b>	<b>215</b>
<b>AS-Interface Cable .....</b>	<b>216</b>
<b>Flat Cable Adapters and Splitters.....</b>	<b>217</b>
<b>Bulkhead Connectors, Cordgrips, and Conduit Adapters.....</b>	<b>220</b>
<b>Covers and Mounting Accessories.....</b>	<b>221</b>
<b>AC Input Accessories.....</b>	<b>222</b>
<b>Passive and Protected Tees .....</b>	<b>223</b>
<b>PROFIBUS Accessories .....</b>	<b>224</b>


## Handheld Programmer

The handheld programmer can be used to program any I/O module on the network. It can also be used as a diagnostic tool to read the slave profile, set parameters, read inputs, and set outputs.

Model	Description
<b>VBP-HH1-V3.0-KIT-110V</b>	Handheld programmer in case with four programming cables and power supply. All cables listed here are included.
<b>VBP-HH1-V3.0-110V</b>	Handheld programmer
<b>VAZ-PK-1,5M-V1-G</b>	Cable to connect handheld to module with programming jack. All G2, G12, KE, KE1, KE2, PM, and A type bases support this cable.
<b>V1-G-2M-PVC-V1-G</b>	Cable to connect handheld to module with male M12 quick disconnect, 2m long. All G16, photoeyes, cylindrical inductive, F85A, and L2 type modules use this cable.
<b>V1S-G-2M-PVC</b>	Cable with flying leads to connect programmer to devices with only AS-Interface terminal connections (e.g., CB1 module)
<b>VAZ-9VDC-CHRG-115V</b>	Replacement battery charger
<b>VAZ-PK-FK-0,2M-V1-W</b>	Cable for addressing all G10 I/O modules



VBP-HH1-V3.0-KIT-110V



- 1 AS-Interface +
- 2 reserved (do not connect)
- 3 AS-Interface -
- 4 reserved (do not connect)
- 5 reserved (do not connect)




9 VDC

### Specifications

<b>PROTECTION (IEC)</b>	IP20	
<b>TEMPERATURE RANGE</b>	Working	32 °F to +104 °F (0 °C to +40 °C)
	Storage	-4 °F to +104 °F (-20 °C to +40 °C)

Dimensions in mm



VBP-HH1-V3.0-110V



VAZ-PK-1,5M-V1-G



VAZ-PK-FK-0,2M-V1-W

V1-G-2M-PVC-V1-G



V1S-G-2M-PVC



### Buttons

- ↑ : Moves up to select options like data, address, and parameter
- ↓ : Moves down to select options like data, address, and parameter
- PRG:** Sets address, temporarily sets parameter, sets ID1 code, sets outputs
- ADR:** Searches for AS-Interface slaves, reads inputs, turns programmer on, scans network
- MODE:** Selects between mode of operation (ADDR, ID, IO, ID1, ID2, PERI, PARA, Data)

### Modes of Operation

- ADDR:** Reads all AS-Interface addresses on network, program AS-Interface node address.
- ID:** Reads ID code of selected address.
- IO:** Reads IO code of selected address.
- ID1:** Reads ID1 code of selected address. This code can also be written.
- ID2:** Reads ID2 code of selected address.
- PERI:** Shows the state of the peripheral fault bit sent by the AS-Interface master.
- PARA:** Reads and writes parameters of selected address, all parameter setting is temporary.
- DATA:** Reads inputs and sets outputs on the selected address.

### Display

Shows addresses 1-29, 1-29a, 1-29b, all modes of operation, 2-7 segment display for data read/write.

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com



**PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com



## Software and Cables

All Pepperl+Fuchs software need only be purchased one time. As newer versions are available and features are added, an updated copy can be sent from the factory to you free of charge. The Control Tools software includes all cables required to connect to the K20 AS-Interface gateways. Extra cable is required when using this software with the Compact I/O or ControlLogix cards.

### Control Tools Software and Cables

#### Features

- Configuration screen to set up network
- Diagnostic counters for network troubleshooting
- Fault detector shows extra diagnostics
- Address Assistant to aid in configuring nodes
- Safety monitor diagnostic interface
- Stand-alone control programming/simulating tool (Gateways must support it or have purchased VAZ-CTR unlock code.)

VAZ-SIMON+-R2-1.8M-PS/2



Model	Description
<b>VAZ-SW-ACT32</b>	Control Tools diagnostic and configuration software for all gateways except SST-ASI-SLC. RS232 cable for all K20, K30, and K31 gateways included.
<b>K-ADP2 RPI</b>	Cable required to use Control Tools with ControlLogix (VBM-CLX-DM) or Compact I/O (VBM-MLX/CPLX) cards

### Safety Software and Cables

#### Features

- Easy Programming of e-stops, light curtains, and gate switches
- OR, AND, Logic devices available
- On delay and Off delay safe time functions
- Supports safe coupling to other networks
- Supports debounced safety contacts
- Up to 16 (K30, K31), 8 (KE) safe output channels
- Device index assignment
- Selection of 1 or 3 simulated slaves
- Start via standard or safety slave, monitor input, or automatic
- Safety devices with local acknowledge and startup test
- Immediate stop or on time delay for safe shutdown



VAZ-SW-SIMON+

VAZ-SIMON-RJ45



VAZ-SIMON-USB



VAZ-SIMON-R2

Model	Description
<b>VAZ-SIMON-USB</b>	USB programming cables for all KE safety monitors
<b>VAZ-SIMON-R2</b>	RS232 programming cable for all K12 safety monitors
<b>VAZ-SIMON+-R2-1,8M-PS/2</b>	RS232 programming and diagnostic cable with PS/2 on one side and DB9 on other. Used for all K20, K30, K31 gateways with RS232 port.
<b>VAZ-SIMON-RJ45</b>	Cable to connect two K12 monitors together in the event one has failed. Automatically transfers data from unpowered failed monitor to replacement monitor. Replacement monitor must be new or have program that is not validated.
<b>VAZ-SW-SIMON+</b>	Safety software for use with all safety monitors.

## Diagnostic Tools

The network analyzer is used to determine the quality of the network. It is an indispensable tool for diagnosing problems and troubleshooting the network. Two modes of operation allow you to get online statistics to gauge the health of the network or trace the network to look at individual AS-Interface transactions. Kit includes analyzer, USB to serial adapter, screwdriver, and software.

### Analyzer Features

- RS232 connection for PC
- Trigger input, 24 V
- Output signal 5 VDC
- Statistical mode for easy health status of network
- Advanced trace mode for details of traffic analysis

Model	Description
VAZ-ANALYZER	AS-Interface network analyzing tool ensures that the network is routed and wired correctly during installation.



### Analyzer Specifications

OPERATING CURRENT		70 mA
POWER SUPPLY		from AS-Interface
AS-i CONNECTOR		Terminals
MEMORY		256,000 AS-Interface telegrams
PROTECTION (IEC)		IP20
TEMPERATURE RANGE	Working	+32 °F to +131 °F (0 °C to +55 °C)
	Storage	-13 °F to +158 °F (-25 °C to +70 °C)

There are two modes of operation. The first is "online statistics," where the overall health of the network is read. The second is "trace mode," where individual AS-i telegrams are recorded, filtered, and viewed for later analysis. This mode is often used to track down specific input, output, or timing problems.

### Online Statistics

Advance statistics (check for)

- Little or no missing telegrams.
- No slave telegrams without master call.

Consecutive errors

- Make sure consecutive errors are kept to a minimum. (6x = configuration error)

Network overview

- Check to make sure all connected nodes are green.

I/O data

- Verify that the input and output data is correct.
- Find out if a certain input is flickering or turning on for a short time by running a trace on that input.

Single Slave/N-Slaves				B-Slaves			
Master Tel	Missing	Master Tel	Missing	Master Tel	Missing	Master Tel	Missing
0	16	18040	0	1	16		
1	17	18039	0	2	17		
2	18	18039	0	3	18		
3	19	18039	0	4	19		
4	20	18039	0	5	20		
5	21			6	21		
6	22			7	22		
7	23			8	23		
8	24			9	24		
9	18039	0	25	10	25		
10	18039	0	26	11	26		
11	18039	0	27	12	27		
12	18040	0	28	13	28		
13	18040	0	29	14	29		
14	18040	0	30	15	30		
15	18040	0	31				

UAS-Interface: 31 DV Cycle Time: 2.22 ms  
Slave Telegrams without Master Call: 0 Measuring Time: 00:00:47

## Master Simulators

These simulators can emulate or convert a network like DeviceNet, PROFIBUS, or RS485 for easy connection to your PC. These devices can be useful when trying to see how the I/O is mapped or exchanged on the network, or as a simple diagnostic tool to make sure the upper-level bus connection on the gateway is still functioning. These can be used with any PROFIBUS, DeviceNet or RS485 device like RFID controllers, I/O modules, network couplers, encoders, or any device that can connect to the network. The DeviceNet and PROFIBUS simulators also come with a simple software package and convenient drivers for use with a PC. If using AS-Interface gateways, Control Tools software must also be purchased separately.

### DeviceNet Specifications

<b>OPERATING CURRENT</b>	< 60 mA
<b>POWER SUPPLY</b>	5 V from USB
<b>MAX CABLE LENGTH</b>	< 2 m DeviceNet
<b>DEVICENET CONNECTOR</b>	9-pin D-sub connector
<b>BAUD RATES SUPPORTED</b>	125, 250, or 500 kbps
<b>TEMPERATURE RANGE</b>	Working: +32 °F to +131 °F (0 °C to +55 °C) Storage: -13 °F to +158 °F (-25 °C to +70 °C)

### PROFIBUS Specifications


<b>OPERATING CURRENT</b>	< 60 mA
<b>POWER SUPPLY</b>	5 V from RS-232 port
<b>MAX CABLE LENGTH</b>	2 m RS232, 2 m PROFIBUS
<b>DEVICENET CONNECTOR</b>	9-pin D-sub connector
<b>BAUD RATES SUPPORTED</b>	19200 bps
<b>TEMPERATURE RANGE</b>	Working: +32 °F to +131 °F (0 °C to +55 °C) Storage: -13 °F to +158 °F (-25 °C to +70 °C)

### RS485 Specifications


<b>OPERATING CURRENT</b>	< 60 mA
<b>POWER SUPPLY</b>	5 V from RS-232 port
<b>MAX CABLE LENGTH</b>	2m RS232, 2m RS485
<b>DEVICENET CONNECTOR</b>	9-pin D-sub connector
<b>BAUD RATES SUPPORTED</b>	up to 57600 bps
<b>TEMPERATURE RANGE</b>	Working: +32 °F to +131 °F (0 °C to +55 °C) Storage: -13 °F to +158 °F (-25 °C to +70 °C)

Model	Description
<b>VAZ-DN-SIM-USB</b>	DeviceNet to USB converter, connects any DeviceNet slave to a PC, simulator software included
<b>VAZ-PB-SIM</b>	PROFIBUS to RS232 converter, connects any PROFIBUS slave to a PC, simulator software included
<b>VAZ-R4-R2</b>	RS485 to RS232 converter, connects any RS485 device to a PC


#### VAZ-DN-SIM-USB



#### VAZ-PB-SIM



#### VAZ-R4-R2




## AS-Interface Terminator and Tuner

A number of AS-Interface tools are available to extend the network past the 100 m limit without the use of a repeater. The AS-Interface terminator is placed at the end of the network farthest away from the AS-Interface power supply and is used to stabilize the network when the cable length is exceeded. Network segments can be extended to 200 m. The AS-Interface tuner, which has the terminator built in, is also placed at the end of the network. It can extend the AS-Interface network segment up to 300 m. The terminator and tuner can only extend a network which is correctly wired, using specified AS-Interface cable, and is free from noise. We recommend using an analyzer to identify network problems (see page 214). If repeaters are used, use only advanced repeaters. Their fast response times are required for long AS-Interface cable runs.

Model	Description
VAZ-G10-TERM	AS-Interface Terminator, extends AS-Interface network up to 200 m, two impedance options, place at end
VAZ-TUNER	AS-Interface Tuner, extends AS-Interface network up to 300 m, place at end


### VAZ-G10-TERM



### LEDs

Green: AS-i voltage > 26.5 V

Yellow: AS-i voltage > 18 V



### Terminator Specifications

OPERATING CURRENT	15 mA
POWER SUPPLY	from AS-Interface
AS-i CONNECTOR	Flat cable
PROTECTION (IEC)	IP67, IP68*, IP69K*
TEMPERATURE RANGE	Working: -13 °F to +158 °F (-25 °C to +70 °C) Storage: -13 °F to +185 °F (-25 °C to +85 °C)


\*With VAZ-FK-S...flat cable

### Tuner Specifications

OPERATING CURRENT	60 mA
POWER SUPPLY	from AS-Interface
AS-i CONNECTOR	M12 connector female and flat cable
PROTECTION (IEC)	IP65
TEMPERATURE RANGE	Working: +32 °F to +131 °F (0 °C to +55 °C) Storage: -13 °F to +167 °F (-25 °C to +75 °C)

Dimensions in mm

### VAZ-TUNER



The VAR-KE3-TERM repeater has an integrated termination switch that can extend the total length of the network to 300 m. See page 65.

### LEDs (diagnostic)

**ERROR:** Red: errors > 5% within 1 s or configuration error

**WARNING:** Yellow: errors < 1% but less than 5% within 1 s

**GREEN:** < 1% errors in 1 second

**AS-Interface Power:** Green (solid): AS-Interface powered  
Green (blinking): Voltage low

### Rotary Switch, MODE

**0:** Not tuning and no termination active




**1:** Use fixed termination, no tuning

**2:** Tune the network (AS-Interface gateway/scanner must be in config. mode; Error, Warning, and Green LEDs will strobe while tuning)

**3:** Run program, used after tuning is complete

### Button

**Set:** Press and hold for > 5 s to tune (Must be in tune mode), press once to clear diagnostic LEDs



## Bases

Bases are used to mount the AS-Interface module to the machine and also hold the flat cable in place. Most bases are sold separately so you can choose the version that best fits the application. The bases with addressing jacks U-G1FA or U-G1FFA should be used wherever possible because of the ease of programming and performing diagnostics without having to remove the module from the base.

Model	Description
<b>U-G3FF</b>	Base to connect yellow and black cable to all 4 port G2 modules
<b>U-G3FF-DIN</b>	Base to connect yellow and black cable to all 4 port G2 modules, with DIN rail clip
<b>U-G2FF</b>	Base to connect yellow and black cable to all 8 port G2 modules
<b>U-G2FF-DIN</b>	Base to connect yellow and black cable to all 8 port G2 modules, with DIN rail clip
<b>U-G1F</b>	Connection of up to 2 yellow flat cables to any module that supports this base type
<b>U-G1FA</b>	Connection of up to 2 yellow flat cables to any module that supports this base type, with addressing jack
<b>U-G1FF</b>	Connection of 1 yellow and 1 black flat cable to any module that supports this base type
<b>U-G1FFA</b>	Connection of 1 yellow and 1 black flat cable to any module that supports this base type, with addressing jack
<b>U-G1PP</b>	Round cable base to connect AS-Interface and auxiliary power to any module that supports this base type
<b>VAZ-DK-G1</b>	Cover for any U-G1... base



### Base Specifications

<b>PROTECTION (IEC)</b>	IP67 (with top connected)
<b>HOUSING MATERIAL</b>	PBT
<b>TEMPERATURE RANGE</b>	
Working	-13 °F to +131 °F (-25 °C to +60 °C)
Storage	-40 °F to +185 °F (-40 °C to +85 °C)


Dimensions in mm

**U-G1F**  
**U-G1FA**


**U-G1FF**  
**U-G1FFA**



**U-G3FF**  
**U-G3FF-DIN**




**U-G2FF**  
**U-G2FF-DIN**



**U-G1PP**



**VAZ-DK-G1**



Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
SENSING YOUR NEEDS



## AS-Interface Cable



AS-Interface cable can either be flat or round and has certain impedance characteristics specifically for AS-Interface. AS-Interface was designed without a shield and for use with a flat cable profile. Flat cable piercing technology means no more stripping, cutting, or buying of special length AS-Interface cable. It is the least expensive network technology on the market and the quickest to install.



Model	Description
VAZ-FK-S-YE	Yellow flat cable with a standard rubber jacket, 100 m roll
VAZ-FK-S-YE-1000M	Yellow flat cable with a standard rubber jacket, 1000 m roll
VAZ-FK-S-BK	Black flat cable with a standard rubber jacket, 100 m roll
VAZ-FK-S-BK-2,5MM	Black flat cable with a standard rubber jacket, 100 m roll, 2.5 mm <sup>2</sup>
VAZ-FK-S-BK-1000M	Black flat cable with a standard rubber jacket 1000 m roll
VAZ-FK-R-YE	Yellow flat cable with an oil-resistant jacket, 100 m roll
VAZ-FK-R-YE-1000M	Yellow flat cable with an oil-resistant jacket, 1000 m spool
VAZ-FK-R-BK	Black flat cable with an oil-resistant jacket, 100 m roll
VAZ-FK-R-BK-1000M	Black flat cable with an oil-resistant jacket, 1000 m spool
VAZ-FK-S-YE-SAFETY	Yellow flat cable with a standard rubber jacket, 100 m roll, red "Safety" text included on jacket
VAZ-RK-PVC-ABG 2X1,3-GY 100M	2-conductor round cable with shield, 100 m roll
VAZ-FK-R-STRIPPER	Flat cable stripper for use with any flat cable type
VAZ-FK-R-STRIPPER-BLADES	Replacement blades for VAZ-FK-R-STRIPPER



VAZ-FK-R-STRIPPER

### Flat Cable Specifications

WIRE GAUGE	VAZ-FK-S-...	1.5 mm <sup>2</sup>
	VAZ-FK-S-BK-2,5MM	2.5 mm <sup>2</sup>
CURRENT CARRYING CAPACITY		8 A (1.5 mm <sup>2</sup> ), 15 A (2.5 mm <sup>2</sup> )
VOLTAGE RATING		300 V
JACKET MATERIAL	VAZ-FK-S-...	Rubber compound
	VAZ-FK-R-...	TPE, PVC
UV RESISTANCE		Only black cable is approved for use outdoors
BEND RADIUS		10 mm on broad side
CONDUCTORS		2, brown, blue
OPERATING TEMPERATURE	At Standstill	-40 °F to +185 °F (-40 °C to +85 °C)
	In Motion	-13 °F to +185 °F (-25 °C to +85 °C)
APPROVALS	VAZ-FK-S-...	CE 
	VAZ-FK-R-...	CE 



Dimensions in mm


### Round Cable Specifications

WIRE GAUGE	16 AWG
OUTSIDE DIAMETER	0.271"
SHIELDING (for mechanical strength)*	Braided tinned copper shield 90% coverage
CURRENT CARRYING CAPACITY	> 8 A
VOLTAGE RATING	300 V
JACKET MATERIAL	Gray PVC jacket, insulation polyethylene
CONDUCTORS	2, black, white
OPERATING TEMPERATURE	-4 °F to +167 °F (-20 °C to +70 °C)

\* Because of shielding, the AS-Interface line should be limited to 70 m of total cable length.

Any round cable will work for AS-Interface as long as it meets the following electrical characteristics. A two-conductor PLTC cable from Belden, 1035A for example, is often used for round cable applications. Electrical characteristics should be evaluated at 167 kHz, and shielding should be avoided if possible.

GAUGE	16 AWG
NOM. CONDUCTOR DC RESISTANCE	< 4.2 Ohm/1000 ft
NOM. CAPACITANCE CONDUCTOR TO CONDUCTOR	< 24 pF/ft
NOM. INDUCTANCE	0.121-0.395 µH/ft



VAZ-RK-PVC-ABG 2X1,3-GY-100M

## Flat Cable Adapters and Splitters

AS-Interface was designed around the flat cable concept. To make wiring easier, new and innovative flat cable adapters were designed to connect to IO modules, junction boxes, valves, and other devices on the network. All flat cable connections are watertight and tested and designed to AS-Interface specifications.

### Flat Cable to M12 Adapters

Model	Description
<b>VAZ-T1-FK-G10-V1</b>	Connects the AS-Interface yellow cable to an M12 quick disconnect
<b>VAZ-2T1-FK-G10-V1</b>	Connects the AS-Interface yellow and black cable to an M12 quick disconnect
<b>VAZ-2T2-FK-G10-V1</b>	Connects the AS-Interface yellow and black cable to two M12 quick disconnects
<b>VAZ-2T8-G11-V1</b>	Connects the AS-Interface to 8 M12 quick disconnects. AS-Interface trunk-in is M12 male connector
<b>VAZ-2T8-G11-F</b>	Connects the AS-Interface yellow and black flat cable to 8, M12 quick disconnects

### VAZ-...-G10-V1 Specifications

<b>RATED OPERATING CURRENT</b>	< 4 A total	
<b>PROTECTION (IEC)</b>	IP67, IP68*, IP69K*	
<b>HOUSING MATERIAL</b>	PA 6 GF 25 Ultramid	
<b>TEMPERATURE RANGE</b>	Working	-13 °F to +167 °F (-25 °C to +75 °C)
	Storage	-13 °F to +185 °F (-25 °C to +85 °C)
<b>SCREW MOUNTING TORQUE</b>	1.65 Nm	
<b>CONTACTS</b>	Gold-plated pins, 2 per tray	
<b>FLAT CABLE CONNECTIONS</b>	T1(1), 2T1(2)	


\*With VAZ-FK-S...flat cable

### VAZ-2T8-G11... Specifications


<b>RATED OPERATING CURRENT</b>	< 4 A total	
<b>BASE</b>	Included	
<b>PROTECTION (IEC)</b>	IP68, IP69K	
<b>HOUSING MATERIAL</b>	PBT PC	
<b>TEMPERATURE RANGE</b>	Working	-13 °F to +158 °F (-25 °C to +70 °C)
	Storage	-13 °F to +185 °F (-25 °C to +85 °C)
<b>FLAT CABLE CONNECTIONS</b>	2	

Dimensions in mm

#### VAZ-2T8-G11-V1



#### VAZ-2T8-G11-F




#### LED Indicators


**AS-i:** Green: AS-i powered  
Red: Polarity reversed

**AUX:** Green: Auxiliary powered  
Red: Polarity reversed


#### VAZ-T1-FK-G10-V1 VAZ-2T1-FK-G10-V1




#### VAZ-T1-FK-G10-V1




#### VAZ-2T1-FK-G10-V1




#### VAZ-2T2-FK-G10-V1



#### VAZ-2T2-FK-G10-V1



#### VAZ-2T8-G11-V1 VAZ-2T8-G11-F



**Male**  
VAZ-2T8-G11-V1 only

**Female**

Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
SENSING YOUR NEEDS



## Flat Cable Adapters and Splitters (cont.)

### Single Flat Yellow to M12 Pigtail Straight

Model	Length
VAZ-T1-FK-G10-0,3M-PUR-V1-G	300 mm
VAZ-T1-FK-G10-1M-PUR-V1-G	1 m
VAZ-T1-FK-G10-2M-PUR-V1-G	2 m
VAZ-T1-FK-G10-5M-PUR-V1-G	5 m

### Single Flat Yellow to M12 Pigtail Right Angle

Model	Length
VAZ-T1-FK-G10-1M-PUR-V1-W	1 m
VAZ-T1-FK-G10-2M-PUR-V1-W	2 m
VAZ-T1-FK-G10-5M-PUR-V1-W	5 m

### Dual Flat Yellow and Black to M12 Pigtail Straight

Model	Length
VAZ-2T1-FK-G10-1M-PUR-V1-G	1 m
VAZ-2T1-FK-G10-2M-PUR-V1-G	2 m
VAZ-2T1-FK-G10-5M-PUR-V1-G	5 m

### Dual Flat Yellow and Black to M12 Pigtail Right Angle

Model	Length
VAZ-2T1-FK-G10-1M-PUR-V1-W	1 m
VAZ-2T1-FK-G10-2M-PUR-V1-W	2 m
VAZ-2T1-FK-G10-5M-PUR-V1-W	5 m

### Specifications





<b>RATED OPERATING CURRENT</b>	4 A
<b>PROTECTION (IEC)</b>	IP67, IP68*, IP69K*
<b>HOUSING MATERIAL</b>	PBT PC
<b>CABLE MATERIAL</b>	PUR, black
<b>WIRE GAUGE</b>	22 AWG
<b>TEMPERATURE RANGE</b>	Working -13 °F to +167 °F (-25 °C to +75 °C)
	Storage -13 °F to +185 °F (-25 °C to +85 °C)
<b>SCREW MOUNTING TORQUE</b>	1.65 Nm
<b>FLAT CABLE CONNECTIONS</b>	T1 (1), 2T1 (2)

\* With VAZ-FK-S...flat cable

Dimensions in mm

VAZ-T1-FK-G10...-PUR-V1-G  
VAZ-2T1-FK-G10...-PUR-V1-G

VAZ-T1-FK-G10...-PUR-V1-W  
VAZ-2T1-FK-G10...-PUR-V1-W



# Flat Cable Adapters and Splitters (cont.)

## Splitters

Model	Description
<b>VAZ-2FK-G10-BRIDGE</b>	Flat cable splitter, two trays are connected together
<b>VAZ-T1-FK-G10-CLAMP1</b>	Flat cable splitter, two trays are connected together, also connects the flat cable to spring terminals
<b>VAZ-2T1-FK-G10-CLAMP1</b>	Connects both the yellow and black flat cable to spring terminals


## Specifications

<b>RATED OPERATING CURRENT</b>	8 A (4 A for VAZ-T1-FK-G10-CLAMP1)
<b>PROTECTION (IEC)</b>	VAZ-...BRIDGE IP67, IP68*, IP69K* VAZ-...CLAMP1 IP20
<b>HOUSING MATERIAL</b>	PBT PC
<b>TEMPERATURE RANGE</b>	Working -13 °F to +167 °F (-25 °C to +75 °C) Storage -13 °F to +185 °F (-25 °C to +85 °C)
<b>SCREW MOUNTING TORQUE</b>	1.6 Nm
<b>WIRE GAUGE</b>	CLAMP1 only (24 AWG - 16 AWG, strip 10 mm)
<b>FLAT CABLE TRAYS</b>	2


\*With VAZ-FK-S...flat cable

Dimensions in mm


**VAZ-2FK-G10-BRIDGE**




**VAZ-2FK-G10-BRIDGE**




**VAZ-T1-FK-G10-CLAMP1**




**VAZ-2T1-FK-G10-CLAMP1**



**VAZ-T1-FK-G10-CLAMP1  
VAZ-2T1-FK-G10-CLAMP1**



## Mounting Configurations




## Bulkhead Connectors, Cordgrips, and Conduit Adapters

These accessories are often used to connect flat cable to a junction box or enclosure. Drill a hole with the appropriate mounting hole clearances and mount the accessory in the box.

Model	Description
VAZ-T1-FK-PG9	Flat cable bulkhead adapter with PG9 threads, 0.606" mounting hole clearance
VAZ-T1-FK-PG11	Flat cable bulkhead adapter with PG11 threads, 0.740" mounting hole clearance
VAZ-T1-FK-M20	Flat cable bulkhead adapter with M20 threads, 0.807" mounting hole clearance
PG11 CORD GRIP	Cord grip for round cable, PG11 threads, 0.740" mounting hole clearance
VAZ-PG11-FKD	Inserts to seal around flat cable, fits into PG11 cord grip, bag of 10
PG11-1/2NPT	Adapter to convert a PG11 opening like on U-G1PP to a 1/2" NPT opening
VAZ-FK-GLAND-12NPT	Cord grip and insert for flat cable, 1/2" NPT, bag of 10
VAZ-FK-GLAND-M20	Cord grip and insert for flat cable, M20 with nut, bag of 10
VAZ-2FK-GLAND-12NPT	Cord grip and insert for two flat cables, 1/2" NPT, bag of 10
VAZ-2FK-GLAND-M20	Cord grip and insert for two flat cables, M20 with nut, bag of 10

VAZ-T1-FK-PG9  
VAZ-T1-FK-PG11  
VAZ-T1-FK-M20




### VAZ-T1-FK... Specifications

<b>RATED OPERATING CURRENT</b>	2 A
<b>PROTECTION (IEC)</b>	IP67
<b>HOUSING MATERIAL</b>	PUR and Ni-Brass
<b>TEMPERATURE RANGE</b>	Working: -13 °F to +140 °F (-25 °C to +60 °C) Storage: -13 °F to +185 °F (-25 °C to +85 °C)
<b>WIRE GAUGE</b>	22 AWG
<b>WIRE LENGTH</b>	200 mm


VAZ-FK-GLAND-12NPT  
VAZ-FK-GLAND-M20



VAZ-FK-GLAND-12NPT




VAZ-FK-GLAND-M20




VAZ-2FK-GLAND-12NPT  
VAZ-2FK-GLAND-M20



VAZ-2FK-GLAND-12NPT



VAZ-2FK-GLAND-M20



PG11-1/2NPT



VAZ-PG11-FKD



PG11 CORD GRIP



## Covers and Mounting Accessories

Model	Description
VAZ-V1-B3	Dust cover to mount over a female connector on G2, G11 and G12 type modules, M12 x 1
VAZ-V3-B	Dust cover to mount over a female connector, M8 x 1 (pack of 10)
VAZ-G4-B1	Additional covers to plug unused ports on the G4 type housing, M12 x 1.5
VAZ-FK-CL1	Cable clip to attach 1 flat cable to machine
VAZ-2FK-CL2	Cable clip to attach 1 or 2 flat cables to machine with super 3M adhesive
V1-CLIP	Attaches to M12 male once connected to I/O block to protect against accidental removal
VAZ-FK-ED2	Cord grip with flat cable profile to terminate flat cable (pack of 10)
MH V3-BIT-M8	Bit to attach all M8 connectors to I/O modules
MH V1-BIT-M12	Bit to attach all M12 connectors to I/O modules
MH V1-SCREWDRIVER	Torque screwdriver for use with MH...bits, preset to .4Nm

Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories

VAZ-V1-B3




VAZ-V3-B



VAZ-G4-B1




V1-CLIP



VAZ-FK-ED2



VAZ-FK-CL1




MH V3-BIT M8



MH V1-BIT M12



VAZ-2FK-CL2



Adhesive Tape: Pressure sensitive foam 1.02 mm thick with rubber adhesive and protective liner. Mount is designed to support 0.62 lbs. (281 g) maximum weight on a clean, dry, smooth, grease-free surface

Dimensions in mm

MH V1-SCREWDRIVER



Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001  
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411  
fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs  
Singapore: +65 6779 9091  
fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com


## AC Input Accessories

All standard I/O modules in this catalog are for DC inputs. If you want AC inputs for a new project, or to retrofit a job, then these accessories are what you need. Inputs are for 120 VAC/DC inputs and outputs connect directly to the I/O module. If multiple optocouplers are used, the shorting rail will save you a great deal of installation time. All of the DC positives and AC neutrals can be jumpered together.


Model	Description
VAZ-PLC-OSC-120UC/48DC/100/SEN	Optocoupler, converts 120 VAC inputs to DC for input to any AS-Interface module
VAZ-FBST 500-PLC GY	Shorting rail will connect AC Neutrals or AS-i + together on module, 500 mm long

### Specifications

INPUT DATA	
VOLTAGE RANGE	96-132 VAC / 88-121 VDC
CURRENT CONSUMPTION	3.5 mA
RESPONSE TIME	6 ms
TURN OFF TIME	10 ms
FREQUENCY	10 Hz
OUTPUT DATA	
VOLTAGE RANGE	3 VDC to 48 VDC
VOLTAGE DROP	≤ 1 V
CURRENT LIMIT	100 mA
CURRENT CONSUMPTION	≈ 0 mA





Dimensions in mm



### LED Indicators

Yellow: Input on



VAA-4E4A-KE-ZE/R

4 x VAZ-PLC-OSC-120UC/48DC/100/SEN

## Passive and Protected Tees

These protected and unprotected Tees allow for easy splitting of the AS-Interface round cable. The protected Tees will shut off the drop on overload or short circuit. The drop autorecovers when the short is removed. Each protected drop can be for up to one I/O module each.



Model	Description
<b>VAZ-RK-TEE</b>	Passive drop connector, 2 drops, trunk in, trunk out
<b>VAZ-RK-4TEE</b>	Passive drop connector, 4 drops, trunk in, trunk out
<b>VAZ-RK-P-TEE</b>	Protected drop connector, 1 drop, trunk in, trunk out
<b>VAZ-RK-P-4TEE</b>	Protected drop connector, 4 drops, trunk in, trunk out

### Specifications


<b>PASSIVE DROP CONNECTORS</b>	
<b>MAX CURRENT</b>	8 A
<b>PROTECTED DROP CONNECTORS</b>	
<b>MAX CURRENT (TRUNK)</b>	8 A
<b>TRIP CURRENT</b>	240 mA
<b>HOLDING CURRENT AFTER TRIP</b>	28 mA
<b>RESET CURRENT</b>	< 28 mA
<b>VOLTAGE DROP</b>	< 1 V
<b>TEMPERATURE RANGE</b>	-40 °F to +185 °F (-40 °C to +85 °C)

Dimensions in mm


**VAZ-RK-TEE**




**VAZ-RK-P-TEE**



**VAZ-RK-4TEE**



**VAZ-RK-P-4TEE**



Gateways and Scanners

Power Supplies and Repeaters

I/O Modules

Safety at Work

Sensors

Cordsets

Accessories

Subject to modifications without notice

Pepperl+Fuchs Group  
www.pepperl-fuchs.com

USA: +1 330 486 0001

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411

fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs

Singapore: +65 6779 9091

fa-info@sg.pepperl-fuchs.com

**PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com



## PROFIBUS Accessories

Model	Description
VAZ-PB-DB9-W	DB9 PROFIBUS connector with termination switch

### Specifications

<b>MATERIAL DATA</b>	
<b>BODY</b>	Metal-plated ABS
<b>CABLE DIAMETER</b>	Accepts cables from 7.6 mm...8.4 mm dia
<b>TERMINATION</b>	Yes, switchable
<b>ELECTRICAL DATA</b>	
<b>BAUD RATE</b>	Max 12 Mbps
<b>CURRENT RATING</b>	4 A
<b>VOLTAGE RATING</b>	125 VDC
<b>ENVIRONMENTAL DATA</b>	
<b>PROTECTION CLASS</b>	IP40
<b>TEMPERATURE RANGE</b>	-4 °F to +158 °F (-20 °C to +70 °C)

Dimensions in mm





**Address**

The identification number of a module. The default setting for AS-Interface modules is 0 and can be set to values between 1A-31A or 1B-31B. There is no limit to the number of times the address can be changed.

**Actuator**

A simple output device that carries out a movement (e.g., contactor or valve control).

**Analog Profile 7.3**

A device profile that provides 4-16 bit analog signals to be transferred to or from the AS-Interface scanner. The scanner/gateway and the module must both support the Analog Profile 7.3 for communication to take place.

**APM**

An abbreviation for alternating pulse modulation. A stream of 2 bits on the AS-Interface cable where each bit represents a  $\sin^2$  pulse. Each positive pulse follows a negative pulse and vice versa. Alternative pulse modulation is highly resistant to interference.

**AS-Interface 2.0 specification**

AS-Interface accommodates 31 I/O modules where each module uses one, complete address between 1 and 31.

**AS-Interface 2.1 specification**

Allows I/O modules to take up only one half of an address. Therefore, scanners/gateways that support this addressing scheme are able to communicate with up to 62 modules on a network.

**AS-Interface 3.0 specification**

The latest specification that among others includes profiles allowing up to 62 4 in/4 out modules on one network. All profiles of earlier specifications are supported.

**ASIC**

Application Specific Integrated Circuit. Every module contains an AS-Interface ASIC.

**Automatic Addressing**

With the system in operation, a new module can be connected to replace an existing module. The new module will automatically assume the address of the one it is replacing. The address of the new module must be 0 and auto addressing must be enabled.

**Bit error rate**

The statistical mean of the errors occurring during transmission.

**Configuration data**

The display of all current I/O modules determines the actual status of the network. The profiles (I/O, ID, ID1, ID2) are stored in the list of the detected slaves (LDS).

**Cycle time**

The time span between two I/O transfers on a single module. The fewer the nodes, the shorter the cycle time.

**Data integrity**

A measure of the error free operation of data transfer.

**Enhanced logic functionality**

In addition to providing additional logic operations, SafetyMonitors with enhanced versions offer increased functionality allowing users to create configurations with more complex rules and procedures.

**Forward and backward compatibility**

Any scanner/gateway can communicate with any type of node with the specifications of 2.0, 2.1, and 3.0.

**Galvanic isolation**

Transformer isolation between two AS-Interface segments.

**Gateway**

A device that controls all AS-Interface communications and is a single drop on a higher level bus system.

**Ground fault detection**

An AS-Interface cable must not be grounded under any circumstances. Grounding the cable would lead to faults that may cause the system to become unstable and disrupt the noise immunity of the network. All power supplies with EFD in their model number have ground fault detection. Any AS-Interface gateway with K20 in the model number can also detect this problem.

**I/O code**

The I/O code, stored in the module, specifies to the master/scanner how many inputs and outputs the module has.

**I/O module**

This device connects directly to AS-Interface and accepts up to 4 inputs and 4 outputs from standard devices.

**ID-code**

Identifies the type of module. The manufacturer sets this value.

**ID1**

Part of the device profile. A freely configurable code between 0 and F.

**ID2**

Part of the device subprofile. Determines how a module will act on the network.

**Insulation displacement**

An electrical connection to the AS-Interface flat cable made without the use of a cutting tool.

**Intelligent sensor**

A sensor with an AS-Interface ASIC that uses one address.

**Interoperability**

Two modules or scanner/modules from different manufacturers are able to work together.

**Mechanical profile**

Guarantees a correct connection of the yellow cable every time by eliminating the danger of reversing polarity.

**Message**

A complete group of bits that presents information.

**Operating current**

Current needed by the device for proper operation.

## Glossary

### OSSDs

Output signal switching devices (OSSDs), the safety relays in a SafetyMonitor.

### Parameter bits

A four-bit code indicating how the I/O module will function. Examples: N.C./N.O., light-on/dark-on for photoelectric sensors. Parameter bits can be changed as needed and are set on power up.

### Parity check

Simple error checking of the sum of the user bits contained in one telegram (address, data, control bits, parity bit) which must be even in AS-Interface.

### Passive module

A device that connects one or more intelligent devices to AS-Interface. It does not require an address.

### Plug and Play

Automatic installation of hardware components on Windows based operating systems.

### Projected data

The current stored configuration of AS-Interface. The I/O and ID codes are permanently stored in the gateway/scanner. The gateway/scanner compares the current configuration and default configuration to detect improperly connected or missing modules.

### Redundant piercing connection technology

Two flat cable pierce connections that nestle tightly and securely among the copper strands in the core of each of the conductors.

### Release circuit

Release circuits are safe output contacts, controlled by logic in the AS-Interface SafetyMonitor. A single SafetyMonitor can up to 16 independent release circuits. This means that up to 16 independent shut-off states can be realized. Dependent release circuits operate in tandem.

### Remaining error probability

Indicates the number of errors that could occur during a transmission based on the average of previous error detections.

### Safe Remote Output

A set of safe contacts that are not located inside the SafetyMonitor but are mounted remotely on the network. Multiple safe remote outputs can switch simultaneously (dependent release circuits) or independently (independent release circuits).

### Safety at Work

The safety components of AS-Interface in applications up to category 4, SIL 3.

### SafetyMonitor

A monitoring device that contains output signal switching devices (OSSDs) replacing safety relays. Evaluates all data sent across the AS-Interface network.

### SafetyNode

I/O modules constructed to satisfy the rules and regulations necessary to obtain the desired safety ratings.

### Scanner Cards

Directly mounted in the PLC rack and appearing in the PLC configuration as large I/O cards. Also any PC card that connects to the ISA, PCI, or PC104 busses.

### Sensor

A device that indicates the presence of something and relays the information back to a controller. Some of the most common types of sensors are inductive, capacitive, photoelectric, and ultrasonic.

### Telegram

A message sent by the master and answered by an I/O module.

### Transmission (Baud) rate

The transmission speed of a bit on the AS-Interface cable measured in bits per second (bps). AS-Interface's baud rate is approximately 167 kbps.

### Watchdog

Switches outputs to their deenergized state when there is no communication for more than 40 ms on the AS-Interface network.

## Trademark Information

AS-Interface™ is a trademark of AS-International.

ControlLogix™, CompactLogix™, and MicroLogix™ are trademarks of Allen Bradley.

DeviceNet™ and EtherNet/IP™ are trademarks of Open DeviceNet Vendor Association (ODVA).

PROFIBUS® and PROFINET® are registered trademarks of PROFIBUS Nutzerorganisation e.V.

Modbus® and Modbus®/TCP are registered trademarks of Modbus-IDA.

MOVIMOT® and MOVISWITCH® are registered trademarks of SEW Eurodrive.

ECOLAB® is a registered trademark of Ecolab Inc.

## Chemical Resistivity Charts

A= excellent

B= good

C= moderate

D= nonresistive

## METALS

This chemical resistance chart rates the effect of chemicals on metals used in the construction of Pepperl+Fuchs' products. Concentration of chemicals listed are 100%, unless otherwise specified.

	302/304 SS	316 SS	Hastelloy	Titanium	Aluminum	Tantalum
Citric acid	A	A	A	A	C	-
Copper chloride	C	D	A	A	D	-
Cresols 2	A	A	-	-	B	A
Detergents	A	A	-	-	A	A
Diesel fuel	A	A	-	-	A	-
Dyes	A	A	-	-	B	-
Ethyl acetate	A	A	B	-	B	-
Ferric chloride	D	D	B	A	D	-
Ferric sulfate	A	C	A	A	D	A
Formic acid	C	B	A	C	D	-
Fuel oils	A	A	A	A	A	A
Gasoline	A	A	A	D	A	-
Grease 4	A	A	-	-	A	-
Hydraulic oil	A	A	-	-	A	-
Hydrochloric acid (20%)	-	D	B	C	D	-
Hydrofluoric acid(20%)	-	D	B	D	D	-
Hydrogen peroxide (10%)	-	C	A	C	A	-
Hydrogen sulfide (aqueous)	-	A	A	A	C	-
Isopropyl acetate	-	B	-	-	C	-
Kerosene 2	A	A	A	A	A	A
Lubricants	-	A	A	A	A	-
Magnesium sulfate	B		B	A	B	-
Methyl acetate	A	A	A	-	A	-
Methyl alcohol	A	A	A	B	A	-
Methylene chloride	B	B	B	B	A	-
Nitric acid (20%)	A	A	A	A	D	-
Oil (soybean)	A	A	A	A	B	A
Phosphoric acid (40%)	A	B	A	B	C	-
Potassium sulfide	B	A	-	A	-	-
Propane (liquified)	A	A	A	-	A	-
Sodium carbonate	B	A	A	A	D	-
Sodium hydroxide (20%)	B	A	B	A	D	-
Sodium sulfate	B	B	B	A	A	-
Sulfuric acid (10-75%)	D	D	B	D	D	-
Xylene	A	A	A	A	A	A

## PLASTICS

This chemical resistance chart rates the effect of chemicals on plastics used in the construction of Pepperl+Fuchs' products. Concentration of chemicals listed are 100%, unless otherwise specified.

	PVC	PUR	Hypalon (CSM)	Teflon	Polyethylene	Polypropylene	Viton
Citric acid	B	A	A	A	B	B	A
Copper chloride	A	A	A	A	B	A	A
Cresols 2	D	D	D	A	D	C	A
Detergents	A	D	-	A	B	A	A
Diesel fuel	-	D	-	A	-	D	A
Dyes	B	-	-	-	-	-	A
Ethyl acetate	D	D	D	A	C	C	D
Ferric chloride	A	B	B	A	B	A	A
Ferric sulfate	A	-	A	A	-	A	A
Formic acid	D	-	-	A	B	A	B
Fuel oils	A	D	D	A	D	B	A
Gasoline	C	B	B	A	D	C	A
Grease 4	A	A	-	A	-	-	A
Hydraulic oil	A	-	B	A	-	D	A
Hydrochloric acid (20%)	A	-	A	A	A	A	A
Hydrofluoric acid(20%)	D	B	A	A	C	A	A
Hydrogen peroxide (10%)	A	-	-	A	A	-	-
Hydrogen sulfide (aqueous)	A	-	B	A	B	A	B
Isopropyl acetate	B	D	-	-	-	-	D
Kerosene 2	A	B	-	A	D	D	A
Lubricants	A	C	D	A	-	A	A
Magnesium sulfate	A	-	A	A	B	A	A
Methyl acetate	-	-	D	A	-	-	D
Methyl alcohol	A	D	A	A	A	A	D
Methylene chloride	D	D	-	A	C	B	B
Nitric acid (20%)	A	D	D	A	C	A	A
Oil (soybean)	B	A	B	A	A	A	A
Phosphoric acid (40%)	A	A	-	A	A	A	A
Potassium sulfide	A	C	B	A	A	A	A
Propane (liquified)	A	D	B	-	C	B	A
Sodium carbonate		A	A	A	B	A	A
Sodium hydroxide (20%)	A	C	A	A	A	A	B
Sodium sulfate	A	A	A	A	A	A	A
Sulfuric acid (10-75%)	A	-	C	A	A	A	A
Xylene	D	D	D	A	C	C	A

These charts are a general guide and do not guarantee chemical compatibility.  
Pepperl+Fuchs, Inc. assumes no responsibility for the use of this information.

## IP Ratings

### Definition:

The first numeral defines the amount of protection against penetration of solid objects into the housing.

The second numeral defines the amount of protection against liquids penetrating the housing.


Additional information on ratings can be found in the following chart or the 1976 IEC Publication, Classification of Degrees of Protection Provided by Enclosures.

### Example: What is IP67?

Complete protection of live parts. Protection against the penetration of dust and water immersion.

### Testing Criteria:

- Test Class:** IP67 test  
**Conditions:** 1 m head of water over the test piece for a duration of 30 minutes.  
Room temperature  $\pm 5^{\circ}\text{C}$   
**Test:** Insulation and operation
- Test Class:** IP68 test (Encapsulated products)  
**Conditions:** 1m head of water over the test piece for 24 hours of operation under water, with cyclical activation and deactivation under nominal loading. Cycle time 2 hours.  
Room temperature  $\pm 5^{\circ}\text{C}$   
**Test:** Insulation and operation
- Test Class:** IP69K test  
**Conditions:** Protection against ingress of water from jets at a pressure of 1450 psi and at temperatures of up to  $80^{\circ}\text{C}$ . This is the level of pressure and temperature required for thorough cleaning of meat, fish, poultry and dairy precessing lines.



## A

AB12 .....	168
AB18 .....	168
AB30 .....	168

## B

BF5-30 .....	168
BF12 .....	168
BF18 .....	168
BF30 .....	168
BSM58 .....	192
BSS58 .....	192
BT 65 .....	178
BT 115A .....	178
BVM58 .....	188
BVS58 .....	188

## F

FE-RR1 .....	186
--------------	-----

## K

K17-STR-24..30VDC-5A .....	68
K24-STR-24..30VDC-10A .....	68
K34-STR-24..30V-3X500VAC-10A .....	68
K-ADP2 RPI .....	34, 213

## L

LD28-LAS-F1-B3B/73c .....	183
LV28-LAS-F1-B3B/73c .....	183

## M

MH4-2057 .....	171
MH4-2681 UNI .....	171
MH V1-BIT-M12 .....	223
MH V1-SCREWDRIVER .....	223
MH V3-BIT-M8 .....	223

## N

NBB6-F-B3B .....	175
NBB15-30GM60-B3B-V1 .....	167
NBB20-L2-B3B-V1 .....	173
NBB20-U1-B3B .....	170
NBN30-L2-B3B-V1 .....	173
NBN40-L2-B3B-V1 .....	173
NBN40-U1-B3B .....	170
NCB4-12GM60-B3B-V1 .....	166
NCB5-18GM60-B3B-V1 .....	166
NCN3-F31-B3B-V1-K .....	177
NCN3-F31-B3B-V1-V1 .....	177
NCN4-12GM60-B3B-C2-V1 .....	166
NCN8-18GM60-B3B-V1 .....	167

## O

OMH-21 .....	185
OMH-21-T .....	185
OMH-MLV11-K .....	185
OMH-RL2-H .....	185
OMH-RL2-S .....	186
OMH-RL25 .....	185

## P

PG11-1/2NPT .....	63, 66, 94, 118, 122, 222
PG11 CORD GRIP .....	94, 118, 122, 222

## R

REF-A25 .....	187
REF-A35 .....	187
REF-H32 .....	186
REF-H51x72 .....	186
REF-H100 .....	186
REF-MA21 .....	187
REF-MH20 .....	187
REF-MH23 .....	187
REF-MH50 .....	187
REF-MH78 .....	187
RL28-8-H-700-RT-B3B/73c .....	180
RL28-55-B3B/73c .....	181
RL28-55-LAS-B3B/73c .....	181
RL28-55-V-B3B/73c .....	182
RT1 X 2 .....	187
RT1 X 100 .....	187
RT2 X 100 .....	187
RT3 X 100 .....	187

## S

SST-ASI-SLC .....	30
-------------------	----

## U

U-G1F .....	217
U-G1FA .....	217
U-G1FF .....	63, 217
U-G1FFA .....	94, 118, 122, 142, 217
U-G1PP .....	63, 66, 94, 118, 122, 142, 217
U-G2FF .....	77, 217
U-G2FF-DIN .....	217
U-G3FF .....	77, 217
U-G3FF-DIN .....	217

## V

V1-CLIP .....	142, 223
V1-G-0,3M-PUR-ABG-V1-W-Y .....	203
V1-G-0,5/2,5M-PUR-V1-G .....	199
V1-G-2M-PUR-V1-G .....	199
V1-G-2M-PUR-V1-W .....	199
V1-G-2M-PVC .....	198
V1-G-2M-PVC-V1-G .....	199, 212
V1-G-2M-PVC-V1-W .....	199
V1-G-3M-T-0M-V1-G .....	206
V1-G-5M-PUR-V1-G .....	199
V1-G-5M-PUR-V1-W .....	199
V1-G-5M-PVC .....	198
V1-G-5M-PVC-V1-G .....	199
V1-G-5M-PVC-V1-W .....	199
V1-G-10M-PUR-V1-G .....	199
V1-G-10M-PUR-V1-W .....	199
V1-G-10M-PVC .....	198
V1-G-10M-PVC-V1-G .....	199
V1-G-10M-PVC-V1-W .....	199
V1-G-15M-PVC .....	198
V1-G-20M-PVC .....	198
V1-G-42-0,3M-PUR-ABG-V1-W-Y .....	203
V1-G-V1-Y904948 .....	202
V1S-G-2M-PVC .....	198, 212
V1S-G-5M-PVC .....	198
V1S-G-10M-PVC .....	198
V1S-W-2M-PVC .....	198

V1S-W-5M-PVC .....	198
V1S-W-10M-PVC .....	198
V1-W-0,5/2,5M-PUR-V1-G .....	199
V1-W-2M-PUR-V1-G .....	199
V1-W-2M-PVC .....	198
V1-W-2M-PVC-V1-G .....	199
V1-W-5M-PUR-V1-G .....	199
V1-W-5M-PVC .....	198
V1-W-5M-PVC-V1-G .....	199
V1-W-10M-PUR-V1-G .....	199
V1-W-10M-PVC .....	198
V1-W-10M-PVC-V1-G .....	199
V1-W-15M-PVC .....	198
V1-W-20M-PVC .....	198
V1-W-42-2M-PVC-V11-W .....	201
V1-W-42-5M-PVC-V11-W .....	201
V3-GM-1M-PUR-V3-GM .....	205
V3-GM-2M-PUR-ABG43-V1-G .....	158
V3-GM-2M-PUR-V3-GM .....	205
V3-GM-5M-PUR-ABG43-V1-G .....	158
V3-GM-5M-PUR-V3-GM .....	205
V3-GM-10M-PUR-V3-GM .....	205
V11-G-1M-PVC-V11-G .....	200
V11-G-2M-PVC-V11-G .....	200
V11-G-3M-PVC-V11-G .....	200
V11-G-4M-PVC-V11-G .....	200
V11-G-5M-PVC-V11-G .....	200
V11-G-6M-PVC-V11-G .....	200
V11-G-7M-PVC-V11-G .....	200
V11-G-8M-PVC-V11-G .....	200
V11-G-10M-PVC-V11-G .....	200
V11S-T-V11 .....	208
V15-G-2M-PVC .....	198
V15-G-5M-PVC .....	198
V15-G-10M-PVC .....	198
V15S-G-2M-PVC .....	198
V15S-G-5M-PVC .....	198
V15S-G-10M-PVC .....	198
V15S-TEE-V15 .....	209
V15S-T-V15 .....	207
V15S-YEE-V15 .....	209
V15-W-2M-PVC .....	198
V15-W-5M-PVC .....	198
V15-W-10M-PVC .....	198
V31-GM-0,1M-PUR-V1-G .....	204
V31-GM-42-2M-PVC-V11-W .....	204
VAA-2E1A-F85A-S-V1 .....	144
VAA-2E1A-G10-SAJ/EA2L-1M .....	136
VAA-2E1A-G10-SAJ/EA2L-2X1M .....	136
VAA-2E1A-IER1-S-1M-V1 .....	153
VAA-2E-IER2-S-1M-V1 .....	153
VAA-2E1A-PM-S .....	144
VAA-2E2A-G12-SAJ/EA2L .....	136
VAA-2E2A-IM1-J-S-V1 .....	147
VAA-2E2A-KE1-S/E2 .....	135
VAA-2E3A-LIM1-PL-J-S-V1 .....	148
VAA-2E3A-LIM1-PL-L-S-V1 .....	148
VAA-2E3A-LIM1-PU-J-S-V1 .....	148
VAA-2E3A-LIM1-PU-L-S-V1 .....	148
VAA-2EA-G1-ZE/P-S .....	120
VAA-2EA-G1-ZE/P-V2A .....	120
VAA-2EA-G2-ZA/EA2 .....	74
VAA-2E-F85A-S-V1 .....	144
VAA-2E-G4-SE .....	137
VAA-2E-IER2-S-0,15M-V1 .....	153
VAA-2E-IM1-J-S-V1 .....	147
VAA-2E-KE1-S .....	135
VAA-2E-PM-S .....	144
VAA-3E-HH30-J-S-V1 .....	160
VAA-4A-70MM .....	115
VAA-4A-G12-EA2L .....	79
VAA-4E2A-G1-ZE/PEXT-S .....	120
VAA-4E2A-G1-ZE/P-S .....	120
VAA-4E4A-CB1-Z/E2 .....	103
VAA-4E4A-CB2-Z/E2 .....	103
VAA-4E4A-G2-ZA/EA2 .....	74

VAA-4E4A-G4-ZE/E2 .....	92	VAZ-IEI1-READER1-S-V3 .....	156	VBA-2E-KE2-I/U.....	108
VAA-4E4A-G11-ZAJ/EA2L-F.....	83	VAZ-IEI1-TAG1-S.....	156	VBA-2E-KE2-I/U-V3.0.....	108
VAA-4E4A-G11-ZAJ/EA2L-V1.....	83	VAZ-IER1-ACTUATOR1-S.....	153	VBA-4A-G11-I/U-F.....	107
VAA-4E4A-G12-ZAJ/EA2L.....	79	VAZ-IER2-ACTUATOR2-S.....	153	VBA-4E1A-KE3-ZEJ/SR.....	138
VAA-4E4A-G12-ZAL/EA2L.....	79	VAZ-IM1-90°-BOLT-S.....	151	VBA-4E2A-G1-ZE/PEXT-S.....	120
VAA-4E4A-G16-ZEJ/E2L.....	96	VAZ-IM1-BASE-BOLT-S.....	151	VBA-4E2A-G1-ZE/P-S.....	120
VAA-4E4A-KE1-Z/E2.....	103	VAZ-IM1-BASE-S.....	151	VBA-4E2A-G2-XE/E2.....	74
VAA-4E4A-KE-ZEJQ/E2L.....	99	VAZ-IM1-BOLT-S.....	151	VBA-4E2A-KE1-Z/E2.....	103
VAA-4E4A-KE-ZE/R.....	99	VAZ-IM1-LR-RADIUS-BOLT-S.....	151	VBA-4E3A-G2-ZA/EA2.....	74
VAA-4E-G4-ZE.....	92	VAZ-IM1-TD-RADIUS-BOLT-S.....	151	VBA-4E3A-G4-ZE/E2.....	92
VAA-4E-IEI1-CONTROL-J-S.....	156	VAZ-LAMP-70MM-BU.....	115	VBA-4E3A-G12-ZAJ/EA2L.....	79
VAA-LT3-F86-V1.....	114	VAZ-LAMP-70MM-BULB-5W/24V.....	115, 118	VBA-4E3A-KE-ZEJQ/E2L.....	99
VAN-24DC-K28.....	62	VAZ-LAMP-70MM-CL.....	115	VBA-4E3A-KE-ZE/R.....	99
VAN-115/230AC-K16.....	59	VAZ-LAMP-70MM-GN.....	115	VBA-4E4A-CB1-ZEJ/E2J.....	103
VAN-115/230AC-K19.....	59	VAZ-LAMP-70MM-RD.....	115	VBA-4E4A-CB1-ZEJ/E2J-FL.....	103
VAN-115/230AC-K27.....	59	VAZ-LAMP-70MM-YE.....	115	VBA-4E4A-G2-ZA/EA2.....	74
VAN-G4-PE-4A.....	62	VAZ-LED-70MM-BU.....	115	VBA-4E4A-G4-ZE/E2.....	92
VAN-KE2-2PE.....	62	VAZ-LED-70MM-CL.....	115	VBA-4E4A-G11-ZAJ/EA2L-F.....	83
VAR-G4F.....	65	VAZ-LED-70MM-GN.....	115	VBA-4E4A-G11-ZAJ/EA2L-V1.....	83
VAR-KE3-TERM.....	65	VAZ-LED-70MM-RD.....	115	VBA-4E4A-G12-XEL.....	79
VAS-1A1L-K12.....	130	VAZ-LED-70MM-YE.....	115	VBA-4E4A-G12-ZAJ/EA2L.....	79
VAS-1A-K12.....	130	VAZ-MH-1/2"Conduit-70MM.....	118	VBA-4E4A-G12-ZAL/EA2L.....	79
VAS-2A1L-K12.....	130	VAZ-MH 90°-70MM.....	115	VBA-4E4A-G16-ZEJ/E2L.....	96
VAS-2A1L-K31.....	130	VAZ-MH 100-70MM.....	115	VBA-4E4A-KE-ZEJQ/E2L.....	99
VAS-2A8L-KE4-8SE.....	130	VAZ-PB-DB9-W.....	45, 226	VBA-4E4A-KE-ZE/R.....	99
VAS-2A-K12.....	130	VAZ-PB-SIM.....	45, 215	VBA-4E4E-G12-ZAJ.....	79
VAS-4A16L-K31.....	130	VAZ-PG11-FKD.....	222	VBA-4E-G2-ZA.....	74
VAZ-2FK-CL2.....	223	VAZ-PK-1,5M-V1-G.....	212	VBA-4E-G4-PT100.....	107
VAZ-2FK-G10-BRIDGE.....	221	VAZ-PK-FK-0,2M-V1-W.....	90, 142, 212	VBA-4E-G4-ZE.....	92
VAZ-2FK-GLAND-12NPT.....	222	VAZ-PLC-OSC-120UC/48DC/100/SEN.....	224	VBA-4E-G11-ZAJ-F.....	83
VAZ-2FK-GLAND-M2.....	222	VAZ-R4-R2.....	53, 215	VBA-4E-G11-ZAJ-V1.....	83
VAZ-2T1-FK-G10-1M-PUR-V1-G.....	220	VAZ-RK-4TEE.....	225	VBA-4E-G12-ZAJ.....	79
VAZ-2T1-FK-G10-1M-PUR-V1-W.....	220	VAZ-RK-P-4TEE.....	225	VBA-4E-G12-ZAL.....	79
VAZ-2T1-FK-G10-2M-PUR-V1-G.....	220	VAZ-RK-P-TEE.....	225	VBA-4E-G16-ZEJ.....	96
VAZ-2T1-FK-G10-2M-PUR-V1-W.....	220	VAZ-RK-PVC-ABG 2X1,3-GY 100M.....	218	VBA-4E-KE1-Z.....	103
VAZ-2T1-FK-G10-5M-PUR-V1-G.....	220	VAZ-RK-TEE.....	225	VBA-4E-KE-ZEJQ.....	99
VAZ-2T1-FK-G10-5M-PUR-V1-W.....	220	VAZ-SIMON-R2.....	133, 213	VBA-8E-G2-ZA.....	74
VAZ-2T1-FK-G10-CLAMP1.....	221	VAZ-SIMON+R2-1,8M-PS/2.....	45, 133, 213	VBA-LT2-G1.....	114
VAZ-2T1-FK-G10-V1.....	219	VAZ-SIMON-RJ45.....	133, 213	VBG-DN-K20-D.....	36
VAZ-2T2-FK-G10-V1.....	219	VAZ-SIMON-USB.....	133, 213	VBG-DN-K20-DMD.....	36
VAZ-2T8-G11-F.....	219	VAZ-SW-ACT32.....	34, 38, 45, 50, 53, 213	VBG-DN-K20-DMD-BV.....	36
VAZ-2T8-G11-V1.....	219	VAZ-SW-SIMON+.....	45, 50, 133, 213	VBG-ENX-K20-D.....	47
VAZ-9VDC-CHRG-115V.....	212	VAZ-T1-FK-G10-0,3M-PUR-V1-G.....	220	VBG-ENX-K20-DMD.....	47
VAZ-ANALYZER.....	214	VAZ-T1-FK-G10-1M-PUR-V1-G.....	220	VBG-ENX-K30-DMD-S16.....	48
VAZ-CLAMP-70MM.....	115	VAZ-T1-FK-G10-1M-PUR-V1-W.....	220	VBG-MOD-K20-D.....	52
VAZ-CLAMP-70MM-90°.....	115	VAZ-T1-FK-G10-2M-PUR-V1-G.....	220	VBG-PB-K20-D.....	40
VAZ-CLIP-G12.....	81	VAZ-T1-FK-G10-2M-PUR-V1-W.....	220	VBG-PB-K20-DMD.....	40
VAZ-CTR.....	38, 45, 53	VAZ-T1-FK-G10-5M-PUR-V1-G.....	220	VBG-PB-K20-DMD-BV.....	40
VAZ-DK-G1.....	217	VAZ-T1-FK-G10-5M-PUR-V1-W.....	220	VBG-PB-K25.....	40
VAZ-DN-SIM-USB.....	38, 215	VAZ-T1-FK-G10-CLAMP1.....	221	VBG-PB-K30-DMD-S16.....	41
VAZ-FBST 500-PLC GY.....	224	VAZ-T1-FK-G10-V1.....	219	VBG-PB-K30-D-S16.....	41
VAZ-FK-CL1.....	223	VAZ-T1-FK-M20.....	169, 222	VBG-PN-K20-D.....	47
VAZ-FK-ED2.....	223	VAZ-T1-FK-PG9.....	222	VBG-PN-K20-DMD.....	47
VAZ-FK-GLAND-12NPT.....	222	VAZ-T1-FK-PG11.....	222	VBG-PNS-K30-DMD.....	48
VAZ-FK-GLAND-M20.....	222	VAZ-TUBE400-70MM.....	118	VBM-CLX-DM.....	30
VAZ-FK-R-BK.....	218	VAZ-TUBE-BASE-70MM.....	118	VBM-CTR-K20-R2.....	52
VAZ-FK-R-BK-1000M.....	218	VAZ-TUNER.....	216	VBM-MLX/CPLX.....	30
VAZ-FK-R-STRIPPER.....	218	VAZ-V1-B3.....	77, 81, 86, 223	VBP-HH1-V3.0-110V.....	212
VAZ-FK-R-STRIPPER-BLADES.....	218	VAZ-V3-B.....	97, 223	VBP-HH1-V3.0-KIT-110V.....	212
VAZ-FK-R-YE.....	218	VBA-1E3A-M18-ZE/E2-V1.....	124		
VAZ-FK-R-YE-1000M.....	218	VBA-2A-G4-I.....	107		
VAZ-FK-S-BK.....	218	VBA-2A-G4-U.....	107		
VAZ-FK-S-BK-2,5MM.....	218	VBA-2A-G11-I-F.....	107		
VAZ-FK-S-BK-1000M.....	218	VBA-2A-G11-I-V1.....	107		
VAZ-FK-S-BK-SEAL.....	114	VBA-2A-KE2-I/U.....	108		
VAZ-FK-S-YE.....	218	VBA-2E1A-G10-ZAL/E2L-1M-2V1-W.....	88		
VAZ-FK-S-YE-1000M.....	218	VBA-2E2A-G2-ZA/EA2.....	74		
VAZ-FK-S-YE-SAFETY.....	218	VBA-2E2A-G2-ZEJ/XE2J.....	74		
VAZ-FLASH-70MM-RD.....	115	VBA-2E2A-G4-ZE/E2.....	92		
VAZ-FLASH-70MM-YE.....	115	VBA-2E2A-G12-ZAJ/EA2L.....	79		
VAZ-G4-B1.....	223	VBA-2E-G4-I.....	107		
VAZ-G10-TERM.....	216	VBA-2E-G4-U.....	107		
VAZ-HH30-BRACKET.....	159	VBA-2E-G10-ZAJ-1M-V1-W.....	88		
VAZ-HORN-70MM-0...100DBA-8TONE.....	115	VBA-2E-G10-ZEJ-1M-2V1-W.....	88		
VAZ-HORN-70MM-85DBA.....	115	VBA-2E-G11-I/U/PT100-F.....	107		
VAZ-HORN-70MM-105DBA.....	115	VBA-2E-G11-I/U/PT100-V1.....	107		



# SPOTLIGHT on Identification Products

## IDENTControl Solutions

Pepperl+Fuchs offers a wide selection of RFID readers for factory automation. IDENTControl is unique because of its metal housing, graphical display, and universal connectivity to low frequency, high frequency and microwave read heads.

- Metal housing IP67
- Over 50 different tags available
- 14 different read head styles
- EtherNet/IP and DeviceNet connectivity
- Modbus/TCP, TCP/IP, PROFINET, PROFIBUS, RS-232 supported
- Email notification / web page configuration
- IDENTControl compact 1- and 2-channel versions available



## Handheld Solutions

Pepperl+Fuchs handheld solutions are rugged, light weight, and feature full graphical displays. They are often used for inventory management, offline write stations and cordless tracking systems.

- Read/write data to any P+F or ISO standard RFID tag
- Wireless
- Full graphical display with keyboard
- Will read 1-D or 2-D bar codes
- Includes RS-232 / PS2 / USB support



## Applications In:

- Material handling, warehousing, and inventory control
- Printing, labeling, sorting, bulk mailing, and inserting
- Automotive and allied industries
- Pharmaceutical & medical instrumentation
- Factory automation & electronics



## Need Help Solving a Tough Application?

Pepperl+Fuchs wants to ensure that you receive the service and support you need when you need it, 24 hours every day. You can find CAD drawings, download product data sheets, or request free literature. Get it all on the web at [www.pepperl-fuchs.us](http://www.pepperl-fuchs.us).

## Need More? Ask an Expert.

With a click of the mouse, you can get advice from engineers who are experts in AS-Interface technology, who are familiar with a wide range of applications, and who can help you solve your most challenging production requirements. For reliable advice, visit [www.pepperl-fuchs.us/askfa](http://www.pepperl-fuchs.us/askfa) and ask an expert.



Visit us at [www.pepperl-fuchs.us](http://www.pepperl-fuchs.us) or call us at 330-486-0001

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - [sales@steveneng.com](mailto:sales@steveneng.com) - [www.stevenengineering.com](http://www.stevenengineering.com)



# FACTORY AUTOMATION – SENSING YOUR NEEDS



Pepperl+Fuchs sets the standard in quality and innovative technology for the world of automation. Our expertise, dedication, and heritage of innovation have driven us to develop the largest and most versatile line of industrial sensor technologies and interface components in the world. With our global presence, reliable service, and flexible production facilities, Pepperl+Fuchs delivers complete solutions for your automation requirements—wherever you need us.

## Contact

Pepperl+Fuchs Inc.  
1600 Enterprise Parkway  
Twinsburg, Ohio 44087 · USA  
**Tel. +1 330 486-0001 • Fax +1 330 405-4710**  
**E-mail: [fa-info@us.pepperl-fuchs.com](mailto:fa-info@us.pepperl-fuchs.com)**

## Worldwide Headquarters

Pepperl+Fuchs GmbH · Mannheim · Germany  
E-mail: [fa-info@de.pepperl-fuchs.com](mailto:fa-info@de.pepperl-fuchs.com)

## USA Headquarters

Pepperl+Fuchs Inc. · Twinsburg · USA  
E-mail: [fa-info@us.pepperl-fuchs.com](mailto:fa-info@us.pepperl-fuchs.com)

## Asia Pacific Headquarters

Pepperl+Fuchs Pte Ltd · Singapore  
Company Registration no. 199003130E  
E-mail: [fa-info@sg.pepperl-fuchs.com](mailto:fa-info@sg.pepperl-fuchs.com)

**[www.pepperl-fuchs.us](http://www.pepperl-fuchs.us)**

 **PEPPERL+FUCHS**  
*SENSING YOUR NEEDS*

Subject to modifications • © 2012 PEPPERL+FUCHS, INC. • Printed in USA • Part No. 910247 01/12

Courtesy of Steven Engineering, Inc. - (800) 258-9200 - [sales@steveneng.com](mailto:sales@steveneng.com) - [www.stevenengineering.com](http://www.stevenengineering.com)