# **Refrigerated Air Dryer**

# IDFA□E/F Series

# For use in Europe, Asia and Oceania

# Standard/IDFA E Series

●Power supply voltage: Single-phase 230 VAC (50Hz)

	Rated inlet	Air flow c	apacity (m		
Model	condition	Outlet air	pressure of	dew point	Port size
	condition	3°C	7°C	10°C	
IDFA3E		12.0	15.0	17.0	Rc 3/8
IDFA4E		24.0	31.0	34.0	Rc 1/2
IDFA6E		36.0	46.0	50.0	
IDFA8E		65.0	83.0	91.0	Rc 3/4
IDFA11E	35°C	80.0	101.0	112.0	
IDFA15E1	0.7 MPa	120.0	152.0	168.0	Rc 1
IDFA22E		182.0	231.0	254.0	R 1
IDFA37E		273.0	347.0	382.0	R 1 1/2
IDFA55E		390.0	432.0	510.0	
IDFA75E		660.0	720.0	822.0	R 2

# Refrigerant R134a(HFC) R407C(HFC)

for ozone is zero.

AT

IDFA

**IDFB** 

IDH ID

IDG **IDK AMG** AFF AM AMD **AMH** AME

**AMF** 

**ZFC** 

SF

**SFD** 

LLB

AD 🗆

GD

Improved corrosion resistance with the use of stainless steel, plate type heat exchanger (IDFA4E to 75E, 100F to 150F)



# Large size/IDFA□F Series

●Power supply voltage: Three-phase 380 VAC (50Hz) For Asia and Oceania Three-phase 400 VAC (50Hz) For Europe

Tolerant of high temperature environment! Top of its class in the industry for the large air-cooled type

Ambient temperature 45°C at max. Inlet air temperature 60°C at max.

Energy saving design Exhaust heat reduced by 25% at max. Ambient temperature increase suppressed. Employs a heat exchanger made of high corrosion-resistant stainless steel.

# Refrigerant R407C(HFC

Coefficient of destruction fro ozone is zero.

Model	Rated inlet condition	Outlet air pressure dew point	Air flow capacity (m³/h [ANR])	Port size
IDFA100F-38	40°C 0.7 MPa		960	R 2
IDFA125F-38		10°C	1210	R 2 1/2
IDFA150F-38			1500	DIN flange 80
IDFA100F-40	35°C 0.7 MPa	3°C	860	R 2
IDFA125F-40			1100	R 2 1/2
IDFA150F-40			1340	DIN flange 80



# **INDEX**

# 1. Standard Products IDFA□E Series



							1
	Rated		Air flow capacity (m3/h [ANR])				
Model	inlet	Outlet air pressure dew point			Refrigerant	Port size	Page
	condition	3°C	7°C	10°C			
IDFA3E		12	15	17		Rc 3/8	
IDFA4E		24	31	34		Rc 1/2	
IDFA6E		36	46	50	R134a (HFC)	Rc 3/4	D 02 to 04
IDFA8E		65	83	91			P. 92 to 94
IDFA11E	35°C	80	101	112			
IDFA15E1	0.7 MPa	120	152	168		Rc 1	
IDFA22E		182 231 254	R 1				
IDFA37E		273	347	382	R407C (HFC)	R 1 <sup>1</sup> / <sub>2</sub>	P. 95 to 97
IDFA55E		390	432	510	H407C (HFC)	D.O.	F. 95 10 91
IDFA75E		660	720	822		R2	

# 2. Large size



Model	Rated inlet condition	Outlet air pressure dew point	Air flow capacity (m³/h [ANR])	Port size	Page
IDFA100F-38			960	R2	
IDFA125F-38	40°C 0.7 MPa	10°C	1210	R2 1/2	
IDFA150F-38	U.7 IVIFA		1500	DIN flange 80	P. 98 to 100
IDFA100F-40	35°C		860	R2	P. 96 to 100
IDFA125F-40	0.7 MPa		1100	R2 1/2	
IDFA150F-40			1340	DIN flange 80	

# 3. Options

o. Options				
Specifications	Applicable model	Suffix (Option symbol)	Page	
Cool compressed air output	IDFA3E to 11E	IDFA□E-23-A		
Anti-corrosive treatment	IDFA3E to 75E IDFA100F to 150F	IDFA□E-23-C IDFA□F-□-C		
With Chinese labels and a Chinese operation manual	IDFA3E to 75E IDFA100F to 150F	IDFA□E-23-G IDFA□F-□-G	P. 101	
For medium air pressure (Up to 1.6 MPa)	IDFA6E to 37E IDFA100F to 150F	IDFA□E-23-K IDFA□F-□-K		7
With heavy duty auto drain (For medium air pressure)	IDFA4E to 75E	IDFA□E-23-L		
With circuit breaker	IDFA4E to 75E IDFA100F to 150F	IDFA□E-23-R IDFA□F-□-R		
With terminal block for power supply, run & alarm signal and remote operation	IDFA4E to 75E	IDFA□E-23-T	P. 102	
Timer type solenoid valve with auto drain (Applicable to medium air pressure)	IDFA4E to 75E IDFA100F to 150F	IDFA□E-23-V IDFA□F-□-V		

# 4. Optional Accessories

Description	Page
Dust-protecting filter set	P. 103
Foundation bolt set	P. 103

# IDFA E Series **Model Selection**

The corrected air flow capacity, which considers the user's operating conditions, is required for selecting the air dryer. Please select using the following procedures.

However, for 400 VAC, model should also be selected based on the amount of processed air of 380 VAC regarding IDFA100F to 150F. (Correction factor is based on the rated conditions of 380 VAC, so when the factor of rated conditions of 400 VAC is inputted , the amount of processed air of 400 VAC can be found.)

# Read the correction factor.

Obtain the correction factor A to D suitable for your operating condition using the table below.

IDFA□E Selection Example						
Condition Data symbol Correction factor N						
Inlet air temperature	40°C	Α	0.83			
Ambient temperature	35°C	В	0.83			
Inlet air pressure	0.5 MPa	С	0.92			
Air consumption	31 m <sup>3</sup> /h	_	_			

Note) Values obtained from the table below

# Calculate the corrected air flow capacity.

Obtain the corrected air flow capacity from the following formula. Corrected air flow capacity = Air consumption ÷ (Correction factor A x B x C)

Corrected air flow capacity = 31  $m^3/h \div (0.83 \times 0.83 \times 0.92) = 48.9 m^3/h$ 

# Select the model.

Select the model which air flow capacity exceeds the corrected air flow capacity using the specification table. (For air flow capacity, refer to the data D below.)

According to the corrected air flow capacity of 48.9 m3/h, the IDFA8E will be selected when the required output air pressure dew point is 3°C. The IDFA6E will be selected when the required pressure dew point is 10°C.

# Option

Finalize the model number.

Refer to pages 101 and 102. Refer to pages 92, 95 and 98.

Select accessories sold separately.

Refer to page 103.

Data	A:	Inlet	Air	Tempe	erature

Inlet air	Correcti	on factor	Inlet air	Correction factor
temperature (°C)		IDFA55E to 75E	temperature (°C)	IDFA100F to 150F
5 to 25	1.30	1.33	5 to 30	1.41
30	1.25	1.16	35	1.21
35	1	1	40	1
40	0.83	0.8	45	0.92
45	0.7	0.64	50	0.75
50	0.6	0.48	55	0.63
			60	0.53

# **Data B: Ambient Temperature**

Ambient temperature	Correcti	on factor	Ambient temperature	Correction factor
(°C)	IDFA3E to 11E  IDFA15E1 to 75E		(°C)	IDFA100F to 150F
20	1.1	1.1	2 to 25	1.06
25	1	1	30	1.02
30	0.91	0.97	32	1
35	0.83	0.89	35	0.99
40	0.79	0.77	40	0.98
			45	0.92

# Data C: Inlet Air Pressure

Inlet air pressure	Correcti	on factor	Inlet air pressure	Correction factor
(MPa)	IDFA3E to 11E	IDFA15E1 to 75E	(MPa)	IDFA100F to 150F
0.3	0.80	0.72	0.2	0.84
0.4	0.87	0.81	0.3	0.87
0.5	0.92	0.88	0.4	0.9
0.6	0.96	0.95	0.5	0.93
0.7	1.00	1.00	0.6	0.96
0.8	1.04	1.06	0.7	1
0.9	1.07	1.11	0.8	1.03
1	1.1	1.16	0.9	1.06
1.2	1.16	1.21	1 to 1.6	1.09
1.4	1.21	1.25		
1.6	1.25	1.27		

# **Data D: Air Flow Capacity**

Model		Air flow capacity (m³/h [ANR])					
		IDFA3E	IDFA4E	IDFA6E	IDFA8E	IDFA11E	
Outlet air	3°C	12	24	36	65	80	
pressure	7°C	15	31	46	83	101	
dew point	10°C	17	34	50	91	112	
Mary In the State of State of the State of State							

Mode	.1	Air flow capacity (m³/h [ANR])											
Woder		IDFA15E1	IDFA22E	IDFA37E	IDFA55E	IDFA75E							
Outlet air	Outlet air 3°C		182	273	390	660							
pressure	7°C	152	231	347	432	720							
dew point	10°C	168	254	382	510	822							

Mode	.1	Air flow capacity (m <sup>3</sup> /h [ANR])										
IVIOGE	31	IDFA100F	IDFA150F									
Outlet air	3°C	670	860	1045								
pressure	7°C	816	1029	1275								
dew point	10°C	960	1210	1500								

HAW AT

IDF

IDU

IDF

IDFA

**IDFB** 

IDH

ID

IDG

IDK

AMG

AFF

AM AMD

AMH AME AMF **ZFC** SF

SFD


LLB AD 🗆 GD

# Refrigerant R134a (HFC) IDFA E Series

3E, 4E, 6E, 8E, 11E, 15E (Inlet air temperature: 35°C)

 $\epsilon$ 

# How to Order



#### Options and Available Combinations (Size/Option)

									, -   ,
Symbol Note 2)	Nil	Α	С	G	K	L	R	Т	V
Option	None	Cool compressed air output	Anti- corrosive treatment	With Chinese labels and a Chinese operation manual	For medium air pressure ( Auto drain bowl type: ( Metal bowl with level gauge )	With heavy duty auto drain (Applicable to medium air pressure)	With circuit breaker	With terminal block for run & alarm signal	Timer type solenoid valve with auto drain (Applicable to medium air pressure)
3E	•	•	•	•	_	_	_	_	_
4E	•	•	•	•	_	•	•	•	•
6E	•	•	•	•	•	•	•	•	•
8E	•	•	•	•	•	•	•	•	•
11E • •		•	•	•	•	•	•	•	
15F1	•	_	•	•	•	•	•	•	•

Note 1) G thread (PF thread) can accept the R thread (PT male thread), thus making no "F" in the thread specification setting.

A conversion hexagon nipple for the R thread (PT male thread) is also contained.

Note 2) Enter alphabetically when multiple options are combined. However, the following combination cannot be achieved.

Combination of K, L and V cannot be achieved because an auto drain can only be attached to a single option.

Note 3) Refer to pages 101 and 102 for further details on optional specifications.

Note 4) Option "H" (Auto-drain bowl type: Metal bowl) is only applicable to the IDFA6E-20. However, options K, L, and V cannot be selected in combination.

# Refrigerated Air Dryer IDFA E Series

# Standard Specifications



Mode	Standard temperature air inlet  IDFA3E   IDFA4E   IDFA6E   IDFA11E   IDFA15E1									
Specifications	IDFA3E	IDFA4E	IDFA6E Note 9)	IDFA8E	IDFA11E	IDFA15E1				
Fluid			Compre	ssed air		•				
Inlet air temperature   (°C)   Inlet air pressure   (MPa)   Ambient temperature (Humidity)   (°C)			5	to 50						
Inlet air pressure (MPa)			0.15	to 1.0						
Ambient temperature (Humidity) (°C)		2 to 40 (Relative humidity of 85% or less)								
Note 1) Outlet air pressure dew point (3°C)	12									
Standard condition Outlet air pressure dew point (7°C	15	31	46	83	101	152				
Air flow capacity (ANR) Outlet air pressure dew point (10°C)	17	34	50	91	112	168				
e m³/h Com-Note 2) Outlet air pressure dew point (3°C)	13	25	37	68	83	125				
pressor outlet air pressure dew point (7°C)	16	32	48	86	105	158				
m <sup>3</sup> /h Com-loc <sup>2</sup> Outlet in pressure dew point. (3°C outlet are pressure dew point. (10°C outlet are pressure dew point. (	18	35	52	95	116	175				
Inlet air pressure (MPa)	0.7									
Inlet air temperature (°C)		35								
Ambient temperature (°C)			2	5						
Power supply voltage	Single	e-phase: 23	0 VAC [Volt	age fluctua	ation ±10%]	50 Hz				
Power consumption Note 6) (W) Operating current Note 6) (A)	180 208 385 4									
Operating current Note 6) (A)		1.2		1.4	2.7	2.9				
Applicable circuit breaker capacity $^{\text{Note 5}}$ (sensitivity current 30 mA)		5 10								
Condenser			Air-ce	ooled						
Refrigerant			R134a	(HFC)						
Refrigerant charge (kg)	0.15	0.2	0.23	0.27	0.29	0.47				
Auto drain		FI	oat type (No	ormally ope	en)					
Port size	Rc 3/8	Rc 1/2		Rc 3/4		Rc 1				
Accessory	Hexagon nipple									
Weight (kg)	18	22	23	27	28	46				
Coating color	Body panel: White 1 Base: Gray 2									
Compliant standards	EC Directive (with CE marking)									
	on (ANR) [atmospheric pressure at 20°C, relative humidity at 65%]									

Symbol Refrigerated air dryer Auto drain

Note 2) Air flow capacity converted by the compressor intake condition [atmospheric pressure at 32°C, relative humidity at 75%]

Note 3) The operation range does not guarantee the use with normal air flow capacity.

Note 4) Please select a model in accordance with the Model Selection (Page 91). Note 5) Product other than the option R is not equipped with an earth leakage breaker. Please purchase an appropriate earth leakage breaker separately.

Note 6) These values are reference values under rated conditions, and are not guaranteed. Do not use these values for the thermal set values, etc.

Note 7) When a short-term interruption of the power supply (including momentary interruption) occurs in this equipment, the restarting of normal operations may require some time or may be impossible due to the operation of protective devices even after the supply of power returns.

Replacement Parts			Body
Model	IDFA3E IDFA4E	IDFA6E   IDFA8E   IDFA11E   IDFA15E1	
Auto drain replacement part no. Note 8)	AD38	AD48	Auto drain
8) The part number for the auto drain	n components without	including the body part.	Auto drain


Note Body part replacement is impossible

Note 9) The specifications of the IDFA6E-20 are the same as those of the IDF6E-20 (page 29) aside from the compliant standards.


# Construction Principle (Air/Refrigerant Circuit)

Humid, hot air coming into the air dryer will be cooled down by a cooler re-heater (heat exchanger). Water condensed at this time will be removed from the air by auto drain and drained out automatically. Air separa-ted from the water will be heated by a cooler re-heater (heat exchanger) to obtain the dried air, which goes through to the outlet side

## IDFA3E



# **IDFA4E. IDFA6E** IDFA8E, IDFA11E, IDFA15E1



IDF IDU IDF

HAA HAW AT

IDFA IDFB

IDH ID

IDG IDK

AMG AFF

AM

AMD

AMH AME

AMF

ZFC

SF

SFD


LLB


 $\mathsf{AD}\square$ 


# IDFA□E Series

# **Dimensions**

# IDFA3E to 15E1







Dimension	ns													(mm)
Model	Port size	Α	В	С	D	Е	F	G	K*	L*	M*	N*	Р	Q
IDFA3E	Rc 3/8	226	410	473	67	125	304	33	36	154	21	330		15
IDFA4E	Rc 1/2		453	400			000					075		13
IDFA6E			455	498	0.4	40	283			040		275	_	
IDFA8E	Rc 3/4	270	405		31	42	055	80	15	240	80	000		15
IDFA11E			485	568			355					300		
IDFA15E1	Rc 1	300	603	578	41	54	396	87		43	101	380	314	16


<sup>\*</sup> Meaning the foot dimensions for the IDFA3E.

# Refrigerant R407C (HFC) IDFA E Series

22E, 37E, 55E, 75E (Inlet air temperature: 35°C)



**How to Order** 



# Options and Available Combinations (Size/Option)

Symbol Note 2)	Nil	С	G	K	L	R	T	V
Option	None	Anti- corrosive treatment	With Chinese labels and a Chinese operation manual	For medium air pressure ( Auto drain bowl type: ( Metal bowl with level gauge )	With heavy duty auto drain (Applicable to medium air pressure)	With circuit breaker	With terminal block for run & alarm signal	Timer type solenoid valve with auto drain (Applicable to medium air pressure)
22E	•	•	•	•	•	•	•	•
37E	•	•	•	•	•	•	•	•
55E	•	•	•	_	•	•	•	•
75E	•	•	•	_	•	•	•	•

Note 1) G thread (PF thread) can accept the R thread (PT male thread), thus making no "F" in the thread specification setting. Note 2) Enter alphabetically when multiple options are combined.

However, the following combination cannot be achieved.

. Combination of K, L and V cannot be achieved because an auto drain can only be attached to a single option.

Note 3) Refer to pages 101 and 102 for further details on optional specifications.

AT

İĎŪ IDF

IDFA

IDFB

IDH ID

IDG

IDK

AMG AFF

AM

AMD

AMH AME

AMF

ZFC

SF

SFD LLB

 $\mathsf{AD}\square$ 

# IDFA E Series



# Refrigerated air dryer Auto drain

# Standard Specifications

			N	/lodel	Sta	andard temp	erature air ir	ılet				
	ecifications	S			IDFA22E	IDFA37E	IDFA55E	IDFA75E				
Note 3)	Fluid				Compressed air							
Operating range	Inlet air te	emperatu	ire	(°C)		5	to 50					
ating	Inlet air p	ressure	(1	MPa)		0.15	to 1.0					
Oper	Ambient	temperat	ure (Humidity)	(°C)	2 to 40 (	Relative hun	nidity of 85%	or less)				
		Note 1) Standard	Outlet air pressure dew point	(3°C)	182	273	390	660				
æ l	A ! 41	condition	Outlet air pressure dew point	(7°C)	231	347	432	720				
Note 4)	Air flow capacity	(ANR)	Outlet air pressure dew point	(10°C)	254	382	510	822				
	m³/h	Com-Note 2)	Outlet air pressure dew point	(3°C)	189	284	405	686				
ä		pressor intake	Outlet air pressure dew point	(7°C)	240	361	449	748				
eciti		condition	Outlet air pressure dew point	(10°C)	264	854						
Rated specifications	Inlet air p	ressure	(1	MPa)		0.7						
Rate	Inlet air to	emperatu	ire	(°C)		3	5					
	Ambient			(°C)		2	-					
	Power su					230 VAC [Volt						
trica	Power co	nsumpti	on Note 6)	(W)	760 1390			1700				
				(A)	4.3 6.1			7.9				
·	•	rcuit brea	aker capacity Note 5)	(A)		10		20				
Cc	ndenser					Air-ce						
Re	frigerant					R407C	(HFC)					
Re	frigerant o	charge		(kg)	0.42	0.73	0.55	0.67				
Αu	ito drain					Float (Normal						
Po	rt size				R 1	R 11/2	R	2				
Αc	cessory					-	_					
We	eight			(kg)	54 62 100			116				
Co	ating cold	or				Body pane Base: Gra						
Co	mpliant st	tandards			EC	Directive (w	ith CE marki	ing)				
Note	e 1) Air flow o	capacity un	der the standard condition	on (AN	R) [atmospheric	pressure at 2	0°C, relative hu	midity at 65%]				

Note 1) Air flow capacity under the standard condition (ANR) [atmospheric pressure at 20°C, relative humidity at 65%] Note 2) Air flow capacity converted by the compressor intake condition [atmospheric pressure at 32°C, relative humidity at 75%].

Note 3) The operation range does not guarantee the use with normal air flow capacity.

Note 4) When operating conditions are different from the rated specifications, please select a model in accordance with the Model Selection (Page 91).

Note 5) Product other than the option R is not equipped with an earth leakage breaker. Please purchase an appropriate earth leakage breaker separately. Note 6) These values are reference values under rated conditions, and are not guaranteed. Do not use these val-

Note 6) These values are reference values under rated conditions, and are not guaranteed. Do not use these values for the thermal set values, etc.


Note 7) When a short-term interruption of the power supply (including momentary interruption) occurs in this equipment, the restarting of normal operations may require some time or may be impossible due to the operation of protective devices even after the supply of power returns.

Auto drain

- 4	nepiacement raits					
	Model	IDFA22E	IDFA37E	IDFA55E	IDFA75E	1
	Auto drain replacement part no. Note 8)		AD	048		]
e 8	B) The part number for the auto drain com Body part replacement is impossible.	ponents with	out including	the body pa	rt.	Body


# **Construction Principle (Air/Refrigerant Circuit)**


Humid, hot air coming into the air dryer will be cooled down by a cooler re-heater (heat exchanger). Water condensed at this time will be removed from the air by auto drain and drained out automatically. Air separated from the water will be heated by a cooler re-heater (heat exchanger) to obtain the dried air, which goes through to the outlet side.



# **Dimensions**

# IDFA22E, IDFA37E







# Dimensions

														()
Model	Port size	Α	В	С	D	Е	F	G	K	L	M	N	Р	Q
IDFA22E	R 1	290	775	623	134	405	698		10	25	0.5	600	340	
IDFA37E	R 1 <sup>1</sup> / <sub>2</sub>	290	855	623	134	405	698	93	13	25	85	680	340	_

# **IDFA55E, IDFA75E**





(mm)

)imen	sions	

Model	Port size	Α	В	С	D	E	F	G	K	L	М	N	Р	Q	R
IDFA55E	D 0	470	٥٠٠	800	(400)	(070)	(868)	(110)	10	-00	75	700	F00	(110)	F10
IDFA75E	H2	2 470	855	900		(2/3)	(968)	(110)	13	500	/5	700	526	(110)	519

**SMC** 

IDF IDFA
IDFA
IDFB
IDH
IDG

IDK

AMG AFF AM

AMD AMH

AME AMF ZFC

SFD LLB AD

# Refrigerant R407C (HFC)


# IDFA100F/125F/150F Series

For use in Europe, Asia and Oceania


(Max. inlet air temperature: 60°C, Max. ambient temperature: 45°C)

( (

# **How to Order**



Note) Enter alphabetically when multiple options are combined. Example: When the IDFA100F-38 is provided with options C or R or V, the model number will be the IDFA100F-38-CRV.



Note) Enter alphabetically when multiple options are combined. Example: When the IDFA100F-40 is provided with options C or R or V, the model number will be the IDFA100F-40-CRV.

# Refrigerated Air Drver IDFA100F/125F/150F Series

# Standard Specifications





		Model		in Asia and			r use in Euro			
	ecifications		IDFA100F-38	IDFA125F-38	IDFA150F-38	IDFA100F-40	IDFA125F-40	IDFA150F-40		
<b>ದ</b> ್ಣ	Fluid			Compressed air						
ati ∑	Inlet air tempe	rature °C		5 to 60						
Operating range Note 3)	Inlet air pressu	ure MPa	ı	0.15 to 1.0/0.15 to 1.6 for option K						
ΟĒ	Ambient temperature			2 to 45	(Relative hu	midity 85%	or less)			
us	Air flow capacity	Standard condition (ANR) Note 1	960	1210	1500	860	1100	1340		
conditions	m³/h	Compressor intake Note 2 condition	1000	1255	1560	875	1119	1363		
	Inlet air pressu		ı		0	.7				
Rated	Inlet air tempe			40			35			
Bal	Ambient temp			32		25				
- 9	Outlet air pressure of	dew point °C		10		3				
tions	Power supply	voltage	Thre	e-phase 380	VAC	Thre	e-phase 400	VAC		
Sectr	Power supply Power consum Operating curi	ption kW	2.8	3.4	3.4	2.5	2.7	2.7		
Beds	Operating curi	rent A	5.1	6.3	6.3	4.5	5.3	5.9		
	plicable circuit I pacity Note 4)	breaker A			1	5				
	at discharge fro ndenser	m kW	7.5	9	11.5	7	8	10		
Re	frigerant				R407C	(HFC)		•		
Re	frigerant charg	je kg	1.25	1.36	2.0	1.25	1.36	1.8		
Αι	ıto drain	-		loat type (Nostands for a			9.			
Port size			R2	R2 1/2	DIN flange 80	R2	R2 1/2	DIN flange 80		
W	eight	kg	245	270	350	245	270	350		
Cc	pating color			Body panel: White 1 Base: Gray 2						
Co	mpliant standa	ards		EC Dire	ctive complia	nt (with CE i	marking)			
Note	1) Air flow canaci	ity under the s	andard condition (AND) (atmospheric proceure 20°C, relative humidity 65°/1							

Note 1) Air flow capacity under the standard condition (ANR) [atmospheric pressure 20°C, relative humidity 65%] Note 2) Air flow capacity converted by the compressor intake condition [atmospheric pressure 32°C]

Note 3) The operation range does not guarantee the use with normal air flow capacity. When operating conditions are

different from the rated specifications, please select a model in accordance with Model Selection (page 91). Note 4) Install a circuit breaker with a sensitivity 30 mA.

Air dryer model	IDFA100F	IDFA125F	IDFA150F
Heavy duty auto drain replacement part no. Note 5)	ADH-E400		
Dustproof filter set for condenser	IDF-FL219		IDF-FL220

Note 5) Part number of only the exhaust mechanism replacement kit excluding the housing



HAA HAW AT IDU

IDFA IDFB IDH ID IDG IDK AMG AFF

AM

AMD

AMH

AME

AMF **ZFC** 

SF

SFD

LLB

 $\mathsf{AD}\square$ 

GD


# Construction (Air/Refrigerant Circuit)

#### IDFA100F/125F/150F

Symbol

Refrigerated air dryer

Auto drain



Hot and humid air entering the air dryer is cooled down by the cooler re-heater (heat exchanger). The moisture which is condensed and separated is automatically exhausted by the auto drain. The air which has had its moisture removed is heated in two stages by the re-heater (heat exchanger) in the cooler re-heater and by the secondary heater, and is supplied to the outlet side as warm and dry air.

# Secondary heater

Compressed air from which drainage has been exhausted exchanges heat with refrigerant which has been compressed by the refrigerator, to give the following effects:


- 1. The outlet air temperature increases, preventing condensation of the piping on the outlet side.
- 2. The amount of heat exhausted from the condenser is reduced.
- 3. Energy saving operation of the dryer is achieved by reducing the amount of heat exhausted from the condenser.



# IDFA100F/125F/150F Series

# **Dimensions**


# IDFA100F/125F



Note) In addition to the overall length of the body, the filter mounting part (bracket) projects 10 mm.

Dimension	าร												(mm)		
Model	Port size	Α	В	С	D	E	F	G	K	L	M	N	Р		
IDFA100F	R2	670	1120	1100 1070	1076	1276	276 267	460	1375	335	20	20 712	107	700	752
IDFA125F	R2 1/2	700	1120	12/6	267	655	13/5	350	20	/12	78	935	752		

# IDFA150F



Dimensions (mm)														
Model	Port size	Α	В	С	D	E	F	G	K	L	M	N	Р	
IDEA150E	DIN florage 90	050	1200	1222	260	720	1/132	475	20	000	217	025	1020	

100

# IDFA E/F Series **Options 1**

For "How to Order" optional models, refer to pages 92, 95 and 98.

# Option symbol Cool compressed air output

IDFA3E to 11E

There is no heating of cooled, dehumidified air as it leaves the air dryer The air flow capacity with this option is smaller than that of the standard dryer. (The external dimensions are identical with the standard product.) Note) Perform thermal insulation treatment for piping and equipment installed after the dryer to prevent the formation of condensation.

### Air Flow Capacity

Model	IDFA3E	IDFA4E	IDFA6E	IDFA8E	IDFA11E
Air flow capacity m3/h (ANR)	8	23	29	32	39

Conditions: Inlet air pressure: 0.7 MPa, Inlet air temperature: 35°C Outlet air temperature: 10°C Ambient temperature: 25°C

# Option symbol

IDFA all models Anti-corrosive treatment

This minimizes the corrosion of the copper and copper alloy parts when the air dryer is used in an atmosphere containing hydrogen sulfide or sulfurous acid gas. (Corrosion cannot be completely prevented.) Special epoxy coating: Copper tube and copper alloy parts.

The coating is not applied on the heat exchanger or around electrical parts, where operation may be affected by the coating.

\* Corrosion is not covered under warranty.

# Option symbol

With Chinese labels and a Chinese operation manual

IDFA all models

In addition, Chinese labels are put on the external panels. A Chinese operation manual is also included.

# Option symbol

Moderate pressure specification Auto drain bowl type: Metal bowl with level gauge

IDFA6E to 37E

The auto drain is changed from the standard one to one with a moderate pressure specification

A metal bowl with a level gauge which can confirm the water level is used for the auto drain

#### Specifications

- 1. Maximum operating pressure: 1.6 MPa
- 2. Dimensions ... same as standard products

#### Replacement Parts

Model	Auto drain assembly part no.	Note
IDFA6E to 15E1	IDF-S0086	The AD48-8-X2110 auto drain, insulator, and One-touch fitting are included.
IDFA22E, 37E	AD48-8-X2110	Single auto drain unit



The maximum operating pressure is 1.6 MPa The internal drain piping material is changed from nylon to metal

# Specifications

- 1. Maximum operating pressure: 1.6 MPa
- 2. Dimensions ... same as standard products

#### Option symbol With heavy duty auto drain IDFA4F to 75F (Applicable to moderate air pressure

The float type auto drain used in the standard air dryer is replaced with a heavy duty auto drain (ADH4000-04) which enables the drainage to discharge more efficiently.

### IDFA4E to 15E

(mm)		
Α		
55		
67		
139		
47		

HAA

HAW

AT

IDF

iĐÙ

IDF **□FS** 

IDFA

**IDFB** 

IDH

ID

IDG


IDK

SF


SFD

LLB

AD 🗆 GD



#### IDFA22E to 75E



Note 1) The heavy duty auto drain and the ball valve are both enclosed in the same shipping package as the main body of the air dryer. Customers are required to mount the parts to the air dryer. (Except IDFA22E to 75E)

Note 2) Customers will need to supply the fitting and tubing for the drain piping. (Except IDFA22E to 75F)

#### Penlacement Parte: Heavy Duty Auto Drain

Replacement Parts: neavy Duty Auto Drain								
Model	Replacement part no. (Description)	Configuration						
IDFA4E to 15E1	ADH4000-04 (Heavy duty auto drain)	Heavy duty auto drain						
IDFA22E to 75E	ADH-E400 (Replacement kit for exhaust mechanism)	Replacement kit for exhaust mechanism  Housing (You don't need to purchase a new housing.)						

# IDFA□E/F Series Options 2


For "How to Order" optional models, refer to pages 92, 95 and 98.



IDFA4E to 75E, IDFA100F to 150F


A circuit breaker with cover is attached to the side of the air dryer. This saves additional electrical wiring at the time of installation.

#### IDFA4E to 15E1




Dimensions (mi							
Model	Α	В	С	D	E		
IDFA4E, 6E, 8E, 11E	32	230	97	34	15		
IDFA15E1	43	258	102	82	_		

## IDFA22E to 75E



ı	Dimensions (mi						
	Model	Α	В	С	D	E	F
	IDFA22E	125	59		40	25	46
Ī	IDFA37E	125	39	60			46
	IDFA55E	148	81	60	60	50	36
Ī	IDFA75E	133	73		00	50	30

# IDF100F to 150F



(mm)
В
535
5 333
537

# **Breaker Capacity and Sensitivity Current**

	Voltage	Model	Breaker capacity	Sensitivity current	
	IDFA4E-23, IDFA6E-23 IDFA8E-23, IDFA11E-23	5 A			
	230 V type	IDFA15E1-23, IDFA22E-23 IDFA37E-23, IDFA55E-23	10 A	30 mA	
		IDFA75E-23	20 A		
	380/400 V type	IDFA100F, IDFA125F IDFA150F	15 A		

# Option symbol

With terminal block for power supply, run & alarm signal and remote operation

IDFA4E to 75E


In addition to the terminals for the power supply, terminals for the operating signal and the error signal are also available. (No-voltage contact) Also, in the case of remote control, operate it from the power supply side while the air dryer switch remains ON.

Contact capacity: 230 VAC, 4 A 24 VDC, 5 A for operating and error signals.

Minimum current value: 20 V, 5 mA (AC/DC) for operating and error signals.


Note 1) Terminal block for power supply, run & alarm signal and remote operation is mounted on the standard types of the IDFA100F to 150F.

Note 2) Please be sure to confirm the electric circuits with the drawings or instruction manual before using the output signal.



Dimensions (mm)				
Model	Α	В	С	D
IDFA4E, 6E, 8E, 11E	32	230	67	179
IDFA15E1	43	258	77	158

# IDFA22E to 75E



Dimensions				(mm)
Model	Α	В	С	D
IDFA22E, 37E	25	46	135	81
IDFA55E, 75E	50	36	207	81

# Option sy

Timer type solenoid valve with auto drain (Applicable to medium air pressure)

IDFA4E to 75E IDFA100F to 150F

Drainage is discharged by controlling a solenoid valve with a timer.

A strainer for solenoid valve protection and stop valve are also included.
(Dimensions are the same as the standard type.)

Maximum operating pressure: 1.6 MPa (IDFA100F to 150F: 1.0 MPa)

\* The timer-type solenoid valve actuates once (for 0.5 s) every 30 s.

### Replacement Parts

Model	Part no.	Note
IDFA4E to 37E	IDF-S0198	230 VAC
IDFA55E, 75E	IDF-S0302	230 VAC
IDFA100F to 150F	IDF-S0405	200 VAC

# IDFA E/F Series **Optional Accessories**

		Features	Specifications	Applicable dryer
Dust-protecting filter set		Prevents a decline in the performance of the air dryer, even in a dusty atmosphere.	Max. ambient temperature 40°C	IDFA3E to 75E
Foundation bolt set	N.	Bolts for fixing the air dryer to the foundations.  Easy to secure by striking its axle.	Stainless steel	IDFA4E to 75E IDFA100F to 150F

# How to Order

**Dust-protecting filter set** 

Applicable dryer •				
Symbol	Applicable dryer			
209	IDFA3E			
202	IDFA4E			
203	IDFA6E			
204	IDFA8E			
205	IDFA11E			
206	IDFA15E1			
207	IDFA22E			
208	IDFA37E			
213	IDFA55E			
214	IDFA75E			

Foundation bolt set

IDF-AB 500


Applicable dryer

Symbol	Applicable dryer	
500	IDFA4E to 75E	
501	IDFA100F to 150F	

# **Dust-protecting Filter Set/Dimensions**








			V			
IDF-FL	202	to	208.	213.	21	4)

Dimension	s			(mm)
Part no.	Applicable dryer	Α	В	Weight (g)
IDF-FL209	IDFA3E	220	240	35
IDF-FL202	IDFA4E	310	405	45
IDF-FL203	IDFA6E	375	195	55
IDF-FL204	IDFA8E	340	265	70
IDF-FL205	IDFA11E	375	205	75
IDF-FL206	IDFA15E1	440	370	120
IDF-FL207	IDFA22E	420	315	100
IDF-FL208	IDFA37E	550	365	140
IDF-FI 213	IDEA55E	720	400	175

610 560

IDF-FL214 IDFA75E

# **Foundation Bolt Set/Dimensions**



Dimensions					(mm
Part no.	Applicable dryer	Nominal thread size	Material	Pcs. of 1 set	Α
IDF-AB500	IDFA4E to 75E	M10	Stainless steel	4	50
IDF-AB501	IDFA100F to 150F	IVITO	Stamless steel	4	70

**ØSMC** 

HAA HAW AT IDF İĎŪ IDF

IDFA

IDFB

IDH ID IDG IDK AMG AFF AM

AMD AMH AME AMF

ZFC SF

SFD

LLB

AD□



# IDFA□E/F Series Specific Product Precautions 1


Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 6 to 8 for Air Preparation
Equipment Precautions.

#### Installation

# 

- Avoid locations where the air dryer will be in direct contact with wind and rain. (Places where relative humidity is greater than 85%)
- · Avoid exposure to direct sunlight.
- Avoid locations that contain much dust, corrosive gases, or flammable gases. Failure due to corrosion is not covered under warranty. However, when the risk of corrosion is high, select "Option C" (copper tubing with anti-corrosive treatment).
- · Avoid locations of poor ventilation and high temperature.
- Avoid too close to a wall etc. Leave sufficient room between the dryer and the wall according to the "Maintenance space" in the operation manual.
- Avoid locations where a dryer could draw in high temperature air that is discharged from an air compressor or other dryer.



The air exhaust should not flow into the neighboring equipment. (Top side)

- · Avoid locations subjected to vibration.
- Avoid possible locations where the drain can freeze.
- Use the air dryer with an ambient temperature lower than 40°C.
- Avoid installation on machines for transporting, such as trucks, ships, etc.
- Avoid locations which experience sudden pressure/flow rate changes.

## **Drain Tube**

# **⚠** Caution

- A polyurethane tube is attached as a drain tube for the IDFA3E to 75E and IDFA100F to 150F. Use this tube to discharge drainage.
- Do not use the drain tube in an upward direction. Do not bend or crush the drain tube. (Operation of the auto drain will stop water vapor from discharging through the air outlet.)

  If it is unavoidable that the tube goes unwards make sure it only.

If it is unavoidable that the tube goes upwards, make sure it only goes as far as the position of the auto drain.

# **Power Supply**

# **⚠** Caution

- · Connect the power supply to the terminal block.
- · Install a suitable circuit breaker applicable for the specific model.
- The voltage fluctuation should be maintained within  $\pm 10\%$  of the rated voltage.

Note) Select a circuit breaker with a sensitivity current 30 mA. As regards rated current, refer to "Applicable circuit breaker capacity" on pages 93, 96 and 99.


# Air Piping


# **⚠** Caution

- Be careful to avoid an error in connecting the air piping at the compressed air inlet (IN) and outlet (OUT).
- · Install by-pass piping since it is needed for maintenance.

# Compressed air inlet Compressed air outlet Valve closed Valve open

#### IDFA4E to 15E1







# IDFA□E/F Series Specific Product Precautions 2

Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 6 to 8 for Air Preparation Equipment Precautions.

# Air Piping Caution IDFA55E, 75E Compressed air outlet Valve closed Valve open

- When tightening piping at the air inlet/outlet tube, the hexagonal parts of the port on the air dryer side or piping should be held firmly with a spanner or adjustable angle wrench.
- Variations in operating conditions may cause condensation to form at the surface of the outlet piping. Apply thermal insulation around the piping to prevent condensation from forming.
- Vibration resulting from the compressor should not be transmitted through air piping to the air dryer.
- Do not allow the weight of the piping to lie directly on the air dryer.
- If a metallic flexible tubing is used for the inlet/outlet air piping, abnormal noise might be generated in the piping. In that case, please change it to the rigid tubing.

# **Protection Circuit**

# **⚠** Caution

When the air dryer is operated under the following stated conditions, a protection circuit is activated, the light turns off and operation stops.

- . When the compressed air temperature is too high.
- When the compressed air flow rate is too high.
- When the ambient temperature is too high. (40°C or higher, however, 45°C or higher for IDFA100F to 150F)
- When the fluctuation of the power supply is beyond the rated voltage ±10%.
- When the dryer is drawing in high temperature air that is discharged from an air compressor or other dryer.
- The ventilation port is obstructed by a wall or clogged with dust.

# **Compressor Air Delivery**

# **↑** Caution

Use an air compressor with an air delivery of 100 L/min or larger with the IDFA3E to 75E series.

Since the auto drain of the IDFA3E to 75E is designed in such a way that the valve remains open unless the air pressure rises to 0.15 MPa or higher (0.05 MPa or more for IDFA100F to 150F), air will blow out from the drain discharge port at the time of air compressor start-up until the pressure increases. Therefore, if an air compressor has a small air delivery, the pressure may not be sufficient.

# **Auto Drain**

# 

The auto drain may not function properly, depending on the quality of the compressed air. Check the operation once a day.

# **Cleaning of Ventilation Area**

# 

Remove dust from the ventilation area once a month using a vacuum cleaner or an air blow nozzle.

# **Delay for Restarting**

# 

- Allow at least three minutes before restarting the dryer. If the air dryer is restarted within three minutes after being stopped, the protection circuit will be activated, operating light turns off and the dryer will not be activated.
- The residual drainage in the air dryer may splash over the outlet when the operation is re-started, so it is recommended to install a filter on the outlet of the air dryer.

# Modifying the Standard Specifications

# **⚠** Caution

Do not modify the standard product using any of the optional specifications once the product has been supplied to a customer. Check the specifications carefully before selecting an air dryer.

HAA HAW

AT IDF

IDU IDF □FS

IDFA IDFB

IDH ID

IDG IDK

AMG

AFF

AMD

AMH

AME

AMF ZFC

SF

SFD

AD□



# *IDFA*□*E/F Series*Specific Product Precautions 3

Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 6 to 8 for Air Preparation Equipment Precautions.

# ■ Refrigerant with GWP reference

	Global warming potential (GWP)		
Refrigerant	Regulation (EU) No 517/2014 (Based on the IPCC AR4)	Revised Fluorocarbons Recovery and Destruction Law (Japanese low)	
R134a	1,430	1,430	
R404A	3,922	3,920	
R407C	1,774	1,770	
R410A	2,088	2,090	

Note 1) This product is hermetically sealed and contains fluorinated greenhouse gases (HFC). When this product is sold on the market in the EU after January 1, 2017, it needs to be compliant with the quota system of the F-Gas Regulation in the EU.

Note 2) See specification table for refrigerant used in the product.