3 Port Solenoid Valve

V100 Series

Rubber Seal

CE



Note) Refer to page 1367 for details.

Standard

Large flow capacity

V124

V114A

V124A

Coil temperature rises: 1°C (with power saving circuit)

N.O.

N.C.

N.O.

Sonic condu	ctance	C: 0.037 (Standard)/C: 0.076 (Large flow capacity)									
Series			Flow rate characteristics								
Jenes		C[dm³/(s.b	ar)]	b			Cv	V100			
Standard	V1□4	0.037		0.11			0.008	S070			
Large flow capacity	V1□4A	0.076		0.070			0.016	0070			
Maniations								VQD			
Variations								VQD-V			
		Turne of	Oranatia		Po	wer cons	umption (W)	VUD-V			
Series		Type of actuation	Operatin	g pressure range (MPa)	Stan	Idard	VK				
Standard	V114	N.C.		0 to 0.7	0.3	35	0.1*	VT			

0 to 0.7

0 to 0.7

0 to 0.7

Note) Refer to page 1367 for details.

0.1*

_

0.35

1

1


1357

VV061

3 Port Solenoid Valve/Direct Operated V100 Series **Rubber Seal**



Specifications



Note 1) Based on dynamic performance test JIS B8419; 2010 (standard type; at coil temperature of 20°C, with rated voltage, without surge voltage suppressor)

Note 2) Impact resistance: No malfunction resulted in an impact test using a drop impact tester. The test was performed one time each in the axial and right angle directions of the main valve and armature, for both energized and de-energized states. (Value in the initial stage)

Vibration resistance: No malfunction resulted in 45 to 2000 Hz, a one-sweep test performed in the axial and right angle directions of the main valve and armature for both energized and de-energized states. (Value in the initial stage)

Solenoid Specifications

Series			V114/V124	V114A/V124A				
Jelles			V114/V124 V114A/V124A					
Electrical entry			Grommet (G)/(H), L plug connector(L) M plug connector (M)					
Coil rated voltage (V)	DC		24, 12,	6, 5, 3				
con rated voltage (v)	AC 50/60 Hz		100, 110, 200, 220	—				
Allowable voltage fluc	tuatio	n	-10 to 1	10% *				
Power consumption (W)	consumption DC		Standard: 0.35 (with light: 0.4) With power saving circuit 0.1 Note) [Starting 0.4, Holding 0.1]	1 W (with light: 1.1)				
		100 V	0.78 (with light: 0.81)	-				
Apparent power (VA)	AC	110 V [115 V]	0.86 (with light: 0.89) [0.94 (with light: 0.97)]	_				
Apparent poner (TA)	70	200 V	1.18 (with light: 1.22)	-				
			1.30 (with light: 1.34) [1.42 (with light: 1.46)]	_				
Surge voltage suppres	ssor		Refer to page 1367.					
Indicator light			LE	Ð				

* Can be used for 110 VAC and 115 VAC, 220 VAC and 230 VAC in common.

* For 115 VAC and 230 VAC, the allowable voltage fluctuation will be -15% to 5% of the coil rated voltage.

* The voltage drop will occur due to the internal circuit of S, Z and T types (with energy saving circuits).

Allowable voltage fluctuations should be within the range below.


S and Z types 24 VDC: -7% to +10%

12 VDC: -6% to +10%

* Select the DC standard type or the power saving circuit type when the valve is continuously energized for long periods of time. Note) Refer to page 1367 for details.



Symbol



3 Port Solenoid Valve V100 Series

Specifications

Valve	Model Operating Note 4) Pressure range (MPa)		Vacuum specific	ation (MPa) Note 4)	Port	size	Weight (g) Note 2)		
model	Typactu	Woder	range (MPa)	Port 1	Port 3	Port 1, 3	Port 2	Grommet	L plug connector M plug connector
V114	N.C.	Standard	0 to 0.7	-100 kPa to 0.6	-100 kPa to 0	M5 x 0.8	M5 x 0.8		Plug connector
V114A	N.C.	Large flow capacity	0 to 0.7	-100 kPa to 0.6	-100 kPa to 0	M5 x 0.8	M5 x 0.8	V1□4:13(27)	V1[]4:12(26)
V124 Note 1)	N.O.	Standard	0 to 0.7	-100 kPa to 0	-100 kPa to 0.6	M5 x 0.8	M5 x 0.8		V1_4A:15(29)
V124A Note 1)	N.O.	Large flow capacity	0 to 0.7	-100 kPa to 0	-100 kPa to 0.6	M5 x 0.8	M5 x 0.8	VILL4A.10(50)	VI4A. 13(23)

Valve	Flow rate characteristics												
model		1→2 [3→2 Note 3)]		2→3 [2→1 Note 3)]									
	C[dm ³ /(s·bar)]	b	Cv	C[dm ³ /(s·bar)]	b	Cv							
V114	0.037	0.11	0.008	0.054	0.35	0.015							
V114A	0.076	0.07	0.016	0.099	0.23	0.024							
V124 Note 1)	0.054	0.35	0.015	0.037	0.11	0.008							
V124A Note 1)	0.099	0.23	0.024	0.076	0.07	0.016							


Note 1) For both V124 and V124A, pressure from port 3 and exhaust from port 1.

Note 2) The values shown in () are for values with sub-plate.

Note 3) For 10-V124(A)

Note 4) Note that, if the difference between the inlet side and the outlet side is extremely low (0.001 MPa or less as a guide), air may not be output or the flow rate may deteriorate excessively due to the quality of the lubricant and air in the solenoid valve (mixing in of the drain, etc.).

Construction




Component Parts

No.	Description	Material
1	Body	Resin
2	Cover	Stainless steel
3	Push rod	Resin
4	Armature assembly	Stainless steel, Resin
5	Poppet	FKM
6	Return spring	Stainless steel
7	Poppet spring	Stainless steel
8	Coil assembly	-
9	Manual override	Resin

Replacement Parts


No.	Description	Part no.	Material	Note		
10	Gasket assembly	V100-31-1A	FKM, Steel	Gasket, 2 screws		
11	Sub-plate	V100-74-1	Aluminum die-cast	-		



V100 Series

How to Order

Note) DC specifications only



^{*} LN and MN types are with 2 sockets.

Refer to page 1366 for the different lead wire lengths of L and M plug connectors.


* Refer to page 1367 for the connector assembly with a dustproof cover for L and M plug connectors.

*∕*SMC

3 Port Solenoid Valve V100 Series

CE

How to Order



* LN and MN types are with 2 sockets.

Refer to page 1366 for the different lead wire lengths of L and M plug connectors.

* Refer to page 1367 for the connector assembly with a dustproof cover for L and M plug connectors.

1361

VV061

VV100

V100


S070 VQD


VOD-V


VK VT

V100 Series

Base Mounted (With sub-plate)







1362

3 Port Solenoid Valve V100 Series Manifold Specifications

Manifold Specifications



Model		Type S41				
Manifold		Single base type/B mount				
P (SUP)/R (EXH) type		Common SUP/Common EXH				
Valve stations		2 to 20 stations				
Output port	Location	Base				
porting specifications	Direction	Side				
Port size	Port 1, 2, 3	M5 x 0.8				

Note 1) V114(A) and V124(A) cannot be mounted to the same manifold. Note 2) For V124(A), pressure from port 3 and exhaust from port 1.


Flow Rate Characteristics Note 1)

Manifold		Port size	Port size Flow rate characteristics									
		Port 1, 2, 3	1	\rightarrow 2 [3 \rightarrow 2 ^{Note 2})]	2→3 [2→1 Note 2)]						
		Port 1, 2, 3	C[dm3/(s·bar)]	b	Cv	C[dm3/(s·bar)]	b	Cv				
	V114		0.032	0.13	0.007	0.050	0.26	0.012				
Tupo V//100 S41	V114A	M5 x 0.8	0.070	0.10	0.016	0.085	0.16	0.020				
Type VV100-S41	V124	NID X U.O	0.050	0.26	0.012	0.032	0.13	0.007				
	V124A		0.085	0.16	0.020	0.070	0.10	0.016				

Note 1) Values when mounted on the manifold base (5 stations) Note 2) For 10-V124(A)

How to Order Valve Manifold Assembly (Example)


Ordering example



1363

V100 Series

Common SUP/Common EXH




Gasket Assembly

Part No. V100-31-1A Round head combination screw Found head combination screw Gasket Capplicable base • Sub-plate • Sub-plate • Type VV100-S41 manifold base

Blanking Plate Assembly

Part No. V100-77-1A

Place the notch mark on a blanking plate to the port 2 side when assembling.



Sub-plate

• Type VV100-S41 manifold base

🗥 Caution

Mounting screw tightening torques M2: 0.12 N·m


SMC


3 Port Solenoid Valve **V100 Series**

Type S41 Manifold: Side Ported/VV100-S41-Stations -M5


Note) []: AC 〈 〉: values for the large flow type (A)

Grommet (G), (H)






(n station) ----- (1 station)








* Other dimensions are same as the grommet type.

M plug connector (M)



VV061
VV100
V100
S070
VQD
VQD-V
VK
VT

* Other dimensions are same as the grommet type.

Station	2 stations	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20 stations
L1	33.5	44	54.5	65	75.5	86	96.5	107	117.5	128	138.5	149	159.5	170	180.5	191	201.5	212	222.5
L2	27.5	38	48.5	59	69.5	80	90.5	101	111.5	122	132.5	143	153.5	164	174.5	185	195.5	206	216.5

SMC

1365



V100 Series Specific Product Precautions 1

Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 3 to 9 for 3/4/5 Port Solenoid Valve Precautions.

A Warning Manual Override Operation

Since connected equipment will be actuated when the manual override is operated, first confirm that conditions are safe.

Non-locking push type [Standard type]

Press in the direction of the arrow



Locking slotted type [B type]

Turn in the direction of arrow.



▲ Caution


When operating with a screw driver, turn it gently using a watchmakers' screw driver. [Torque: less than 0.1Nm]

ACaution

How to Use of Plug Connector

1. Attaching and detaching connectors

- To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve so that the lever's pawl is pushed into the groove and locks.
- To detach a connector, remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.



2. Crimping of lead wires and sockets

Strip 3.2 to 3.7 mm at the end of the lead wires, insert the ends of the core wires evenly into the sockets, and then crimp with a crimping tool. When this is done, take care that the coverings of the lead wires do not enter the core wire crimping area.

Use special tool when crimping. (Consult with SMC for the crimping tool.) $% \left({{\left({{{\rm{CONSULT}}} \right)}_{\rm{CONSULT}}} \right)$

Core wire crimping area Socket Hook Core wire Lead wire Lead wire Lead wire Max. cover diameter: ø1.7 mm

▲ Caution

How to Use a Plug Connector


3. Attaching and detaching lead wires with sockets

Attaching

Insert the sockets into the square holes of the connector (\oplus, \bigcirc) indication), and continue to push the sockets all the way in until they lock by hooking into the seats in the connector. (When they are pushed in, their hooks open and they are locked automatically.) Then confirm that they are locked by pulling lightly on the lead wires.

Detaching


To detach a socket from a connector, pull out the lead wire while pressing the socket's hook with a stick having a thin tip (about 1 mm). If the socket will be used again, first spread the hook outward.



Plug Connector Lead Wire Length

Standard length is 300 mm, but the following length is also available.

How to Order Connector Assembly



SMC's Lead Wire Specifications

Cover diameter: 1.55 mm

Conductor area: 0.3 mm² (AWG22 equivalent)

∕⊘SMC




V100 Series **Specific Product Precautions 2**

Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 3 to 9 for 3/4/5 Port Solenoid Valve Precautions.

Surge Voltage Suppressor

<For DC> Grommet, L and M Plug Connector



- · Please connect correctly the lead wires to + (positive) and (negative) indications on the connector
- · For DC voltages other than 12, 24 VDC, incorrect wiring will cause damage to the surge voltage suppressor circuit since a diode to prevent reverse current is not provided. (Wrong polarity will cause trouble.)

Red

(-)

24 V

οv

0.4 W

0.1 W

0 W

Electric circuit (with power saving circuit)

For Single Solenoid

12

<Electric waveform in power saving in the case of V124T>

<u>62 ms</u>

本

i1: Starting current, i2: Holding current

Applied voltage

Standard

With

77. circuit

ED

imer

· Solenoids, whose lead wires have been pre-wired: positive side red and negative side black

With power saving circuit


Power consumption is reduced by approximately 75% compared with the standard product by eliminating the need for electrical current for holding. (Effective after more than 62 ms energized and 24 VDC rated voltage applied.)

Operating Principle

The electrical circuit as shown above, allows reduced holding current consumption and measures power saving. Refer to the electric waveform on the right.

· Please be careful not to reverse the polarity, since a diode to prevent the reversed current is not provided for the power saving circuit

<For AC> Grommet, L and M Plug Connector



A Caution

In the case of varistor surge voltage suppressor, note the surge voltage to be suppressed at controller side as there will be a residual voltage according to the protective element and rated voltage.


Moreover, the residual voltage of the diode is approximately 1 V.

Connector Assembly with Cover


Connector assembly with protective cover enhances dust protection

- Effective in preventing possible short circuit problems due to contaminants in contact with connector section.
- Chloroprene rubber for electrical use, which provides outstanding weather resistance and electrical insulation, is used for the cover material. However, be careful not to allow contact with cutting oil. etc.
- Round cord provides neat appearance.

How to Order



Connector Assembly with Cover/Dimensions







How to Order

Indicate part number of connector assembly with cover in addition to the solenoid valve part number without connector of the plug connector.

<Example 1> Lead wire length: 2000 mm V114-5LOZ-M5

SY100-68-A-20

<Example 2> Lead wire length: 300 mm (Standard) V114-5LPZ-M5

> Symbol for a connector assembly with cover

* No need to indicate the part number for a connector assembly with cover in this case.

1367 A

VV061

