
5.0 MPa Pilot Operated 2/3 Port Solenoid Valve & Check Valve


VCH Series

VCH41/42: 2 Port VCH410: 3 Port VCHC40: Check Valve



431

5.0 MPa Pilot Operated 2 Port Solenoid Valve VCH40 Series



In the symbol Port 1 and Port 2 are shown in a blocked condition, but it is not possible to use the valve in cases of reverse pressure, where the Port 2 pressure is higher than the Port 1 pressure.


Specifications

_					
Model			VCH41 (N.C.)	VCH42 (N.O.)	
	Valve construction		Pilot operated, diaphragm poppet		
	Fluid		Air		
	Ori	fice	ø16	ø17.5	
	stics	C value (Effective area)	17 dm3/(s+bar) (85 mm2)	22 dm ³ /(s•bar) (110 mm ²)	
	Flow acteristics	b	0.08	0.11	
5	chan	Cv	4.5	5.8	
ati	Max. operating pressure		5.0 MPa		
specification	Operating pressure Note 1)		0.5 to 5.0 MPa		
Sec	Fluid temperature		5 to 80°C		
s	Ambient temperature		5 to 80°C		
Valve	Body material		Brass		
Sa	Ма	in seal material	Polyurethane elastomer		
	Enclosure		Water-jet-proof (Equivalent to IP65)		
	Port size		G3/4, 1 (Conforming to ISO1179-1 on the pneumatic/hydraulic G thread)		
	Impact/Vibration _{Note 2)}		300/100 m/s ^{2 Note 3)}		
	Mounting orientation		Unrestricted		
	We	eight	1.67 kg	1.9 kg	
ion	Rated voltage		12 VDC, 24 VDC, 100 VAC, 110 VAC, 200 VAC, 220 VAC (50/60 Hz)		
Coil specification	Allov	vable voltage fluctuation	±10% of rated voltage		
ecif	Ele	ectrical entry	DIN connector		
ll sp	Coi	il insulation type	Class B		
S	Pow	ver consumption Note 4)	5 W (DC),	13 VA (AC)	

Note 1) - Be aware that even if the pressure differential is above the minimum operating pressure differential when the valve is closed, the pressure differential may fail below the minimum operating pressure differential when the valve opens, depending on the power of the supply source (pumps, compressors, etc.) or the type of pipe restrictions.
• Relet to the Selection 5 in the Precautions to n page 441.

Note 2) Impact resistance: No malfunction resulted in an impact test using a drop impact tester. The test was performed one time each in the axial and right angle directions of the main valve and armature, for both neregized and exerciped states. (Valve in the initial stage)

Response Time



Note 1) DC solenoid

Note 2) AC solenoid: It will cause delays around 20 to 30 msec in the OFF response time.

Note 3) Conforms to JIS B 8419-2010


Vibration resistance: No malfunction resulted in 8.3 to 2000 Hz, a one-sweep test performed in the axial and right angle directions of the main valve and armature for both energized and deenergized states. (Value in the initial stage)

Note 3) Vibration resistance is 50 m/s² when a light/surge voltage suppressor is attached. Note 4) No inrush voltages are generated in the AC solenoid because a full-wave rectifier is used.

2 Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com


5.0 MPa Pilot Operated 2 Port Solenoid Valve VCH40 Series

Construction



Component Parts

No.	Description	Material	
1	Body	Brass	
2	O-ring	NBR	
3	Disphrage accombly	Polyurethane elastomer	
з	Diaphragm assembly	Stainless steel	
4	Main valve guide	Resin	
5	Poppet spring	Stainless steel	
6	Hexagon socket head cap screw	Stainless steel	
7	Bonnet	Brass	
8	Hexagon socket head cap screw (with SW)	Carbon steel	
9	O-ring	NBR	
10	Armature assembly	—	
11	Return spring	Stainless steel	
12	Tube assembly	Stainless steel	
13	Nut	Brass	
14	Rubber mount	NBR	
15	DIN connector type solenoid coil	—	
16	Clip	Stainless steel	
17	DIN terminal gasket	CR	
18	DIN connector	_	



Component Parts


No.	Description	Material			
1	Body	Brass	ſ		
2	O-ring	NBR	l		
3	Diankaran arangkar	Polyurethane elastomer			
3	Diaphragm assembly	Stainless steel	l		
4	Main valve guide	Resin			
5	Poppet spring	Stainless steel	i		
6	Bonnet plate	Brass			
7	Hexagon socket head cap screw	Stainless steel	ľ		
8	O-ring	NBR			
9	Valve spring	Stainless steel			
10	Poppet	H-NBR			
11	Bonnet	Brass			
12	Hexagon socket head cap screw (with SW)	Carbon steel			
13	Armature assembly	-			
14	Return spring	Stainless steel			
15	Tube assembly	Stainless steel			
16	Nut	Brass			
17	Rubber mount	NBR			
18	DIN connector type solenoid coil	_			
19	Clip	Stainless steel			
20	DIN terminal gasket	CR			
21	DIN connector	—			

433


VCH40 Series

Dimensions

VCH41 (N.C.)



VCH42 (N.O.)




34 Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

5.0 MPa Check Valve

How to Order






Specifications

Model	VCHC40	
Operating pressure	0.05 to 5.0 MPa	
Cracking pressure	0.05 MPa	
Orifice diameter	ø16	
C value (Effective area)	28 dm ³ /(s·bar) (140 mm ²)	
acteria Book	0.15	
ਸ਼ੁੱ Cv	7.4	
Fluid	Air	
Fluid temperature	5 to 80°C	
Ambient temperature	5 to 80°C	
Body material	Brass	
Seal material	Polyurethane elastomer	
Port size	G3/4, 1 (Conforming to ISO1179-1 on the	
Port size	pneumatic/hydraulic G thread)	
Mounting orientation	Unrestricted	
Weight	1.02 kg	

Construction




Component Parts

No.	Description	Material	
1	Body	Brass	
2	O-ring	NBR	
3	Piston	Aluminum + Hard anodized	
4	Poppet	Polyurethane elastomer	
5	Set screw	Stainless steel	
6	O-ring	NBR	
7	Nut	Stainless steel	
8	Guide ring	Resin	
9	Spring	Stainless steel	
10	Plate	Steel + Electroless nickel plated	
11	Hexagon socket head cap screw (with SW)	Carbon steel	

Dimensions

VCHC40




VDW SX10 VQ LVM

Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

435

5.0 MPa Pilot Operated 3 Port Solenoid Valve VCH400 Series




436

Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

Specifications

Valve construction luid Orifice C value (Effective area) b C v	A	18 1. 0.00 dm3//s hav) (440mm2)	
Drifice	ø G1/2 1→2:20 dm³/(s·bar) (100mm²)	18 1. 0.00 dm3//s hard (440mm2)	
C value	G1/2 1→2:20 dm ³ /(s·bar) (100mm ²)	4 0.00 dm3//s h m) (440 mm2)	
C value (Effective area)		1-2.22 dm ³ /(s.bar) (110mm ²)	
h h		G3/4, 1 $1 \rightarrow 2:22 \text{ dm}^{-}(s \cdot bar) (110 \text{ mm}^{-})$ $2 \rightarrow 3:24 \text{ dm}^{3}(s \cdot bar) (120 \text{ mm}^{-})$	
8 0	G1/2 0.26	G3/4, 1 0.36	
	$\begin{array}{cccc} \text{G1/2} & \begin{array}{c} 1 {\rightarrow} 2 & 5.3 \\ 2 {\rightarrow} 3 & 5.8 \end{array}$	G3/4, 1 1→2 5.8 2→3 6.3	
lax. operating pressure	5.0 MPa		
perating pressure Note 1)	0.5 to 5.0 MPa		
luid temperature	5 to 80°C		
mbient temperature	5 to 80°C		
Body material	Aluminum + H	lard anodized	
lain seal material	Polyurethane elastomer		
inclosure			
Port size		I on the pneumatic/hydraulic G thread)	
npact/Vibration resistance Note 2)			
Nounting orientation	Unrestricted		
Veight	G1/2, 3/4: 1.83 kg, G1: 2.11 kg		
Rated voltage	12 VDC, 24 VDC, 100 VAC, 110 VAC, 200 VAC, 220 VAC (50/60 Hz)		
llowable voltage fluctuation	±10% of rated voltage		
Electrical entry	DIN connector		
Coil insulation type	Class B		
ower consumption Note 4)	5 W (DC),	13 VA (AC)	
	ax. operating pressure perating pressure Note 1) luid temperature mbient temperature ody material ain seal material nclosure ort size pact/Vibration resistance Note 2) ounting orientation /eight ated voltage lowable voltage fluctuation lectrical entry oil insulation type power consumption Note 4)	L 2→3 5.8 ax. operating pressure 5.0 1 perating pressure 5.0 1 perating pressure 5.0 1 uid temperature 5 to 1 ody material Aluminum + F ain seal material Polyurethan nclosure Water-jet-proof (E ort size G1/2, 3/4, 1 (Conforming to ISO1179- pact/Wibration resistance ^{Netz 2} 300/100 r ounting orientation Unres elegipt G1/2, 3/4, 1 (R3 ated voltage 12 VDC, 24 VDC, 100 VAC, 110 V lowabe voltage fluctuation ±10% of ra lectrical entry DIN co oli insulation type Clar	

Response Time



Note 1) DC solenoid

Note 2) AC solenoid: It will cause delays around 20 to 30 msec in the OFF response time Note 3) Conforms to JIS B 8419-2010

Note 1) . Be aware that even if the pressure differential is above the minimum operating pressure differential when the valve is closed, the pressure differential may fall below the minimum operating pressure differential when the valve opens, depending on the power of the supply source (pumps, compressors, etc..) or the type of pipe restrictions. • When used as a selector valve (pressurizing 1, 3 port), the pressure in the port should be

within the range of the port 1 pressure port 3 pressure x 2 (2 times). • Refer to the Design 7 and Selection 5 in the Precautions 1 on page 441.


No malfunction resulted in an impact test using a drop impact tester. The test was stance: performed one time each in the axial and right angle directions of the main valve and armature, for both energized and de-energized states. (Value in the initial stage) Vibration resistance: No malfunction resulted in 8.3 to 2000 Hz, a one-sweep test performed in the axial

and right angle directions of the main valve and armature for both energized and de-

energized states. (Value in the initial stage) Note 3) Vibration resistance is 50 m/s² when a light/surge voltage suppressor is attached. Note 4) No inrush voltages are generated in the AC solenoid because a full-wave rectifier is used.

> . . .

Construction




Со	Component Parts			
No.	Description	Material	VDW	
1	Body	Aluminum + Hard anodized	0140	
2	O-ring	NBR	SX10	
3	O-ring	NBR	VO	
4	Hexagon socket head cap screw	Stainless steel	VQ	
5	Piston A	Aluminum + Hard anodized	1.1/8/	
6	Piston B	Aluminum + Hard anodized	LVM	
7	O-ring	NBR		
8	Poppet	Polyurethane elastomer		
9	Guide ring	Resin		
10	O-ring	NBR		
11	Ring	Resin		
12	Rod	Stainless steel		
13	Hexagon nut	Brass		
14	Hexagon nut class 3	Stainless steel		
15	Poppet spring	Stainless steel		
16	Plate	Steel + Electroless nickel plated		
17	Hexagon socket head cap screw (with SW)	Carbon steel		
18	Bonnet	Aluminum + Hard anodized		
19	O-ring	NBR		
20	Return spring	Stainless steel		
21	Armature assembly			
22	Tube assembly	Stainless steel		
23	Nut	Brass		
24	Rubber mount	NBR		
25	DIN connector type solenoid coil	_		
26	Round Type S retaining ring	Carbon steel		
27	DIN terminal gasket	CR		
28	DIN connector			
IC.		437		


VCH🗆 VDW SX10 VQ


VCH400 Series

Dimensions

VCH410







VCH40 Series Made to Order Specifications:



Please contact SMC for detailed dimensions, specifications and lead times.

1 22.0 MPa 2 Port Air Operated Valve

AXT836 A

s	pecifications

Symbol	Passage	Piping size
Α	N.C.	1/4" fitting integrated type
в	N.O.	1/4" fitting integrated type
С	N.C.	Flange type
D	N.O.	Flange type
Е	Double acting	1/4" fitting integrated type

Symbol

N.O

Double acting





Integrated fitting type Flange type

Specifications


	A, C (N.C. type)	B, D (N.O. type)	E (Double acting)	
Fluid	Air			
Fluid temperature	-10 to 60°C (No freezing)			
Ambient temperature	-10 to 60°C (No freezing)			
Operating pressure range	0 to 22.0 MPa		0 to 20.0 MPa	
Proof pressure	35.0 MPa			
Pilot pressure range	0.4 to 0	0.7 MPa	0.3 to 0.5 MPa	
Valve leakage	0.1 cm ³ /min or less			
Orifice diameter	2.8 mm			

Dimensions


AXT836A

† Līw

N.C



AXT836B



VCH□ VDW SX10 VQ LVM


VCH40 Series

Dimensions




Rc1/8 Rc1/8 Pilot port Plug 91 39.5 Γ 54 41.7 4 x ø5.5 through 8.4 OUT IN O-ring groove ළ O.D. ø7.8 I.D. ø4.2

AXT836D



AXT836E





5.0 MPa Pilot Operated 2/3 Port Solenoid Valves & Check Valves Precautions 1

Be sure to read this before handling the products.

Design

\land Warning

1. Cannot be used as an emergency shutoff valve, etc.

The valves presented in this catalog are not designed for safety applications such as an emergency shutoff valve. If the valves are used in this type of system, other reliable safety assurance measures should also be adopted.

Extended periods of continuous energization

The solenoid coil will generate heat when continuously energized. Avoid using in a tightly shut container. Install it in a wellventilated area. Furthermore, do not touch it while it is being energized or right after it is energized.

3. This solenoid valve cannot be used for explosion proof applications.

4. Maintenance space

The installation should allow sufficient space for maintenance activities

5 Actuator drive

When an actuator, such as a cylinder, is to be driven using a valve, take appropriate measures to prevent potential danger caused by actuator operation.

Use caution regarding exhaust port freezing.

If a high pressure air (more than 1.0 MPa) is quickly exhausted, there may be an occurrence in which the valve will not switch properly or the service life will substantially decrease due to condensation or freezing caused by the substantial temperature change. When condensation or freezing occurs, take measures such as using a freeze-reducing silencer (VCHNF series), etc.

Use caution regarding back pressure.

- 1) When port 3 (EXH) of a 3 port solenoid valve (VCH400 series) is excessively throttled or used as a selector valve (pressurizing 1, 3 port), the pressure in the port should be within a range of half the pressure in port 1 (port 1 pressure ≥ twice as strong as port 3 pressure). Using a 3 port valve beyond its back pressure and/or supply pressure range may cause the valve switch to malfunction or result in unstable operation.
- 2) In the case of a 3 port solenoid valve, when the valve is being switched, a high pressure air will be introduced into the lower pressure side. Therefore, when using this product as a selector valve for switching a high and medium pressure, a relief type regulator (VCHR series) must be used for the medium pressure side.

Selection

A Warning

1. Confirm the specifications.

Give careful consideration to the operating conditions such as the application, fluid and environment, and use within the operating ranges specified in this catalog.

2. Fluid

Corrosive gas

Cannot be used since it will lead to cracks by stress corrosion or result in other incidents.

3. Air quality

1) Use clean air.

Do not use compressed air which includes chemicals, synthetic oils containing organic solvents, salt or corrosive gases, etc., as it can cause damage or malfunction.

2) Install air filters.

Install air filters close to valves at their upstream side. A filtration degree of 5 µm or less should be selected.

3) Install an air drver or after-cooler. etc.

Compressed air that includes excessive drainage may cause malfunction of valves and other pneumatic equipment. To prevent this, install an air drver or after cooler, etc.

4) If excessive carbon powder is generated, eliminate it by installing mist separators at the upstream side of valves.

If excessive carbon powder is generated by the compressor, it may adhere to the inside of the valves and cause a malfunction.

Refer to Best Pneumatics No. 6 for further details on compressed air quality.

Ambient environment

Use within the operable ambient temperature range. Confirm the compatibility between the product's composition materials and the ambient atmosphere. Be sure that the fluid used does not touch the external surface of the product.

5. Supply source

If the primary side air is throttled, flow may be reduced resulting in the malfunction of the switch or instability in the response time because of the pilot operated solenoid valve. Conduct piping work suited for the secondary side piping (air consumption). Also, when a regulator is installed, the air supply will stop right after the solenoid valve is switched due to the response time of the regulator. Thus, when using it below the minimum operating pressure, adjust the pipe size, length or provide an air tank, etc.

441

@SMC Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com



5.0 MPa Pilot Operated 2/3 Port Solenoid Valves & Check Valves Precautions 2

Be sure to read this before handling the products.


Selection

ACaution

1. Leakage voltage

When the solenoid valve is operated using the controller, etc., the leakage voltage should be the product allowable leakage voltage or less.

Particularly when using a resistor in parallel with a switching element and using a C-R element (surge voltage suppressor) to protect the switching element, take note that leakage current will flow through the resistor, C-R element, etc., creating a possible danger that the valve may not turn off.



AC coil: 10% or less of rated voltage DC coil: 2% or less of rated voltage $% 10^{-1}$

Mounting

Warning

 If air leakage increases or equipment does not operate properly, stop operation.

After mounting is completed, confirm that it has been done correctly by performing a suitable function test.

2. Do not apply external force to the coil section.

Be sure to apply the wrench to the external part of the piping connection. (Hexagonal parts or width across flats) Also, use caution when mounting a silencer or piping to the VCH410 series 3 port solenoid valve because the top (G1/4) is a pilot exhaust port.

3. Be sure not to position the coil downwards.

When mounting a valve with its coil positioned downwards, foreign objects in the fluid will adhere to the iron core leading to a malfunction.

 Avoid sources of vibration, or adjust the arm from the body to the minimum length so that resonance will not occur. Piping

▲ Caution


1. Preparation before piping

Before piping is connected, it should be thoroughly blown out with air (flushing) or washed to remove chips, cutting oil and other debris from inside the pipe.

Avoid pulling, compressing, or bending the valve body when piping.

2. Winding of sealaut tape

Pipe tape is not necessary since this product uses a pneumatic and hydraulic purpose G thread which conforms to ISO 1179-1. When an R (taper) thread is used, leave 1 to 2 threads at the tip exposed before winding the piping thread around it 4 to 5 times.



Always tighten threads with the proper tightening torque.

When attaching fittings to valves, tighten with the proper tightening torque shown below.

Tightening Torque for Piping

Connection threads	Proper tightening torque N·m
G, Rc 1/2	28 to 30
G, Rc 3/4	28 to 30
G, Rc 1	36 to 38

4. Connection of piping to products

When connecting piping to a product, refer to its operation manual to avoid mistakes regarding the supply port, etc.

- · Port 1: Supply port
- Port 2: Output port
- Port 3: Exhaust port
- Note) Supply port when used as a selector valve. However, use within the range of the port 1 pressure ≥ port 3 pressure x 2 (2 times).

∕⊘SMC



5.0 MPa Pilot Operated 2/3 Port Solenoid Valves & Check Valves Precautions 3

Be sure to read this before handling the products.

2

Wiring

A Caution

- 1. As a rule, use electrical wire with a cross sectional area of 0.5 to 1.25 mm² for wiring. Furthermore, do not allow excessive force to be
- applied to the lines. 2. Use electrical circuits which do not generate chat-
- tering in their contacts. 3. Use voltage which is within ±10% of the rated voltage. In cases with a DC power supply where importance is placed on responsiveness, stay within $\pm 5\%$ of the rated value. The voltage drop is the value in the lead wire section connecting the coil.
- 4. When a surge from the solenoid affects the electrical circuitry, install a surge absorber, etc., in parallel with the solenoid.


Or, adopt an option that comes with the surge voltage protection circuit. (However, a surge voltage occurs even if the surge voltage protection circuit is used. For details, please consult with us.)


Electrical Connections

A Caution

DIN connector

Since internal connections are as shown below for the DIN connector, make connections to the power supply accordingly.





Note) For an outside cable diameter of ø9 to 12 mm, remove the internal parts of the rubber seal before using

Electrical Circuits A Caution DIN connector DC circuit AC circuit Rectifier Varistor Varisto element 1(+)c $1(\sim)$ aristor SOL SOL 2 (-) 0 2(~)c

Operating Environment

A Warning

- 1. Do not use the valves in an atmosphere having corrosive gases, chemicals, salt water, water, steam, or where there is direct contact with any of these
- 2. Do not use in explosive atmospheres.
- 3. Do not use in locations subject to vibration or impact.
- 4. Do not use in locations where radiated heat will be received from nearby heat sources.
- 5. Employ suitable protective measures in locations where there is contact with water droplets, oil or welding spatter, etc.

VCH

VDW SX10

VO

LVM

Maintenance

\land Warning

1. Removing the product

- 1) Shut off the fluid supply and release the fluid pressure in the system.
- Shut off the power supply.
- Dismount the product.

2. Low frequency operation

Switch valves at least once every 30 days to prevent malfunction. Also, in order to use it under the optimum state, conduct a regular inspection once a half year.

🗥 Caution

1. Storage

In the case of long term storage, thoroughly remove all moisture to prevent rust and deterioration of rubber materials, etc.

2. Exhaust the drain from an air filter periodically.