
#### 3 Port Solenoid Valve


#### VQZ100/200/300 Series

Metal Seal Rubber Seal





SYJ VQZ ۷P VG VP3




#### Compact, High Flow

		Valve width	Flow rate characteristics				
Series		(mm)	Metal seal	Rubber seal			
		(11111)	C [dm <sup>3</sup> /(s·bar)]	C [dm <sup>3</sup> /(s·bar)]			
rted	VQZ100	10	_	0.56 (Poppet)			
Body ported	VQZ200	15	1.3	1.7			
Bod	VQZ300	18	2.4	3.0			
nted	VQZ100	10	_	1.0 (Poppet)			
Base mounted	VQZ200	15	2.0	3.0			
Base	VQZ300	18	3.2	4.1			



#### VQZ100/200/300

#### **Solenoid Valve Variations**



#### Manifold

#### **Body Ported**



			Piping specif	Applicable	A		
Series	Base model	Piping	Bor	e size	solenoid	Applicable stations	
		direction	1(P), 3(R)	2(A)	valve		
VQZ100	00 VV3QZ12-□□□ T		Rc 1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ115	2 to 20 stations	
VQZ200	VV3QZ22-□□□	Тор	Rc 1/8	C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ2□2	2 to 20 stations	
VQZ300	VV3QZ32-□□□	Тор	Rc 1/4	C6 (for ø6) C8 (for ø8) C10 (for ø10) Rc 1/4	VQZ3□2	2 to 20 stations	


#### **Base Mounted**




			Piping specif	Applicable	A P 1.1.		
Series	Base model	Piping	Bor	e size	solenoid	Applicable stations	
		direction	1(P), 3(R)	2(A)	valve		
VQZ100	VV3QZ15-□□□	Side/ top	Rc 1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ115	2 to 20 stations	
VQZ200	VV3QZ25-□□□	Side	Rc 1/4	C4 (for ø4) C6 (for ø6) C8 (for ø8) Rc 1/8	VQZ2□5	2 to 20 stations	
VQZ300	VV3QZ35-□□□	/3QZ35-□□□ Side		C6 (for ø6) C8 (for ø8) C10 (for ø10) Rc 1/4	08 (for ø8) 010 (for ø10) <b>VQZ3</b> □5		

#### **Manifold Options**

#### **Body Ported**





**SWC** 

P.1252

P.1245


## Body Ported Plug Lead Unit

#### 3 Port Solenoid Valve

# *VQZ100/200/300* Series Single Unit (€

Note) CE-compliant:DC type only.

#### VQZ100 / How to Order Valve



Note) Standard lead wire length: 300 mm

Note) For applicable One-touch fitting and silencer models for this valve series, refer to page 1258.

Note) When placing an order for body ported solenoid valve as a single unit, mounting screw for manifold and gasket are not attached. Order them separately, if necessary. (For details, refer to page 1237.)


#### Body Ported VQZ100/200/300 Series

#### VQZ200/300 / How to Order Valve




Note) AC-type models that are CE-compliant have DIN terminals only





1223



#### Specifications

Valve construction	Metal seal	Rubber seal	VQZ100 (Poppet seal)			
valve construction	ivietai seai	nubbei seai	VQZ 100 (Foppet Seat)			
Fluid	Air					
Max. operating pressure (MPa)	0.7 (High pressure type: 1.0)	0.7	0.7 (High pressure type: 1.0)			
Min. operating pressure (MPa)	0.1	0.15	0.15			
Ambient and fluid temperature (°C)	-10 to 50 (No freezing)					
Max. operating frequency (Hz)	20	5	20			
Pilot exhaust method	Individua	l exhaust	Common exhaust Note 1)			
Lubrication		Not required				
Manual override	Push typ	e, Locking type (Tool i	required)			
Mounting orientation	Free					
Impact/Vibration resistance (m/s²) Note 2)	150/30					
Enclosure*	Dustpr	oof (DIN terminal: IP65	5 Note 3)			

<sup>\*</sup> Based on IEC60529

Indicator light

Vibration resistance: No malfunction occurred in one sweep test between 45 and 2000 Hz. Test was performed to axis and right angle directions of the main valve and armature when pilot signal is ON and OFE (Volte in the initial other).

and OFF. (Value in the initial state)

Note 3) When IP65 compliant DIN terminals are selected: VQZ<sub>3</sub><sup>2</sup>□2□-□Y□□W1-□□

#### **Solenoid Specifications**

Electrical entry		Grommet (G) L-type plug connector (L)	M-type plug connector (M) DIN terminal (Y)			
		G, L, M	Υ			
Coil rated voltage		С	24	, 12		
(V)	-	AC 50/60 Hz	100, 110,	200, 220*		
Allowable voltage t	luctua	ation	±10% of ra	ted voltage*		
Power consumption (W)		Standard	0.35 [(With light: 0.4 (DIN	terminal with light: 0.45)]		
	DC	High speed response, high pressure	0.9 [(With light: 0.95 (DIN terminal with light: 1.0)]			
		100 V	0.78 (With light: 0.81)	0.78 (With light: 0.87)		
Apparent power		110 V [115 V]	0.86 (With light: 0.89) [0.94 (With light: 0.97)]	0.86 (With light: 0.87) [0.94 (With light: 1.07)]		
(VA)*	AC	200 V	1.18 (With light: 1.22)	1.15 (With light: 1.30)		
		220 V [230 V]	1.30 (With light: 1.34) [1.42 (With light: 1.46)]	1.27 (With light: 1.46) [1.39 (With light: 1.60)]		
Surge voltage supp	oresso	or	Var	istor		

LED (Neon light when AC with DIN terminal)

#### Semi-standard Specifications

High speed response type
High pressure type (Metal seal type only)
External pilot type*

<sup>\*</sup> For details on external pilot type, refer to page 1236.



Symbol Description				
X30 Pilot valve common exhaust				
X90	Main valve fluororubber			
X113	All fluororubber			

#### Flow Rate Characteristics

Series		c- Model			Flow rate characteristics					Response time (ms) Note 1)																
	Valve construc-			$1 \rightarrow 2 \; (P \rightarrow A)$		$2 \rightarrow 3 \; (A \rightarrow R)$		i Stariuaru: i sneen	High	AC	Note 2) Weight															
	tion			C [dm³/(s•bar)]	b	Cv	C [dm³/(s•bar)]	b	Cv																	ΑΟ
VQZ100	N.C. valve	Poppet	VQZ115	0.59	0.44	0.17	0.56	0.30	0.14	10 or less	_	13 or less	22 or less	24												
	N.C.	Metal seal	VQZ212	1.2	0.21	0.30	1.3	0.24	0.33	22 or less	14 or less	18 or less	34 or less													
VQZ200	valve	Rubber seal	VQZ232	1.6	0.33	0.39	1.7	0.37	0.45	22 or less	15 or less	_	36 or less	57												
VQZ200	N.O.	Metal seal	VQZ222	1.2	0.25	0.31	1.3	0.20	0.31	22 or less	14 or less	18 or less	34 or less	57												
	valve	Rubber seal	VQZ242	1.6	0.36	0.40	1.7	0.36	0.45	22 or less	15 or less	_	36 or less	,]												
	N.C.	Metal seal	VQZ312	2.7	0.18	0.62	2.4	0.28	0.56	22 or less	17 or less	22 or less	34 or less													
VQZ300	valve	Rubber seal	VQZ332	3.5	0.34	0.87	3.0	0.33	0.72	33 or less	25 or less	_	57 or less	93												
	N.O.	Metal seal	VQZ322	2.6	0.21	0.59	2.2	0.16	0.49	22 or less	17 or less	22 or less	34 or less	93												
	valve	Rubber seal	VQZ342	3.5	0.38	0.88	2.9	0.27	0.69	33 or less	25 or less	_	57 or less													

Note 1) Based on JIS B 8419: 2010 (Supply pressure: 0.5 MPa; with light/surge voltage suppressor: clean air) Response time values will change depending on pressure and air quality.

1224



Note 1) When using body ported type as a single unit, the individual exhaust is used.

Note 2) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Value in the initial state)


<sup>\*</sup> In common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC

<sup>\*</sup> For 115 VAC and 230 VAC, the allowable voltage is -15% to +5% of rated voltage

Note 2) Weight for threaded connection

#### Construction








#### **Component Parts**

00	ponent i arte		
No.	Description	Material	Note
1	Body	Resin	
2	Spool valve	Aluminum/HNBR	
3	Pilot valve assembly	_	
4	P. R plate	Resin/Aluminum	VQZ100-12A (Standard) VQZ100-12B (External pilot type) Note)


Note) It is not possible to change the standard product to external pilot type, and vice versa.

#### VQZ200/300

#### Metal seal type










#### Rubber seal type










VP3

SYJ VQZ





$C_{\Lambda}$	mnc	non	t Da	rte


COIII	ponent i arts		
No.	Description	Material	Note
1	Body	Aluminum die-casted	
_	Spool, Sleeve	Stainless steel	Metal seal
2	Spool valve	Aluminum/HNBR	Rubber seal
3	Piston	Resin	
4	Pilot valve assembly	_	


Note) For "How to Order Pilot Valve Assembly", refer to page 1237.

#### **Dimensions: VQZ100**


#### Single Unit


Grommet (G): VQZ115□-□G□1-C3, C4, C6-PR






Note) For bracket assembly part no., refer to page 1237.






Note) For One-touch fittings for P/R port and silencer part no., refer to page 1258.

#### L-type plug connector (L): VQZ115□-□L□1-C3, C4, C6-PR



Unless otherwise indicated, dimensions are the same as Grommet (G). [ ]: AC

#### M-type plug connector (M): VQZ115□-□M□1-C3, C4, C6-PR



Unless otherwise indicated, dimensions are the same as Grommet (G).


[ ]: AC


#### Body Ported VQZ100/200/300 Series

#### **Dimensions: VQZ200**

#### Single Unit


Grommet (G): VQZ2□2□-□G□1-C4, C6





M-type plug connector (M): VQZ2 2 - M 1-C4, C6


[ ]: AC



Unless otherwise indicated, dimensions are the same as Grommet (G).

[ ]: AC

#### DIN terminal (Y): VQZ2 2 - Y 1-C4, C6



Unless otherwise indicated, dimensions are the same as Grommet (G).

SYJ

VQZ

VΡ


VG

VP3


#### **Dimensions: VQZ300**

#### Single Unit


Grommet (G): VQZ3 2 - G 1-C6, C8, C10



#### L-type plug connector (L): VQZ3 2 - L 1-C6, C8, C10




M-type plug connector (M): VQZ3 2 - M 1-C6, C8, C10



Unless otherwise indicated, dimensions are the same as Grommet (G) [ ]: AC

DIN terminal (Y): VQZ3 2 - Y - 1-C6, C8, C10



Unless otherwise indicated, dimensions are the same as Grommet (G).

[ ]: AC

#### **Body Ported**

Plug Lead Unit


#### 3 Port Solenoid Valve

# VQZ100/200/300 Series

Manifold Connector Kit

Note) For CE-compliant models, DC type only.

#### VQZ100 / How to Order Manifold



For DIN rail part no., refer to page 1235.


Note 2) When two or more symbols are specified, indicate them alphabetically.

> Note) For 1(P), 3(R) of optional thread type, refer to page 1236.

#### VQZ100 / How to Order Valve

Kit type

C Connector



Note) When placing an order for body

norted solenoid valve as a single unit, mounting screw for manifold

and gasket are not attached. Order

them separately, if necessary. (For details, refer to page 1237.)

3 110 VAC [115 VAC] (50/60 Hz)

4 220 VAC [230 VAC] (50/60 Hz)

5 24 VDC

6 12 VDC

#### VQZ200/300 / How to Order Manifold




Note) AC-type models that are CE-compliant have DIN terminals only.

as a single unit, mounting screw for manifold and gasket


are not attached. Order them separately, if necessary.

(For details, refer to page 1237.)





#### VQZ200/300 / How to Order Valve



1230


5 24 VDC

6 12 VDC




#### Body Ported VQZ100/200/300 Series

#### **Manifold Specifications**



		Pip	ing spec	ifications	Applicable		Manifold
Series	Base model	Piping	Ŭ .	Port size	solenoid	Applicable stations	base
		direction	1(P), 3(R)	2(A)	valve	Stations	weight (g)
VQZ100	VV3QZ12-□□□	Тор	Rc 1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ115	2 to 20 stations	2 stations: 83 Addition per station: 19
VQZ200	VV3QZ22-□□□	Тор	Rc 1/8	C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ2□2	2 to 20 stations	2 stations: 68 Addition per station: 20
VQZ300	VV3QZ32-□□□	Тор	Rc 1/4	C6 (for ø6) C8 (for ø8) C10 (for ø10) Rc 1/4	VQZ3□2	2 to 20 stations	2 stations: 114 Addition per station: 37

#### How to Order Manifold Assembly (Example)




SYJ


VQZ


VP

VG VP3

#### **Dimensions: VQZ100**







Unless otherwise indicated, dimensions are the same as Grommet (G). [ ]: AC

Unless otherwise indicated, dimensions are the same as Grommet (G).


[ ]: AC


Dimer	Dimensions n: Stations (Max. 20 stations)												stations)						
<u> </u>	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	85.5	85.5	98	110.5	123	135.5	148	148	160.5	173	185.5	198	210.5	210.5	223	235.5	248	260.5	273
L2	75	75	87.5	100	112.5	125	137.5	137.5	150	162.5	175	187.5	200	200	212.5	225	237.5	250	262.5
L3	43.5	54	64.5	75	85.5	96	106.5	117	127.5	138	148.5	159	169.5	180	190.5	201	211.5	222	232.5
L4	21	16	17	18	19	20	21	15.5	16.5	17.5	18.5	19.5	20.5	15.5	16.5	17.5	18.5	19.5	20.5
L5	30.5	41	51.5	62	72.5	83	93.5	104	114.5	125	135.5	146	156.5	167	177.5	188	198.5	209	219.5


#### Body Ported VQZ100/200/300 Series

#### **Dimensions: VQZ200**


#### VV3QZ22- Stations C








The dashed lines indicate the DIN rail mounting [-D].




Unless otherwise indicated, dimensions are the same as Grommet (G).

#### M-type plug connector (M)



Unless otherwise indicated, dimensions are the same as Grommet (G). ]: AC

#### DIN terminal (Y)



Unless otherwise indicated, dimensions are the same as Grommet (G).

#### Dimensions

Dimer	Dimensions n: Stations (Max. 20 stations											stations)							
<u> </u>	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	85.5	110.5	123	135.5	148	173	185.5	198	223	235.5	248	260.5	285.5	298	310.5	335.5	348	360.5	373
L2	75	100	112.5	125	137.5	162.5	175	187.5	212.5	225	237.5	250	275	287.5	300	325	337.5	350	362.5
L3	54	70	86	102	118	134	150	166	182	198	214	230	246	262	278	294	310	326	342
L4	16	20.5	18.5	17	15	19.5	18	16	20.5	19	17	15.5	20	18	16.5	21	19	17.5	15.5
L5	43	59	75	91	107	123	139	155	171	187	203	219	235	251	267	283	299	315	331


**SMC** 

SYJ


VQZ

VΡ VG VP3


#### **Dimensions: VQZ300**








Unless otherwise indicated, dimensions are the same as Grommet (G). [ ]: AC



Unless otherwise indicated, dimensions are the same as Grommet (G). ]: AC

#### DIN terminal (Y)

£



Unless otherwise indicated, dimensions are the same as Grommet (G).

The dashed lines indicate the DIN rail

mounting [-D].

Dimer	Dimensions n: Stations (Max. 20 stations)											stations)							
<u> </u>	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	98	110.5	135.5	148	173	198	210.5	235.5	248	273	285.5	310.5	323	348	360.5	385.5	398	423	435.5
L2	87.5	100	125	137.5	162.5	187.5	200	225	237.5	262.5	275	300	312.5	337.5	350	375	387.5	412.5	425
L3	61	80	99	118	137	156	175	194	213	232	251	270	289	308	327	346	365	384	403
L4	18.5	15.5	18.5	15	18	21	18	21	17.5	20.5	17.5	20.5	17	20	17	20	16.5	19.5	16.5
L5	49	68	87	106	125	144	163	182	201	220	239	258	277	296	315	334	353	372	391

#### Body Ported VQZ100/200/300 Series


#### **Manifold Options**

Blanking plate assembly

VVQZ100-10A-5 (for VQZ100) VVQZ200-10A-2 (for VQZ200)

VVQZ300-10A-2 (for VQZ300)

It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.



#### Blanking plug


KQ2P-23


KQ2P-04

**KQ2P-06** 

**KQ2P-08** 

KQ2P-10






10

#### DIN rail AXT100-DR-□

As for □, enter the number from the DIN rail dimensions table
 For L dimension, refer to the dimensions of each kit.

Each manifold can be mounted on a DIN rail. Insert "D" at the end of the manifold part number. The DIN rail is approximately 30 mm longer than the length of manifold.





KQ2P-10 22

L Dimension																				
No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L dimension	23	35.5	48	60.5	73	85.5	98	110.5	123	135.5	148	160.5	173	185.5	198	210.5	223	235.5	248	260.5
No.	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
L dimension	273	285.5	298	310.5	323	335.5	348	360.5	373	385.5	398	410.5	423	435.5	448	460.5	473	485.5	498	510.5

SYJ

(mm)

D

8

31.5 5

32 6

35

39 10

43 12


VP


VG

VP3

#### Silencer (for manifold EXH port)

Silencer is installed in the manifold EXH port.





#### Dimensions

Model	Silencer part no.				
VQZ100	AN110-01				
VQZ200	AN110-01				
VQZ300	AN20-02				

For a silencer to be mounted in a single valve unit, refer to page 1258.

#### VQZ Series Body Ported

#### Semi-standard Specifications (



VQZ200/300


0.1 to 0.7 MPa

0.15 to 0.7 MPa

-100 kPa to 0.7 MPa

#### **External Pilot Specification**

The external pilot specification is used when the operating pressure is below the minimum operating pressure 0.1 to 0.15 MPa or when valve is used for a vacuum application. Order a valve by adding the external pilot specification [R] to the part number.




Note 1) In case of the high pressure type, upper limit of max, operating pressure and external pilot pressure range is 1 MPa.

Note 2) Pump down from 1(P) port when VQZ100 series vacuum type is specified. Apply pressure from 3(R) port to relieve vacuum pressure. Set the release pressure at 50% of external pilot pressure or less In addition, when the VQZ100 is to be used at an operating pressure

greater than 0.2 MPa, please assure that the operating pressure is set to equal to or less than the external pilot pressure.

#### Inch Size One-touch Fittings and Optional Threads

Inch size One-touch fittings and NPT, NPTF and G thread are available



CE-compliant

Thread type (Cylinder port and 1(P), 3(R) ports)

CE-compliant


Nil	Rc	
N	NPT	
Т	NPTF	
F	G	

Operating pressure range Note 1)

Note 1) 3(R) port of the VQZ200 is only G1/16. Note 2) Except VQZ100

Manifold Part No.

Valve Part No.



#### IP65 Enclosure (Based on IEC60529)

DIN terminal is available with IP65 enclosure.

#### Valve Part No.

(Applicable to the VQZ200/300 rubber seal with the exception of the external pilot type)



(The standard valve has an individual exhaust for the pilot valve.)

**ØSMC** 

#### **VQZ** Series Body Ported

#### **Replacement Parts**

One-touch Fitting Assembly (for Cylinder port)

Fitting size Model	СЗ	C4	C6	C8	C10	M5 (VQZ100 only)
VQZ100/200	VVQ1000-50A-C3	VVQ1000-50A-C4	VVQ1000-50A-C6	_	_	VVQ1000-50A-M5
VQZ300	Ī	_	VVQ1000-51A-C6	VVQ1000-51A-C8	VVQ1000-51A-C10	_

Note) Purchasing order is available in units of 10 pieces



DC: SY100-30-4A-100 VAC: SY100-30-1A-

200 VAC: SY100-30-2A-

Other AC voltages: SY100-30-3A-

Without lead wire: SY100-30-A (with connector and 2 sockets only)

# Lead wire length

NII	300 mm
6	600 mm
10	1000 mm
15	1500 mm
20	2000 mm
25	2500 mm
30	3000 mm
50	5000 mm

Include the connector assembly part number together with the part number for the plug connector's solenoid valve without connector.

VQZ115-1LO1-M5-PR

#### <Pilot valve assembly>

М



100 VAC (50/60 Hz) 2 200 VAC (50/60 Hz) 3 110 VAC (50/60 Hz) 4 220 VAC (50/60 Hz) None (Applicable to VQZ200/300) 24 VDC Yes (Applicable to VQZ100) 6 12 VDC

			iocarour ona
Symbol		Electrical entry	Light/surge voltage
DC	AC	Electrical entry	suppressor
G	_	Grommet (DC specification)	None
LU	LZ	L-type plug connector with lead wire	
LOU	LOZ	L-type plug connector without connector	Yes
MU	MZ	M-type plug connector with lead wire	165
MOU	MOZ	M-type plug connector without connector	

Manual override

В

Coil voltage

(Applicable to the VQZ100)

Non-locking push type

Electrical entry

SYJ

VOZ

۷P VG

VP3

Locking slotted type

Note) VQZ pilot valve electrical entry (L, M) is the opposite of the how to order of valve body Pilot valve model

V111 | M- | M |

V111□M-□L□

#### SY100-30-4A-20 SY100-30-1A-20 <Gasket and screw assembly>

Example) In case of 2000 mm of lead wire

How to Order

VQZ115-5LO1-M5-PR

Model	Part no.
VQZ100	VQZ100-GS-5
VQZ200	VQZ200-GS-2
VQZ300	VQZ300-GS-2

Note 1) The above part numbers are for 10 valves (a set of 10 gaskets and 20 screws) Note 2) VQZ100 is common to the body ported type and base mounted type.

#### <Bracket assembly>


Model	Part no.	Tightening torque (N·m) Note)						
VQZ100	VQZ100-FB							
VQZ200	VQZ200-FB	0.25 to 0.35						
VQZ300	VQZ300-FB							
	NI - A TOTAL A COLUMN							

Note) Tightening torque when mounting a bracket on the valve.

#### VQZ115□-□M□1 <DIN terminal type (Applicable to the VQZ200/300)>

Valve model

VQZ115□-□L□1



Note) Semi-standard

	Coil voltage •	Symbol	
1	100 VAC (50/60 Hz)		
2	200 VAC (50/60 Hz)	Y	DII
3	110 VAC (50/60 Hz)	YO	DII
4	220 VAC (50/60 Hz)	YZ	DII
5	24 VDC	YS Note)	DIN
		YOS Note)	DIN
6	12 VDC	YOS NOW	(DC
			_

Flectrical entry

		u. 0 , 0
Symbol	Electrical entry	Light/surge voltage suppressor
Υ	DIN terminal	None
YO	DIN terminal without connector	None
YZ	DIN terminal with light/surge voltage suppressor	Yes
YS Note)	DIN terminal with surge voltage suppressor (DC specification)	Yes
YOS Note)	DIN terminal with surge voltage suppressor, without connector (DC specification)	(Without light)

Note) For AC voltage valves there is no "S" type. It is already built-in to the rectifier circuit.

#### **∖** Caution

When replacing only the pilot valve assembly, use caution because it is not possible to convert to a V115 (DIN terminal) from a V111 (Grommet, L-type, M-type), or vice versa.




### Base Mounted Plug Lead Unit

#### 3 Port Solenoid Valve

# **VQZ100/200/300** Series Single Unit (€

Note) For CE-compliant models, DC type only.

#### VQZ100 / How to Order Valve



Note) For sub-plate part no., refer to page 1254.

Note) When ordering single unit of the base mounted type solenoid valve, the mounting screws and gaskets for the manifold are included.


#### Base Mounted VQZ100/200/300 Series

#### VQZ200/300 / How to Order Valve



Note) AC-type models that are CE-compliant have DIN terminals only.





KR Note 1, 2) High p (Metal Note 1) Semi-standard

Note 2) For details on external pilot type, refer to page 1253. Note 3) For AC specification power consumption, refer to page 1240.

High pressure/External pilot type

(Metal seal type only)



Use standard (DC) specification for continuous duty.

Note 1) Standard lead wire length: 300 mm Note 2) For AC voltage valves there is no "S" type. It is already built-in to the rectifier priguit

With light/

suppressor

surge voltage

connector

#### Coil voltage

O DC

	ii voitage
1	100 VAC (50/60 Hz)
2	200 VAC (50/60 Hz)
3	110 VAC [115 VAC] (50/60 Hz)
4	220 VAC [230 VAC] (50/60 Hz)
5	24 VDC
	12 VDC

Note) For sub-plate part no., refer to page 1254.

Note) When ordering single unit of the base mounted type solenoid valve, the mounting screws and gaskets for the manifold are included.

connector

(DC speci

fication)

With surge

suppressor

voltage

fication)

With surge

suppressor

voltage





Semi-standard Specifications

#### **Specifications**

Valve construction	Metal seal	Rubber seal	VQZ100 (Poppet seal)
Fluid		Air	
Max. operating pressure (MPa)	0.7 (High pressure type: 1.0)	0.7	0.7 (High pressure type: 1.0)
Min. operating pressure (MPa)	0.1	0.15	0.15
Ambient and fluid temperature (°C)		-10 to 50 (No freezing)	
Max. operating frequency (Hz)	20	20	
Pilot exhaust method	Individua	l exhaust	Common exhaust
Lubrication		Not required	
Manual override	Push typ	e, Locking type (Tool r	equired)
Mounting orientation		Free	
Impact/Vibration resistance (m/s²) Note 1)		150/30	
Enclosure*	Dustpr	oof (DIN terminal: IP65	Note 2))

<sup>\*</sup> Based on IEC60529

Grommet (G)

1.18 (With light: 1.22)

1.30 (With light: 1.34)

[1.42 (With light: 1.46)]

M-type plug connector (M)

1.15 (With light: 1.30)

1.27 (With light: 1.46)

[1.39 (With light: 1.60)]

Varistor LED (Neon light when AC with DIN terminal)

Note 2) When IP65 compliant DIN terminals are selected: VQZ3050-0Y00W1-0-0

#### Solenoid Specifications

		Electrical entry			L-type plug connector (L)	DIN terminal (Y)			
High s	peed response type				G, L, M	Υ			
	ressure type (Metal seal type only)	Coil rated voltage	- 1	DC	24	, 12			
Extern	al pilot type*	(V)	-	AC 50/60 Hz	100, 110,	200, 220*			
	ails on external pilot type, refer to page 1253.	Allowable voltage t	luctu	ation	±10% of ra	ted voltage*			
	, , , , , , , , , , , , , , , , , , ,			Standard	0.35 [(With light: 0.4 (DIN terminal with light: 0.4				
Made to Order	Made to Order	Power consumption (W)	DC	High speed response, high pressure	0.9 [(With light: 0.95 (DII	N terminal with light: 1.0)]			
0.00	(For details, refer to page 1255.)			100 V	0.78 (With light: 0.81)	0.78 (With light: 0.87)			
Symbo X30	Description Pilot valve common exhaust	Apparent power		110 V [115 V]	0.86 (With light: 0.89) [0.94 (With light: 0.97)]	0.86 (With light: 0.87) [0.94 (With light: 1.07)]			
YOO	1 liot valve common exhaust	(VA)	AC	200 V	1.18 (With light: 1.22)	1.15 (With light: 1.30)			

Surge voltage suppressor

Indicator light

200 V

220 V

[230 V]

#### Flow Rate Characteristics

Main valve fluororubber

All fluororubber

					Flow	rate ch	aracteristics			Res	sponse tir	ne (ms) N	ote 1)	
Series	Valve construc-	Mode	el	1 → 2 (	P → A)		2 → 3 (	$A \rightarrow R)$		Standard:	High speed	High pressure:	AC	Note 2) Weight
	tion  100 N.C. valve Poppet  N.C. Metal seal			C [dm³/(s•bar)]	b	Cv	C [dm³/(s•bar)]	Ь	Cv		response: 0.9 W	0.9 W	AC	(g)
VQZ100	N.C. valve	Poppet	VQZ115	0.87	0.46	0.23	1.0	0.35	0.25	10 or less	_	13 or less	22 or less	24
	N.C.	Metal seal	VQZ215	1.7	0.17	0.38	2.0	0.20	0.45	22 or less	14 or less	18 or less	34 or less	
VQZ200	valve	Rubber seal	VQZ235	2.3	0.46	0.65	3.0	0.40	0.80	22 or less	15 or less	_	36 or less	52
VQZZUU	N.O.	Metal seal	VQZ225	1.7	0.18	0.38	1.8	0.21	0.39	22 or less	14 or less	18 or less	34 or less	
	valve	Rubber seal	VQZ245	2.5	0.43	0.67	3.0	0.30	0.74	22 or less	15 or less	_	36 or less	.]
	N.C.	Metal seal	VQZ315	3.0	0.21	0.70	3.2	0.27	0.80	22 or less	17 or less	22 or less	34 or less	
VO7200	valve	Rubber seal	VQZ335	4.5	0.42	1.3	4.1	0.36	1.0	33 or less	25 or less	_	57 or less	78
VQZ300	VQZ300 N.O.	Metal seal	VQZ325	2.9	0.21	0.72	2.9	0.16	0.69	22 or less	17 or less	22 or less	34 or less	] <sup>′</sup> °
	valve	Rubber seal	VQZ345	4.4	0.45	1.2	4.5	0.38	1.2	33 or less	25 or less	_	57 or less	

Note 1) Based on JIS B 8374-1981 (Supply pressure: 0.5 MPa; with light/surge voltage suppressor: clean air)

Note 2) Weight without sub-plate.



X90

X113

Note 1) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Value in the initial state)

Vibration resistance: No malfunction occurred in one sweep test between 45 and 2000 Hz. Test was performed to axis and right angle directions of the main valve and armature when pilot signal is ON and OFF. (Value in the initial state)

<sup>\*</sup> In common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC


<sup>\*</sup> For 115 VAC and 230 VAC, the allowable voltage is -15% to +5% of rated voltage.

Response time values will change depending on pressure and air quality.

#### Base Mounted VQZ100/200/300 Series

#### Construction

#### **VQZ100** Poppet type







#### **Component Parts**

No.	Description	Material	Note
1	Body	Resin	
2	Spool valve	Aluminum/HNBR	
3	Pilot valve assembly	_	
4	Port plug	Resin/HNBR	VVQZ100-CP

#### VQZ200/300 Metal seal type










#### Rubber seal type






VQZ VP

SYJ

VG VP3





#### **Component Parts**


No.	Description	Material	Note
1	Body	Aluminum die-casted	
•	Spool, Sleeve	Stainless steel	Metal seal
2	Spool valve	Aluminum/HNBR	Rubber seal
3	Piston	Resin	
4	Pilot valve assembly	_	

Note) For "How to Order Pilot Valve Assembly", refer to page 1254.


#### **Dimensions: VQZ100**

#### Single Unit

Grommet (G): VQZ115□-□G□1-01




#### L-type plug connector (L): VQZ115□-□L□1-01



#### Unless otherwise indicated, dimensions are the same as Grommet (G). [ ]: AC


#### M-type plug connector (M): VQZ115□-□M□1-01



Unless otherwise indicated, dimensions are the same as Grommet (G).

#### Base Mounted VQZ100/200/300 Series

#### **Dimensions: VQZ200**




( ): VQZ215-□G□1-01


#### L-type plug connector (L): VQZ2 5 - L 1-01 Approx. 300 79 [81.2] (Lead wire length) 49.8[56.8] Unless otherwise indicated, dimensions are the same as Grommet (G).

M-type plug connector (M): VQZ2 5 - M 1-02


[ ]: AC



Unless otherwise indicated, dimensions are the same as Grommet (G). [ ]: AC



10 (10.5)



Unless otherwise indicated, dimensions are the same as Grommet (G). [ ]: AC

18 (17)

SYJ

VQZ

۷P

VG

VP3

#### **Dimensions: VQZ300**


# Single Unit Grommet (G): VQZ3□5□-□G□1-02 2 x e4.5 (For mounting) Approx. 300 (Lead wire length) M5 x 0.8

[1(P), 3(R) port]

L-type plug connector (L): VQZ3 $\square$ 5 $\square$ - $\square$ L $\square$ 1- $^{02}_{03}$ 


(External pilot port)

<External pilot only>



Unless otherwise indicated, dimensions are the same as Grommet (G). [ ]: AC

#### M-type plug connector (M): VQZ3 $\square$ 5 $\square$ - $\square$ M $\square$ 1- $^{02}_{03}$



Unless otherwise indicated, dimensions are the same as Grommet (G). [ ]: AC


1244

#### DIN terminal (Y): VQZ3 5 - Y 101-03

( ): VQZ315-□G□1-02

13 (14)

47



Unless otherwise indicated, dimensions are the same as Grommet (G).

#### **Base Mounted** Plug Lead Unit


#### 3 Port Solenoid Valve

# VQZ100/200/300 Series

Manifold Connector Kit

Note) For CE-compliant models, DC-type only.


#### VQZ100 / How to Order Manifold



Note 1) When CP port plug is attached on all 2(A) port. Valve on manifold is top ported.

Note 2) Specify the mixture port (including top and side piping) by the manifold specification sheet. Note 3) For inch size One-touch fittings, refer to page 1253.

#### VQZ100 / How to Order Valve




#### VQZ200/300 / How to Order Manifold




Note) AC-type models that are CE-compliant have DIN terminals only.





#### VQZ200/300 / How to Order Valve

Note 2) For inch size One-touch fittings, refer to page 1253.



#### Base Mounted VQZ100/200/300 Series


#### **Manifold Specifications**



		Pir	ing spec	ifications	A II I I		Note)	
Series	Base model	Piping	<del></del>	Port size	Applicable solenoid	Applicable	Manifold base	
		direction	1(P), 3(R)	2(A)	valve	stations	weight (g)	
VQZ100	VV3QZ15-□□□	Side/Top	Rc 1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ115	2 to 20 stations	2 stations: 83 Addition per station: 19	
VQZ200	VV3QZ25-□□□	Side	Rc 1/4	C4 (for ø4) C6 (for ø6) C8 (for ø8) Rc 1/8	VQZ2□5	2 to 20 stations	2 stations: 126 Addition per station: 38	
VQZ300	VV3QZ35-□□□	Side	1(P) port Rc 3/8 3(R) port Rc 1/4	C6 (for ø6) C8 (for ø8) C10 (for ø10) Rc 1/4	VQZ3□5	2 to 20 stations	2 stations: 209 Addition per station: 60	

Note) Weight for threaded connection.

#### How to Order Manifold Assembly (Example)



SYJ

VQZ VP


VG


VP3

#### **Dimensions: VQZ100: Top Ported**

#### VV3QZ15- Stations Port size C Grommet (G) D side U side L1 (5) L2 M5 x 0.8 (Rail mounting hole pitch: 12.5) (DIN rail clamp thread) (PE: Pilot EXH port) (Pitch) M5 x 0.8 Approx. 300 44.9 P = 10.5 16.5 (X: External pilot port) (Lead wire length) 5.5 <For external pilot> (DIN rail) (4.5) (2.5) (99) 59.3 46.5 43.9 16.3 35 19.3 2 (8) 1/8 2 x ø4.3 L5 (For mounting) One-touch fitting [1(P), 3(R) port] 15 [2(A) port] M5 x 0.8 L4 L3 Applicable tubing O.D.: ø3.2, ø1/8" 39.5 [2(A) port] ø4, ø5/32" ø6, ø1/4" (Station 1) ----- (Station n) (3.2) 45.2 (For M5) 44.1 8 5 20 (7.5)

The dashed lines indicate the DIN rail mounting [-D].






Dimer	nsions															n: S	tations (I	Max. 20	stations)
L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	85.5	85.5	98	110.5	123	135.5	148	148	160.5	173	185.5	198	210.5	210.5	223	235.5	248	260.5	273
L2	75	75	87.5	100	112.5	125	137.5	137.5	150	162.5	175	187.5	200	200	212.5	225	237.5	250	262.5
L3	43.5	54	64.5	75	85.5	96	106.5	117	127.5	138	148.5	159	169.5	180	190.5	201	211.5	222	232.5
L4	21	16	17	18	19	20	21	15.5	16.5	17.5	18.5	19.5	20.5	15.5	16.5	17.5	18.5	19.5	20.5
L5	30.5	41	51.5	62	72.5	83	93.5	104	114.5	125	135.5	146	156.5	167	177.5	188	198.5	209	219.5

М5

#### Base Mounted VQZ100/200/300 Series

#### Dimensions: VQZ100: Side Ported






The dashed lines indicate the DIN rail mounting [-D].

# L-type plug connector (L) ORC YOURSE AND DEATH OF THE PLAN OF THE

Unless otherwise indicated, dimensions are the same as Grommet (G).  $[\ \ ]:$  AC

#### M-type plug connector (M)



Unless otherwise indicated, dimensions are the same as Grommet (G). [ ]: AC

Dimer	nsions															n: S	tations (I	Max. 20	stations)
<u> </u>	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	85.5	85.5	98	110.5	123	135.5	148	148	160.5	173	185.5	198	210.5	210.5	223	235.5	248	260.5	273
L2	75	75	87.5	100	112.5	125	137.5	137.5	150	162.5	175	187.5	200	200	212.5	225	237.5	250	262.5
L3	43.5	54	64.5	75	85.5	96	106.5	117	127.5	138	148.5	159	169.5	180	190.5	201	211.5	222	232.5
L4	21	16	17	18	19	20	21	15.5	16.5	17.5	18.5	19.5	20.5	15.5	16.5	17.5	18.5	19.5	20.5
L5	30.5	41	51.5	62	72.5	83	93.5	104	114.5	125	135.5	146	156.5	167	177.5	188	198.5	209	219.5

**SMC** 


SYJ

VQZ


VΡ

VG VP3


#### **Dimensions: VQZ200**









(Station 1) -----(Station n)





The dashed lines indicate the DIN rail mounting [-D].


#### L-type plug connector (L)



Unless otherwise indicated, dimensions are the same as Grommet (G).


[ ]: AC

#### M-type plug connector (M)



Unless otherwise indicated, dimensions are the same as Grommet (G). [ ]: AC

#### DIN terminal (Y)



Unless otherwise indicated, dimensions are the same as Grommet (G).

#### Dimensions


Dilliel	1510115															n: S	tations (i	viax. 20	stations)
n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	85.5	98	123	135.5	148	173	185.5	198	210.5	235.5	248	260.5	285.5	298	310.5	323	348	360.5	373
L2	75	87.5	112.5	125	137.5	162.5	175	187.5	200	225	237.5	250	275	287.5	300	312.5	337.5	350	362.5
L3	52	68	84	100	116	132	148	164	180	196	212	228	244	260	276	292	308	324	340
L4	17	15	19.5	18	16	20.5	19	17	15.5	20	18	16.5	21	19	17.5	15.5	20	18.5	16.5
L5	42	58	74	90	106	122	138	154	170	186	202	218	234	250	266	282	298	314	330


1250



#### Base Mounted VQZ100/200/300 Series

#### **Dimensions: VQZ300**





Dimer	n: Stations (Max. 20 statio															stations)			
	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	98	123	148	160.5	185.5	198	223	248	260.5	285.5	298	323	348	360.5	385.5	398	423	448	460.5
L2	87.5	112.5	137.5	150	175	187.5	212.5	237.5	250	275	287.5	312.5	337.5	350	375	387.5	412.5	437.5	450
L3	66	86	106	126	146	166	186	206	226	246	266	286	306	326	346	366	386	406	426
L4	16	18.5	21	17.5	20	16	18.5	21	17.5	20	16	18.5	21	17.5	20	16	18.5	21	17.5
L5	48	68	88	108	128	148	168	188	208	228	248	268	288	308	328	348	368	388	408

SYJ VQZ

۷P

VG

VP3

#### **Manifold Options**

Blanking plate assembly

or planning to mount a spare valve, etc.

VVQZ100-10A-5 (for VQZ100)

VVQZ200-10A-5 (for VQZ200) VVQZ300-10A-5 (for VQZ300)

It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons



#### Blanking plug


KQ2P-23

KQ2P-04

**KQ2P-06** 

**KQ2P-08** 

KQ2P-10






Dimensions								
Applicable fitting size ød	Model	A	L	D				
3.2	KQ2P-23	16	31.5	5				
4	KQ2P-04	16	32	6				
6	KQ2P-06	18	35	8				
8	KQ2P-08	20.5	39	10				
10	KQ2P-10	22	43	12				

#### DIN rail

#### AXT100-DR-□

As for □, enter the number from the DIN rail dimensions table
 For L dimension, refer to the dimensions of each kit.

Each manifold can be mounted on a DIN rail. Insert "D" at the end of the manifold part number. The DIN rail is approximately 30 mm longer than the length of manifold.







#### L Dimension No. | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 |

VO.	-	4	0	4	3	0	-	0	9	Ū	11	12	10	14	13	10	17	10	19	20
nension	23	35.5	48	60.5	73	85.5	98	110.5	123	135.5	148	160.5	173	185.5	198	210.5	223	235.5	248	260.5
No.	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
nension	273	285.5	298	310.5	323	335.5	348	360.5	373	385.5	398	410.5	423	435.5	448	460.5	473	485.5	498	510.5
	No.	No. 21	No. 21 22	No. 21 22 23	No. 21 22 23 24	No. 21 22 23 24 25	No. 21 22 23 24 25 26	No. 21 22 23 24 25 26 27	No. 21 22 23 24 25 26 27 28	No. 21 22 23 24 25 26 27 28 29	No. 21 22 23 24 25 26 27 28 29 30	No. 21 22 23 24 25 26 27 28 29 30 31	No. 21 22 23 24 25 26 27 28 29 30 31 32	No. 21 22 23 24 25 26 27 28 29 30 31 32 33	No. 21 22 23 24 25 26 27 28 29 30 31 32 33 34	No. 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35	Hension 23 35.5 48 60.5 73 85.5 98 110.5 123 135.5 148 180.5 173 185.5 198 210.5 No. 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36	Hension 23 55,5 48 60.5 73 85,5 98 1105 123 135,5 148 105,5 173 185,5 198 2105 223 40. 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37	Hersion 23 35.5 48 60.5 73 85.5 98 1105 123 1355 148 100.5 173 1855 198 2105 223 235 40. 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38	Pension 23 35.5 48 60.5 73 85.5 98 110.5 123 135.5 148 100.5 173 185.5 198 210.5 223 235.5 248

#### Silencer (for manifold EXH port)

Silencer is installed in the manifold EXH port.





D	ime	ns	ioi	n

Model	Silencer part no.
VQZ100	
VQZ200	AN20-02
VQZ300	AN20-02

#### Port plug VVQZ100-CP (for VQZ100)

This is used when changing piping location. (Side or Top)



#### VQZ Series Base Mounted

#### Semi-standard Specifications (€




0.1 to 0.7 MPa

0.15 to 0.7 MPa

#### **External Pilot Specification**

The external pilot specification is used when the operating pressure is below the minimum operating pressure 0.1 to 0.15 MPa or when valve is used for a vacuum application. Order a valve by adding the external pilot specification [R] to the part number.



VV3QZ Entry is the same as standard products.

Operating pressure range Note 1) -100 kPa to 0.7 MPa Note 1) In case of the high pressure type, upper limit of max. operating pressure and external pilot pressure range is 1 MPa.

Metal seal

Rubber seal

(VQZ100: poppet)

External pilot

pressure range


Note 2) When using the VQZ100 series for a vacuum application, vacuum air through its 1(P) port. When supplying vacuum-release air, supply it through its 3(R) port. But do not supply vacuum-release air exceeding 50% for the external pilot pressure.

In addition, when the VQZ100 is to be used at an operating pressure greater than 0.2 MPa, please assure that the operating pressure is set to equal to or less than the external pilot pressure.

0.2 to 0.7 MPa

#### Inch Size One-touch Fittings and Optional Threads

Inch size One-touch fittings and NPT, NPTF and G thread are available.




Note 1) Except VQZ100, mixing One-touch fittings and thread types is impossible

#### Note 2) Metric size One-touch fittings (C□) are also available

#### Optional Threads Other than Rc


Rc specifications are standard for all ports, however, NPT, NPTF and G are available for overseas markets. Add the appropriate symbol following the port size in the standard part number.



DIN terminal is available with IP65 enclosure.

Valve Part No.

(Applicable to the VQZ200/300 rubber seal with the exception of the external pilot type)



VOZ

۷P

VG

VP3

#### VQZ Series Base Mounted

#### **Replacement Parts**

One-touch Fitting Assembly (for Cylinder port)

Fitting size Model	СЗ	C4	C6	C8	C10	M5 (VQZ100 only)
VQZ100	VVQ1000-50A-C3	VVQ1000-50A-C4	VVQ1000-50A-C6	_	_	VVQ1000-50A-M5
VQZ200	_	VVQ1000-51A-C4	VVQ1000-51A-C6	VVQ1000-51A-C8	_	_
VQZ300	_	_	VVQ2000-51A-C6	VVQ2000-51A-C8	VVQ2000-51A-C10	_

Note) Purchasing order is available in units of 10 pieces.

#### <Plug connector assembly>

DC: SY100-30-4A-100 VAC: SY100-30-1A-

200 VAC: SY100-30-2A-


Other AC voltages: SY100-30-3A-

Without lead wire: SY100-30-A (with connector and 2 sockets only)

#### Lead wire length

Nil	300 mm
6	600 mm
10	1000 mm
15	1500 mm
20	2000 mm
25	2500 mm
30	3000 mm
50	5000 mm

#### <Pilot valve assembly>



		E	lectrical entry 🜢
Symbol		Floatrical autor	Light/surge voltage
DC	AC	Electrical entry	suppressor
G	_	Grommet (DC specification)	None
LU	LZ	L-type plug connector with lead wire	
LOU	LOZ	L-type plug connector without connector	Yes
MU	MZ	M-type plug connector with lead wire	162
	1107	1.1.1	1

LOU	LOZ	L-type plug connector without connector	Yes			
MU MZ		M-type plug connector with lead wire	163			
MOU	MOZ	M-type plug connector without connector				
Note) The electrical entry (L, M) for the VQZ100 pilot valve is different from that of the main valve model number.						

How to Order

Include the connector assembly part number together with the part number for the plug connector's solenoid valve without connector.

Example) In case of 2000 mm of lead wire

VQZ115-5LO1-M5 VQZ115-1LO1-M5

SY100-30-4A-20 SY100-30-1A-20


V
V

#### <Gasket and screw assembly>

Model	Part no.
VQZ100	VQZ100-GS-5
VQZ200	VQZ200-GS-5
VQZ300	VQZ300-GS-5

Note) The above part numbers are for 10 valves (a set of 10 gaskets and 20 screws)

#### <DIN terminal type (Applicable to the VQZ200/300)>



Note) Semi-standard

Coil voltage

#### 100 VAC (50/60 Hz) 200 VAC (50/60 Hz) 3 110 VAC (50/60 Hz) 220 VAC (50/60 Hz) 24 VDC 12 VDC

#### <Sub-plate>

Model		Sub-plate part no.						
Wiode		For internal pilot	For external pilot					
VQZ10	00	VQZ100-S-01 (-Q)	VQZ100-S-01®-R (-Q)					
VQZ20	00	VQZ200-S- <sup>01</sup> / <sub>02</sub> (-Q)	VQZ200-S-01/18-R (-Q)					
VQZ30	0	VQZ300-S- <sup>02</sup> / <sub>03</sub> ★ (-Q)	VQZ300-S-02 1 -R (-Q)					

\* Thread type

1254

Electrical entry Light/surge voltage suppressor Electrical entry None Yes

ı	Y	DIN terminal	None					
ł	YO	YO DIN terminal without connector						
ł		DIN terminal with light/surge voltage suppressor	Yes					
J	YS Note)	DIN terminal with surge voltage suppressor (DC specification)	Yes					
	YOS Note)	DIN terminal with surge voltage suppressor, without connector (DC specification)	(Without light)					

Note) For AC voltage valves there is no "S" option. It is already built-in to the rectifier circuit



When replacing only the pilot valve assembly, use caution because it is not possible to convert to a V115 (DIN terminal) from a V111 (Grommet, L-type, M-type), or vice versa.

#### *VQZ200/300* Series Made to Order



Please contact SMC for detailed dimensions, specifications and lead times.


#### 1 Pilot Valve Common Exhaust Specification

Pilot exhaust is exhausted through the main R port.

- \* Not designed to prevent leakage to outside.
- \* A combination of external pilots is not available.
- \* "How to Order Manifold" is the same as standard products. Please specify this to "How to Order Valve."

#### Applicable solenoid valve series: VQZ200/300

#### **How to Order**




#### 2 Main Valve Fluororubber Specification

The seal material, the part of the main valve in contact with fluid, is made of fluororubber.

\* "How to Order Manifold" is the same as standard products. Please specify this to "How to Order Valve."

#### Applicable solenoid valve series: VQZ200/300

#### **How to Order**




#### 3 All Fluororubber Specification

The rubber material of the part in contact with fluid, is made of fluororubber.

\* "How to Order Manifold" is the same as standard products. Please specify this to "How to Order Valve."

#### Applicable solenoid valve series: VQZ200/300

#### How to Order





Be sure to read this before handling the products.


Refer to back page 50 for Safety Instructions and pages 3 to 9 for 3/4/5 Port Solenoid Valve Precautions.

#### **Manual Override**

#### **⚠** Caution

Without an electric signal for the solenoid valve the manual override is used for switching the main valve. Push type is standard. Locking type (Tool required) is available as an option.

#### 1. VQZ100



Press in the direction of the arrow.

#### Locking type (Tool required)



Turn 90° in the direction of arrow.


#### 2. VQZ200/300

#### Push type (Tool required)



Push down on the manual override button with a small screwdriver until it stops. Release the screwdriver and the manual override will return.

#### Locking type (Tool required)



Push down completely on the manual override button with a small screwdriver. While down, turn clockwise 90° to lock it. Turn it counterclockwise to release it.

#### Locked position



#### **Precautions**


When operating with a screwdriver, turn it gently using a watchmaker's screwdriver. (Torque: less than 0.1 N•m)
Press and rotate to lock the manual operation of VQZ200/300. If rotate without pressing, manual breakage and air leakage could be occurred.

#### How to Use L/M-Type Plug Connector

#### **∧** Caution

#### 1. Attaching and detaching connectors


To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve and remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.



#### Light/Surge Voltage Suppressor

#### **⚠** Caution


#### 1. L/M-type plug connector




#### 2. DIN terminal

<DC>


With surge voltage suppressor (YS, YOS)



#### Light/surge voltage suppressor (YZ)



<AC> With light (YZ)



Note) Surge voltage suppressor of varistor has residual voltage corresponding to the protective element and rated voltage; therefore, protect the controller side from the surge.



Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 3 to 9 for 3/4/5 Port Solenoid Valve Precautions.


#### **Lead Wire Connection**

#### 

#### 1. Crimping of lead wires and sockets

Not necessary if ordering the lead wire pre-connected model. Strip 3.2 to 3.7 mm at the end of the lead wires, insert the ends of the core wires evenly into the sockets, and then crimp with a crimping tool. When this is done, take care that the coverings of the lead wires do not enter the core wire crimping area.

(Please contact SMC for the crimping tools.)




#### 2. Attaching and detaching sockets with lead wires

#### Attaching

Insert the sockets into the square holes of the connector  $\bigcirc$ ,  $\bigcirc$  indication), and continue to push the sockets all the way in until they lock by hooking into the seats in the connector. (When they are pushed in, their hooks open and they are locked automatically.) Then, confirm that they are locked by pulling lightly on the lead wires.

#### Detaching

To detach a socket from a connector, pull out the lead wire while pressing the socket's hook with a stick having a thin tip (approx. 1 mm). If the socket will be used again, first spread the hook outward.




#### **Pilot Valve Replacement**


#### **∧** Caution

1.When replacing a current type valve with a new type for maintenance or other reasons, a "conversion connector assembly" is necessary to convert the connector from 3 terminals to 2 terminals and must be ordered separately. (When ordering, refer to the below part nos.)

For pilot valves, there is no compatibility between the current type and new type. When replacing a pilot valve, be sure to confirm whether it is the new type or the current type.

#### [Current]







Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 3 to 9 for 3/4/5 Port Solenoid Valve Precautions.

#### How to Use DIN Terminal

#### 1. EN-175301-803C (Former DIN 43650C) (8 mm between pins)

The DIN terminal type with an IP65 enclosure is protected against dust and water, however, it must not be used in water.

#### 2. Connection

- Loosen the holding screw and pull the connector out of the solenoid valve terminal block.
- After removing the holding screw, insert a flat head screwdriver, etc. into the notch on the bottom of the terminal block and pry it open, separating the terminal block and the housing.
- Loosen the terminal screws (slotted screws) on the terminal block, insert the cores of the lead wires into the terminals according to the connection method, and fasten them securely with the terminal screws.
- 4) Secure the cord by fastening the ground nut.

#### 3. Changing the entry direction

After separating the terminal block and housing, the cord entry can be changed by attaching the housing in the desired direction (4 directions at  $90^\circ$  intervals).

\* When equipped with a light, be careful not to damage the light with the cord's lead wires.


#### 4. Precautions

Plug in and pull out the connector vertically without tilting to one side.

#### 5. Compatible cable

Cable O.D.: ø3.5 to ø7

(Reference) 0.5 mm², 2-core or 3-core, equivalent to JIS C 3306



#### **DIN Connector Part No.**


#### Without light

Rated voltage	Voltage symbol	Part no.
All voltages	None	SY100-82-1

#### With light

Rated voltage	Voltage symbol	Part no.
24 VDC	24 V	SY100-82-3-05
12 VDC	12 V	SY100-82-3-06
100 VAC	100 V	SY100-82-2-01
200 VAC	200 V	SY100-82-2-02
110 VAC (115 VAC)	110 V	SY100-82-2-03
220 VAC (230 VAC)	220 V	SY100-82-2-04

#### Circuit diagram with light




#### Fitting and Silencer Part No. for P, R Ports When Using Valve as an Individual Unit

Part no. for one-touch fitting for 1(P) port and silencer/one-touch fitting for 3(R) port

Series	Sories (1) One-touch		(2) For 3(R) port	
Selles	fitting for 1(P) port	Silencer	One-touch fitting	
VQZ100	KQ2H06-M5A	AN120-M5	KJS04-M5A	
VQZ200	KQ2S06-01AS	INA-25-46	IN-457-32L (for ø6)	
VQZ300	KQ2H08-02AS	AN101-01	KQ2H06-01AS	

The diameter of the above fitting and silencer is the maximum diameter to in the EXH port.





Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 3 to 9 for 3/4/5 Port Solenoid Valve Precautions.

#### **One-touch Fittings Replacement**

#### 

The built-in fittings on the manifold can be changed easily. Simply remove the corresponding valve and take out the fitting clip underneath.


Take out the clip with a screwdriver, etc., then replace the fittings. About mounting the fittings, after inserting the fitting until it stops, then put the clip into the prescribed position.

VQZ200: Horizontally clipped to the valve body

VQZ100/300: Vertically clipped to the valve body

#### ■Valve







#### Valve Clip Part No. (10 pcs. included)

Series	Part number
VQZ100	VQZ100-2-FC
VQZ200	VQZ200-2-FC
VQZ300	VQZ300-2-FC

#### ■Manifold base





#### Precautions

When pulling the fitting assembly away from the valve base, remove the clip, then connect a tube or plug (KQ2P-□□) with the One-touch fitting and pull it out holding the tube or plug. Do not hold the release bushing to avoid damage.

#### **DIN Rail Removal/Mounting**


#### 

#### 1. Removing

- 1) Loosen the clamp screw on the a side of both ends of the
- Lift the (a) side of the mani fold off the DIN rail and slide it in the direction of the b side.

#### 2. Mounting

- 1) Catch the hook of the DIN rail bracket on the b side on the DIN rail
- 2) Push side a onto the DIN rail and tighten the clamp screw. The proper tightening torque for screws is 0.3 to 0.4 N·m.



#### Valve Mounting

#### 

1. After confirming the gasket is correctly placed under the valve, securely tighten the bolts with the proper torque shown in the table below.

Model	Proper tightening torque
VQZ100	0.13 to 0.19 N·m
VQZ200	0.25 to 0.35 N·m
VOZ300	0.5 to 0.7 N·m



LYS

VOZ

۷P

VG

VP3


1259 A

#### **VQZ100 Piping Direction Replacement**

#### **⚠** Caution

#### 1. How to replace the port direction

Fitting and port plug are modules. After removing the clip with a flat head screwdriver, take out the fitting and port plug. The piping direction (side or top) can be altered by exchanging the fitting and port plug. During exchange, insert the fitting and the port plug until they contact the wall, then, insert the clip to specified position.




#### Precautions

The clip length for the valve and the base are different. Fitting may detach if the incorrect clip is used.

2. Valve piped on top can be operated independently by using PR plate.

(Refer to the below part numbers when placing an order.)



VQZ100-12A (Standard) VQZ100-12B (External pilot type)

\* 2 set screws are included.