

## **2**-color display


See abnormal values at a glance.




#### **Piping Variations**


# R1/8, NPT1/8 M5 x 0.8 Rc1/8, G1/8 A4, 96 One-touch fitting M5 x 0.8

#### Space-saving




#### **Mounting Variations**





#### Series



#### Secret code setting function-----

A function to prevent operation by anyone other than the designated operator while the keys are locked.



An optional 3-digit value is entered.

\* The set-value can be checked while the keys are locked.

#### Power-saving function-----

The display can be turned off to save the power consumption. (Power consumption reduced by max. 20%)



The value disappears and decimal points start flashing.

#### Resolution conversion function-----

The flickering on the display can be eliminated.



(Only the displayed value is changed, and there is no effect on the accuracy.)

#### MPa/kPa switching function-----

The indication unit for vacuum, compound pressure and positive pressure can be integrated into either MPa or kPa.




kPa Stick the label (enclosed with the product) of a desired unit

# 2-Color Display High-Precision ( € c 🗫 us

**Digital Pressure Switch** 



## ZSE40A(F)/ISE40A Series



Made to Order

ming to ISO228-1

ombination of piping specifications w	ith option 1 and part numbers of option

Option 1			Piping							
Description	Symbol	Part no.	01	N01	W1	WF1	M5	C4	C6	
Bracket A	Α	ZS-24-A	0	0	0	0	×	×	×	
Bracket B	В	ZS-24-B	×	×	0	0	×	×	×	
Bracket D	D	ZS-24-D	0	0	0	0	×	×	×	
Panel mount adapter	Е	ZS-35-C	0	0	×	×	×	×	×	
ranei mount adapter	_	ZS-35-D	×	×	0	0	0	0	0	
Panel mount adapter +	F	ZS-35-F	0	0	×	×	×	×	×	
Front protective cover	г	7S-35-G	×	×	0		0	0	0	

#### Output specifications 9


Х	NPN open collector 2 outputs (with copy function)
Υ	PNP open collector 2 outputs (with copy function)
R	NPN open collector 2 outputs + Analog voltage/Auto-shift switching
Т	PNP open collector 2 outputs + Analog voltage/Auto-shift switching
S	NPN open collector 2 outputs + Analog current/Auto-shift switching
٧	PNP open collector 2 outputs + Analog current/Auto-shift switching

Options 1/Part No. use the following part numbers to place an order.				
Part no.	Option			
ZS-24-A	Bracket A Mounting screw M3 x 5L, M4 x 5L (2 pcs. for each)			
ZS-24-B	Bracket B Mounting screw M4 x 5L (2 pcs.)			
ZS-24-D	Bracket D Mounting screw M3 x 5L, M4 x 5L (2 pcs. for each)			
ZS-35-C	Panel mount adapter (Piping: For 01/N01)			
ZS-35-D	Panel mount adapter (Piping: For W1/WF1/M5/C4/C6)			
ZS-35-F	Panel mount adapter + Front protective cover (Piping: For 01/N01)			
ZS-35-G	Panel mount adapter + Front protective cover (Piping: For W1/WF1/M5/C4/C6)			

#### Unit specifications


Nil	With unit switching function Note 1)
M	Fixed SI unit Note 2)
Р	With unit switching function Note 1) (Initial value psi)

Note 1) Under the New Measurement Law sales of switches with the unit switching function are not allowed for use in Japan. Note 2) Unit: kPa, MPa



Some options are unavailable depending on the piping specifications. Refer to "Combination of piping specifications with option 1

W1/WF1/M5/C4/C6



<sup>\*</sup> No lead wires are connected.

#### **Specifications**

Refer to pages 11 and 12 for Pressure Switch Precautions. For details about the Specific Product Precautions, refer to the Operation Manual on the SMC website, http://www.smcworld.com

		Model	ZSE40A (vacuum pressure)	ZSE40AF (compound pressure)	ISE40A (positive pressure)				
Rated pre	essure ra	nge	0.0 to -101.3 kPa	-100.0 to 100.0 kPa	-0.100 to 1.000 MPa				
Display/S	et press	ure range	10.0 to -105.0 kPa	-105.0 to 105.0 kPa	-0.105 to 1.050 MPa				
Withstan	d pressu	re	500 kPa	500 kPa	1.5 MPa				
Display/N	/linimum	unit setting	0.1 kPa	0.1 kPa	0.001 MPa				
Applicable fluid			Air, N	Air, Non-corrosive gas, Non-flammable gas					
Power supply voltage			12 to 24 VDC $\pm$ 10%, Ripple (p-p) 10% or less (with power supply polarity protection)						
Current of	onsump	tion	45 mA or less						
Switch or			NPN or PNP open collector 1 output or 2 outputs						
Maximum load current				80 mA					
		m applied voltage		28 V (at NPN output)					
		al voltage		1 V or less					
		se time	2.5 ms (with anti-	chattering function: 20, 100, 500	), 1000, 2000 ms)				
		rcuit protection		Yes					
Repeat accuracy				±0.2% F.S. ±1 digit					
Hysteresis mode				Variable (0 or above) Note 1)					
,	Windov	comparator mode							
	Voltage		1 to 5 V ±	0.6 to 5 V ±2.5% F.S.					
outp	output	Linearity	±1% F.S.						
		Output impedance	Approx. 1 kΩ						
Analog output	Not	Output current (Rated pressure range)	4 to 20 mA	2.4 to 20 mA ±2.5% F.S.					
	Current			±1% F.S.					
	output	Load impedance	Maximum load impedance: $300~\Omega$ (Power supply voltage 12 V) $600~\Omega$ (Power supply voltage 24 V) Minimum load impedance: $50~\Omega$						
Auto-shif	t input		Non-voltage input (Reed or Solid state), Low level: 0.4 V or less, 5 ms or longer input						
Display			3 1/2-digit, 7-segment, 2-color LCD (Red/Green)						
Display a	ccuracy		±2% F.S.	±1 digit (Ambient temperature of	f 25 ±3°C)				
Indicator	light		Lights up who	en output is turned ON. OUT1, C	OUT2: Orange				
		closure		IP65					
	Op	erating temperature range Note 4)	Operating: -5 to 50°	C, Stored: $-10$ to $60^{\circ}$ C (No freez	ring or condensation)				
Environn	nent Op	erating humidity range	Operating	/Stored: 35 to 85% RH (No cond	densation)				
	Wi	thstand voltage	1000 VAC	for 1 minute between terminals a	and housing				
Insulation resistance		ulation resistance	50 MΩ or more (500 VDC n	neasured via megohmmeter) bet	ween terminals and housing				
Tempera	ture char	acteristics		±2% F.S. (25°C reference)					
Lead wire	•		Oilproof heavy-duty vinyl cable 5 cores ø3.5, 2 m Conductor area: 0.15 mm² (AWG26) Insulator O.D.: 0.95 mm						
Standard	s			CE, UL/CSA (E216656), RoHS					
AL				value more than the fluctuating widt					

Note 1) If the applied pressure fluctuates around the set-value, the hysteresis must be set to a value more than the fluctuating width, otherwise chattering will occur.

#### **Piping Specifications**

Part no.		01	N01	W1	WF1	M5	C4	C6		
Port size		R1/8 (With M5 female thread)	NPT1/8 (With M5 female thread)	Rc1/8 G1/8 M5 x 0.8 female thread		ø4 One-touch ø6 One-tou				
Material	Sensor pressure receiving area				Silicon					
of parts in contact with fluid	Piping port	C3602 (Electrole O-ring:	ss nickel plating) HNBR	ing) ZDC2 ZDC2, POM, Stai O-ring: HNBR C3604 (Electroles O-ring: HN			ess nickel plating)			
Weight		78 g	79 g	97	' g 104 g		101 g		101 g	
	M8 connector	45 g	46 g				-			

ZSE20 ISE20 ZSE30 ISE30

ZSE10 ISE70 ZSE80 ISE80 PS ISA3 ISA2 ISE35 PSE IS ISG

Note 2) When the analog voltage output is selected, the analog current output cannot be selected.

Note 3) When the analog current output is selected, the analog voltage output cannot be selected.

Note 4) UL temperature rating: The maximum ambient temperature is 50°C.


#### Set Pressure Range and Rated Pressure Range

#### Set the pressure within the rated pressure range.

The set pressure range is the range of pressure that is possible in setting.

The rated pressure range is the range of pressure that satisfies the specifications (accuracy, linearity, etc.) on the switch.


Although it is possible to set a value outside the rated pressure range, the specifications will not be guaranteed even if the value stays within the set pressure range.




Rated pressure range of switch
Set pressure range of switch

#### **Analog Output**

В







Range	Rated pressure range	Α	В	С
For vacuum pressure	0.0 to -101.3 kPa	10.1 kPa	0	–101.3 kPa
For compound pressure	-100.0 to 100.0 kPa	_	-100.0 kPa	100.0 kPa
For positive pressure	-0.100 to 1.000 MPa	-0.100 MPa	0	1.000 MPa


C

Pressure

### Internal Circuits and Wiring Examples


#### -X

#### NPN (2 outputs) + Copy function




#### -R/-S

-R: NPN (2 outputs) + Analog voltage output -S: NPN (2 outputs) + Analog current output




#### -T/-V

- -T: PNP (2 outputs) + Analog voltage output
- -V: PNP (2 outputs) + Analog current output




#### For M8 connector, 3 pins


#### -N NPN (1 output)




## PNP (2 outputs) + Copy function




#### -R/-S NPN (2 outputs) + Auto-shift input



#### -T/-V PNP (2 outputs) + Auto-shift input



## PNP (1 output)



ISE20 ZSE30 ISE30 IŠE40

ZSE20

ZSE10 ISE10 ISE70

ZSE80 ISE80

PS ISA3

ISA2 ISE35

> PSE ıs


ISG

ZSM1

#### Dimensions (For details about lead wires, refer to the product specifications.)

#### ZSE40A(F)/ISE40A-01 40.2 -N01 M5 x 0.8 thread depth 5 26.2 4.5 30 우 Pipina port 2 x M3 x 0.5 01: R1/8 thread depth 4 N01: NPT1/8 ø3.5 8.8 Atmospheric vent port ø2.6 14.7 When the pressure switch is used in a place where water and dust splashes may occur, insert a tube into the atmospheric vent port, and route the other end of the tube to a safe place away from water and dust. \* SMC TU0425 (polyurethane, O.D. ø4, I.D. ø2.5) suits to the pressure


#### ZSE40A(F)/ISE40A-W1




WF1: G1/8

#### Dimensions/For M8 (3-pin) connector

#### ZSE40A/ISE40A-01-□-□L -N01-□-□L





## M8 (3-pin) cable with connector V100-49-1-□



Cable length(L)	Part no.
300 mm	V100-49-1-1
500 mm	V100-49-1-2
1000 mm	V100-49-1-3
2000 mm	V100-49-1-4
5000 mm	V100-49-1-7

#### PCA-1557772





ZSE20 ISE20 ZSE30 ISE30

ZSE10 ISE10

ISE70 ZSE80 ISE80

PS ISA3

ISA2

ISE35 PSE

IS


ISG ZSM1

\_-----


#### **Dimensions** (For details about lead wires, refer to the product specifications.)

#### ZSE40A(F)/ISE40A-C4


-C6



Atmospheric vent port ø2.6



When the pressure switch is used in a place where water and dust splashes may occur, insert a tube into the atmospheric vent port, and route the other end of the tube to a safe place away from water and dust. \* SMC TU0425 (polyurethane, O.D. ø4, I.D. ø2.5) suits to the pressure switch.





**Dimensions** (For details about lead wires, refer to the product specifications.)


#### ZSE40A(F)/ISE40A-01-□-□A□

-N01-□-□A□

#### With bracket A








ZSE20 ISE20 ZSE30 ISE30


ZSE10


ISE10
ISE70
ISE80
PS
ISA3
ISA2
ISE35
PSE
IS
ISG
ISG




For M8 (3-pin) connector ZSE40A/ISE40A-01-□-□LA -N01-□-□LA


#### With bracket A







**Dimensions** (For details about lead wires, refer to the product specifications.)





**Dimensions** (For details about lead wires, refer to the product specifications.)

#### ZSE40A(F)/ISE40A-W1-□-□A□

-WF1-□-□A□


#### With bracket A







#### ZSE40A(F)/ISE40A-W1-□-□B□ -WF1-□-□B□

#### With bracket B







ZSE20 ISE20 ZSE30 ISE30

ZSE10 ISE10

ISE70 ZSE80 ISE80

PS ISA3

ISA2

ISE35 PSE

> IS ISG


ZSM1


**Dimensions** (For details about lead wires, refer to the product specifications.)


ZSE40A(F)/ISE40A-W1-□-□D□


-WF1-□-□D□

#### With bracket D











**Dimensions** (For details about lead wires, refer to the product specifications.)


#### ZSE40A(F)/ISE40A-01-□-□E□

-N01-□-□E□

#### Panel mount adapter








ZSE20 ISE20

ZSE30 ISE30

ZSE10 ISE10 ISE70 ZSE80 ISE80

ISA3
ISA2
ISE35
PSE
IS


ZSM1





#### ZSE40A(F)/ISE40A-01-□-□F□


-N01-□-□F□

#### Panel mount adapter + Front protective cover










59


**Dimensions** (For details about lead wires, refer to the product specifications.)


#### ZSE40A(F)/ISE40A-W1-□-□E□

-WF1-□-□E□

#### Panel mount adapter










#### ZSE40A(F)/ISE40A-W1-□-□F□

-WF1-□-□F□

#### Panel mount adapter + Front protective cover









Dimensions (For details about lead wires, refer to the product specifications.)


ZSE40A(F)/ISE40A-C4-□E□

-C6-□E□

Panel mount adapter










#### ZSE40A(F)/ISE40A-C4-□F□

-C6-□F□

Panel mount adapter + Front protective cover







ZSE20 ISE20 ZSE30 ISE30

ZSE10 ISE10

ISE70 ZSE80 ISE80

PS

ISA3


ISE35 PSE

IS

ISG ZSM1

61

#### **Dimensions**



Note) This is the minimum value for the piping method 01 or N01.

Take the piping material and tubing into account for design. When the corner is to have radius, it must be R3 or less.

#### **Function Details**

The F□ in ( ) shows the function code number. Refer to the Operation Manual for the details of operation procedures and function codes.

#### A Copy function (F97)

The settings of the master sensor can be copied to the slave sensors, reducing setting labor and minimizing risk of mistakes in setting.

Can copy to up to 10 switches simultaneously. (Maximum transmission distance 4 m)



Slave pressure switch Master n units pressure switch 1 unit 2 units (Up to 10 switches) OUT2 FUNC (-) 700 C (C) C 222 NC 2 T 멸 Brow œ (Copy wire) (Copy wire) (Copy wire Copy 41 Power supply

1) Wire as shown in the left figure.

- 2) Select the slave switch which is to be the master, and change it into a master using the buttons. (In the default setting, all switches are set as slaves.)
- 3) Press the S button of the master switch to start copying.

#### **PSE** IS

ZSE20

ISE20

ZSE30

ISE30 IŠE40 ZSE10 ISE10

ISE70

ZSE80

ISE80

PS

ISA3

ISA2

ISE35


ISG

ZSM1

Auto-preset function, when selected in the initial setting, calculates and stores the set-value from the measured pressure. The optimum set-value is determined automatically by repeating vacuum and break with the target workpiece several times.

#### Suction Verification

B Auto-preset function (F4)




#### Formula for Obtaining the Set-Value

P_1 or P_2	H_1 or H_2
$P_1 (P_2) = A - (A-B)/4$ $n_1 (n_2) = B + (A-B)/4$	H_1 (H_2) =  (A-B) /2

#### C Display calibration function (F6)

Fine adjustment of the indicated value of the pressure sensor can be made within the range of ±5% of the read value.

(The scattering of the indicated value can be eliminated.)



Note) When the display calibration function is used, the set pressure value may change ±1 digit.

#### Peak/Bottom value indication

This function constantly detects and updates the maximum (minimum) value and allows to hold the maximum (minimum) pressure value

When the ( ) volume buttons are simultaneously pressed for 1 second or longer, while "holding", the hold value will be reset.

#### E Keylock function

Prevents operation errors such as accidentally changing setting

#### E Zero-clear function

This function clears and resets the zero value on the display of measured pressure.

For the pressure switch with analog output, the analog output shifts according to the indication. The indicated value can be adjusted within ±7% F.S. of the pressure when ex-factory. (ZSE40AF (for compound pressure) ±3.5% F.S.)



#### **Function Details**

#### **G** Error indication function

Error name	Error code	Description	Action		
Overcurrent	Er 1	Load current of 80 mA or more is applied to the switch output (OUT1).	Eliminate the cause of the over current by turning		
error	E-2	Load current of 80 mA or more is applied to the switch output (OUT2).	off the power supply, and then turn on it again.		
Residual pressure error	Er3	During zero-clear operation, pressure over ±7% F.S. is applied. (ZSE40AF (compound) ±3.5% F.S.) After 1 second, the mode will reset to measurement mode. ±1% F.S. of the zero-clear range varies between individual products.	Perform zero-clear operation again after restoring the applied pressure to an atmospheric pressure condition.		
Applied	HHH	Supply pressure exceeds the maximum set pressure.	Reset applied pressure to a level within the set		
pressure error	LLL	Supply pressure is below the minimum set pressure.	pressure range.		
Auto-shift error	٥٢	The value measured at the time of auto-shift input is outside the set pressure range.  * After displaying the error code for about 1 second, the switch returns to the measuring mode.	The controller does not respond to the auto-shift signal. Check the equipment and machinery for this point.		
	Er0				
	٤٠٢				
System error	ErB	Internal data error	Turn off the power supply and then turn on it again. If the failure cannot be solved, please contact SMC		
System error	Er7	mional data on o	for investigation.		
	Er8				
	Erg				

If the failure cannot be solved after the above instructions are performed, please contact SMC for investigation.


#### H Anti-chattering function (F3)

A large bore cylinder or ejector consumes a large volume of air in operation and may experience a temporary drop in the supply pressure. This function prevents detection of such temporary drops in the supply pressure as an error.

Available response time settings
20 ms, 100 ms, 500 ms, 1000 ms, 2000 ms

#### <Principle>

This function averages pressure values measured during the response time set by the user and then compares the average pressure value with the pressure set point value to output the result on the switch.



#### Display unit switching function (F0)

Display units can be switched with this function.

Display unit	ρ	R	GF	ЬЯr	P5 ,	ıπΗ	Kññ
Minimum unit setting	kPa	MPa*	kgf/cm <sup>2</sup>	bar	psi	inHg	mmHg
ZSE40A (vacuum pressure)	0.1	0.001	0.001	0.001	0.01	0.1	1
ZSE40AF (compound pressure)	0.1	0.001	0.001	0.001	0.02	0.1	1
ISE40A (positive pressure)	1	0.001	0.01	0.01	0.1		

<sup>\*</sup> The ZSE40A (vacuum pressure) and ZSE40AF (compound pressure) will have different setting and display resolution when the unit is set to MPa.

The  $F\square$  in ( ) shows the function code number. Refer to the Operation Manual for the details of operation procedures and function codes.

#### J Power-saving mode (F80)

Power-saving mode can be selected.

It shifts to the power-saving mode without button operation for 30 seconds. It is set to the normal mode (Power-saving mode is OFF.) when ex-factory. (Decimal points and operation indicator light (only when the switch output is turned ON.) blink in the power-saving mode.)


#### K Setting of secret code (F81)

Users can select whether a secret code must be entered to release key lock. At the time of shipment from the factory, it is set such that the secret code is not required.

#### Auto-shift function (F5)

When there are large fluctuations in the supply pressure, the switch may fail to operate correctly. The auto-shift function compensates such supply pressure fluctuations. It measures the pressure at the time of auto-shift signal input and uses it as the reference pressure to correct the set-value on the switch.

#### Set-value correction by auto-shift function



#### \* Rectified value

When the auto-shift is selected, "aaa" will be displayed for about 1 second, and the pressure value at that point will be saved as a rectified value "£.5". Based on the saved rectified values, the set-value Note) of "P. I". "H. I". "P. 2", and "H. 2" will likewise be rectified.

Note) When an output is reversed, "n\_1", "H\_1", "n\_2", "H\_2" will be rectified

#### Settable Range for Auto-Shift Input


	Set pressure range	Settable range
Compound pressure	-105.0 to 105.0 kPa	-210 to 210 kPa
Vacuum pressure	10.0 to -105.0 kPa	115.0 to -115.0 kPa
Positive pressure	-0.105 to 1.050 MPa	-1.155 to 1.155 MPa

#### Auto-shift zero


The basic function of auto-shift zero is the same as the function for auto-shift. Also, it corrects values on the display, based on a pressure value of "I", when the auto-shift is selected.

#### Connection example of auto-shift function

#### Output specifications: -R/-S NPN (2 outputs) + Auto-shift input



#### Output specifications: -T/-V PNP (2 outputs) + Auto-shift input



ZSE20 ISE20 ZSE30 ISE30

ZSE40 ISE40 ZSE10 ISE10

ZSE80 ISE80

ISA3

ISA2

PSE IS

ISG ZSM1

## ZSE40A(F)/ISE40A Series **Made to Order**



Please contact SMC for detailed dimensions, specifications and lead times.




Symbol -X501

It has a lead wire extended to 3 meters.

#### **How to Order**

\* Refer to "How to Order" on page 47 for standard specifications.




2 M12 4-pin Pre-wired Connector (Lead wire length 100 mm)

Symbol -X531

#### How to Order

\* Refer to "How to Order" on page 47 for standard specifications.



Y: PNP open collector 2 outputs

