♦ IO-Link Compatible 3-Screen Display




Digital Gap Checker







NPN/PNP Switch Function




3-Screen Display (Setting)



Window Comparator Type


The gap range is adjustable.



ISA3-L Series

Zero cut-off range can be changed.


The lower limit of the display/setting range has been extended.



CAT.ES100-125A

Double sensor providing improved preventive and predictive maintenance (IoT) based on IO-Link





Process data provides not only the **Displayed value** (1), but also the **Outlet pressure value** (2) and the **Supply pressure value** (3) detected using pressure sensors before and after the orifice.

Process Data

Item						Gap	size (Re	ference):	16 Bit s	igned ir	teger					
Bit offset	63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48
Item		Supply pressure value: 16 Bit signed integer														
Bit offset	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32
Item	Outlet pressure value: 16 Bit signed integer															
Bit offset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
Item	Error diagnosis			()			Pressure diagnosis)	Outlet side SW2	Outlet side SW1	Supply side SW2	Supply side SW1	Distance detection SW2	Distance detection SW1
Bit offset	15	14	13	12	11	10	9	8	7	6	3	2	5	4	1	0
	A							A								

Diagnosis item

- Abnormal temperature
- Display pressure range has exceeded the lower limit
- · Internal product malfunction
- · Outside of zero-clear range

Diagnosis item

Detected pressure:
 Less than –20 kPa

Example of Detection Applications Using the Switching Outputs and Value

	Outlet pres	ssure value	Supply pres	pressure value Displayed v		ue (Gap size)	
Setting	SW2	SW1	SW2	SW1	SW2	SW1	
example	En_2: 5.0	EP1L: 25.0 EP1H: 50.0	SP_2: 200.0	Sn_1: 100.0	n_2: 150	n_1: 50	Diagnosis item
Mode	Hysteresis	Window comparator	Hysteresis	Hysteresis	Hysteresis	Hysteresis	
Setting	Turns ON at 5 kPa or less	Turns ON at 25 to 50 kPa	Turns ON at 200 kPa or more	Turns ON at 100 kPa or less	Turns ON at	Turns ON at	
contents	5 KPa or less	25 10 50 KPa	200 KPa of more	100 KPa of less	150 μm or less	50 μm or less	
	_	_	_	_	0	0	Confirmation of close contact: 50 µm or less
	_	_	_	_	0	_	Confirmation of approximate contact: 150 µm or less
Output	_	_	_	0	_	_	Insufficient supply pressure: 100 kPa or less
status	_	_	0	_	_	_	Excessive supply pressure: 200 kPa or more
	_	0	_	_	_	_	Detection nozzle clogging
	0	_	_	_	_	_	Orifice clogging

○: The corresponding bit in the process data is "1:ON" —: The corresponding bit in the process data is "0:OFF" or not determined


Process data provides (1) Displayed value, (2) Outlet pressure and

(3) Supply pressure value


Not only the displayed value, but also the pressure value (supply pressure, outlet pressure) which affect the de-

tection can be transmitted in real time.






The relationship between the displayed value (gap distance guideline) and detection nozzle clogging/orifice clogging




The displayed value (gap distance guideline) is affected by the detection nozzle clogging or the internal orifice clogging. The displayed value alone may not be the correct detection result. It is important to check the detection nozzle and the orifice for clogging.

Monitoring of the outlet pressure value




The displayed value varies if the detection nozzle or internal orifice is clogged. It is possible to detect clogging by monitoring the outlet pressure during workpiece transfer (the workpiece is not placed).



clogging) clogging) (Orifice clogging)


Monitoring of the supply pressure value Change of the outlet pressure when the supply pressure changes




transferred (not placed) also varies depending on the supply pressure. The supply pressure and the outlet pressure need to be monitored simultaneously.



IO-Link is an open communication interface technology between the sensor/ actuator and the I/O terminal that is an international standard, IEC61131-9.



[&]quot;ModE LoC" is displayed when the data storage lock is enabled. (Except for version mismatch or when in SIO mode)



^{*1} The displayed value (estimated gap distance) will vary depending on individual product differences and nozzle machining dimensions.

3-Step Setting (Switch Point Change Mode)

 Simple setting of the switch point value (point at Pressing the
and
buttons simultaneously for a minimum of 1 second Snap shot then releasing the buttons when the displayed switch point value disapwhich the clearance reaches the switch point value) function pears will make the switch point the same as the current displayed value. Clearance gauge Switch point setting Placed Workpiece (Switch output ON) Displayed value Switch point Switch point value ≥ Displayed value Air Not placed (Switch output OFF)

switch point value.

2 Press the A or v button to set the

- 1 To reproduce the placement condition, press the (sin) button while the sub display shows the OUT1 switch point value (n_1).
- Operation is different from products which are not IO-Link compliant (1 output, 2 outputs type).

3-Screen Digital Display


 The seating condition can be checked at a glance. The sub screen can display 1 of 12 display options.

3 Press the

the setting.

button to complete

Switch point value < Displayed value



*1 The displayed value is a reference value obtained by converting the distance between the workpiece and the detection surface into a digital numerical value. It is not displayed in units. For details, refer to the Relationship Between Displayed Value and Distance on page 18.

Rated Distance Range: 3 types are available.



3 Setting Modes Select the setting mode that best meets your needs. 3-Step Setting Simple Setting **Function Selection Mode** Mode Mode Output target selection • Output mode selection • Switch point value setting • Switch point value setting • Selection of normal or reversed • Hysteresis value setting • Switch point value setting 0000000 • Hysteresis value setting Delay time setting*1 • Hysteresis value setting • Delay time setting*1 • Display color selection Higher **Settings** Simple function 1 Mode selection Press the SET button while the sub Press for between Press for between display is showing the target item. 1 and 3 seconds. 3 and 5 seconds. * Example for OUT1 2 Output target selection OUT1 is fixed to distance detection. For OUT2, select distance, supply pressure, outlet pressure, etc. can oUt 1 d iSt be set for OUT2. 3 Output mode selection Select from •Hysteresis mode Window comparator mode When "Others" is selected as the output target for OUT2, • Error output or Output off can be selected. 4 Normal or reversed output selection Select from • Normal output • Reversed output 5 Set value (Switch point value) setting Adjust the numerical value. 6 Hysteresis value setting • Adjust the numerical value. Display color selection Select from OUT2 setting*2 ON Green /OFF Red (OUT1 or OUT2) ON Red /OFF Green (OUT2 or OUT2) Normally Red /Normally Gree **Setting Completed** Setting Completed **Setting Completed**

^{*2} Refer to the Operation Manual for details on setting the OUT2.



^{*1} Available when OUT2 is not set for "distance." It can be set in the next step of the Hysteresis value setting.

2 Outputs Type


(1) Displayed value, (2) Outlet pressure value, and

(3) Supply pressure value can be selected in OUT2.

Supply pressure




The pressure and gap size are detected by the pressure sensors at the front and back of the orifice before output.



Monitoring of the Outlet Pressure Value (2)

 OUT2 detection of rising pressure when a workpiece is not placed that signifies detection nozzle clogging.

Only nozzle clogging is detected by the window comparator mode and setting the response time.




Can discern between 2 different types of workpiece

Outlet pressure


OUT2

Can detect raw material workpieces and defective workpieces via the pressure (OUT2)




Monitoring of the Displayed Value (Gap Size) (1)

Can discern between 2 different types of workpiece
 Can detect the difference between raw material workpieces and defective workpieces via the gap size



Monitoring of the Supply Pressure Value (3)

 Detection of rated pressure range via OUT2



Improved Environmental Resistance

Easier maintenance

The internal orifice part can be removed for cleaning. It is not necessary to remove the piping or metal connection fitting for cleaning even when the product is installed in the user's equipment.



* Once the orifice has been removed, the switch point will need to be set again.

- Measures against drainage
 Drainage increased 10 times or more
 - * Based on SMC's specific testing conditions (Oil proof test)
 - * Compared with the ISA2

Withstand pressure increased by 3 times*1 compared with the ISA2

Max.: 600 kPa

*1 Compared with the ISA2 with a 0.2 MPa pressure gauge


High-pressure flushing

* The switch output will be OFF during flushing.

Noise reduction, Energy saving, Measures against clogging







A

Exhaust noise: Zero

Noise reduction

The existing model (ISA2) needs to exhaust air from the exhaust port due to its bridge circuit.

However, the ISA3 does not exhaust air from the product body. This reduces noise considerably compared with the existing model.

Air consumption: 60% reduction*1

Energy saving

The new detection principle eliminates the need for air to be exhausted from the product. This makes the flow consumption 0 L/min when a workpiece is seated.

The result is a great reduction in air consumption compared with the existing model.

*1 Conditions: Unseated for 5 seconds and seated for 20 seconds (For the G type)



Number of orifices: $3 \rightarrow 1$

Measures against clogging

By reducing the number of internal orifices from 3 to 1, there is less possibility of fluctuations in the output due to clogging. By removing the setting dial for S3, fluctuations in the detection distance can be prevented.

D

Orifice area ratio: 68% increase*1

Measures against clogging

A larger orifice area lowers the possibility of clogging. However, even if the orifice does become clogged with foreign matter, the product construction allows for the internal orifice to be removed for cleaning.


*1 Excludes the F type







Space saving and man-hour reduction by centralized lead wires

Installation space:30 mm reduction







Keylock Function

 A key LED turns ON when the product is locked and button operation is disabled to prevent unintentional changes to set values.



Piping Variations



Mounting







Manifold

Regulator Pracket mounting only

Without control unit








* The electrical entry of the centralized lead wire for the M12 connector is on the right side.

When using a right-sided supply port, arrange the centralized lead wire so that it does not interfere with the control unit.




Application Examples

Detection of the table and pallet seating



Workpiece clamp detection



Clamping completed

Main Functions

■ Display OFF mode

Display OFF mode can be selected. The display can be turned OFF to reduce power consumption.



.....

The numerical value disappears and only the decimal points blink.

The numerical value disappears and When the security code

When the security code is activated, the code needs to be entered before the product can be operated.





Display color

The color of the main display can be set to change depending upon the output activity. The display color change makes visual identification of the output ON/ OFF easier.

When ON: Green	When OFF: Orange
When ON: Orange	When OFF: Green
Normally: Orange	
Normally: Green	

■ Unit selection function

the pressure unit displayed on the sub screen can be changed.

Display unit	kPa	bar	psi
Minimum setting resolution	0.1	0.001	0.02

■ Displayed value compensation

The displayed value can be corrected within $\pm 20\%$ R.D. of the displayed value at the time of shipment.

■ Forced output


The output can be fixed to an ON/OFF state when starting the system or during maintenance. This enables the confirmation of the wiring and prevents system errors due to unexpected output.

■ Zero-clear of pressure value

The pressure value displayed on the sub screen can be cleared to zero.



Series Variations



3-Screen Display Digital Gap Checker

Without Control Unit

ISA3-L Series (FOHS



How to Order

ISA3-GCL-M2

Rated distance range

F	0.01 to 0.03 mm
G	0.02 to 0.15 mm
Н	0.05 to 0.30 mm

Piping specification •

	Supply side	Detection side
С	Rc1/8	ø4 One-touch fitting *1
F	G1/8 * ³	G1/8*3

- *1 When F is selected for the rated distance range
- When G or H is selected for the rated distance range
- *3 Conforming to ISO 1179-1

Output specification •

IO-Link: Switch output 1 + Switch output 2 (Switch output: NPN or PNP switching type)

OUT1: Gap size detection OUT2: Gap size, outlet pressure, supply pressure detection (Select from the above.)

Unit specification of ● pressure value

Nil	With unit			
1411	selection function *9			
M	Fixed SI unit *10			
*9 Under the New				

Measurement Act, digital gap checkers with the unit selection function are no longer allowed for use in Japan.

*10 Unit: kPa

Option 2 (Bracket)

Nil None (DIN rail mounting) *7 With bracket *5 *8		(=
(DIN rail mounting) */ With bracket *5 *8	NII	None
18.000	IVII	(DIN rail mounting) *7
9.0		
	В	

- *7 Order DIN rail separately. (Refer to page 21.)
- About the number of brackets, 1 station: 1 piece is packed, 2 stations or more: 2 pieces are packed.

Bracket mounting position

2 stations

(Mount to 1st and 2nd stations)

Ontion 1 (Cable)

Stations •

1 station

2 stations

3 stations

4 stations

5 stations

6 stations

3

5


			Option 1 (Cable)
Nil	Straight *5 *6		Centralized lead wire (Lead wire only) *4 *5
L	Right angle *5 *6	S	
	None not be selected for 1 station set is provided per manifold.		Centralized lead wire (With bracket) *4 *5

Т

A centralized lead wire is provided with M12 connectors for the number of stations.

Refer to page 25 for details.

- At the factory, the options are not attached to the product, but packed together with it for shipment.
- *6 Cables are provided for the number of stations.



3-Screen Display Digital Gap Checker

With Control Unit

ISA3-L Series (FOHS



How to Order

ISA3-GCL-M2

Rated distance range

	<u> </u>
F	0.01 to 0.03 mm
G	0.02 to 0.15 mm
Н	0.05 to 0.30 mm

Piping specification

	<u>-</u> _	<u> </u>
	Supply side	Detection side
С	Rc1/8	ø4 One-touch fitting *1
F	G1/8 * ³	G1/8*3

- *1 When F is selected for the rated distance range
- *2 When G or H is selected for the rated distance range
- *3 Conforming to ISO 1179-1

Output specification

IO-Link: Switch output 1 + Switch output 2 (Switch output: NPN or PNP switching type)

OUT1: Gap size detection OUT2: Gap size, outlet pressure, supply pressure detection (Select from the above.)

Unit specification of pressure value

Nil	With unit
INII	selection function *12
M	Fixed SI unit *13

*12 Under the New Measurement Act, digital gap checkers with the unit selection function are no longer allowed for use in Japan.

*13 Unit: kPa

Otations •			
1	1 station		
2	2 stations		
3	3 stations		
4	4 stations		


6 stations Option 1 (Cable)


5 stations

	Nil	Straight *5 *6		
	L	Right angle *5 *6	Ø	
	N	None		
*4 Cannot be selected for 1 station				


- One set is provided per manifold. A centralized lead wire is provided with M12 connectors for the number of stations. Refer to page 25 for details.
- *5 At the factory, the options are not attached to the product, but packed together with it for shipment.
- *6 Cables are provided for the number of stations.

Centralized lead wire (Lead wire only) *4 *5





Т



rated voltage

Nil	24 VDC
1 *11	100 VAC
2 *11	110 VAC


*11 Produced upon receipt of order

◆Regulator (Refer to page 22.)

П		1400				
L	N *10		Withou	ut regula	ator	
	0*10		Without	pressur	e gauge	
	1		Round type pressure gauge	0.4 MPa		
	2	ulator	Square type pressure gauge	U.4 IVIFA	MPa single	
	3	п	Round type pressure gauge	0.2 MPa	notation	
	4	reg	Square type pressure gauge	U.Z IVIFA		
	5 *10	ıд	Round type pressure gauge	0.4 MPa	MPa-psi double notation	
	6*10	⋛	Square type pressure gauge	U.4 IVIFA	psi single notation	
	7 *10		Round type pressure gauge	0.2 MPa	MPa-psi double notation	
	8*10		Square type pressure gauge	U.Z IVIFA	psi single notation	

*10 Produced upon receipt of order

Control unit (Regulator, 2-port valve)




Control unit piping specification *8

Gap checker piping specification	Supply port piping specification
С	Rc1/4
F	G1/4 *9

- *8 When the control unit is mounted, the piping specifications of the supply port will be changed due to piping specification of the gap checker.
- *9 Conforming to ISO 16030

Option 2 (Bracket)



*7 The bracket for control unit is shipped mounted on the product.

Specifications

For gap checker precautions and specific product precautions, refer to the "Operation Manual" on the SMC website.

	Model		ISA3-FL	ISA3-GL	ISA3-HL		
Applicable fluid				Dry air (Filtered through a 5 μm filte	r)		
Rated distance range		0.01 to 0.03 mm	0.02 to 0.15 mm	0.05 to 0.30 mm			
	Displayable/Settable range	ge (Distance reference) *1	0 to 60 *2	0 to 300 *2 *3	0 to 500 *2 *4		
	Minimum display resoluti	ion (Distance reference) *1	1				
OUT1	Rated pressure r	ange		100.0 to 200.0 kPa			
OUT2 *6	Displayable range	(Pressure value) *5		-20.0 to 220.0 kPa			
	Repeatability		0.005 mm or less	0.010 mm or less	0.020 mm or less		
	Temperature character	ristics (Reference: 25°C)	0.010 mm or less	0.015 mm or less	0.030 mm or less		
	Hysteresis		0 to variable (Default: 3) 0 to variable (Default: 20)				
	Rated pressure r	ange	·	0.0 to 200.0 kPa			
	Set pressure ran	ge	-20.0 to 220.0 kPa				
OUT2 *7	Minimum display	setting resolution	0.1 kPa				
0012	Repeatability			±0.5% F.S. ±1 digit			
	Temperature character	ristics (Reference: 25°C)		±2% F.S.			
	Hysteresis	,		0 to variable *8			
Withstand	pressure			600 kPa			
Detection r	nozzle			ø1.5 * ⁹			
	ion flow rate		5 L/min or less	12 L/min or less	22 L/min or less		
•		as a switch output device	24 V	/DC ±10% with 10% voltage ripple o	r less		
Electrical	voltage When use	ed as an IO-Link device	1:	8 to 30 VDC, including ripple (p-p) 1	0%		
Electrical	Current consum	ption		25 mA or less			
	Protection			Power supply polarity protection			
Switch out	put		Selec	ct from NPN or PNP open collector of	output.		
	Maximum loa	ad current	10 mA				
	Maximum ap	plied voltage	30.0 V				
	Residual vol	tage	1 V or less (at 10 mA)				
	Short-circuit	protection	Provided				
			2-screen display (3 types of display are available: Sub screen: 4-digit x 2)				
Display			Main screen: 4-digit 7-segment, 2-color (Orange/Green)				
			Sub screen: 9-digit (Up	pper 9-digit, 4-digit, 3-digit 11-segme	ent, 7-segment for other)		
	Enclosure			IP67 equivalent *10			
Environme		mperature range		0°C, Stored: -20 to 70°C (No conde			
resistance	Operating hu	umidity range		ing/stored: 35 to 85% RH (No conde			
resistance	Withstand vo			(in 50/60 Hz) for 1 minute between to			
	Insulation re		2 MΩ or more (500 VDC	measured via megohmmeter) between	een terminals and housing		
	For C type	Supply port		Rc1/8			
Piping	1 of o type	Detection port	ø4 One-touch fitting		ouch fitting		
i ipilig	For F type	Supply port		G1/8 (Conforming to ISO 1179-1)			
	1 of 1 type	Detection port	G1/8 (Conforming to ISO 1179-1)				
	Lead wire with c	onnector	M12 lead wire with 4 pin connector, 4 cores, ø4, 5 m Conductor O.D.: 0.72 mm, Insulator O.D.: 1.14 mm				
Cable			M12 lead wire with 4 pin connector part, 4 cores, Ø4, Insulator O.D.: 1.14 mm				
ou	Centralized lead wire		Centralized lead wire part, 2 to 3 stations: 8 cores, ø6, 5 m, 4 to 6 stations: 14 cores, ø6, 5 m				
				50 mm, Insulator O.D.: 1.00 mm (2 to			
Weight			113 g (Cable not included, One-touch fitting)				
Standards IO Link type		CE marking (EMC Directive, RoHS Directive)					
	IO-Link type	on .	Device				
	IO-Link versi		V1.1				
	Communication speed		COM2 (38.4 kbps)				
Communi	Configuration file tion Minimum cycle time		IODD file *11				
	ode) Process data		4.2 ms				
(IO-LIIIK MC		ata communication	Input data: 8 bytes, Output data: 0 bytes				
				Yes			
	Data storage			Yes			
	Event function Vendor ID		Yes 131 (0 x 0083)				

- *1 For details, refer to the Relationship Between Displayed Value and Distance on page 18.
 *2 If hysteresis is set to 3 (Default setting), the "Displayable/Settable range" of the F type is limited to 57. If hysteresis is set to 20 (Default setting), the G type is limited to 280 and the H type is limited to 480. (Reversed output: Factory default value)
 *3 Due to the zero-cut function, the values of 8 and under are displayed as 0 at factory default setting.
- *4 Due to the zero-cut function, the values of 29 and under are displayed as 0 at factory default setting.
 *5 The pressure value will be the indicated on the sub screen.

- *7 Refers to when OUT2 is set to detect the pressure

 *8 If the applied pressure fluctuates around the set value, the hysteresis must be set to a value more than the fluctuating width, otherwise chattering will occur.

 *9 For details on the detection nozzle, refer to the figures on page 18.

 *10 Only applies to the digital gap checker body excluding the control unit.

 *11 The configuration file can be downloaded from the SMC website,

- https://www.smcworld.com Products with tiny scratches, marks, or display color or brightness variations which do not affect the performance of the product are verified as conforming

Rated Distance Range and Displayable/Settable Range

⚠ Caution

The displayed value is a reference value obtained by converting the distance between the workpiece and the detection surface into a digital numerical value. It is not displayed in units. For details, refer to the Relationship Between Displayed Value and Distance on page 18. Rated distance range: Distance range within which the product meets the specifications

Displayable/Settable range: Range within which it is possible to display or set values, (Not guaranteed to meet the specifications)

Model				Distance	
iviouei	0 mm 0.02 mm	0.05 mm	0.15 mm	0.30 mm	0.50 mm
ISA3-F type					
ISA3-G type					
ISA3-H type					
			Rated distance range	Displayable/Settable range	:::::When zero cut-off is minimum



Supply Pressure Dependence Characteristics


The distance for the product to turn ON varies depending on the supply pressure.

The graphs below show the variation of the distance for the product to turn ON, for 3 types of gap, by changing the supply pressure (±50 kPa) when the product is set to turn ON at 150 kPa supply pressure.

Test conditions

Detection nozzle: Ø1.5 Piping: F type Ø4 x Ø2.5 tube/G, H type Ø6 x Ø4 tube
Reference pressure: 150 kPa

Use within the rated pressure range (100 kPa to 200 kPa).
It will be impossible to measure the gap when the operating pressure is less than 80 kPa or over 220 kPa. And the output will be OFF.
(Refer to the Relationship Between Supply Pressure and Display on page 26.)



ISA3-L Series

Response Time

Response time is the elapsed time between the pressure supply and the turning ON of the switch output.

The response time varies depending on the piping length from the OUT port to the detection nozzle, and the seating condition of the workpiece. The graphs below show the response time when the workpiece is approached at 90% distance and 0% distance (close contact). (* The switch point is 100% distance.)


(Example: When the switch point is set to 0.1 mm, the response time when the workpiece is at 0.09 mm and 0 mm are measured.)

Test conditions

Detection nozzle: \emptyset 1.5 **Piping:** F type \emptyset 4 x \emptyset 2.5 tube/G, H type \emptyset 6 x \emptyset 4 tube

Supply pressure: 200 kPa

Response time when the workpiece is set at 90% distance
Response time for close contact of workpiece



Relationship Between Displayed Value and Distance


The graphs below show the relationship between the displayed value and distance.

- The data shown below are for reference. They change depending on the individual product differences and machining dimensions of the nozzle.
- The zero-cut function forcibly displays 0 when the value is less than the set value. Although the zero cut-off range can be set to 0, it may not be 0 even in close contact, due to the characteristics of the product.


Detection nozzle: Ø1.5
Detection nozzle piping: F type Ø4 x Ø2.5 tube 1 m, 3 m, 5 m/G, H type Ø6 x Ø4 tube 1 m, 3 m, 5 m
Supply pressure: 200 kPa

ISA3-FL

est condition




ISA3-GL



ISA3-HL

* Default setting: Values of 8 and under are displayed as "0."





* Default setting: Values of 29 and under are displayed as "0."

Detection Nozzle Shape

The nozzle shape must be similar to Fig. 1. Do not chamfer the nozzle as shown in Fig. 2, as the characteristics will be affected.

Fig. 1: Recommended nozzle shape






ø3 or more

Internal Circuits and Wiring Examples


When used as a switch output device

* The numbers in the circuit diagrams show the connector pin layout.


Setting of NPN open collector 2 outputs



Setting of PNP open collector 2 outputs



When used as an IO-Link device




 Refer to the Web Catalog for wiring details of the VX2 series (2-port solenoid valve).




ISA3-L Series

Construction Diagram



3-Screen Display Digital Gap Checker ISA3-L Series

Construction Diagram



If there is a possibility that the atmospheric vent port of the gap checker will be exposed to water or dust, insert a tube into the atmospheric vent port and route the other end of the tube to a safe place away from water or dust.

* For tubing, please use the SMC TU0425 (polyurethane, O.D. ø4, I.D. ø2.5) for the gap checker.

∧ Caution


SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.



ISA3-L Series


Parts List



*1 Spacers are included for 4 and 6 stations.

Joint screws screws, spacers, 2 nuts

Stations	Part no.
2	ISA-16-2
3	ISA-16-3
4 *1	ISA-16-4
5	ISA-16-5
6 *1	ISA-16-6



Seal for extra station ISA-15 1 pc.




③ Threaded plug with seal ISA-12-□ 1 pc.

Piping	Part no.	
Rc1/8	ISA-12-A	
G1/8	ISA-12-C	




■ Bracket ISA-14



With 3 tapping screws (3 x 8)

■ DIN rail ISA-5-1



Stations	Part no.	L
1	ISA-5-1	73.0
2	ISA-5-2	135.5
3	ISA-5-3	173.0
4	ISA-5-4	210.5
5	ISA-5-5	248.0
6	ISA-5-6	285.5


■ Lead wire with connector ZS-31-B ZS-31-C




ZS-31-C Right angle 5 m



■ Centralized lead wire ISA-21-2




■ Bracket for centralized lead wire ISA-20



* With 2 mounting screws (M3 x 16L)

3-Screen Display Digital Gap Checker ISA3-L Series


Parts List (Control Unit)



- *1 The pressure gauge port is 1/8. The pressure gauge is included in the package, but not assembled.
- *2 This product is for overseas use only according to the New Measurement Act. (The SI unit type is provided for use in Japan.)

For details, refer to the Web Catalog.






product without thread machining (symbol: Z)

For specifications other than X276, refer to the **Web Catalog**.


■ Bracket (when control unit fitted) ISA-17

cannot be selected.



With 2 tapping screws (3 x 8)

■ Spacer with bracket Y200T-A



■ Modular adapter E210-U01



■ Spacer ISA-18




 When a 2-port solenoid valve is connected to the right




ISA3-L Series

Dimensions

ISA3-□□L-□□□B (Bracket mounting)




ISA3-□□L-□□□ (DIN rail mounting)




(3-Screen Display) Digital Gap Checker ISA3-L Series

Dimensions





ISA3-□C: Rc1/4

ISA3-□F: G1/4*1



- *1 Conforming to ISO 16030
- *2 Conforming to ISO 1179-1
- * Bracket mounting only





						<u> </u>
Stations	1	2	3	4	5	6
L1	55.6	93.6	131.6	169.6	207.6	245.6
L2	136.4	174.4	212.4	250.4	288.4	326.4
Piping type C (ø4 One-touch fitting) C (ø6 One-touch fitting) F (G thread)						


13.6



ISA3-L Series

Dimensions

ZS-31-B (Cable with connector)



ZS-31-C (Cable with connector)






Blue

	•	•
-	5000	23.5
		- W 8
		30.0
		ø15

Pin no. Lead wire color Description Pin no. Lead wire color Brown DC(+) White OUT2 Black

ISA-21-□ (Centralized lead wire)



Description

DC(-)

OUT1

For 2 to 3 Stations

For 4 to 6 Stations

i di 2 to 3 Stations					
M12 connector no.	Pin no.	Description	Output lead wire color		
1	1	DC(+)	Brown*1	Orongo	
	2	OUT2		Orange	
	3	DC(-)	Blue*1	Black	
	4	OUT1		DIACK	
2	1	DC(+)	Brown*1	Red	
	2	OUT2		Rea	
	3	DC(-)	Blue*1	White	
	4	OUT1		vvnite	
3	1	DC(+)	Brown*1	Green	
	2	OUT2		Green	
	3	DC(-)	Blue*1	Gray	
	4	OUT1			


M12 connector no.	Pin no.	Description	Output lead wire color	
1	1	DC(+)	Brown*1	Yellow
	2	OUT2		Yellow
	3	DC(-)	Blue*1	Black
	4	OUT1		ыаск
2	1	DC(+)	Brown*1	Purple
	2	OUT2		Purple
	3	DC(-)	Blue*1	White
	4	OUT1		vvriite
	1	DC(+)	Brown*1	Gray/
3	2	OUT2		Black
	3	DC(-)	Blue*1	C === :
	4	OUT1		Gray

M12 connector no.	Pin no.	Description	wire	ıt lead color
4	1	DC(+)	Brown*1	Orange/
	2	OUT2		Black
	3	DC(-)	Blue*1	Orongo
	4	OUT1		Orange
5	1	DC(+)	Brown*1	Red/
	2	OUT2		Black
	3	DC(-)	Blue*1	Red
	4	OUT1		neu
6	1	DC(+)	Brown*1	Green/
	2	OUT2		Black
	3	DC(-)	Blue*1	Croon
	4	OUT1		Green


ISA-14 (Bracket when control unit not fitted)

6.5 1.6


Y200T-A (Spacer with bracket)



ISA-17 (Bracket when control unit fitted)



ISA-20 (Bracket for centralized lead wire)






^{*1} Brown and blue are connected inside the product.

3-Screen Display Digital Gap Checker ISA3-L Series

Error Indication

Main screen	Name	Description	Measures
	Supply pressure error	Displayed when supply pressure is outside the range of 80 kPa to 220 kPa. Measurement is not possible.	Supply rated pressure (100 kPa to 200 kPa). The product will return to measurement mode automatically.
	Outside of the displayable range (Switch point change mode)	The workpiece is outside the displayable range.	Move the workpiece closer to the detection nozzle.
Er !	OUT1 over current error	The switch output (OUT1) load current of 80 mA or more flows.	Turn the power OFF and remove the cause of the over current. Then turn the power ON again.
Er 2	OUT2 over current error	The switch output (OUT2) load current of 80 mA or more flows.	Turn the power OFF and remove the cause of the over current. Then turn the power ON again.
Er 3	Zero clear error	Zero clear was not performed at atmospheric pressure. (Pressure outside of ± 14 kPa was supplied present.)	Perform zero clear at atmospheric pressure.
Er 30 FSE2	Pressure adjustment error during calibration	Fine adjustment of the pressure display at the OUT port was not performed correctly during calibration. (When the pressure after the adjustment is below the supply pressure lower limit (80 kPa) or exceeds the display set range upper limit (220 kPa))	Keep the SUP port pressure and OUT port pressure the same and perform fine adjustment of the OUT port pressure display value. Set the pressure within 80 kPa to 220 kPa.
Er [] Er 4 to Er 9 Er 4[]	System error	An internal data error has occurred.	Turn the power OFF and turn it ON again.
Er 15	Version does not match	IO-Link version does not match that of the master. The master uses version 1.0.	Ensure that the master IO-Link version matches the device version.
Sub screen	Name	Description	Measures
HHH	Supply pressure error (When [SUP side pressure value	Pressure exceeding 220 kPa is supplied.	Keep the supply pressure within the display-
LLL	display] is set to the sub screen)	Vacuum pressure (less than -20 kPa) is supplied.	able range of –20 kPa to 220 kPa.

Relationship Between Supply Pressure and Display



⚠ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)*1), and other safety regulations.

Caution: Caution indicates a hazard with a low level of risk which, If not avoided, could result in minor or moderate injury.

Warning: Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

⚠ Danger: Danger indicates a nazaru wiiii a nigin ieve, on no.
if not avoided, will result in death or serious injury. **Danger** indicates a hazard with a high level of risk which, *1) ISO 4414: Pneumatic fluid power - General rules relating to systems.

ISO 4413: Hydraulic fluid power – General rules relating to systems.

IEC 60204-1: Safety of machinery - Electrical equipment of machines. (Part 1: General requirements)

ISO 10218-1: Manipulating industrial robots - Safety.

⚠ Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
 - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
 - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
 - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.
 - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
 - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
 - 3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
 - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

⚠ Caution

1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary. If anything is unclear, contact your nearest sales branch.

Limited warranty and Disclaimer/ **Compliance Requirements**

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.*2) Also, the product may have specified durability, running distance or
 - replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.
 - *2) Vacuum pads are excluded from this 1 year warranty.

A vacuum pad is a consumable part, so it is warranted for a year after it is delivered.

Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

Compliance Requirements

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

⚠ Caution

SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

A Safety Instructions Be sure to read the "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual" before use.