
# Series 10-SYJ300/500/700

Rubber Seal 3 Port Solenoid Valve




# 3 Port Solenoid Valve 10-SYJ300/500/700

# **Manifold Variations**

							A po	ort size				
Valve series		A port	P, R ports				With One-touch fitting					
	valve series	location	size	M3	M5	1/8	Applicable tubing O.D.					
							ø4	ø6	ø8	N3	N7	N9
ted	10-SYJ300 P.609	Тор	M5 x 0.8	Note)		—	_	—	_	—	_	_
Body ported	10-SYJ500 P.620	Тор	1/8	—	•	_	_	_	_	_	_	_
<b>B</b> B	<b>10-SYJ700</b> тор Р.632	1/8	—	—	Note)	_	—		—	_	—	
		rop	1/4	_	_		_	—	_	—	_	_
		Side	M5 x 0.8	Note)	_	—	—	—	_	—	—	_
Base mounted	10-SYJ300 P.609	Side	1/8	_	•	—	•	—	_		—	_
our	10-SYJ500	Bottom	1/8	—				—	_	—	—	—
E B	P.620	Side	1/8	_	•		$\bullet$		_			_
as		Bottom	1/8			Note)		_	-			
m	10-SYJ700	Dottom	1/4	_			_	_	—	_	—	—
	P.632	Side	1/4	—			—			_		

Note) Only for internal pilot



Series 10-SYJ300

Series 10-SYJ500

Series 10-SYJ700

# Series 10-SYJ300 Rubber Seal 3 Port Pilot Solenoid Valve



Body ported



Base mounted

#### Symbol

# Internal pilot

10-SYJ312M

10-SYJ324M 2(4)

2(A)  $\succ$ (P)1 3(R)

2	2(A)	
ď		
(P)	 I 3(R)	



# Specifications

Fluid		Air		
Operating pressure range (MPa)	Internal pilot	0.15 to 0.7	Air Cylinders	
Ambient and fluid ter	nperature (°C)	-10 to 50 (No freezing.)	Š	
Response time ms (a	t 0.5 MPa) Note 1)	15 or less	Air	
Max. operating freque	ency (Hz)	10		
Manual override (Mar	nual operation)	Non-locking push type, push-turn locking slotted type, push-turn locking lever type	Rotary Actuators	
Pilot exhaust method		Main/Pilot valve common exhaust	tual	
Lubrication		Not required	Ac	
Mounting orientation		Unrestricted	ary	
Impact/Vibration resist	stance (m/s2) Note 2)	150/30	Bat	
Enclosure		Dust proof (* M8 connector conforms to IP65.)		
Note 2) Impact resistance:     No malfunction occurred when it was tested in the axial direction and at right     angles to the main valve and armature in both energized and de-energized     states once for each condition.     (Default settings)				
Vibration resistance		urred in a one-sweep test between 45 and 2000 Hz.		
Test was performed in both energized and de-energized states in the axial direction and at right angles to the main valve and armature. (Default settings)				
			Air Preparation Equipment	

# **Solenoid Specifications**

Electrical entry			Grommet (G), (H), L plug connector (L), M plug connector (M), M8 connector (W)		
Coil rated	DC		24, 12, 6, 5, 3		
voltage (V)	Α	C 50/60 Hz	100, 110, 200, 220		
Allowable voltage	fluctu	ation	±10% of rated voltage *		
		Standard	0.35 (With light: 0.4)		
Power consumption (W)	DC	With power saving circuit	0.1 (With light only) * [Starting 0.4, Holding 0.1]		
		100 V	0.78 (With light: 0.81)		
Apparent power		110 V [115 V]	0.86 (With light: 0.89) [0.94 (With light: 0.97)]		
(VA) *	AC	200 V	1.18 (With light: 1.22)		
		220 V [230 V]	1.30 (With light: 1.34) [1.42 (With light: 1.46)]		
Surge voltage suppressor		or	Diode (Varistor when non-polar types)		
Indicator light			LED		

\* For 115 VAC and 230 VAC, the allowable voltage is -15% to +5% of rated voltage.

\* For details, refer to page 643.

## Flow Rate Characteristics/Weight

			_		F	low rate ch	aracteristic	6		Effective	1	Weight (g) Note	e)	Flov
Valve	model	Actuation	Port size	i	I→2 (P→A)		2	→3 (A→R)		area	0	L/M plug	M8	
		type	Size	C [dm <sup>3</sup> /(s bar)]	b	Cv	C [dm3/(s bar)]	b	Cv	(mm <sup>2</sup> )	Grommet	connector	connector	
Body	10-SYJ312M	N.C.	M3 x 0.5	-	-	-	-	-	-	0.9	32	33	37	hes
ported	10-SYJ322M	N.O.	WI3 X U.S	-	-	-	-	-	-	0.9	32	33	3/	vitch
Base mounted			M5 x 0.8	0.41	0.18	0.086	0.35	0.33	0.086		53 (32)	54 (00)	50 (07)	e Swi re Se
(with sub-plate)	10-SYJ324M	N.O.	O.U X CIVI	0.36	0.31	0.089	0.36	0.31	0.089	] –	53 (32)	54 (33)	58 (37)	sure
Note) Value f	or DC. Add 1	g for AC.	( ): W	ithout sub-pl	ate.									ress

**SMC** 

604


irrectional ntrol Valves

Modular F. R.

Pressure Control Equipment

Fittings & Tubing

/ Control



605

Control Valves

Air Cylinders

**Rotary Actuators** 

ι cri Modular F.


Pressure Control Equipment


Fittings & Tubing

Flow Control Equipment

Pressure Switches/ Pressure Sensors

# Construction





#### Component Parts

V111

Coil type Nil

No.	Description	Material	Note
1	Body	Zinc die-casted	White
2	Piston plate	Resin	White
3	End cover	Resin	White
4	Piston	Resin	-
5	Spool valve assembly	Aluminum, H-NBR	-

G

How to Order Pilot Valve Assembly

5

#### Replacement Parts

Benla	cement Parts	U		Grippers
No.	Description	Part no.	Note	Air
6	Sub-plate Note)	SYJ300-9-1(-Q)	Zinc die-casted	
7	Pilot valve	V111(T)-000		_
Note) Ad	dd suffix "-Q" for the CE-c	ompliant product.		Air Preparation Equipment

т	With power saving circuit (24, 12 VDC only)		
	ver saving circuit is not		
ava	ilable for W□ type.		
	Rated voltage	•	
5	24 VDC	1	
6	12 VDC		
٧	6 VDC		
s	5 VDC		
R	3 VDC		Ι.
1	100 VAC 50/60 Hz	9	
2	200 VAC 50/60 Hz	Iſ	G
3	110 VAC 50/60 Hz	11	Н
3	[115 VAC 50/60 Hz]		L
4	220 VAC 50/60 Hz	11	LI
-	1000 V/AO 50/00 LI-1	i h	

Standard

[230 VAC 50/60 Hz] \* For type W□, only DC

voltage is available

* CE-compliant:	For	DC	only.
-----------------	-----	----	-------

Light/Surge	voltage	supp	ressor

- Nil Without light/surge voltage suppressor S With surge voltage suppressor Z With light/surge voltage suppressor
- R With surge voltage suppressor (Non-polar type) U With light/surge voltage suppressor (Non-polar type)
- For AC voltage valves there is no "S" option. It is already built into the rectifier circuit.
   For "R" and "U", only DC voltage is available.
- Power saving circuit is only available for the "Z" type.

## Electrical entry

G	Grommet, 300 mm lead wire						
н	Grommet, 600 mm lead wire						
L		With lead wire					
LN	L plug	Without lead wire					
LO	connector	Without connector					
М		With lead wire					
MN	M plug	Without lead wire					
мо	connector	Without connector					
wo	M8	Without connector cable					
WD	connector	With connector cable Note 1					

W connector With connector ca \* For connector cable of M8 connector, refer to page 646.

Note 1) Enter the cable length symbols in .

Please be sure to fill in the blank referring to page 646.

Note) Since V111 is CE-compliant as standard, the suffix "-Q" is not necessary.




606

# **Body Ported**

# Grommet (G), (H): 10-SYJ3 2M- H - -M3

# With bracket: 10-SYJ3□2M-□<sup>G</sup><sub>H</sub>□□-M3-F





L plug connector (L): 10-SYJ3□2M-□L□□-M3


9.2

7

M plug connector (M): 10-SYJ3□2M-□M□□-M3 M8 connector (WO): 10-SYJ3 2M- WO -- M3








 Refer to page 646 for dimensions with connector cable.


16.4

\* [ ] for AC

607







# Series 10-SYJ300 Manifold Specifications



# Manifold Specifications

Model	For internal pilot	Type 20	Type 41, S41	Type 42, S42		
Manifold type		Single base/B mount				
P (SUP), R (EXH)		Common SUP/Common EXH				
Valve stations		2 to 20 stations				
A port	Location	Valve	Base			
Porting specifications	Direction	Тор	Side			
	P, R port	M5 x 0.8	M5 x 0.8	¥8		
Port size	A port	M3 x 0.5	M3 x 0.5	M5 x 0.8 C4 (ø4 One-touch fitting)		

# **Flow Rate Characteristics**


			Port	size	1	F 1→2 (P→A		aracteristics	; 2→3 (A→F	R)	Effective
	Manifold		1(P), 3(R) Port	2(A) Port	C [dm³/(s·bar)]	b	Cv	C [dm³/(s·bar)]	b	Cv	(mm <sup>2</sup> )
Body ported for internal pilot	Type 10-SS3YJ3-20	10-SYJ3⊡2M	M5 x 0.8	M3 × 0.5	-	-	-	-	-	-	0.9
	Type 10-SS3YJ3- 41 S41	10-SYJ3⊡4M	M5 x 0.8	M3 x 0.5	-	-	-	-	-	-	1.5
Base mounted	Type 10-SS3YJ3-42-M5	10-SYJ3⊡4M	1/8	M5 x 0.8	0.31	0.17	0.075	0.32	0.11	0.072	-
for internal pilot	Type 10-SS3YJ3-42-C4	10-51J3_4W	1/0	C4	0.33	0.36	0.086	0.33	0.2	0.082	-
	Type 10-SS3YJ3-S42-M5			M5 x 0.8	0.32	0.3	0.079	0.33	0.35	0.086	-
	Type 10-SS3YJ3-S42-C4 10-SYJ304M		1/8	C4	0.35	0.17	0.082	0.35	0.26	0.086	-

Note) The values are for individually operated 2 position type manifold bases.


# How to Order Manifold (Example)

# Combinations of Solenoid Valve, Manifold Gasket and Manifold Base

#### Body ported (Type 10-SYJ3 2M(-Q))



#### Applicable base 10-SS3YJ3-20(-Q) Manifold base




Base mounted (Type 10-SYJ3 4M(-Q))


Round head combination screw

#### Applicable base Sub-plate


10-SS3YJ3-41(-Q) 10-SS3YJ3-S41(-Q) Manifold 10-SS3YJ3-42(-Q) base 10-SS3YJ3-S42(-Q)

# **Blanking Plate Assembly**





Note) For more than 8 stations, supply/exhaust air to/from both sides of P port and R port.




# Type 41 Manifold: Side Ported/10-SS3YJ3-41-Stations -M3

Type S41 Manifold: Side Ported

## Grommet (G)

#### (Pilot valve is on the A port side) 10-SS3YJ3-S41- Stations -M3 g. 8 68 68 68 68 6 **\* \* \* \*\*** ( + + L1 L2 3.5 (Light/surge voltage suppressor) = ø Approx. 300 (Lead wire length) 5 26.6 ٩ ÷ 48.8 [51] д 11 ሐ φ 0 Φ 6 2 x ø3.5 L2 (For mounting) Manual Manual override override (Pitch) P=10.5 12.5 Approx. 300 (Lead wire length) M5 x 0.8 2 x ø3.5 (P, R port) 48.8 [51] (For mounting) 0 ₽ Q 26.6 ₽ 22 (Station n) ----- (Station 1) ≓, ¢ (Pitch) 4.5 12.5 P=10.5 41.5 [48.5] (Station 1) ----- (Station n) 60 6 9 **69 69 69** 6 26.1 ¢ ∆ € 우 우 41.5 [48.5] (Pitch) M3 x 0.5 P=10.5 13.5 (A port) А 약 19 (Pitch) 11.5 P=10.5 M3 x 0.5


L plug connector (L)




(A port)

M plug connector (M)

M8 connector (WO)






 Refer to page 646 for dimensions with connector cable.

Station	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
L1	35.5	46	56.5	67	77.5	88	98.5	109	119.5	130	140.5	151	161.5	172	182.5	193	203.5	214	224.5
L2	28.5	39	49.5	60	70.5	81	91.5	102	112.5	123	133.5	144	154.5	165	175.5	186	196.5	207	217.5

## 613



Station Station 2 3 6 8 10 19 Station 20 4 5 7 9 11 12 13 14 15 16 17 18 L1 41.5 52 62.5 73 83.5 94 104.5 115 125.5 136 146.5 157 167.5 178 188.5 199 209.5 220 230.5 12 54.5 33.5 44 65 75.5 96.5 107 117.5 128 138.5 149 159.5 201.5 212 222.5 86 170 180.5 191 614 **SMC** 

ø4. ø5/32

# Series 10-SYJ500 Rubber Seal 3 Port Pilot Solenoid Valve



Body ported



Base mounted

10-SYJ52<sup>2</sup><sub>4</sub>M 2(A)

(P)1 3(B)

Symbol Internal pilot 10-SYJ51<sup>2</sup> M

2(A)

(P)1 3(B)

Made to Order (For details, refer to page 640.)

# Specifications

Fluid		Air					
Operating pressure range (MPa)	Internal pilot	0.15 to 0.7					
Ambient and fluid ter	nperature (°C)	-10 to 50 (No freezing.)					
Response time ms (a	t 0.5 MPa) Note 1)	25 or less					
Max. operating freque	ency (Hz)	5					
Manual override (Mar	nual operation)	Non-locking push type, push-turn locking slotted type, push-turn locking lever type					
Pilot exhaust method	1	Main/Pilot valve common exhaust					
Lubrication		Not required					
Mounting orientation		Unrestricted					
Impact/Vibration resis	stance (m/s2) Note 2)	150/30					
Enclosure		Dust proof (* DIN terminal, M8 connector conforms to IP65.					
* Based on IEC60529							

Note 1) Based on dynamic performance test, JIS B 8374-1981. (Coil temperature: 20°C, at rated voltage, without surge voltage suppressor.)

No malfunction occurred when it was tested in the axial direction and at right Note 2) Impact resistance: angles to the main valve and armature in both energized and de-energized states once for each condition. (Default settings)

Vibration resistance: No malfunction occurred in a one-sweep test between 45 and 2000 Hz. Test was performed in both energized and de-energized states in the axial direction and at right angles to the main valve and armature. (Default settings)

# Solenoid Specifications

Electrical entry				. plug connector (L), DIN terminal (D), (Y), ector (W)				
			G, H, L, M, W	D, Y				
Coil rated	D	С	24, 12, 6, 5, 3	24, 12				
voltage (V)	Α	C 50/60 Hz	100, 110,	200, 220				
Allowable voltage	fluctu	ation	±10% of rate	ed voltage *				
Devee		Standard	0.35 (With light: 0.4 (DIN	terminal with light: 0.45))				
Power consumption (W)	DC	With power saving circuit	0.1 (With li [Starting 0.4,	ght only) * Holding 0.1]				
		100 V	0.78 (With light: 0.81)	0.78 (With light: 0.87)				
Apparent power		110 V [115 V]	0.86 (With light: 0.89) [0.94 (With light: 0.97)]	0.86 (With light: 0.97) [0.94 (With light: 1.07)]				
(VA) *	AC	200 V	1.18 (With light: 1.22)	1.15 (With light: 1.30)				
		220 V [230 V]	1.30 (With light: 1.34) [1.42 (With light: 1.46)]	1.27 (With light: 1.46) [1.39 (With light: 1.60)]				
Surge voltage sup	press	or	Diode (DIN terminal, varistor when non-polar types)					
Indicator light			LED (Neon light when AC with DIN terminal)					

\* Common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC.

\* For 115 VAC and 230 VAC, the allowable voltage is -15% to +5% of rated voltage.

\* For details, refer to page 643.

# Flow Rate Characteristics/Weight

		A	Devit			Flow rate ch	aracteristics			Weight (g) Note)			
Valve n	nodel	Actuation	Port size		1→2 (P→A)	→2 (P→A)		2→3 (A→R)			L/M plug	DIN	M8
		type	SIZE	C [dm3/(s·bar)]	b	Cv	C [dm3/(s·bar)]	b	Cv	Grommet	connector	terminal	connector
Body	10-SYJ512M	N.C.	M5 x 0.8	0.53	0.45	0.14	0.47	0.39	0.12	46	47	68	51
ported	10-SYJ522M	N.O.	0.0 X CIVI	0.66	0.45	0.18	0.66	0.45	0.18	40	47	00	51
			1/8	1.2	0.41	0.32	1.1	0.46	0.32	00 (40)	04 (47)	00 (00)	05 (54)
(with sub-plate)	10-SYJ524M	N.O.	1/0	1.3	0.37	0.33	1.2	0.48	0.34	60 (46)	61 (47)	82 (68)	65 (51)

Note) Value for DC. Add 3 g for AC. ( ): Without sub-plate.


615

**SMC** 


#### 3 Port Pilot Solenoid Valve 10-SYJ500

Note) AC-type models that are CE-compliant have DIN terminals only. [Option]

How to Order




# Construction



#### **Component Parts**

No.	Description	Material	Note
1	Body	Aluminum die-cast	White
2	Piston plate	Resin	White
3	End cover	Aluminum die-cast	White
4	Piston	Resin	-
5	Spool valve assembly	-	-
6	Spool spring	Stainless steel	_





NO

 $\leq \nabla$ 

**Replacement Parts** 

Sub-plate No

Pilot valve

Description

Bracket assembly

Note) Add suffix "-Q" for the CE-compliant product.

No

7

8

2(A)

(P)1 3(R)

361

(A)

2

(P)

3

(B)

Part no.

SYJ500-9-1(-Q)

V111(T)-000

SYJ5000-13-3A

24

ſ

Note

Aluminum die-cast


(8

Note) Since V111 and V115 are CE-compliant as standard, the suffix "-Q" is not necessary.

**SMC** 

# **Body Ported**






618

# **Base Mounted (With Sub-plate)**

\* [ ] for AC




L plug connector (L): 10-SYJ5\_4M-\_L\_\_01\_ 10-SYJ5\_4M-\_M\_\_01\_

619

M plug connector (M):

DIN terminal (D, Y): 10-SYJ5\_4M-\_\_\_\_\_\_\_\_\_\_\_\_\_\_ M8 connector (WO): 10-SYJ504M-0W000-010



# Series 10-SYJ500 **Manifold Specifications**

## Manifold Specifications

a company
-----------

Model	For internal pilot	Type 20	Type 40	Type 41
Manifold type			Single bas	e/B mount
P (SUP), R (EXH	)		Common SUP,	common EXH
Valve stations			2 to 20	stations
A port Porting	Location	Valve		Base
specifications	Direction	Тор	Bottom	Side
	P, R port	1/8	1/8	1/8
Port size	A port	M5 x 0.8	M5 x 0.8 1/8	M5 x 0.8, <sup>1</sup> /8, C4 (ø4 One-touch fitting), C6 (ø6 One-touch fitting)

# Flow Rate Characteristics

			Port	size			Flow rate ch	naracteristics			Air Grippers
	anifold		FOIL	SIZE		1→2 (P→A)		2→3 (A→R)			•
IVI	annoid		1(P), 3(R) port	2(A) port	C [dm³/(s·bar)]	b	Cv	C [dm <sup>3</sup> /(s·bar)]	b	Cv	
Body ported for internal pilot	Type 10-SS3YJ5-20	10-SYJ502M	1/8	M5 x 0.8	0.47	0.43	0.13	0.74	0.32	0.19	ir Preparation Equipment
	Type 10-SS3YJ5-40-M5		1/8	M5 x 0.8	0.71	0.52	0.21	0.81	0.28	0.20	ara
	Type 10-SS3YJ5-40-01	]	1/8	1/8	0.98	0.36	0.25	0.92	0.24	0.22	epi
Base mounted	Type 10-SS3YJ5-41-M5		1/8	M5 x 0.8	0.71	0.49	0.20	0.80	0.23	0.19	P L
for internal pilot	Type 10-SS3YJ5-41-01	10-SYJ5⊡4M	1/8	1/8	1.0	0.37	0.26	0.96	0.25	0.24	Air
	Type 10-SS3YJ5-41-C4	]	1/8	C4	0.68	0.35	0.17	1.0	0.25	0.24	
	Type 10-SS3YJ5-41-C6		1/8	C6	1.0	0.27	0.25	1.0	0.30	0.26	
lote) The values are for	r individually operat	ed 2 position	type manifold	l bases.							Modular F. R.

# How to Order Manifold (Example)

Instruct by specifying the valves and blanking plate assembly to be mounted on the manifold along with the manifold base model no.

(Example)		L
10-SS3YJ5-20-03 ······· 1 set (manifold base)	10-SS3YJ5-41-03-C6 ····· 1 set (manifold base)	l
* 10-SYJ512M-5LZ-M5 ······ 2 sets (valve)	* 10-SYJ514M-5G 2 sets (valve)	
Т	* SYJ500-10-3A ······ 1 set (blanking plate assembly)	
└→ The asterisk denotes the symbol for assembly. Prefix	it to the part no. of the solenoid valve, etc.	l

Pressure Control Equipment

[Option]

Directional Control Valves


Air Cylinders

**Rotary Actuators** 


## Combinations of Solenoid Valve, Manifold Gasket and Manifold Base

#### Body ported (Type 10-SYJ5 2M(-Q))

#### Base mounted (Type 10-SYJ5□4M(-Q))




Applicable base Type 10-SS3YJ5-20(-Q) Manifold base




# Sub-plate Type 10-SS3YJ5-40(-Q) Manifold Type 10-SS3YJ5-41(-Q) base

### **Blanking Plate Assembly**



#### Part no.: SYJ500-10-1A(-Q)




\land Caution

Mounting screw tightening torque

#### M2.5: 0.45 N·m

Use caution to the assembly orientation for solenoid valves (blanking plate) and manifold gasket.

Note) Add suffix "-Q" for the CE-compliant product.




Note) For more than 9 stations, supply air to both sides of P port and exhaust air from both sides of R port.

3 Port Pilot Solenoid Valve 10-SYJ500

Pressure Control Equipment Fittings & Tubing Flow Control Equipment Pressure Switches/ Pressure Sensors

# Type 20 Manifold: Top Ported/10-SS3YJ5-20-Stations-00 (-F)

\* [ ] for AC




L plug connector (L)

M plug connector (M)

DIN terminal (D, Y)


M8 connector (WO)



 Refer to page 646 for dimensions with connector cable.

Station	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
L1	53	69	85	101	117	133	149	165	181	197	213	229	245	261	277	293	309	325	341
L2	40	56	72	88	104	120	136	152	168	184	200	216	232	248	264	280	296	312	328
L3	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240	256	272	288	304
L4	8	24	40	56	72	88	104	120	136	152	168	184	200	216	232	248	264	280	296


623



624

# Type 41 Manifold: Side Ported/10-SS3YJ5-41-Stations -C4, N3 C6, N7 C4

# Grommet (G)





L plug connector (L)


M plug connector (M)


DIN terminal (D, Y)

M8 connector (WO)










*	Refer to page 646 for
	dimensions with connector
	cable

Port size	Station	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
One-touch	L1	50	66	82	98	114	130	146	162	178	194	210	226	242	258	274	290	306	322	338
fitting	L2	41	57	73	89	105	121	137	153	169	185	201	217	233	249	265	281	297	313	329

Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

625



# Series 10-SYJ700 Rubber Seal 3 Port Pilot Solenoid Valve



Body ported




Base mounted

#### Symbol

Internal pilot

10-SYJ714M



Made to Order (For details, refer to page 640.)

## Specifications

Fluid		Air				
Operating pressure range (MPa)	Internal pilot	0.15 to 0.7				
Ambient and fluid ter	nperature (°C)	-10 to 50 (No freezing.)				
Response time ms (a	t 0.5 MPa) Note 1)	30 or less				
Max. operating freque	ency (Hz)	5				
Manual override (Manual operation)		Non-locking push type, push-turn locking slotted type, push-turn locking lever type				
Pilot exhaust method		Main/Pilot valve common exhaust				
Lubrication		Not required				
Mounting orientation		Unrestricted				
Impact/Vibration resis	stance (m/s²) Note 2)	150/30				
Enclosure		Dust proof (* DIN terminal, M8 connector: IP65)				
without surge voltage	ge suppressor.)	3 8374-1981. (Coil temperature: 20°C, at rated voltage,				

Note 2) Impact resistance: No malfunction occurred when it was tested in the axial direction and at right angles to the main valve and armature in both energized and de-energized

states once for each condition.

(Default settings)

Vibration resistance: No malfunction occurred in a one-sweep test between 45 and 2000 Hz. Test was performed in both energized and de-energized states in the axial direction and at right angles to the main valve and armature. (Default settings)

# Solenoid Specifications

Electrical entry			Grommet (G), (H), L plug connector (L), M plug connector (M), DIN terminal (D), (Y), M8 connector (W)				
			G, H, L, M, W	D, Y			
Coil rated	D	С	24, 12, 6, 5, 3 24, 12				
voltage (V)	Α	C 50/60 Hz	100, 110, 200, 220				
Allowable voltage	fluctu	ation	±10% of rate	ed voltage *			
Denner	DC	Standard	0.35 (With light: 0.4 (DIN terminal with light: 0.45))				
Power consumption (W)		With power saving circuit	0.1 (With light only) * [Starting 0.4, Holding 0.1]				
		100 V	0.78 (With light: 0.81)	0.78 (With light: 0.87)			
Apparent power		110 V [115 V]	0.86 (With light: 0.89) [0.94 (With light: 0.97)]	0.86 (With light: 0.97) [0.94 (With light: 1.07)]			
(VA) *	AC	200 V	1.18 (With light: 1.22)	1.15 (With light: 1.30)			
		220 V [230 V]	1.30 (With light: 1.34) [1.42 (With light: 1.46)]	1.27 (With light: 1.46) [1.39 (With light: 1.60)]			
Surge voltage suppressor			Diode (DIN terminal, varistor when non-polar types)				
Indicator light			LED (Neon light when AC with DIN terminal)				

common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC.

\* For 115 VAC and 230 VAC, the allowable voltage is -15% to +5% of rated voltage.

\* For details, refer to page 643.

# Flow Rate Characteristics/Weight

		<b>-</b> (		Flow rate characteristics							Weight (g) Note)			
Valve model		Type of actuation	Port size	1→2 (P→A)			2→3 (A→R)			Grommet	L/M plug	DIN	M8	
		actuation	SIZE	C [dm <sup>3</sup> /(s·bar)]	b	Cv	C [dm <sup>3</sup> /(s·bar)]	b	Cv	Gronninet	connector	terminal	connector	
Body	10-SYJ712M	N.C.	1/8	2.8	0.43	0.77	2.5	0.51	0.76	75	76	97	80	
ported	10-SYJ722M	N.O.		2.7	0.38	0.72	2.4	0.42	0.69				00	
	10-SYJ714M	N.C.	1/8	2.9	0.32	0.71	2.7	0.34	0.69				140 (80)	
Base mounted	10-SYJ724M	N.O.	1/0	2.8	0.21	0.70	2.3	0.45	0.63	135 (75)	136 (76)	157 (07)		
(with sub-plate)	10-SYJ714M	N.C.	1/4	3.0	0.31	0.74	2.6	0.33	0.66	135 (75)	130 (76)	157 (97)		
	10-SYJ724M		1/4	2.7	0.31	0.68	2.3	0.48	0.64					

Note) Value for DC. Add 3 g for AC. (): Without sub-plate.


627




#### 3 Port Pilot Solenoid Valve 10-SYJ700


Note) AC-type models that are CE-compliant have DIN terminals only. [Option]

How to Order



# Construction





#### **Replacement Parts**

No.	Description	Part no.	Note		
7	Curls and atta Note)	SYJ700-9-1(-Q)	1/8	Aluminum	
'	Sub-plate Note)	SYJ700-9-2(-Q)	1/4	die-casted	
8	Pilot valve	V111(T)-000			
-	Bracket assembly	SYJ700-19-1A			

Note) Add suffix "-Q" for the CE-compliant product.


5

D

#### Component Parts

	No.	Description	Material	Note
_	1	Body	Aluminum die-casted	White
	2	Piston plate	Resin	White
	3	End cover	Aluminum die-casted	White
	4	Piston	Resin	-
	5	Spool valve assembly	-	-
	6	Spool spring	Stainless steel	-

# How to Order Pilot Valve Assembly



Note) Since V111 and V115 are CE-compliant as standard, the suffix "-Q" is not necessary.

# Sated voltage 5 24 VDC 6 12 VDC 1 100 VAC 50/60 Hz 2 200 VAC 50/60 Hz 3 110 VAC 50/60 Hz 110 VAC 50/60 Hz 220 VAC 50/60 Hz 120 VAC 50/60 Hz 120 VAC 50/60 Hz

V115 -

\* DC specifications of type D and DO are only available with 12 and 24 VDC.

 Power saving circuit is not available for D, Y, DO and YO types.

# Light/Surge voltage suppressor Without light/surge voltage suppressor

Nil	Without light/surge voltage suppress
	14.001

s	vvith surge voltage suppressor
	(Non-polar type)

- (Non-polar type)
   With light/surge voltage suppressor
- Z (Non-polar type)
- \* DOZ and YOZ are not available.
- For AC voltage valves there is no "S" option. It is already built into the rectifier circuit.

#### Electrical entry


	DIN terminal	With connector			
DO	(Type D)	Without connector			
Υ	DIN terminal	With connector			
YO	(Type Y)	Without connecto			

 Do not replace V111 (G, H, L, M, W) with V115 (DIN terminal) and vice versa when replacing pilot valve assembly only.



# **Body Ported**


\* [ ] for AC




# **Base Mounted (With Sub-plate)**

\* [ ] for AC

# Grommet (G), (H): 10-SYJ7 4M-



L plug connector (L): 10-SYJ7 4M-DL - ... M plug connector (M): 10-SYJ7\_4M-\_M\_\_-<sup>01</sup>\_ DIN terminal (D, Y): 10-SYJ7□4M-□<sup>D</sup><sub>Y</sub>□□-<sup>01</sup><sub>02</sub>□ 

 Refer to page 646 for dimensions with connector cable.

# Series 10-SYJ700 **Manifold Specifications**



## **Manifold Specifications**

Model	For internal pilot	Type 20	Type 21	Type 40	Type 41	Type 42				
Manifold typ		1990 20	Type 21	Single base/E		1990 42				
P (SUP), R (I	EXH)		Common SUP, common EXH							
Valve statio	ns	2 to 20 stations								
A port Porting	Location	Valve	Valve	Base	Base	Base				
specifications	Direction	Тор	Тор	Bottom	Bottom	Side				
	P, R port	1/8	1/4	1/8	1/4	1/4				
Port size	A port	1 <sub>/8</sub>	¥8	1/8	1/8	1/8 C6 (#6 One-touch fitting C8 (#8 One-touch fitting				

# **Flow Rate Characteristics**

				Port size		Flow rate characteristics						
Manifold			Fort size			1→2 (P→A)		2→3 (A→R)			6	
r				2(A) port	C [dm <sup>3</sup> /(s·bar)]	b	Cv	C [dm³/(s·bar)]	b	Cv	Preparation	
Body ported	Type 10-SS3YJ7-20	10 CV 17 014	1/8	1/8	2.2	0.34	0.55	2.3	0.27	0.59	ade	
for internal pilot	Type 10-SS3YJ7-21	10-51J/	1/4	1/8	2.2	0.39	0.59	2.4	0.32	0.62	Pro	
	Type 10-SS3YJ7-40		1/8	1/8	2.1	0.35	0.59	2.3	0.27	0.54	Air Pr	
Base mounted	Type 10-SS3YJ7-41		1/4	1/8	2.2	0.35	0.59	2.4	0.36	0.66		
for internal pilot	Type 10-SS3YJ7-42-01		1/4	1/8	2.0	0.27	0.47	2.2	0.32	0.56		
for internal pilot	Type 10-SS3YJ7-42-C6		1/4	C6	1.6	0.32	0.39	2.2	0.27	0.54	L L L	
	Type 10-SS3YJ7-42-C8	] [	1/4	C8	2.1	0.24	0.51	2.3	0.31	0.59	1 L	
ote) The values are fo	or individually operat	ed 2 position	type manifold	bases.							Modular	

## How to Order Manifold (Example)

Instruct by specifying the valves and blanking plate assembly to be mounted on the manifold along with the manifold base model no.

(Example)

(Example)		L
10-SS3YJ7-20-03 ······· 1 set (manifold base)	10-SS3YJ7-42-03-01 ······ 1 set (manifold base)	l
* 10-SYJ712M-5LZ-01 ······ 2 sets (valve)	* 10-SYJ714M-5G 2 sets (valve)	l
* SYJ700-10-1A 1 set (blanking plate assembly)	* SYJ700-10-2A ······ 1 set (blanking plate	I
T	assembly)	I
➡ The asterisk denotes the symbol for assembly. Prefix	it to the part no. of the solenoid valve, etc.	l

Pressure Control Equipment


Air Grippers

Pressure Switches/ Pressure Sensors

[Option]

## Combinations of Solenoid Valve, Manifold Gasket and Manifold Base

Body ported (Type 10-SYJ7 2M(-Q)) Base mounted (Type 10-SYJ7 4M(-Q))




Applicable base Type 10-SS3YJ7-20(-Q) Manifold Type 10-SS3YJ7-21(-Q) base Sub-plate Type 10-SS3YJ7-40(-Q) Type 10-SS3YJ7-41(-Q) Type 10-SS3YJ7-42(-Q) base

\land Caution

Mounting screw tightening torque

M3: 0.8 N·m

Use caution to the assembly orientation for solenoid valves, gasket and optional parts.




**Blanking Plate Assembly** 

<Standard>


Note) It can be mounted on a body ported manifold base. However, when mounting a blanking part to a valve, place an order for a separate gasket (SYJ700-5-3) when placing an order for the valve.

When using the SYJ700-10-1A, a gasket for this blanking plate assembly can be used as a gasket for the valve as well.


#### <CE-compliant>



## Part no.: SYJ700-10-2A-2-Q



**SMC** 




Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com


634

# Type 20 Manifold: Top Ported/10-SS3YJ7-20-Stations (-00 □)

## Grommet (G)



(Station n) ----- (Station 1)




L plug connector (L)


M plug connector (M)


DIN terminal (D, Y)

## M8 connector (WO)



Station	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
L1	59	78	97	116	135	154	173	192	211	230	249	268	287	306	325	344	363	382	401
L2	49	68	87	106	125	144	163	182	201	220	239	258	277	296	315	334	353	372	391






**SMC** 

# Type 40 Manifold: Bottom Ported/10-SS3YJ7-40-Stations-01

## Grommet (G)




L plug connector (L)


M plug connector (M)


DIN terminal (D, Y)


## M8 connector (WO)



637








 Refer to page 646 for dimensions with connector cable.

Station	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
L1	59	78	97	116	135	154	173	192	211	230	249	268	287	306	325	344	363	382	401
L2	49	68	87	106	125	144	163	182	201	220	239	258	277	296	315	334	353	372	391



Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

**SMC** 

Max. 10

78.1 [85.1]

Approx. 300 (Lead wire length)

51.6

67 [74]

Station 2 

(Lead wire length)

Station

L1

L2

Approx. 300

Station 20

Fittings & Tubing

Flow Control Equipment

Pressure Switches/ Pressure Sensors

71.5

\* Refer to page 646 for

cable

 dimensions with connector

M8

81.7


100.5

Applicable cable O.D.


ø3.5 to ø7

# Type 41 Manifold: Bottom Ported/10-SS3YJ7-41-Stations-01

## Grommet (G)



\* Other dimensions are the same as type 42. For dimensions, refer to page 638.





Be sure to read this before handling. Refer to page 1382 for Safety Instructions and pages 677 to 683 for 3/4/5 Port Solenoid Valve Precautions.

#### Manual Override Operation

# \land Warning

When the manual override is operated, connected equipment will be actuated. Confirm safety before operating.

#### Non-locking push type [Standard]

Press in the direction of the arrow.



#### Push-turn slotted locking type [Type D]

While pressing the lock down, turn it in the direction of the arrow. If it does not turn, it can be operated the same way as the non-locking type.





# ▲ Caution

When operating the locking type D with a screw driver, turn it gently using a watchmakers screw driver. [Torque: Less than 0.1 N·m]

#### Push-turn locking lever type [Type E]

While pressing the lever down, turn it in the direction of the arrow. If it does not turn, it can be operated the same way as the non-locking type.





# **∆** Caution

When locking the manual override on the push-turn locking types (D, E), be sure to push the lock down before turning it. Turning without first pushing it down can cause damage to the manual override and trouble such as air leakage, etc.

#### Solenoid Valve for 200, 220 VAC Specifications

# A Warning

Solenoid valves with grommet and L/M type plug connector AC specifications have a built-in rectifier circuit in the pilot section to operate the DC coil.

With 200, 220 VAC specification pilot valves, this built-in rectifier generates heat when energized. The surface may become hot depending on the energization state; therefore, do not touch the solenoid valves.

#### Main/Pilot Valve Common Exhaust Type

# \land Caution

Pilot air is exhausted through the main valve body rather than directly to atmosphere.

- Suitable for applications where exhausting the pilot valve to atmosphere would be detrimental to the surrounding working environment.
- For use in extremely dirty environments where there is the possibility that dust could enter the pilot exhaust and damage the valve.

Ensure that the piping of exhaust air is not too restrictive.

#### Bracket

# \land Caution

For bracket attached type of the 10-SYJ300 series, do not use it without bracket.



area

Socket

wires

# Series 10-SYJ300/500/700 **Specific Product Precautions 2**


Be sure to read this before handling.

Refer to page 1382 for Safety Instructions and pages 677 to 683 for 3/4/5 Port Solenoid Valve Precautions.

Directional Control Valves How to Use Plug Connector Plug Connector Lead Wire Length A Caution Caution Standard length is 300 mm, but the following lengths are also 1. Attaching and detaching connectors available. Cylinders · To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve so that the lever's pawl is pushed into the How to Order Connector Assembly groove and locks. Air · To detach a connector, remove the pawl from the groove by For DC: SY100 - 30 - 4A pushing the lever downward with your thumb, and pull the connector straight out. Actuators For 100 VAC: SY100 - 30 - 1A Cove Groove For 200 VAC: SY100 - 30 - 2A Cover Rotary Groove l eve For other voltages of AC: SY100 - 30 - 3A Pin DC polar indication Socket Without lead wire: SY100 - 30 - A Lead wire length Grippers (with connector and 2 of sockets only) Nil 300 mm l ead wire Connector 6 600 mm How to Order Hook 10 1000 mm Air 15 1500 mm Include the connector assembly part number together with the part number 20 2000 mm 2. Crimping connection of lead wire and socket for the plug connector's solenoid valve 25 2500 mm Air Preparation Equipment Strip 3.2 to 3.7 mm at the end of the lead wires, insert the end without connector. 30 3000 mm 50 5000 mm of the core wires evenly into the sockets, and then crimp it Example) Lead wire length 2000 mm with a crimping tool. When this is done, take care that the For DC For AC coverings of the lead wires do not enter the core wire crimping 10-SYJ312-5LO-M3 10-SYJ312-1LO-M3 SY100-30-4A-20 SY100-30-1A-20 Use an exclusive crimping tool for crimping. (Please contact SMC for the dedicated crimping tools.) Ω. Core wire цĹ Covering retainer crimping area Modular 0.2 to 0.33 mm<sup>2</sup> Lead wire Max. O.D. of covering: Ø1.7 m -6 Covering Pressure Control Equipment 3. Attaching and detaching sockets with lead Attaching Insert the sockets into the square holes of the connector (+, indication), and continue to push the sockets all the way in & Tubing until they lock by hooking into the seats in the connector. (When they are pushed in, the hooks open and they are locked automatically.) Then confirm that they are locked by Fittings pulling lightly on the lead wires. Detaching To detach a socket from a connector, pull out the lead wire while pressing the socket's hook with a thin tipped stick (approx, 1 mm). If the socket is to be used again, first spread Control Flow Control Equipment the hook outward Connector Socket ead wire Pressure Switches/ Pressure Sensors Hook Pressure



Be sure to read this before handling. Refer to page 1382 for Safety Instructions and pages 677 to 683 for 3/4/5 Port Solenoid Valve Precautions.



**SMC** 



Be sure to read this before handling.

Refer to page 1382 for Safety Instructions and pages 677 to 683 for 3/4/5 Port Solenoid Valve Precautions.

Surge Voltage Suppressor


#### <For AC>

(There is no "S" option, because the generation of surge voltage is prevented by a rectifier.)

# A Caution


#### Grommet, L/M Plug Connector

#### With light (DZ)



#### **DIN Terminal**

With light (DZ)



Note) The surge voltage suppressor of the varistor has residual voltage corresponding to the protective element and rated voltage. Therefore, protect the controller side from the surge voltage. The residual voltage of the diode is approximately 1 V.

### **DIN Terminal Type Y**

DIN connector type Y is a DIN connector that conforms to the DIN pitch 8-mm standard.

# **▲** Caution

- Since a type D DIN connector has a 9.4-mm pitch between DIN terminals, it is not interchangeable.
- Type D DIN connectors have the "N" indication at the end of rated voltage symbol. (For DIN connectors without lights, "N" is not indicated. Please refer to the name plate to distinguish models.)
- · Dimensions are the same as type D DIN connector.
- When replacing only the pilot valve assembly, V115-□D is interchangeable with V115-□Y. Do not replace V111 (G, H, L, M, W) with V115-□Y (DIN terminal), and vice versa.

### How to Use DIN Terminal

# **A** Caution

#### Connection

- 1. Loosen the holding screw and pull the connector out of the solenoid valve terminal block.
- After removing the holding screw, insert a flat head screwdriver, or similar object into the notch on the bottom of the terminal block and pry it open, separating the terminal block and the housing.
- Loosen the terminal screws (slotted screws) on the terminal block, insert the cores of the lead wires into the terminals according to the connection method, and fasten them securely with the terminal screws.

How to Use DIN Terminal

# A Caution

4.Secure the cord by fastening the ground nut.

#### A Caution

When making connections, take note that using other than the supported size (03.5 to 07) heavy duty cord will not satisfy IP65 (enclosure) standards. Also, be sure to tighten the ground nut and holding screw within their specified torque ranges.

#### Changing the entry direction

After separating the terminal block and housing, the cord entry can be changed by attaching the housing in the desired direction (4 directions at 90° intervals).

\* If equipped with a light, be careful not to damage the light with the cord's lead wires.


#### Precautions

Plug in and pull out the connector vertically without tilting to one side.

#### Compatible cables

Cord O.D.: ø3.5 to ø7

(Reference) 0.5 mm<sup>2</sup>, 2-core or 3-core, equivalent to JIS C 3306



#### Solenoid Valve Mounting

A Caution

Mount so that there is no slippage or deformation in gaskets, and tighten with the tightening torque as shown below.

Model	Thread size	Tightening torque				
10-SYJ300	M1.7	0.12 N·m				
10-SYJ500	M2.5	0.45 N⋅m				
10-SYJ700	M3	0.8 N·m				

Preparation

Air

Equipment

Fittings & Tubing

644

**SMC** 



Be sure to read this before handling.

Refer to page 1382 for Safety Instructions and pages 677 to 683 for 3/4/5 Port Solenoid Valve Precautions.

## DIN Connector Part No.

# A Caution


#### <Type D>

Without light	SY100-61-1								
With light									
Rated voltage	Voltage symbol	Part no.							
24 VDC	24 V	SY100-61-3-05							
12 VDC	12 V	SY100-61-3-06							
100 VAC	100 V	SY100-61-2-01							
200 VAC	200 V	SY100-61-2-02							
110 VAC	110 V	SY100-61-2-03							
220 VAC	220 V	SY100-61-2-04							

#### <Type Y>

Without light	SY100-82-1								
With light									
Rated voltage	Voltage symbol	Part no.							
24 VDC	24 VN	SY100-82-3-05							
12 VDC	12 VN	SY100-82-3-06							
100 VAC	100 VN	SY100-82-2-01							
200 VAC	200 VN	SY100-82-2-02							
110 VAC (115 VAC)	110 VN	SY100-82-2-03							
220 VAC (230 VAC)	220 VN	SY100-82-2-04							

#### **Circuit Diagram with Light**




#### Connector Assembly with Cover

# ▲Caution

#### Connector assembly with dust proof protective cover.


- Effective to prevention of short circuit failure due to the entry of foreign matter into the connector.
- Chloroprene rubber for electrical use, which provides outstanding weather resistance and electrical insulation, is used for the cover material. However, do not allow contact with cutting oil, etc.
- Simple and unencumbered appearance by adopting round-shaped cord.

#### How to Order





#### **Connector Assembly with Cover: Dimensions**



#### How to Order

Enter the part number for a plug connector solenoid valve without connector together with the part number for a connector assembly with cover.

Example 1) Lead wire length of 2000 mm 10-SYJ312-5LOZ-M3

SY100-68-A-20

Example 2) Lead wire length of 300 mm (standard) 10-SYJ312-5LPZ-M3

Symbol for connector assembly with cover

\* In this case, the part number for the connector assembly with cover is not required.

⊘SMC



Be sure to read this before handling. Refer to page 1382 for Safety Instructions and pages 677 to 683 for 3/4/5 Port Solenoid Valve Precautions.

#### M8 Connector

# **∆**Caution

 M8 connectors have an IP65 (enclosure) rating, offering protection from dust and water. However please note that these products are not intended for use in water.

Select a SMC connector cable (V100-49-1-□) or a FA sensor type connector, with M8 threaded 3 pin specifications conforming to Nippon Electric Control Equipment Industries Association Standard, NECA4202 (IEC60947-5-2). Make sure the connector 0.D. is 10.5 mm or less when used with the 10-SYJ300 series manifold. If more than 10.5 mm, it cannot be mounted due to the size.

- 2. Do not use a tool to mount the connector, as this may cause damage. Only tighten by hand. (0.4 to 0.6 N·m)
- Excessive stress on the cable connector will cause a loss of the IP65 rating. Please use caution and do not apply a stress of 30 N or greater.

## **▲** Caution

Failure to meet IP65 performance may result if using alternative connectors than those shown above, or when insufficiently tightened.

· Connector cable mounting



Note) Connector cable should be mounted in the correct direction. Make sure that the arrow symbol on the connector is facing the triangle symbol on the valve when using a SMC connector cable (V100-49-1-]). Be careful not to squeeze it in the wrong direction, as problems such as pin damage may occur.


#### Connector cable

· Connector cable for M8 can be ordered as follows:

#### How to Order

1. To order a solenoid valve and connector cable at the same time.

(Connector cable will be included in the shipment of the solenoid valve.)



Directional Control Valves

Cylinders

Air



Be sure to read this before handling. Refer to page 1382 for Safety Instructions and pages 677 to 683 for 3/4/5 Port Solenoid Valve Precautions.

**Replacement of Pilot Valve** 

# ▲Caution

Pilot valves in this series are improved to provide excellent energy saving results. However following this improvement, these new valves are no longer compatible with the existing pilot valve used at the interface. Consult with SMC if you need to exchange these pilot valves, for manual override (marked in orange) of the adapter plate.

