# Vacuum Pad/Bellows Type

2.5-stage Ø20, Ø32, Ø50 5.5-stage Ø20, Ø25, Ø32, Ø40, Ø50

# For the adsorption transfer of workpieces with flexible soft film packaging

# Thin film skirt and special shaped ribs


#### Thin film skirt

Special ribs

Adapts to changes in soft packaging shape

Vacuum leakage reduced by improved sealing effect Prevent the skirt from becoming caught

# New Added: 2.5-stage bellows type



The pad and attachment are made of materials compliant with FDA (U.S. Food and Drug Administration) regulations as well as Food Sanitation Act standards.

### Blue colored pad

Easy to distinguish the vacuum pad by color during contamination inspection




2.5-Stage Bellows Type






# Unstable workpieces such as bagged liquid or powder can be transferred.



**Bellows Type** 




#### Prevents the suction of foreign matter



Stainless steel mesh at suction port\*1


- Prevents the intrusion of foreign matter into piping
- Easy to check for clogging and easy to clean
- Reduced suction filter element replacement frequency
- \*1 The mesh will not fall off because it is integrally molded into the attachment.

# Reduced deflection during transfer before adsorption




SMC

#### **Expanded hole size**




- Expanded hole size to ensure suction flow rate
- Compatible with vacuum blower pumps
- G3/8 and G1/2 standardized for the direct mounting/male thread type Min. opening hole size of the adapter: ø11.5 (Pad diameter: ø32 or ø50)





#### Vacuum Pad/Bellows Type ZP3P-JT Series



#### **Variations**

New Bellows Type 2.5-Stage		Conno	ction thread	Vacuum inlet	Pad diameter		
		Conne	clion lineau	vacuummet	ø20	ø32	ø50
Pad unit 🧾 📒			—	—	•	•	•
			G1/8	*1	•	•	•
Direct mounting		Male	G1/4	*1	•	•	•
(Male thread)		thread	G3/8	*1	•	•	•
		G1/2	*1		•	•	
Direct mounting	F	Female	G1/8	*1	•	_	
(Female thread)	<u>e</u>	thread	G1/4	*1		•	•
Plate mounting	J.	Male	M16 x 1	Rc, NPT1/8	•		
(Male/Female thread)		thread	M20 x 1	Rc, NPT1/4		•	•
Plate mounting		Male	M16 x 1	ø8	•		
(Male thread/ One-touch fitting)		thread	M20 x 1	ø10		•	•
and the second se				*:	1 Same as	the connec	tion thread

Bellows Type 5.5-Stage		Conne	ation throad	Voouum inlot	Pad diameter				
		Conne	ection thread	Vacuum inlet	ø20	ø25	ø32	ø40	ø50
Pad unit			_	—	•	•	•	•	•
Direct mounting		Male	G1/8	*1	┫	•	0	0	-0
(Male thread)		thread		*1			•	•	
Direct mounting	Canse	Female	G1/8	*1		•			
(Female thread)		thread	G1/4	*1			•	•	
Plate mounting	LE.	Male		Rc, NPT1/8		•			
(Male/Female thread)		thread	M20 x 1	Rc, NPT1/4			•	•	
Plate mounting		Male	M16 x 1	ø8	]_∳	•			+
Male thread/ New State thread		thread	M20 x 1	ø10			•	•	
					*1 Sam	e as the co	nnection th	read ON	ewlv added

Same as the connection thread **O** Newly added



# CONTENTS

# Vacuum Pad/Bellows Type ZP3P-JT Series



#### 2.5-Stage/Bellows Type

How to Order	······p. 5
Specifications	······p. 5
Dimensions/Models	······p. 6
Construction	p. 8


Mounting Bracket Assembly

Specific Product Precautions

#### 5.5-Stage/Bellows Type

How to Order	p. 9
Specifications	p. 9
Dimensions/Models p	). 10
Construction	). 12
٩	). 13
<b>q</b>	). 14

2.5-Stage/Bellows Type



#### With adapter

3 Connection thread/4 Vacuum inlet									
	Conne	ction threa	d		Vacuum	inlet	Pad diameter [mm]		
Туре	Thread	Symbol	Size	Thread	Symbol	Size	ø20	ø32, ø50	
		AG01	G1/8				•	•	
	Male	AG02	G1/4		NI:1	*1		•	
Direct	thread	AG03	G3/8	-	Nil				
mounting		AG04	G1/2				_	•	
	Female	BG01	G1/8		Nil	*1	•	—	
	thread	BG02	G1/4				_	•	
	A16 Male			Female	B01	Rc1/8			
			MIGHT	thread	BN01	NPT1/8			
Plate		NI IOX I	M16 x 1 One-touch fitting*2		ø8				
mounting	thread			Female	B02	Rc1/4			
		A20	M20 x 1	thread	BN02	NPT1/4	]		
		A20	IVIZU X I	One-touch fitting*2	10	ø10			

\*1 Use the connection thread.

\*2 Built-in One-touch fitting type

Pad, adapter assembly, and mounting nuts are included but do not come assembled.

#### Specifications

Operating ter	mperature range	−30 to 90°C*1
Pad	Material	Silicone rubber <sup>*2, *3</sup>
	Color	Blue
	Hardness (Shore A: ±5°)	40
	Material	Synthetic resin*2, *4/Stainless steel*5
Attachment	Color	White
	Mesh	Mesh: 60/Opening: 280 μm

\*1 -5 to 60 [°C] for the vacuum inlet with One-touch fitting

\*2 Compliant with FDA (U.S. Food and Drug Administration) regulation 21CFR§177.

\*3 Compliant with the standards for "Rubber apparatus (excluding baby drinking apparatus) and containers/packaging" (D3) (Partial revision: Ministry of Health, Labour, and Welfare Notification No. 595, 2012) in Section 3 "Apparatus and Containers/Packaging" of the Food Sanitation Act, Article 18 "Specifications and Standards for Food and Food Additives, etc." (Ministry of Health and Welfare Notification No. 370, 1959)


\*4 Compliant with the standards for "Synthetic resin apparatus and containers/packaging" (D2) in Section 3 "Apparatus and Containers/Packaging" of the Food Sanitation Act, Article 18 "Specifications and Standards for Food and Food Additives, etc." (Ministry of Health and Welfare Notification No. 370, 1959)

\*5 Stainless steel included only for mesh attachment



Vacuum Pad 2.5-Stage/Bellows Type **ZP3P-JT** Series

#### **Dimensions/Models**



\*1 Same dimension as the pad unit


42.7


50

36.7

Construction

#### **Dimensions/Models**





\*1 Same dimension as the pad unit

## Vacuum Pad *ZP3P-JT Series* 2.5-Stage/Bellows Type Construction

Direct mounting type (Male thread) ZP3P-T□JT2SF-□-A□







Plate mounting (Male/Female thread) ZP3P-T□JT2SF-□-A□-B□






#### Plate mounting (Male thread/One-touch fitting) ZP3P-T□JT2SF-□-A□-□



#### Component Parts

No.	Description	Material (Surface treatment)				
1	Bellows pad	Silicone rubber				
•	Attachment	Synthetic resin				
2	Mesh attachment	Synthetic resin/Stainless steel				
3	Adapter	Aluminum alloy (Anodized)				
4	O-ring	Silicone rubber				
5	Mounting nut	Steel (Trivalent zinc chromated)				
6	Seal	NBR				
7	Cassette					



#### **Replacement Parts**

#### Pad Unit (Without attachment)


au onn (without attachment)					
Part number	Applicable pad dia.				
ZP3P-20JT2SF	ø20				
ZP3P-32JT2SF	ø32				
ZP3P-50JT2SF	ø50				

#### Attachment Unit

Part number	Applicable pad dia.
ZP3PW-20JT2	ø20
ZP3PW-32JT2	ø32
ZP3PW-50JT2	ø50

#### Mesh Attachment Unit

Part number	Applicable pad dia.				
ZP3PWM-20JT2	ø20				
ZP3PWM-32JT2	ø32				
ZP3PWM-50JT2	ø50				



<u> </u>	
20	ø20
25	ø25
32	ø32
40	ø40
50	ø50

#### With adapter

#### **2** Connection thread/**3** Vacuum inlet

	Connection thread				3 Vacuum inlet		Pad diameter [mm]		
Туре	Thread	Symbol	Size	Thread	Symbol	Size	ø20, ø25	ø32 to ø50	
	Male	AG01	G1/8		— Nil	NU	*1	•	
Direct	thread	AG02	G1/4	] _			_	•	
mounting	Female	BG01	G1/8		NIII	*1	•	_	
	thread	BG02	G1/4	— — Nil		_	•		
	Male thread A20			Female	B01	Rc1/8			
			AIC MICHI	thread	BN01	NPT1/8			
Plate			One-to	One-touch fitting*2	08	ø8			
mounting			A20 M20 x 1 Female thread One-touch fitting*2	Female	B02	Rc1/4			
		400		thread	BN02	NPT1/4			
		A20 M2		10	ø10		-		

\*1 Use the connection thread.

\*2 Built-in One-touch fitting type

Pad, adapter assembly, and mounting nuts are included but do not come assembled.

#### Specifications

Operating temperature range		−30 to 90°C* <sup>1</sup>
	Material	Silicone rubber <sup>*2, *3</sup>
Pad	Color	Blue
	Hardness (Shore A: ±5°)	40
Guide	Material	Synthetic resin* <sup>2, *4</sup>
attachment	Color	White

\*1 -5 to 60 [°C] for the vacuum inlet with One-touch fitting

\*3 Compliant with the standards for "Rubber apparatus (excluding baby drinking apparatus) and containers/packaging" (D3) (Partial revision: Ministry of Health, Labour, and Welfare Notification No. 595, 2012) in Section 3 "Apparatus and Containers/Packaging" of the Food Sanitation Act, Article 18 "Specifications and Standards for Food and Food Additives, etc." (Ministry of Health and Welfare Notification No. 370, 1959)


\*4 Compliant with the standards for "Synthetic resin apparatus and containers/packaging" (D2) in Section 3 "Apparatus and Containers/Packaging" of the Food Sanitation Act, Article 18 "Specifications and Standards for Food and Food Additives, etc." (Ministry of Health and Welfare Notification No. 370, 1959)



<sup>\*2</sup> Compliant with FDA (U.S. Food and Drug Administration) regulation 21CFR§177.

Vacuum Pad 5.5-Stage/Bellows Type ZP3P-JT Series

#### **Dimensions/Models**




\*1 Same dimension as the pad unit

Specific Product Mounting Bracket Assembly

40.2

ø8




AG02

6.5

G1/4

\*1 Same dimension as the pad unit

#### **Dimensions/Models**



With adapter Plate mounting type (Male thread/One-touch fitting) ZP3P-T 20 JT5SF-A16-08 s øU 0 **3** Vacuum inlet Width across flats X (One-touch fitting) Connection thread **2** 08 ø8 (Male thread) ≥ 10 ø10 £ M16 x 1 Width across flats V A16 ≥ A20 M20 x 1 øΤ Model Min. 1 Pad Weight openina Numbei 6 > Dimension during Vacuum 0 S U ۷ W Х Q R т Υ ۵ of bellows [g] hole size of Form Material inlet Connection Vacuum adsorption: direction the adapter dia. stages thread inlet 20 35.2 62.1 26.6 A16 08 22 M16 x 1 18 17 5 19 8 ø5 Ø 25 39 65.9 28.4 മ ZP3P т 32 JT 5 SF 51 82.4 63.2 40 A20 10 57.5 26 M20 x 1 29 10 27 6 24 88.9 68.4 ø7.5 <u>(st)\*1</u> 50 65 96.4 75.1 øА

\*1 Same dimension as the pad unit

## Vacuum Pad *ZP3P-JT Series* 5.5-Stage/Bellows Type **Construction**






Plate mounting type (Male/Female thread) ZP3P-T□JT5SF-A□-B□




#### **Component Parts**

No.	Description	Material (Surface treatment)
1	Bellows pad	Silicone rubber
2	Guide attachment	Synthetic resin
3	Adapter	Aluminum alloy (Anodized)
4	O-ring	Silicone rubber
5	Mounting nut	Steel (Trivalent zinc chromated)
6	Seal	NBR
7	Cassette	_



#### Plate mounting type (Male thread/One-touch fitting) ZP3P-T□JT5SF-A□-□



#### Replacement Parts

Pad Unit (Without guide attachment)


au onne (without guide attachment)					
Part number	Applicable pad dia.				
ZP3P-20JT5SF	ø20				
ZP3P-25JT5SF	ø25				
ZP3P-32JT5SF	ø32				
ZP3P-40JT5SF	ø40				
ZP3P-50JT5SF	ø50				

#### **Guide Attachment Unit**

Part number	Applicable pad dia.
ZP3PWG-20JT5	ø20
ZP3PWG-25JT5	ø25
ZP3PWG-32JT5	ø32
ZP3PWG-40JT5	ø40
ZP3PWG-50JT5	ø50

# Vacuum Pad **ZP3P-JT** Series **Mounting Bracket Assembly**

#### Adapter Assembly: Direct Mounting Type



	Tur	Turna	Size	Symbol	1 Pad diameter symbol					
	thread	уре			20	25	32	40	50	
2			G1/8	AG01	ZP3PA-T	ZP3PA-T1JT-AG01		ZP3PA-T2JT-AG01		
Adapter	M tion	1ale	ale G1/4 <b>AG02</b>		ZP3PA-T1	ZP3PA-T1JT-AG02*1		ZP3PA-T2JT-AG02		
Ad		read	G3/8	AG03	ZP3PA-T1	JT-AG03*1	ZP3PA-T2JT-AG03*1			
۲	Con	Γ	G1/2	AG04	-	_	2	ZP3PA-T2JT-AG04*	1	
		male	G1/8	BG01	ZP3PA-T	IJT-BG01		—		
	thr	thread	G1/4	BG02	-	_		ZP3PA-T2JT-BG02		

\*1 2.5-stage bellows only

#### Adapter Assembly: Plate Mounting Type

	oduct part imber 2.5-stage ZP3P - T ① JT2SF - □ - ② - ③   5.5-stage ZP3P - T ① JT5SF - ② - ③   Pad dia. - ② - ③ - ③   • Vacuum inlet - ② - ③   • Connection thread (Male thread)							ead)				
Co pa	-	onent			Male/Female t		unting		ale thread/	One-tou		g ting nut
			Ada (Wit	-	ting nut)		-	Adapter	unting nut)			
		Turne	(Wit	h moun				Adapter	unting nut)	ameter sym	bol	
	ead	Туре		-	Туре	Size	-	Adapter	unting nut)	ameter sym	bol <b>40</b>	50
er	thread	Туре	(Wit	h moun	Туре			Adapter (With mou	unting nut) 1 Pad di 25			50
apter	tion thread	Туре	(Wit	h moun	Type	Size	Symbol	Adapter (With mou	Unting nut) Pad di 25 IT-A16-B01			50
) Adapter	nection thread	Type	(Wit	Symbol	Type	Size Rc1/8	Symbol B01	Adapter (With mou 20 ZP3PA-T1J	Unting nut) Pad di 25 JT-A16-B01 T-A16-BN01			50
(A) Adapter	Connection thread		(Wit	Symbol	Type Female thread One-touch fitting	Size Rc1/8 NPT1/8	Symbol B01 BN01	Adapter (With mou 20 ZP3PA-T1J ZP3PA-T1J	Unting nut) Pad di 25 JT-A16-B01 T-A16-BN01	32		
Adapter	<b>2</b> Connection thread	Male	(Wit	Symbol	Type	Size Rc1/8 NPT1/8 ø8	Symbol B01 BN01 08	Adapter (With mou 20 ZP3PA-T1J ZP3PA-T1J	Unting nut) Pad di 25 JT-A16-B01 T-A16-BN01	32 ZP3P	40 — — —	20-B02
Adapter		Male	(Wit	Symbol	Type Female thread One-touch fitting	Size Rc1/8 NPT1/8 Ø8 Rc1/4	Symbol B01 BN01 08 B02	Adapter (With mou 20 ZP3PA-T1J ZP3PA-T1J	Unting nut) Pad di 25 JT-A16-B01 T-A16-BN01	32 ZP3PA ZP3PA	40 — — — A-T2JT-A2	20-B02 0-BN02

13

B Mounting nut (Single unit) (Sales unit: 10 pcs.)



KQ10-P01A

M20 x 1



## **ZP3P-JT** Series Vacuum Pad/Specific Product Precautions

Be sure to read this before handling the products. Refer to the back cover for safety instructions. For vacuum equipment precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smcworld.com


#### **Operating Precautions**

# **A** Caution

## 1. When mounting the product, tighten with the tightening torque shown in the table below.

If excessive or insufficient tightening torque is applied, sealing failure or loose screws may result.

Direct mounting type (Male thread)	Product part number	Connection thread size	Proper tightening torque [N·m]
	ZP3P-T□JT□-□-AG01	G1/8	3 to 5
Adapter	ZP3P-T□JT□-□-AG02	G1/4	8 to 12
	ZP3P-T□JT2-□-AG03	G3/8	15 to 20
	ZP3P-T□JT2-□-AG04	G1/2	20 to 25



e	Product part number	Connection thread size	Proper tightening torque [N·m]
	ZP3P-T□JT□-□-BG01	G1/8	3 to 5
er	ZP3P-T□JT□-□-BG02	G1/4	8 to 12

Plate mounting type (Male/Female thread (Male thread/One-touch fitting)	Product part number	Connection thread size	Proper tightening torque [N·m
<del>A</del>	ZP3P-T□JT□-□-A16-□	M16 x 1	7 to 9
	ZP3P-T□JT□-□-A20-□	M20 x 1	14 to 17
Mounting nut			

2. Depending on the achieved vacuum pressure, the theoretical lifting force may exceed the strength of the vacuum pad, deforming or breaking the pad.

The safety factor should be 16 times or more of the theoretical lifting force for horizontal lifting, and it should be 25 times or more for vertical lifting.

W: Lifting force [N]

#### [Calculation of theoretical lifting force]

$$W = P \times S \times 0.1 \times 0.1$$

P: Vacuum pressure [kPa] S: Pad area [cm<sup>2</sup>] t: Safety factor Horizontal lifting: 16 or more

Vertical lifting: 25 or more

3. When a bagged workpiece is lifted, the skirt changes its shape according to the changing shape of the workpiece.

As the vacuum pad skirt changes its shape, the actual lifting force may be below the theoretical lifting force. Before use, please conduct testing with the customer's actual equipment.

#### 4. Mount the attachment for use.

Without the attachment, the vacuum pad will be easily deformed, resulting in adsorption failure.

5. When the vacuum pad is pressed onto the workpiece, make sure it stays within the stroke range.

When the maximum stroke is exceeded, the guide attachment may contact the adapter, leading to malfunction.

6. When the attachment is inserted into the vacuum pad, the attachment may damage or break the skirt if it is pulled with excessive force as the skirt is very thin.

Vacuum pad damage or breakage may lead to adsorption failure.

7. When the achieved vacuum pressure is low (approx. -20 [kPa]), the vacuum pad does not completely operate its stroke.

When a 5.5-stage bellows is used, and vacuum pressure is approx. –20 [kPa], the guide function cannot be used effectively because the guide attachment cannot be pulled up into the adapter.

8. Use the product within the operating temperature range. The heat resistant temperature of the attachment (made of synthetic resin) is 90°C.

Operate within the specified operating temperature range (-30 to  $90^{\circ}$ C).

For temperatures outside of the operating temperature range, contact your local SMC representative.

9. Do not interfere with the vacuum pad stroke with an external stopper.

The vacuum pad will become deformed, resulting in adsorption failure or breakage. In some cases, the workpiece will separate from the pad and fall.

10. Vacuum pads are consumable. Please replace them when cracks, wear, or deformation is confirmed during periodic maintenance.

## 11. Before use, please check the transfer conditions with the customer's actual equipment.

Products are confirmed as transferable under SMC's specific testing conditions in the table below, but these are not guaranteed values. The transfer ability varies depending on the workpiece material, the friction between the pad and workpiece, moment, wind, vibration, etc. Testing with the customer's actual equipment is necessary.

#### SMC's Specific Testing Conditions (Reference)

							-/
	Number	Workpiece		Adsorption conditions		Horizontal transfer conditions	
Pad diameter	of bellows stages	Material	Load [kg]	Ejector part number	Supply pressure [kPa]	Speed [mm/s]	Acceleration/ Deceleration [G]
ø20			0.17				2
ø25		Aluminum	0.27				3
ø32	5.5 -stage	metalized	0.5	ZH15D	-85	1000	3
ø40	-stage	film	0.7				4
ø50			1.1				4

 Adsorption is confirmed for 1 stroke, not for a back and forth or repeated operation.

12. When supplying vacuum release air, do so at a release flow rate of 110 L/min (ANR) or less. Failure to do so may result in damage to the vacuum pads.

#### ▲ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "**Caution**," "**Warning**" or "**Danger**." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)<sup>\*1</sup>, and other safety regulations.

- Caution: indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.
- Warning: Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

**Danger** indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

#### **A**Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

- 2. Only personnel with appropriate training should operate machinery and equipment.
  - The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.
- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
  - The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
  - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
  - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

# 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.

- 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
- 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
- An application which could have negative effects on people, property, or animals requiring special safety analysis.
- 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

- \*1) ISO 4414: Pneumatic fluid power General rules relating to systems.
  - ISO 4413: Hydraulic fluid power General rules relating to systems. IEC 60204-1: Safety of machinery – Electrical equipment of machines. (Part 1: General requirements)
  - ISO 10218-1: Manipulating industrial robots Safety. etc.

#### 

 The product is provided for use in manufacturing industries. The product herein described is basically provided for peaceful use in manufacturing industries. If considering using the product in other industries, consult SMC beforehand

and exchange specifications or a contract if necessary. If anything is unclear, contact your nearest sales branch.

#### Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

#### Limited warranty and Disclaimer

- The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.\*2) Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.
  - 2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

#### **Compliance Requirements**

- The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

#### 

#### SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

#### **Revision History**

Edition B \* The 2.5-stage bellows type has been added.

 Plate mounting (One-touch fitting) has been added to the 5.5-stage bellows type.

Y٧

\* Number of pages has been increased from 12 to 16.

A Safety Instructions Be sure to read the "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual" before use.